





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-11102-00-00 | Cylinder Head Assy |
| 02 | 93440-10153-00 | • . Circlip |
| 03 | 90340-18101-00 | • . Plug, Straight Screw |
| 04 | 3GM-11133-10-00 | • . Guide, Intake Valve |
| 05 | 3GM-11134-10-00 | • . Guide, Exhaust Valve |
| 06 | 95617-08625-00 | Bolt, Stud |
| 07 | 94701-00333-00 | Plug, Spark (ngk Dr8ea) |
| 07 | 94701-00222-00 | Plug, Spark (nd X24esr-u) |
| 08 | 90201-103M4-00 | Washer, Plate |
| 09 | 90176-10075-00 | Nut, Crown |
| 10 | 90179-10584-00 | Nut |
| 11 | 99530-10014-00 | Pin, Dowel |
| 12 | 3GM-11182-00-00 | Gasket, Cylinder Head 2 |
| 13 | 3GM-1115A-00-00 | Cam Case Assy |
| 14 | 99510-08016-00 | • . Pin, Dowel |
| 15 | 90105-06153-00 | • . Bolt, Washer Based |
| 16 | 95027-06012-00 | Bolt, Flange |
| 17 | 90430-06014-00 | Gasket |
| 18 | 91005-06541-00 | Bolt, Flange |
| 19 | 95027-06025-00 | Bolt, Flange |
| 20 | 3GM-11191-00-00 | Cover, Cylinder Head 1 |
| 21 | 3GM-11193-00-00 | Gasket, Head Cover 1 |
| 22 | 90109-064F0-00 | Bolt |
| 23 | 90209-11262-00 | Washer |
| 24 | 2GH-1111G-00-00 | Rubber, Mount 1 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-11351-00-00 | Gasket, Cylinder |
| 02 | 3GM-11310-00-00 | Cylinder |
| 03 | 93210-77363-00 | O-ring |
| 04 | 95027-06012-00 | Bolt, Flange |
| 05 | 90430-06014-00 | Gasket |
| 06 | 99510-14016-00 | Pin, Dowel |
| 07 | 3GM-11181-00-00 | Gasket, Cylinder Head 1 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-11411-01-00 | Crankshaft |
| 02 | 2GH-11416-00-00 | Plane Bearing, Crankshaft 1 |
| 02 | 2GH-11416-10-00 | Plane Bearing, Crankshaft 1 |
| 02 | 2GH-11416-20-00 | Plane Bearing, Crankshaft 1 |
| 02 | 2GH-11416-30-00 | Plane Bearing, Crankshaft 1 |
| 02 | 2GH-11416-40-00 | Plane Bearing, Crankshaft 1 |
| 03 | 3GM-11416-00-00 | Plane Bearing, Crankshaft 1 |
| 03 | 3GM-11416-10-00 | Plane Bearing, Crankshaft 1 |
| 03 | 3GM-11416-20-00 | Plane Bearing, Crankshaft 1 |
| 03 | 3GM-11416-30-00 | Plane Bearing, Crankshaft 1 |
| 03 | 3GM-11416-40-00 | Plane Bearing, Crankshaft 1 |
| 04 | 3GM-11631-00-00 | Piston (std) |
| 04 | 3GM-11636-00-00 | Piston (0.50mm O/s) |
| 05 | 3GM-11610-00-00 | Piston Ring Set (std) |
| 05 | 3GM-11610-20-00 | Piston Ring Set (0.50mm Ug) |
| 06 | 3GM-11633-00-00 | Pin, Piston |
| 07 | 93450-19095-00 | Circlip |
| 08 | 3GM-11650-01-00 | Connecting Rod Assy |
| 09 | 12R-11654-00-00 | • . Bolt, Connecting Rod |
| 10 | 90170-08327-00 | • . Nut |
| 11 | 3GM-11656-00-00 | Plane Bearing, Connecting Rod |
| 11 | 3GM-11656-10-00 | Plane Bearing, Connecting Rod |
| 11 | 3GM-11656-20-00 | Plane Bearing, Connecting Rod |
| 11 | 3GM-11656-30-00 | Plane Bearing, Connecting Rod |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-12111-00-00 | Valve, Intake |
| 02 | 3GM-12112-00-00 | Valve, Intake 2 |
| 03 | 3GM-12121-00-00 | Valve, Exhaust |
| 04 | 3GM-12116-00-00 | Seat, Valve Spring |
| 05 | 3GM-12126-00-00 | Seat, Valve Spring 2 |
| 06 | 3GM-12113-00-00 | Spring, Valve Inner |
| 07 | 3GM-12114-00-00 | Spring, Valve Outer |
| 08 | 3GM-12117-00-00 | Retainer, Valve Spring |
| 09 | 1WG-12117-00-00 | Retainer, Valve Spring |
| 10 | 1WG-12118-00-00 | Cotter, Valve |
| 11 | 1WG-12119-00-00 | Seal, Valve Stem |
| 12 | 1HX-12168-00-00 | Pad, Adjusting 2 (1.20) |
| 12 | 1HX-12168-M1-00 | Pad, Adjusting 2 (1.65) |
| 12 | 1HX-12168-R1-00 | Pad, Adjusting 2 (1.70) |
| 12 | 1HX-12168-U1-00 | Pad, Adjusting 2 (1.75) |
| 12 | 1HX-12168-W1-00 | Pad, Adjusting 2 (1.80) |
| 12 | 1HX-12168-Y1-00 | Pad, Adjusting 2 (1.85) |
| 12 | 1HX-12169-11-00 | Pad, Adjusting 2 (1.90) |
| 12 | 1HX-12169-31-00 | Pad, Adjusting 2 (1.95) |
| 12 | 1HX-12169-50-00 | Pad, Adjusting 2 (2.00) |
| 12 | 1HX-12169-70-00 | Pad, Adjusting 2 (2.05) |
| 12 | 1HX-12169-90-00 | Pad, Adjusting 2 (2.10) |
| 12 | 1HX-12168-20-00 | Pad, Adjusting 2 (1.25) |
| 12 | 1HX-12169-E0-00 | Pad, Adjusting 2 (2.15) |
| 12 | 1HX-12169-G0-00 | Pad, Adjusting 2 (2.20) |
| 12 | 1HX-12169-J0-00 | Pad, Adjusting 2 (2.25) |
| 12 | 1HX-12169-L0-00 | Pad, Adjusting 2 (2.30) |
| 12 | 1HX-12169-N0-00 | Pad, Adjusting 2 (2.35) |
| 12 | 1HX-12169-T0-00 | Pad, Adjusting 2 (2.40) |
| 12 | 1HX-12168-40-00 | Pad, Adjusting 2 (1.30) |
| 12 | 1HX-12168-60-00 | Pad, Adjusting 2 (1.35) |
| 12 | 1HX-12168-80-00 | Pad, Adjusting 2 (1.40) |
| 12 | 1HX-12168-A0-00 | Pad, Adjusting 2 (1.45) |
| 12 | 1HX-12168-F0-00 | Pad, Adjusting 2 (1.50) |
| 12 | 1HX-12168-H1-00 | Pad, Adjusting 2 (1.55) |
| 12 | 1HX-12168-K1-00 | Pad, Adjusting 2 (1.60) |
| 13 | 2NK-12153-02-00 | Lifter, Valve |
| 13 | 2NK-12153-09-00 | Lifter, Valve (ug) |
| 14 | 1WG-12153-21-00 | Lifter, Valve |
| 14 | 1WG-12153-09-00 | Lifter, Valve (ug) |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-12171-00-00 | Camshaft 1 |
| 02 | 3GM-12176-00-00 | Sprocket, Cam Chain |
| 03 | 3GM-12181-00-00 | Camshaft 2 |
| 04 | 90105-07342-00 | Bolt, Washer Based |
| 05 | 94581-01108-00 | Chain (did219fs-108l) |
| 06 | 94681-01021-00 | • . Joint, Chain |
| 07 | 2GH-12241-00-00 | Guide, Stopper 2 |
| 08 | 3GM-12210-00-00 | Tensioner Assy, Cam Chain |
| 09 | 90109-112F1-00 | Bolt |
| 10 | 4BE-12213-00-00 | Gasket, Tensioner Case |
| 11 | 95027-06025-00 | Bolt, Flange |
| 12 | 3GM-12251-00-00 | Damper, Chain 1 |
| 13 | 3GM-12252-00-00 | Damper, Chain 2 |
| 14 | 90109-065A8-00 | Bolt |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 1UF-12421-09-00 | Housing, Water Pump |
| 02 | 93306-00106-00 | Bearing |
| 03 | 93101-12060-00 | Oil Seal |
| 04 | 11H-12438-00-00 | Seal, Mechanical |
| 05 | 1UF-12450-00-00 | Impeller Shaft Assy |
| 06 | 99009-12400-00 | Circlip |
| 07 | 1AE-12439-00-00 | O-ring |
| 08 | 93604-10011-00 | Pin, Dowel |
| 09 | 3GM-12422-00-00 | Cover, Housing |
| 10 | 95027-06025-00 | Bolt, Flange |
| 11 | 90430-06014-00 | Gasket |
| 12 | 93210-33133-00 | O-ring |
| 13 | 95027-06050-00 | Bolt, Flange |
| 14 | 4BH-12481-01-00 | Pipe 1 |
| 15 | 93210-23787-00 | O-ring |
| 16 | 95027-08012-00 | Bolt, Flange |
| 17 | 3DX-12469-00-00 | Joint 1 |
| 18 | 93210-30694-00 | O-ring |
| 19 | 95027-06020-00 | Bolt, Flange |
| 20 | 95027-06030-00 | Bolt, Flange |
| 21 | 95027-06040-00 | Bolt, Flange |
| 22 | 3GM-12482-00-00 | Pipe 2 |
| 23 | 93210-18417-00 | O-ring |
| 24 | 93210-23787-00 | O-ring |
| 25 | 95027-06010-00 | Bolt, Flange |
| 26 | 2GH-14413-00-00 | Stay |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-12417-00-00 | Housing, Thermostat |
| 02 | 3GM-12410-00-00 | Thermostat Assy |
| 03 | 3GM-12413-00-00 | Cover, Thermostat |
| 04 | 95027-06025-00 | Bolt, Flange |
| 05 | 3GM-12576-50-00 | Hose 1 |
| 06 | 90450-38040-00 | Hose Clamp Assy |
| 07 | 3GM-12461-50-00 | Radiator Assy |
| 08 | 3GM-12405-50-00 | Blower Assy |
| 09 | 22W-12462-00-00 | Cap, Radiator |
| 10 | 95706-06500-00 | Nut, Flange |
| 11 | 3GM-12682-50-00 | Protector, Heat |
| 12 | 90480-15363-00 | Grommet |
| 13 | 90387-07391-00 | Collar |
| 14 | 90480-10297-00 | Grommet |
| 15 | 90201-063J2-00 | Washer, Plate |
| 16 | 95827-06025-00 | Bolt, Flange |
| 17 | 3GM-12579-50-00 | Hose 4 |
| 18 | 90450-38040-00 | Hose Clamp Assy |
| 19 | 2GH-12484-00-00 | Pipe 4 |
| 20 | 90110-06142-00 | Bolt, Hexagon Socket Head |
| 21 | 93210-23787-00 | O-ring |
| 22 | 90445-096E8-00 | Hose |
| 23 | 90467-08003-00 | Clip |
| 24 | 3GM-12588-50-00 | Hose 5 |
| 25 | 90450-22052-00 | Hose Clamp Assy |
| 26 | 3GM-12589-50-00 | Hose 6 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 1AE-13300-00-00 | Oil Pump Assy |
| 02 | 99510-08012-00 | Pin, Dowel |
| 03 | 2GH-13329-00-00 | Gasket, Pump Cover |
| 04 | 91317-06050-00 | Bolt |
| 05 | 3GM-13412-50-00 | Housing, Strainer |
| 06 | 3GM-13411-00-00 | Strainer, Oil |
| 07 | 95027-06030-00 | Bolt, Flange |
| 08 | 3GM-13171-00-00 | Pipe, Delivery 2 |
| 09 | 90430-10171-00 | Gasket |
| 10 | 90401-10139-00 | Bolt, Union |
| 11 | 3GM-13181-00-00 | Pipe, Delivery 3 |
| 12 | 95027-06012-00 | Bolt, Flange |
| 13 | 93210-06632-00 | O-ring |
| 14 | 3GM-13191-00-00 | Pipe, Delivery 4 |
| 15 | 95027-06012-00 | Bolt, Flange |
| 16 | 93210-06632-00 | O-ring |
| 17 | 2GH-1316E-00-00 | Pipe, Delevery 5 |
| 18 | 93210-07135-00 | O-ring |
| 19 | 95027-06012-00 | Bolt, Flange |
| 20 | 2GH-15123-00-00 | Plate, Buffle 1 |
| 21 | 95027-06012-00 | Bolt, Flange |
| 22 | 1AE-15124-00-00 | Plate, Buffle 2 |
| 23 | 95027-06012-00 | Bolt, Flange |
| 24 | 2GH-15133-00-00 | Plate, Buffle 3 |
| 25 | 95027-06012-00 | Bolt, Flange |
| 26 | 90201-061M7-00 | Washer, Plate |
| 27 | 4BH-13475-00-00 | Gasket |
| 28 | 95827-06016-00 | Bolt, Flange |
| 29 | 3GM-13454-00-00 | Nozzle |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 90401-20158-00 | Bolt, Union |
| 02 | 93210-87723-00 | O-ring |
| 03 | 3FV-13440-00-00 | Element Assy, Oil Cleaner |
| 04 | 3KS-13490-00-00 | Relief Valve Assy |
| 05 | 93210-15566-00 | O-ring |
| 06 | 3GM-13417-50-00 | Cover, Strainer |
| 07 | 3FV-13416-01-00 | Pipe, Oil 1 |
| 08 | 93210-14579-00 | O-ring |
| 09 | 36Y-15189-00-00 | Plug |
| 10 | 93210-16629-00 | O-ring |
| 11 | 3GM-13337-00-00 | Plate, Baffle Lower |
| 12 | 95027-06010-00 | Bolt, Flange |
| 13 | 99510-08016-00 | Pin, Dowel |
| 14 | 4BH-13414-00-00 | Gasket, Strainer Cover |
| 15 | 95027-06030-00 | Bolt, Flange |
| 16 | 3VD-13455-00-00 | Plug |
| 17 | 98907-06008-00 | • . Screw, Bind |
| 18 | 214-11198-01-00 | Gasket |
| 19 | 3GM-13161-01-00 | Pipe, Delivery 1 |
| 20 | 93210-06714-00 | O-ring |
| 21 | 95027-06012-00 | Bolt, Flange |
| 22 | 3GM-15373-00-00 | Pipe, Breather |
| 23 | 3GM-13174-00-00 | Holder, Oil Pipe |
| 24 | 99009-10400-00 | Circlip |
| 25 | 90465-08076-00 | Clamp |
| 26 | 3TJ-13470-00-00 | Oil Cooler Assy |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-13586-00-00 | Joint, Carburetor 1 |
| 02 | 90430-06014-00 | • . Gasket |
| 03 | 91317-06012-00 | • . Bolt |
| 04 | 3GM-13596-00-00 | Joint, Carburetor 2 |
| 05 | 90430-06014-00 | • . Gasket |
| 06 | 91317-06012-00 | • . Bolt |
| 07 | 3LF-13597-00-00 | Joint, Carburetor 3 |
| 08 | 3LF-13598-00-00 | Joint, Carburetor 4 |
| 09 | 93210-44545-00 | O-ring |
| 10 | 91317-08020-00 | Bolt |
| 11 | 90450-57034-00 | Hose Clamp Assy |
| 12 | 90445-08740-00 | Hose |
| 13 | 3GM-14401-00-00 | Air Cleaner Case Assy |
| 14 | 3GM-14451-00-00 | Element, Air Cleaner |
| 15 | 3GM-14422-00-00 | Cap, Cleaner Case 2 |
| 16 | 36F-14452-00-00 | Seal |
| 17 | 3GM-14443-00-00 | Collar |
| 18 | 92907-06600-00 | Washer, Plate |
| 19 | 98517-06140-00 | Screw, Pan Head |
| 20 | 3GM-14453-00-00 | Joint, Air Cleaner 1 |
| 21 | 90450-67066-00 | Hose Clamp Assy |
| 22 | 90445-11288-00 | Hose |
| 23 | 4X7-2149Y-00-00 | Filter Assy |
| 24 | 90445-114E2-00 | Hose |
| 25 | 90467-10008-00 | Clip |
| 26 | 3GM-14432-00-00 | Silencer, Inner |
| 27 | 90480-14023-00 | Grommet |
| 28 | 90387-060M9-00 | Collar |
| 29 | 95817-08030-00 | Bolt, Flange |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LF-14900-01-00 | Carburetor Assy |
| 02 | 3LF-14901-01-00 | • . Carburetor Assy 1 |
| 03 | 3LF-14902-01-00 | • . Carburetor Assy 2 |
| 04 | 3LF-14903-01-00 | • . Carburetor Assy 3 |
| 05 | 3LF-14904-01-00 | • . Carburetor Assy 4 |
| 06 | 12R-14191-00-00 | •• .. Plug, Drain |
| 07 | 98501-05012-00 | •• .. Screw, Pan Head |
| 08 | 98580-04008-00 | •• .. Screw, Pan Head |
| 09 | 98580-04008-00 | •• .. Screw, Pan Head |
| 10 | 98586-05016-00 | •• .. Screw, Pan Head |
| 11 | 92906-05100-00 | •• .. Washer, Spring |
| 12 | 92906-05600-00 | •• .. Washer, Plate |
| 13 | 3EN-14147-00-00 | •• .. O-ring |
| 14 | 53L-14186-00-00 | •• .. Pin, Float |
| 15 | 3GM-14985-00-00 | •• .. Float |
| 16 | 3EN-1410A-01-00 | •• .. Starter Set |
| 17 | 12R-14105-00-00 | •• .. Pilot Screw Set |
| 18 | 3FV-14147-00-00 | •• .. O-ring |
| 19 | 3GM-14940-00-00 | •• .. Diaphragm Assy |
| 20 | 3GM-1411E-00-00 | •• .. Block, Jet |
| 21 | 3FV-14933-00-00 | •• .. Spring, Diaphragm |
| 22 | 3GM-1490J-00-00 | •• .. Needle Set |
| 23 | 3GM-1411A-00-00 | •• .. Block Jet Assy |
| 24 | 3GM-14153-00-00 | •• .. Washer, Main Jet |
| 25 | 1HX-14565-00-00 | •• .. Screw |
| 26 | 3LF-14147-00-00 | •• .. O-ring |
| 27 | 1AE-14147-00-00 | •• .. O-ring |
| 28 | 3GM-14997-00-00 | •• .. Seal |
| 29 | 3GM-14107-17-00 | •• .. Needle Valve Set |
| 30 | 1AE-14227-00-00 | •• .. Washer |
| 31 | 3G2-1423A-76-00 | •• .. Jet, Main (127.5) |
| 31 | 3G2-14231-25-00 | •• .. Jet, Main (125) |
| 32 | 3GM-14141-90-00 | •• .. Nozzle, Main |
| 33 | 830-14231-23-00 | •• .. Jet, Main |
| 34 | 4G0-14142-00-00 | •• .. Jet, Pilot (40) |
| 35 | 3G2-14231-12-00 | •• .. Jet, Main (60) |
| 36 | 92901-05600-00 | • . Washer, Plate |
| 37 | 95380-05800-00 | • . Nut |
| 38 | 3EN-1490K-00-00 | • . Stop Screw Set |
| 39 | 3EN-14261-00-00 | • . Holder |
| 40 | 3GM-14918-00-00 | • . Ring |
| 41 | 17A-14251-00-00 | • . Nipple |
| 42 | 2GH-14197-00-00 | • . Pipe |
| 43 | 3GM-14988-00-00 | • . Pipe, Starter Connecting |
| 44 | 3EN-14997-00-00 | • . Seal |
| 45 | 1KT-14994-00-00 | • . Net, Filter |
| 46 | 822-14147-00-00 | • . O-ring |
| 47 | 3GM-14197-00-00 | • . Pipe |
| 48 | 3GM-14103-00-00 | • . Throttle Screw Set |
| 49 | 92990-06600-00 | • . Washer, Plate |
| 50 | 95380-06600-00 | • . Nut, Hexagon |
| 51 | 3EN-14988-00-00 | • . Pipe, Starter Connecting |
| 52 | 98501-05008-00 | • . Screw, Pan Head |
| 53 | 3GM-14251-00-00 | • . Nipple |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 54 | 3LK-14147-00-00 | • . O-ring |
| 55 | 3GM-14992-00-00 | • . Rod |
| 56 | 3LK-14987-00-00 | • . Hose |
| 57 | 3GM-14197-00-00 | Pipe |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-14610-00-00 | Exhaust Pipe Assy 1 |
| 02 | 90101-06576-00 | • . Bolt |
| 03 | 92907-06600-00 | • . Washer, Plate |
| 04 | 3GM-14821-00-00 | • . Arm, Shaft (valve) |
| 05 | 3GM-14811-00-00 | • . Housing |
| 06 | 2TK-14845-00-00 | • . Dust Seal Assy |
| 07 | 2TK-14867-01-00 | • . Bracket |
| 08 | 90119-06115-00 | • . Bolt, With Washer |
| 09 | 90201-106M5-00 | • . Washer, Plate |
| 10 | 90380-10195-00 | • . Bush, Solid |
| 11 | 2TK-14865-01-00 | • . Pulley |
| 12 | 92990-05200-00 | • . Washer, Plain |
| 13 | 97080-05012-00 | • . Bolt |
| 14 | 90387-106U7-00 | • . Collar |
| 15 | 3GM-14683-00-00 | • . Spring, Hook |
| 16 | 4HD-14826-00-00 | Protector, Exhaust |
| 17 | 90119-06187-00 | Bolt, With Washer |
| 18 | 3YF-14613-01-00 | Gasket, Exhaust Pipe |
| 19 | 90179-08410-00 | Nut |
| 20 | 95817-08035-00 | Bolt, Flange |
| 21 | 3LE-14710-30-00 | Muffler Assy 1 |
| 22 | 3HE-14755-00-00 | • . Gasket, Silencer |
| 23 | 95817-08025-00 | • . Bolt, Flange |
| 24 | 3GM-1133E-51-00 | Cable, Pulley 1 |
| 25 | 3GM-1133F-51-00 | Cable, Pulley 2 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-15100-52-00 | Crankcase Assy |
| 02 | 99530-10014-00 | Pin, Dowel |
| 03 | 90116-10532-00 | Bolt, Stud |
| 04 | 90116-10531-00 | Bolt, Stud |
| 05 | 90116-10576-00 | Bolt, Stud |
| 06 | 90387-05383-00 | Collar |
| 07 | 93210-07135-00 | O-ring |
| 08 | 90105-09373-00 | Bolt, Washer Based |
| 09 | 90105-09580-00 | Bolt, Washer Based |
| 10 | 90201-096J9-00 | Washer, Plate |
| 11 | 95811-06035-00 | Bolt, Flange |
| 12 | 95817-08045-00 | Bolt, Flange |
| 13 | 95817-06060-00 | Bolt, Flange |
| 14 | 95817-06080-00 | Bolt, Flange |
| 15 | 95817-06140-00 | Bolt, Flange |
| 16 | 95817-08045-00 | Bolt, Flange |
| 17 | 95817-08055-00 | Bolt, Flange |
| 18 | 95817-08065-00 | Bolt, Flange |
| 19 | 95817-08090-00 | Bolt, Flange |
| 20 | 95817-08060-00 | Bolt, Flange |
| 21 | 90105-09555-00 | Bolt, Washer Based |
| 22 | 90201-08087-00 | Washer, Plate |
| 23 | 1AE-11166-00-00 | Pipe, Breather 1 |
| 24 | 90467-15054-00 | Clip |
| 25 | 90467-14015-00 | Clip |
| 26 | 2H7-15361-00-00 | Gauge, Level |
| 27 | 3FV-15363-00-00 | Plug, Oil |
| 28 | 93210-27778-00 | O-ring |
| 29 | 4H7-15189-00-00 | Plug |
| 30 | 93210-20573-00 | O-ring |
| 31 | 90340-14068-00 | Plug, Straight Screw |
| 32 | 93210-14369-00 | O-ring |
| 33 | 1AE-15383-00-00 | Plate, Bearing Cover |
| 34 | 90151-06014-00 | Screw, Countersunk |
| 35 | 90462-08184-00 | Clamp |
| 36 | 95027-06012-00 | Bolt, Flange |
| 37 | 90462-08158-00 | Clamp |
| 38 | 99510-12016-00 | Pin, Dowel |
| 39 | 2TK-15105-00-00 | Nozzle Assy |
| 40 | 93210-06632-00 | O-ring |
| 41 | 90116-10569-00 | Bolt, Stud |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-15416-00-00 | Cover, Oil Pump |
| 02 | 1AE-15456-00-00 | Gasket, Oil Pump Cover 1 |
| 03 | 90152-06014-00 | Screw, Countersunk |
| 04 | 3GM-15410-00-00 | Crankcase Cover Assy 1 |
| 05 | 2GH-15435-00-00 | • . Emblem |
| 06 | 3GM-15427-00-00 | Cover, Cap 2 |
| 07 | 1AE-15316-00-00 | Damper, Engine Mount 1 |
| 08 | 92017-06010-00 | Bolt, Button Head |
| 09 | 4BH-15451-00-00 | Gasket, Crankcase Cover 1 |
| 10 | 4CR-15467-00-00 | Gasket |
| 11 | 99510-08012-00 | Pin, Dowel |
| 12 | 95027-06040-00 | Bolt, Flange |
| 13 | 95027-06050-00 | Bolt, Flange |
| 14 | 3GM-15421-00-00 | Cover, Crankcase 2 |
| 15 | 3GM-15362-00-00 | Plug, Oil Level |
| 16 | 93210-27778-00 | O-ring |
| 17 | 3GM-15417-00-00 | Cover, Cap |
| 18 | 3GM-15449-00-00 | Ring, Rubber |
| 19 | 4H7-15486-00-00 | Grommet |
| 20 | 90209-06096-00 | Washer |
| 21 | 98507-06010-00 | Screw, Pan Head |
| 22 | 3GM-15346-00-00 | Breather 1 |
| 23 | 4BH-15463-00-00 | Gasket, Carburetor Cover 2 |
| 24 | 98507-06020-00 | Screw, Pan Head |
| 25 | 90157-06104-00 | Screw, Pan Head |
| 26 | 90152-06024-00 | Screw, Countersunk |
| 27 | 4BH-15461-00-00 | Gasket, Crankcase Cover 2 |
| 28 | 99510-08012-00 | Pin, Dowel |
| 29 | 95027-06030-00 | Bolt, Flange |
| 30 | 95027-06020-00 | Bolt, Flange |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-15512-00-00 | Gear, Idler 1 |
| 02 | 51Y-15521-00-00 | Shaft 1 |
| 03 | 4BH-15517-00-00 | Gear, Idler 2 |
| 04 | 3GM-15580-00-00 | Starter Clutch Outer Assy |
| 05 | 93615-12088-00 | • . Pin, Dowel |
| 06 | 1J7-15583-01-00 | • . Cap, Starter Clutch Spring |
| 07 | 90501-04623-00 | • . Spring, Compression |
| 08 | 3GM-15524-00-00 | Wheel, Starter |
| 09 | 90110-08177-00 | Bolt, Hexagon Socket Head |
| 10 | 4H7-16155-01-00 | Absorber 1 |
| 11 | 3GM-15689-00-00 | Retainer |
| 12 | 3GM-15519-00-00 | Sprocket, Starter 2 |
| 13 | 3GM-15522-00-00 | Shaft 2 |
| 14 | 93306-20335-00 | Bearing |
| 15 | 93306-20541-00 | Bearing (b6205) |
| 16 | 1AE-15381-00-00 | Plate, Bearing Cover |
| 17 | 95027-06016-00 | Bolt, Flange |
| 18 | 3GM-11474-00-00 | Guide, Upper |
| 19 | 95817-06014-00 | Bolt, Flange |
| 20 | 4FM-11456-00-00 | Chain, Primary |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-16150-01-00 | Primary Driven Gear Comp. |
| 02 | 1AE-16154-00-00 | Plate, Thrust 1 |
| 03 | 90560-25270-00 | Spacer |
| 04 | 93310-340N8-00 | Bearing |
| 05 | 4BH-16371-01-00 | Boss, Clutch |
| 06 | 31A-16325-00-00 | Plate, Clutch 2 |
| 07 | 4H7-16321-01-00 | Plate, Friction |
| 08 | 31A-16321-00-00 | Plate, Friction |
| 09 | 3GM-16351-00-00 | Plate, Pressure 1 |
| 10 | 90501-230E4-00 | Spring, Compression |
| 11 | 90159-06123-00 | Screw, With Washer |
| 12 | 3GM-16321-00-00 | Plate, Friction |
| 13 | 1AE-16164-00-00 | Plate, Thrust 2 |
| 14 | 90215-20231-00 | Washer, Lock |
| 15 | 90170-20327-00 | Nut |
| 16 | 3GM-16356-00-00 | Rod, Push 1 |
| 17 | 93210-06632-00 | O-ring |
| 18 | 93511-32027-00 | Ball |
| 19 | 1AE-16357-00-00 | Rod, Push 2 |
| 20 | 93109-08061-00 | Oil Seal |
| 21 | 1TV-16381-10-00 | Push Lever Comp. |
| 22 | 36Y-W0048-00-00 | • . Bleed Screw Kit |
| 23 | 26H-W0098-00-00 | • . Push Lever Seal Kit |
| 24 | 99510-08012-00 | Pin, Dowel |
| 25 | 95027-06030-00 | Bolt, Flange |
| 26 | 95027-06090-00 | Bolt, Flange |
| 27 | 93340-21505-00 | Bearing |
| 28 | 90201-150H2-00 | Washer, Plate |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LE-W1741-00-00 | Main Axle Assy |
| 02 | 90387-253M6-00 | • . Collar |
| 03 | 2GH-17151-00-00 | Gear, 5th Pinion (27z) |
| 04 | 90209-22191-00 | Washer |
| 05 | 93440-25084-00 | Circlip |
| 06 | 2GH-17131-00-00 | Gear, 3rd Pinion (21z) |
| 07 | 2GH-17141-00-00 | Gear, 4th Pinion (23z) |
| 08 | 2GH-17121-00-00 | Gear, 2nd Pinion (18z) |
| 09 | 93306-30525-00 | Bearing (b6305) |
| 10 | 90387-203M7-00 | Collar |
| 11 | 90201-200K3-00 | Washer, Plate |
| 12 | 93306-20455-00 | Bearing |
| 13 | 3GM-W1742-00-00 | Drive Axle Assy |
| 14 | 90387-271T7-00 | • . Collar |
| 15 | 90387-281T8-00 | • . Collar |
| 16 | 90387-211T9-00 | • . Collar |
| 17 | 3GM-17221-00-00 | Gear, 2nd Wheel (32z) |
| 18 | 93305-30501-00 | Bearing |
| 19 | 90387-255V9-00 | Collar |
| 20 | 3GM-17231-00-00 | Gear, 3rd Wheel (29z) |
| 21 | 3GM-17241-00-00 | Gear, 4th Wheel (27z) |
| 22 | 90209-25196-00 | Washer |
| 23 | 93440-28062-00 | Circlip |
| 24 | 3GM-17251-00-00 | Gear, 5th Wheel (28z) |
| 25 | 2GH-17211-01-00 | Gear, 1st Wheel |
| 26 | 93102-35423-00 | Oil Seal |
| 27 | 2GH-17460-11-00 | Sprocket, Drive |
| 28 | 90215-21022-00 | Washer, Lock |
| 29 | 90179-18020-00 | Nut |
| 30 | 278-17424-01-00 | Circlip 1 |
| 31 | 93306-20455-00 | Bearing |
| 32 | 93440-45144-00 | Circlip |


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




3LE332-4180


| Ref No | Part No | Description |
|---|---|---|
| 01 | 4BH-18540-00-00 | Shift Cam Assy |
| 02 | 90501-06022-00 | • . Spring, Compression |
| 03 | 278-18542-00-00 | • . Point, Neutral |
| 04 | 98701-05012-00 | • . Screw, Flat Head |
| 05 | 278-18566-00-00 | • . Plate, Side 2 |
| 06 | 90201-06643-00 | Washer, Plate |
| 07 | 95827-06016-00 | Bolt, Flange |
| 08 | 3LE-18511-00-00 | Fork, Shift 1 |
| 09 | 3LE-18512-00-00 | Fork, Shift 2 |
| 10 | 3LE-18513-00-00 | Fork, Shift 3 |
| 11 | 4BH-18531-00-00 | Bar, Shift Fork Guide 1 |
| 12 | 1AE-18536-00-00 | Stopper, Shift Bar |
| 13 | 90508-26681-00 | Spring, Torsion |
| 14 | 36Y-18140-00-00 | Stopper Lever Assy |
| 15 | 90109-063F8-00 | Bolt |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4G0-18127-00-00 | Stopper, Screw |
| 02 | 93102-12106-00 | Oil Seal |
| 03 | 1AE-18101-01-00 | Shift Shaft Assy |
| 04 | 90508-32682-00 | • . Spring, Torsion |
| 05 | 90387-114K8-00 | • . Collar |
| 06 | 90201-12575-00 | Washer, Plate |
| 07 | 99006-10600-00 | Circlip |
| 08 | 90560-12191-00 | Spacer |
| 09 | 93109-12053-00 | Oil Seal |
| 10 | 2GH-18112-01-00 | Arm, Shift |
| 11 | 2H9-18154-00-00 | Cover, Dust |
| 12 | 95827-06020-00 | Bolt, Flange |
| 13 | 46X-18115-00-00 | Rod, Shift |
| 14 | 90170-06228-00 | Nut (verkehtheit Schraube) |
| 15 | 95304-06700-00 | Nut |
| 16 | 2GH-18110-00-00 | Shift Pedal Assy |
| 17 | 2H9-18154-00-00 | • . Cover, Dust |
| 18 | 132-18113-01-00 | • . Cover, Shift Pedal |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-21110-60-00 | Frame Comp. |
| 02 | 3GM-21190-50-33 | Rear Frame Comp. |
| 03 | 90110-10191-00 | Bolt, Hexagon Socket Head |
| 04 | 91317-10045-00 | Bolt |
| 05 | 90110-10168-00 | Bolt, Hexagon Socket Head |
| 06 | 90387-115V8-00 | Collar |
| 07 | 90387-105V7-00 | Collar |
| 08 | 90179-10590-00 | Nut |
| 09 | 90110-10169-00 | Bolt, Hexagon Socket Head |
| 10 | 3GM-21348-51-00 | Brackt, Tank Fitting |
| 11 | 3GM-21347-00-00 | Bracket, Tank Fitting |
| 12 | 97007-06035-00 | Bolt |
| 13 | 97007-06012-00 | Bolt |
| 14 | 92907-06600-00 | Washer, Plate |
| 15 | 90338-15202-00 | Plug |
| 16 | 2GH-2117T-00-00 | Cover 5 |
| 17 | 90105-10716-00 | Bolt, Washer Based |
| 18 | 90179-10247-00 | Nut |
| 19 | 97007-08035-00 | Bolt |
| 20 | 92990-08200-00 | Washer, Plain |
| 21 | 97027-08035-00 | Bolt |
| 22 | 3GM-2142K-50-00 | Bracket, Radiator |
| 23 | 97007-06012-00 | Bolt |
| 24 | 92907-06600-00 | Washer, Plate |
| 25 | 3GM-2117M-00-00 | Cover 2 |
| 26 | 90267-40076-00 | Rivet, Blind |
| 27 | 2GH-15365-00-00 | Grommet |
| 28 | 3GM-2117A-00-00 | Stay |
| 29 | 90267-40054-00 | Rivet, Blind |
| 30 | 90480-35526-00 | Grommet |
| 31 | 3GM-2117N-00-00 | Cover 3 |
| 32 | 3GM-2117R-00-00 | Cover 4 |
| 33 | 90159-06059-00 | Screw, With Washer |
| 34 | 3GM-21446-03-00 | Stay, Muffler 2 |
| 35 | 3GM-21359-00-00 | Bracket, Coil |
| 36 | 90119-06114-00 | Bolt, With Washer |
| 37 | 3GM-21149-00-00 | Bracket, Battery Box |
| 38 | 95807-06010-00 | Bolt, Flange |
| 39 | 90201-101J1-00 | Washer, Plate |
| 40 | 95707-10500-00 | Nut, Flange |
| 41 | 26H-21308-00-00 | Helmet Hanger Assy |
| 42 | 90149-06150-00 | Screw |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-21511-51-04 | Fender, Front |
| 02 | 90183-05061-00 | Nut, Spring |
| 03 | 90154-05060-00 | Screw, Binding |
| 04 | 90202-05088-00 | Washer, Plate |
| 05 | 3GM-21551-A0-4B | Fender, Over |
| 06 | 90119-06063-00 | Bolt, With Washer |
| 07 | 90387-06648-00 | Collar |
| 08 | 90202-11221-00 | Washer, Plate |
| 09 | 90387-0604T-00 | Collar |
| 10 | 4FM-28372-00-00 | Damper |
| 11 | 1FK-21746-00-00 | Damper |
| 12 | 3GM-21555-A0-4B | Fender, Over 2 |
| 13 | 3GM-W2161-01-00 | Rear Fender Comp. |
| 14 | 97007-06020-00 | Bolt |
| 15 | 92907-06600-00 | Washer, Plate |
| 16 | 90387-061M0-00 | Collar |
| 17 | 31A-14477-00-00 | Plate |
| 18 | 97007-06016-00 | Bolt |
| 19 | 92907-06600-00 | Washer, Plate |
| 20 | 90387-06648-00 | Collar |
| 21 | 3GM-21629-50-00 | Guard, Mud |
| 22 | 90119-06108-00 | Bolt, With Washer |
| 23 | 90159-06056-00 | Screw, With Washer |
| 24 | 3GM-21651-50-P0 | Cover, Rear Fender |
| 25 | 2GH-21732-00-00 | Seal 1 |
| 26 | 3GM-21575-00-00 | Seal 1 |
| 27 | 3GM-21576-00-00 | Seal 2 |
| 28 | 90159-06042-00 | Screw, With Washer |
| 29 | 26L-82131-00-00 | Band, Battery |
| 30 | 90338-07043-00 | Plug |
| 31 | 3GM-21621-00-00 | Flap |
| 32 | 90149-04278-00 | Screw |
| 33 | 95607-04100-00 | Nut, U |
| 34 | 90201-04018-00 | Washer, Plate |
| 35 | 3GM-21649-00-00 | Damper |
| 36 | 3GM-21649-10-00 | Damper |
| 37 | 1RK-22483-00-00 | Damper 1 |
| 38 | 99237-00080-00 | Emblem, Yamaha |
| 39 | 3LE-21663-20-00 | Graphic, Tailcover |
| 40 | 3LE-28100-00-00 | Tool Kit |
| 41 | 90480-10258-00 | Grommet |
| 42 | 90159-06033-00 | Screw, With Washer |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





FWD

3LF351-5220


| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-Y2171-V0-F | Cover, Side 1 |
| 02 | 2GH-21732-00-0( | . Seal 1 |
| 03 | 3LE-2173L-20-00 | . Graphic Set 1 |
| 04 | 90480-01401-00 | Grommet |
| 05 | 90480-22084-00 | Grommet |
| 06 | 3GM-Y2172-N0-F | Cover, Side 2 |
| 07 | 2GH-21732-00-0( | . Seal 1 |
| 08 | 3LE-2174L-20-00 | . Graphic Set 2 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 90159-06033-00 | Screw, With Washer |
| 02 | 90480-01401-00 | Grommet |
| 03 | 90480-22084-00 | Grommet |
| 04 | 3GM-2177G-50-00 | Box, Battery |
| 05 | 90119-06063-00 | Bolt, With Washer |
| 06 | 90387-06024-00 | Collar |
| 07 | 90480-15058-00 | Grommet |
| 08 | 3GM-21249-50-00 | Bracket |
| 09 | 95807-06012-00 | Bolt, Flange |
| 10 | 90480-22362-00 | Grommet |
| 11 | 3GM-21871-50-00 | Tank, Recovery |
| 12 | 90159-06033-00 | Screw, With Washer |
| 13 | 4L0-21875-00-00 | Cap |
| 14 | 1AA-21874-00-00 | Gasket |
| 15 | 3GM-21816-00-00 | Pipe 1 |
| 16 | 437-83936-11-00 | Band, Switch Cord |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-22110-00-00 | Rear Arm Comp. |
| 02 | 3GM-22184-00-00 | Bush |
| 03 | 93317-52865-00 | Bearing |
| 04 | 3GM-22127-00-00 | Shim |
| 05 | 3GM-22128-00-00 | Cover, Thrust 1 |
| 06 | 3GM-22141-00-00 | Shaft, Pivot |
| 07 | 90185-18104-00 | Nut, Self-locking |
| 08 | 90201-18264-00 | Washer, Plate |
| 09 | 3GM-2217A-00-00 | Arm, Relay |
| 10 | 3GM-2217M-00-00 | Arm 1 |
| 11 | 90101-12673-00 | Bolt |
| 12 | 90387-126T1-00 | Collar |
| 13 | 90201-126A7-00 | Washer, Plate |
| 14 | 95617-12100-00 | Nut, U |
| 15 | 93317-41761-00 | Bearing |
| 16 | 90109-101F1-00 | Bolt |
| 17 | 90387-100T8-00 | Collar |
| 18 | 95617-10200-00 | Nut, Self-locking |
| 19 | 93317-42060-00 | Bearing |
| 20 | 90101-10659-00 | Bolt |
| 21 | 90387-124W2-00 | Collar |
| 22 | 90201-10437-00 | Washer, Plate |
| 23 | 95617-10100-00 | Nut, U |
| 24 | 93101-16131-00 | Oil Seal |
| 25 | 93399-99919-00 | Bearing |
| 26 | 3GM-22311-10-00 | Case, Chain |
| 27 | 90159-06084-00 | Screw, With Washer |
| 28 | 90159-06108-00 | Screw, With Washer |
| 29 | 3GM-22321-00-00 | Stay, Chain Case 1 |
| 30 | 3GM-22151-00-00 | Seal, Guard |
| 31 | 90159-06108-00 | Screw, With Washer |
| 32 | 90387-06704-00 | Collar |
| 33 | 90387-06216-00 | Collar |
| 34 | 97007-06012-00 | Bolt |
| 35 | 92907-06600-00 | Washer, Plate |
| 36 | 3GM-22129-00-00 | Cover, Thrust 2 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-22210-10-00 | Shock Absorber Assy, Rear |
| 02 | 90109-101F1-00 | Bolt |
| 03 | 90387-102T0-00 | Collar |
| 04 | 95617-10200-00 | Nut, Self-locking |
| 05 | 3GM-22262-00-00 | Holder, Sub Tank |
| 06 | 24X-22261-00-00 | Damper, Sub Tank |
| 07 | 90480-17359-00 | Grommet |
| 08 | 97007-06040-00 | Bolt |
| 09 | 92907-06600-00 | Washer, Plate |
| 10 | 24X-22262-00-00 | Holder, Sub Tank |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 93332-00008-00 | Bearing |
| 02 | 93332-00001-00 | Bearing |
| 03 | 3GM-23415-00-00 | Cover, Ball Race 1 |
| 04 | 90179-25033-00 | Nut |
| 05 | 26H-23418-01-00 | Washer, Special |
| 06 | 90202-26142-00 | Washer, Plate |
| 07 | 90176-22050-00 | Nut, Crown |
| 08 | 3GM-Y2343-30-00 | Crown, Handle |
| 09 | 91317-08030-00 | • . Bolt |
| 10 | 1UF-27414-00-00 | • . Damper, Footrest |
| 11 | 3GM-23437-00-00 | Cover, Crown |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-23102-A0-00 | Front Fork Assy (l.h) |
| 02 | 3GM-23110-A0-00 | • . Inner Tube Comp.1 |
| 03 | 3GM-23106-A0-00 | • . Outer Tube Comp. (l.h) |
| 04 | 3GM-23145-A0-00 | • . Oil Seal |
| 05 | 3VD-23144-00-00 | • . Seal, Dust |
| 06 | 3VD-23115-00-00 | • . Guide, Cover Upper |
| 07 | 93450-52134-00 | • . Circlip |
| 08 | 3GM-23170-A0-00 | • . Cylinder Comp., Front Fork |
| 09 | 91311-10025-00 | • . Bolt |
| 10 | 90430-10171-00 | • . Gasket |
| 11 | 3GM-23111-A0-00 | • . Bolt, Cap |
| 12 | 93210-16N52-00 | •• .. O-ring |
| 13 | 95307-10600-00 | • . Nut |
| 14 | 3GM-23141-A0-00 | • . Spring, Front Fork |
| 15 | 3GM-23117-A0-00 | • . Guide, Spring |
| 16 | 3GM-2331K-A0-00 | • . Adjuster |
| 17 | 3GM-23153-A0-00 | • . Ring, Snap |
| 18 | 91311-08040-00 | • . Bolt |
| 19 | 3GM-23103-A0-00 | Front Fork Assy (r.h) |
| 20 | 3GM-23120-A0-00 | • . Inner Tube Comp.2 |
| 21 | 3GM-23106-A0-00 | • . Outer Tube Comp. (l.h) |
| 22 | 3GM-23145-A0-00 | • . Oil Seal |
| 23 | 3VD-23144-00-00 | • . Seal, Dust |
| 24 | 3VD-23115-00-00 | • . Guide, Cover Upper |
| 25 | 93450-52134-00 | • . Circlip |
| 26 | 3GM-23170-A0-00 | • . Cylinder Comp., Front Fork |
| 27 | 91311-10025-00 | • . Bolt |
| 28 | 90430-10171-00 | • . Gasket |
| 29 | 3GM-23111-A0-00 | • . Bolt, Cap |
| 30 | 93210-16N52-00 | •• .. O-ring |
| 31 | 95307-10600-00 | • . Nut |
| 32 | 3GM-23141-A0-00 | • . Spring, Front Fork |
| 33 | 3GM-23117-A0-00 | • . Guide, Spring |
| 34 | 3GM-2331K-A0-00 | • . Adjuster |
| 35 | 3GM-23153-A0-00 | • . Ring, Snap |
| 36 | 91311-08040-00 | • . Bolt |
| 37 | 3GM-23340-A0-00 | Under Bracket Comp. |
| 38 | 95827-08035-00 | Bolt, Flange |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LK-24110-01-W5 | Fuel Tank Comp. |
| 02 | 99226-00140-00 | • . Emblem, Yamaha |
| 03 | 3LE-24240-20-00 | • . Graphic Set |
| 04 | 2GH-21732-00-00 | Seal 1 |
| 05 | 2GH-24191-00-00 | Bracket, Fuel Tank 1 |
| 06 | 95304-06800-00 | Nut, Crown |
| 07 | 2GH-24181-00-00 | Damper, Locating 1 |
| 08 | 2GH-24183-00-00 | Damper, Locating 3 |
| 09 | 2GH-24186-00-00 | Washer, Special |
| 10 | 90387-06299-00 | Collar |
| 11 | 97007-06025-00 | Bolt |
| 12 | 92907-06600-00 | Washer, Plate |
| 13 | 95814-06075-00 | Bolt, Flange |
| 14 | 2GH-24184-00-00 | Damper, Locating 4 |
| 15 | 3Y6-24183-00-00 | Damper, Locating 3 |
| 16 | 2GH-24187-00-00 | Washer, Special |
| 17 | 97707-08030-00 | Screw, Tapping |
| 18 | 3GM-24182-01-00 | Damper, Locating 2 |
| 19 | 26H-24500-00-00 | Fuel Cock Assy 1 |
| 20 | 214-24512-00-00 | • . Gasket |
| 21 | 90149-06011-00 | Screw |
| 22 | 90202-05187-00 | Washer, Plate |
| 23 | 3GM-24311-01-00 | Pipe, Fuel 1 |
| 24 | 3GM-24312-00-00 | Pipe 2 |
| 25 | 90467-12124-00 | Clip |
| 26 | 1FK-24560-00-00 | Filter Assy |
| 27 | 1FK-24566-00-00 | Bracket, Filter |
| 28 | 3GM-24136-00-00 | Clamp 2 |
| 29 | 95807-06012-00 | Bolt, Flange |
| 30 | 4HN-24602-00-00 | Cap Assy |
| 31 | 90110-05112-00 | Bolt, Hexagon Socket Head |
| 32 | 91317-05010-00 | Bolt |
| 33 | 90445-102G7-00 | Hose |
| 34 | 90467-09006-00 | Clip |
| 35 | 90480-13163-00 | Grommet |
| 36 | 90387-062L2-00 | Collar |
| 37 | 95707-06500-00 | Nut, Flange |
| 38 | 25H-24180-00-00 | Roll Over Valve Assy |
| 39 | 90461-15100-00 | Clamp |
| 40 | 98507-05010-00 | Screw, Pan Head |
| 41 | 90467-10008-00 | Clip |
| 42 | 90445-11734-00 | Hose |
| 43 | 90467-10008-00 | Clip |
| 44 | 90445-105G5-00 | Hose |
| 45 | 3GM-13907-00-00 | Fuel Pump Comp. |
| 46 | 3GM-14294-00-00 | Hose |
| 47 | 90467-13123-00 | Clip |
| 48 | 3Y6-21747-00-00 | Damper |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-24730-50-00 | Double Seat Assy |
| 02 | 3GM-24731-50-00 | • . Cover, Seat |
| 03 | 2GH-24741-00-00 | • . Pad, Seat |
| 04 | 3GM-24776-50-00 | • . Lever, Seat |
| 05 | 3GM-24718-50-00 | • . Bracket, Seat |
| 06 | 3GM-24728-50-00 | • . Bracket, Seat |
| 07 | 95707-06500-00 | • . Nut, Flange |
| 08 | 1KT-2478F-00-00 | • . Rod, Connecting |
| 09 | 95707-05500-00 | Nut, Flange |
| 10 | 3GM-24796-50-00 | Cover |
| 11 | 4BH-24705-00-00 | Seat Lock Assy |
| 12 | 3GM-W2474-H0-P0 | Bracket |
| 13 | 3LE-2478M-20-00 | • . Graphic, Seat |
| 14 | 98507-06010-00 | Screw, Pan Head |
| 15 | 92907-06100-00 | Washer, Spring |
| 16 | 92907-06600-00 | Washer, Plate |
| 17 | 3GM-2480F-50-00 | |
| 18 | 3GM-24718-00-00 | Bracket, Seat |
| 19 | 98507-06012-00 | Screw, Pan Head |
| 20 | 92907-06200-00 | Washer |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4FM-25168-00-P5 | Cast Wheel, Front |
| 02 | 90387-2200S-00 | Collar |
| 03 | 93306-00420-00 | Bearing |
| 04 | 93102-28021-00 | Oil Seal |
| 05 | 4FM-25149-00-00 | Clutch, Meter |
| 06 | 341-25846-00-00 | Retainer, Clutch |
| 07 | 93105-45017-00 | Oil Seal |
| 08 | 94112-1702T-00 | Tire (130/60 Zr17 C17) |
| 09 | 93900-00030-00 | Valve, Rim |
| 10 | 29L-25398-00-00 | Balancer, Wheel (10g) |
| 10 | 29L-25398-10-00 | Balancer, Wheel (20g) |
| 10 | 29L-25398-20-00 | Balancer, Wheel (30g) |
| 11 | 4FM-25190-00-00 | Gear Unit Assy |
| 12 | 3GM-25181-A0-00 | Axle, Wheel |
| 13 | 90387-2200T-00 | Collar |
| 14 | 90179-18332-00 | Nut |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4FM-2581T-01-00 | Disc Brake Assy |
| 02 | 90109-08718-00 | Bolt |
| 03 | 4FM-2580T-20-00 | Caliper Assy (left) |
| 04 | 4FM-W0057-10-00 | • . Piston Assy, Caliper |
| 05 | 3MA-W0047-10-00 | •• .. Caliper Seal Kit |
| 06 | 4FM-W0057-00-00 | • . Piston Assy, Caliper |
| 07 | 4FM-W0047-00-00 | •• .. Caliper Seal Kit |
| 08 | 4FM-W0045-20-00 | • . Brake Pad Kit |
| 09 | 4FM-25919-00-00 | • . Support, Pad |
| 10 | 4FM-25924-00-00 | • . Pin, Pad |
| 11 | 4FM-25925-00-00 | • . Clip |
| 12 | 1J3-W0048-00-00 | • . Bleed Screw Kit |
| 13 | 4FM-25827-00-00 | • . Shim, Caliper |
| 14 | 4FM-2580U-20-00 | Caliper Assy (right) |
| 15 | 4FM-W0057-10-00 | • . Piston Assy, Caliper |
| 16 | 3MA-W0047-10-00 | •• .. Caliper Seal Kit |
| 17 | 4FM-W0057-00-00 | • . Piston Assy, Caliper |
| 18 | 4FM-W0047-00-00 | •• .. Caliper Seal Kit |
| 19 | 4FM-W0045-20-00 | • . Brake Pad Kit |
| 20 | 4FM-25919-00-00 | • . Support, Pad |
| 21 | 4FM-25924-00-00 | • . Pin, Pad |
| 22 | 4FM-25925-00-00 | • . Clip |
| 23 | 1J3-W0048-00-00 | • . Bleed Screw Kit |
| 24 | 4FM-25827-00-00 | • . Shim, Caliper |
| 25 | 90105-10638-00 | Bolt, Washer Based |
| 26 | 4FM-25196-00-00 | Spoke Set, Inner 1 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-25338-01-P1 | Cast Wheel, Rear |
| 02 | 93306-30416-00 | Bearing |
| 03 | 93106-30029-00 | Oil Seal |
| 04 | 90560-20357-00 | Spacer |
| 05 | 2GH-25364-00-00 | Damper |
| 06 | 93306-30437-00 | Bearing |
| 07 | 94117-1720U-00 | Tire (170/60 Zr17 Cy20z) |
| 08 | 93900-00030-00 | Valve, Rim |
| 09 | 29L-25398-00-00 | Balancer, Wheel (10g) |
| 09 | 29L-25398-10-00 | Balancer, Wheel (20g) |
| 09 | 29L-25398-20-00 | Balancer, Wheel (30g) |
| 10 | 36Y-25366-01-00 | Clutch, Hub |
| 11 | 93306-30562-00 | Bearing |
| 12 | 93106-35030-00 | Oil Seal |
| 13 | 36Y-25377-00-00 | Collar, Wheel |
| 14 | 2GH-25447-22-00 | Sprocket, Driven (47z) |
| 15 | 90116-10485-00 | Bolt, Stud |
| 16 | 95617-10200-00 | Nut, Self-locking |
| 17 | 94581-57110-00 | Chain (did532zlvka1-110l) |
| 17 | 94571-31110-00 | Chain (rk532gsv2-110l) |
| 18 | 3GM-25388-00-00 | Puller, Chain 1 |
| 19 | 3GM-25389-00-00 | Puller, Chain 2 |
| 20 | 90101-08766-00 | Bolt |
| 21 | 95307-08600-00 | Nut |
| 22 | 3GM-25371-00-00 | Bar, Tension |
| 23 | 90105-08321-00 | Bolt, Washer Based |
| 24 | 95707-08500-00 | Nut, Flange |
| 25 | 91490-20020-00 | Pin, Cotter |
| 26 | 3GM-25381-A0-00 | Axle, Wheel |
| 27 | 95607-18200-00 | Nut, Self-locking |
| 28 | 90201-18264-00 | Washer, Plate |
| 29 | 90387-202X9-00 | Collar |
| 30 | 90387-203XD-00 | Collar |
| 31 | 3GM-25876-00-00 | Holder, Brake Hose 2 |
| 32 | 97007-06010-00 | Bolt |
| 33 | 92907-06600-00 | Washer, Plate |
| 34 | 97007-06030-00 | Bolt |
| 35 | 92907-06600-00 | Washer, Plate |
| 36 | 3GM-25875-51-00 | Holder, Brake Hose 1 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 2KT-25831-00-00 | Disc, Brake |
| 02 | 90109-08718-00 | Bolt |
| 03 | 3GM-2580W-10-00 | • . Caliper Assy, Rear 2 |
| 04 | 31A-W0057-00-00 | • . Piston Assy, Caliper |
| 05 | 31A-W0047-00-00 | •• .. Caliper Seal Kit |
| 06 | 26H-W0045-11-00 | • . Brake Pad Kit |
| 07 | 29L-25919-A0-00 | • . Support, Pad |
| 08 | 3HE-25924-00-00 | • . Pin, Pad |
| 09 | 3HE-25925-00-00 | • . Clip |
| 10 | 1J3-W0048-00-00 | • . Bleed Screw Kit |
| 11 | 51J-25836-00-00 | • . Cover, Dust |
| 12 | 1FK-25827-00-00 | • . Shim, Caliper |
| 13 | 1FK-25828-00-00 | • . Shim, Caliper |
| 14 | 3GM-25819-00-00 | Bracket, Caliper |
| 15 | 90105-10638-00 | Bolt, Washer Based |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-26121-51-00 | Handlebar (left) |
| 02 | 3GM-26122-51-00 | Handlebar (right) |
| 03 | 3GM-26111-A0-00 | Handlebar |
| 04 | 3GM-26112-A0-00 | Bar, Handle |
| 05 | 36Y-26246-00-00 | End, Grip |
| 06 | 3GM-26113-50-00 | Damper |
| 07 | 90201-502P8-00 | Washer, Plate |
| 08 | 91317-08025-00 | Bolt |
| 09 | 90109-082A1-00 | Bolt |
| 10 | 4FM-26241-00-00 | Grip (left) |
| 11 | 4FM-26240-00-00 | Grip Assy |
| 12 | 3LN-26270-01-00 | Cable Connector Cap Assy |
| 13 | 3GM-26331-01-00 | Cable, Starter 1 |
| 14 | 3GM-83940-00-00 | Starter Assy |
| 15 | 1WG-83941-00-00 | • . Lever, Starter |
| 16 | 90209-10131-00 | • . Washer |
| 17 | 98906-06008-00 | • . Screw, Bind |
| 18 | 91317-06012-00 | Bolt |
| 19 | 3GM-26302-00-00 | Throttle Cable Assy |
| 20 | 437-83936-11-00 | Band, Switch Cord |
| 21 | 3GM-83969-01-00 | Switch, Handle 5 |
| 22 | 98506-05030-00 | • . Screw, Pan Head |
| 23 | 98506-05040-00 | • . Screw, Pan Head |
| 24 | 4HM-83975-00-00 | Switch, Handle 2 |
| 25 | 90157-05057-00 | • . Screw, Pan Head |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-W2587-50-00 | Master Cylinder Sub Assy |
| 02 | 3GM-W0041-50-00 | • . Cylinder Kit, Master |
| 03 | 93210-15620-00 | • . O-ring |
| 04 | 2VN-25866-00-00 | • . Circlip |
| 05 | 3FV-2589A-00-00 | • . Cover, Dust |
| 06 | 56A-25867-00-00 | Bracket, Master Cylinder |
| 07 | 95027-06025-00 | Bolt, Flange |
| 08 | 3GM-83922-51-00 | Lever 2 |
| 09 | 3FV-2589F-00-00 | Bolt, Lever |
| 10 | 95617-06100-00 | Nut, U |
| 11 | 3FV-25894-00-00 | Tank, Reservoir |
| 12 | 3GM-25852-50-00 | Cap, Reservoir |
| 13 | 3FV-25854-00-00 | Diaphragm, Reservoir |
| 14 | 2J2-25855-50-00 | Bush,diaphragm |
| 15 | 3FV-83980-00-00 | Front Stop Switch Assy |
| 16 | 95817-04012-00 | Bolt, Flange |
| 17 | 92990-04100-00 | Washer, Spring |
| 18 | 92901-04600-00 | Washer, Plate |
| 19 | 3GM-2585F-00-00 | O-ring |
| 20 | 3PA-24356-00-00 | Clip, Pipe 1 |
| 21 | 3GM-26292-50-00 | Stay |
| 22 | 3GM-26131-00-00 | Guide, Cable 1 |
| 23 | 91317-06012-00 | Bolt |
| 24 | 3FV-2589G-00-00 | Holder |
| 25 | 3GM-2589H-00-00 | Screw |
| 26 | 3GM-25872-A0-00 | Hose, Brake 1 |
| 27 | 3GM-25873-A0-00 | Hose, Brake 2 |
| 28 | 90401-10160-00 | Bolt, Union |
| 29 | 90401-10159-00 | Bolt, Union |
| 30 | 90201-10118-00 | Washer, Plate |
| 31 | 3MA-25876-11-00 | Holder, Brake Hose 2 |
| 32 | 3MA-25876-21-00 | Holder, Brake Hose 2 |
| 33 | 95807-06012-00 | Bolt, Flange |
| 34 | 3MA-82591-00-00 | Band |
| 35 | 3GM-23377-00-00 | Bracket, Horn |
| 36 | 3GM-23378-00-00 | Bracket, Horn |
| 37 | 91317-06012-00 | Bolt |
| 38 | 91317-06010-00 | Bolt |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-26450-A1-00 | Master Cylinder Assy (clutch) |
| 02 | 3GM-W0099-00-00 | • . Cylinder Kit, Master (clutch) |
| 03 | 3GM-26464-00-00 | • . Rod, Push |
| 04 | 3GM-26455-00-00 | • . Bush |
| 05 | 55U-25854-00-00 | • . Diaphragm, Reservoir |
| 06 | 3GM-W2585-20-00 | • . Reservoir Cap Set |
| 07 | 98707-04012-00 | • . Screw, Flat Head |
| 08 | 3GM-83912-11-00 | • . Lever 1 |
| 09 | 90149-06287-00 | • . Screw |
| 10 | 95706-06500-00 | • . Nut, Flange |
| 11 | 3GM-83980-00-00 | • . Front Stop Switch Assy |
| 12 | 98706-04016-00 | • . Screw, Flat Head |
| 13 | 56A-25867-00-00 | • . Bracket, Master Cylinder |
| 14 | 97016-06025-00 | • . Bolt |
| 15 | 92906-06600-00 | • . Washer, Plate |
| 16 | 3GM-26470-A0-00 | Hose, Clutch |
| 17 | 90401-10159-00 | Bolt, Union |
| 18 | 90201-10118-00 | Washer, Plate |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-27311-00-00 | Stand, Side |
| 02 | 3GM-27321-00-00 | Bracket, Side Stand |
| 03 | 3GM-21453-00-00 | Bracket, Switch |
| 04 | 90105-06564-00 | Bolt, Washer Based |
| 05 | 90110-08155-00 | Bolt, Hexagon Socket Head |
| 06 | 90109-104E6-00 | Bolt |
| 07 | 90185-10037-00 | Nut, Self-locking |
| 08 | 90506-18224-00 | Spring, Tension |
| 09 | 90506-26225-00 | Spring, Tension |
| 10 | 2KT-27315-00-00 | Link, Side Stand |
| 11 | 1TX-27351-00-00 | Guide, Side Stand |
| 12 | 2GH-27410-00-00 | Front Footrest Assy (left) |
| 13 | 90109-083E2-00 | • . Bolt |
| 14 | 2GH-27413-00-00 | • . Cover, Footrest |
| 15 | 90157-05079-00 | • . Screw, Pan Head |
| 16 | 2GH-27420-00-00 | Front Footrest Assy (right) |
| 17 | 90109-083E2-00 | • . Bolt |
| 18 | 2GH-27413-00-00 | • . Cover, Footrest |
| 19 | 90157-05079-00 | • . Screw, Pan Head |
| 20 | 3GM-27442-00-00 | Bracket 2 |
| 21 | 3GM-27443-00-00 | Bracket 3 |
| 22 | 90214-10056-00 | Washer, Claw |
| 23 | 90109-103A9-00 | Bolt |
| 24 | 90206-17084-00 | Washer, Wave |
| 25 | 90110-08199-00 | Bolt, Hexagon Socket Head |
| 26 | 3GM-2741L-00-00 | Bracket 4 |
| 27 | 1HX-27431-00-00 | Footrest, Rear 1 |
| 28 | 90501-12743-00 | Spring, Compression |
| 29 | 93501-04011-00 | Ball |
| 30 | 90387-064H8-00 | Collar |
| 31 | 1HX-27437-00-00 | Washer, Special |
| 32 | 91317-06045-00 | Bolt |
| 33 | 95607-06100-00 | Nut, U |
| 34 | 3GM-2742L-00-00 | Bracket 5 |
| 35 | 3GM-27441-00-00 | Footrest, Rear 2 |
| 36 | 90501-12743-00 | Spring, Compression |
| 37 | 93501-04011-00 | Ball |
| 38 | 90387-064H8-00 | Collar |
| 39 | 1HX-27437-00-00 | Washer, Special |
| 40 | 91317-06045-00 | Bolt |
| 41 | 95607-06100-00 | Nut, U |
| 42 | 90387-083W8-00 | Collar |
| 43 | 95817-08025-00 | Bolt, Flange |
| 44 | 2H7-27414-00-00 | Damper, Footrest |
| 45 | 90387-10636-00 | Collar |
| 46 | 90105-10316-00 | Bolt, Washer Based |
| 47 | 95707-10500-00 | Nut, Flange |
| 48 | 90201-10669-00 | Washer, Plate |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 2GH-27211-00-00 | Pedal, Brake |
| 02 | 2TK-27813-00-00 | Pin, Pedal Crank |
| 03 | 95607-08100-00 | Nut, U |
| 04 | 90508-20737-00 | Spring, Torsion |
| 05 | 90446-17346-00 | Hose |
| 06 | 3GM-2583V-00-00 | Rr. Master Cylinder Assy. |
| 07 | 2KR-W0042-50-00 | • . Cylinder Kit, Master |
| 08 | 93210-15620-00 | • . O-ring |
| 09 | 95817-04012-00 | • . Bolt, Flange |
| 10 | 92990-04100-00 | • . Washer, Spring |
| 11 | 92901-04600-00 | • . Washer, Plate |
| 12 | 92017-08030-00 | Bolt, Button Head |
| 13 | 47X-27222-00-00 | Joint |
| 14 | 95307-08700-00 | Nut |
| 15 | 90240-08013-00 | Pin, Clevis |
| 16 | 90201-08083-00 | Washer, Plate |
| 17 | 91490-20020-00 | Pin, Cotter |
| 18 | 47X-25894-00-00 | Tank, Reservoir |
| 19 | 360-25854-00-00 | Diaphragm, Reservoir |
| 20 | 2GU-25855-00-00 | Bush,diaphragm |
| 21 | 2KF-25852-50-00 | Cap, Reservoir |
| 22 | 90159-06033-00 | Screw, With Washer |
| 23 | 3GM-25895-50-00 | Hose, Reservoir |
| 24 | 90467-14057-00 | Clip |
| 25 | 3GM-25874-A0-00 | Hose, Brake |
| 26 | 90401-10159-00 | Bolt, Union |
| 27 | 90201-10118-00 | Washer, Plate |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-2831W-A0-00 | Stay, Mirror 1 |
| 02 | 90480-13398-00 | Grommet |
| 03 | 90387-067N5-00 | Collar |
| 04 | 95027-06016-00 | Bolt, Flange |
| 05 | 3GM-2832W-A0-00 | Stay, Mirror 2 |
| 06 | 91317-06016-00 | Bolt |
| 07 | 3GM-28381-A0-00 | Windshield |
| 08 | 90149-05273-00 | Screw |
| 09 | 4FM-28215-00-00 | Washer, Special |
| 10 | 95707-05500-00 | Nut, Flange |
| 11 | 90150-05023-00 | Screw, Round Head |
| 12 | 90179-05523-00 | Nut |
| 13 | 3GM-Y283G-L0-IX | Body, Front Upper 1 |
| 14 | 99236-00100-00 | • . Emblem, Yamaha |
| 15 | 3LE-28390-20-00 | • . Graphic Set, Cowling |
| 16 | 3MA-21649-00-00 | • . Damper |
| 17 | 1FK-83526-00-00 | • . Damper 2 |
| 18 | 90480-14229-00 | Grommet |
| 19 | 90201-08759-00 | Washer, Plate |
| 20 | 90179-06500-00 | Nut |
| 21 | 3GM-28356-A0-00 | Stay 1 |
| 22 | 90105-08748-00 | Bolt, Washer Based |
| 23 | 4FM-26280-10-00 | Rear View Mirror Assy(left) |
| 24 | 4FM-26290-10-00 | Rear View Mirror Assy(right) |
| 25 | 4FM-26299-00-00 | Plate, Mirror Fitting 2 |
| 26 | 3XV-26298-00-00 | Plate, Mirror Fitting 1 |
| 27 | 98707-06025-00 | Screw, Flat Head |
| 28 | 95707-06500-00 | Nut, Flange |
| 29 | 3GM-2838N-A0-00 | Duct 1 |
| 30 | 3GM-2838R-A0-00 | Duct 2 |
| 31 | 3GM-2838T-01-00 | Duct 3 |
| 32 | 3GM-2838U-01-00 | Duct 4 |
| 33 | 3GM-2836H-00-00 | Bracket 5 |
| 34 | 3GM-2836J-00-00 | Bracket 6 |
| 35 | 97707-40112-00 | Screw, Tapping |
| 36 | 3GM-2835U-A0-00 | Panel 1 |
| 37 | 34M-2139X-00-00 | Damper |
| 38 | 3GM-2835V-A0-00 | Panel 2 |
| 39 | 3GM-2139X-00-00 | Damper |
| 40 | 90159-06178-00 | Screw, With Washer |
| 41 | 97707-50012-00 | Screw, Tapping |
| 42 | 90154-05013-00 | Screw, Binding |
| 43 | 90154-05059-00 | Screw, Binding |
| 44 | 90202-05180-00 | Washer, Plate |
| 45 | 90183-05024-00 | Nut, Spring |
| 46 | 3GM-28396-50-00 | Plate 1 |
| 47 | 3GM-28397-50-00 | Plate 2 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-Y283J-M0-7X | Body, Front Lower 1 |
| 02 | 90480-13398-00 | • . Grommet |
| 03 | 3LE-28301-20-00 | • . Graphic Set, Lower Cover 1 |
| 04 | 3LE-28338-20-00 | • . Emblem |
| 05 | 3LE-28315-00-00 | • . Emblem |
| 06 | 3LE-28368-00-00 | • . Emblem |
| 07 | 3GM-Y283K-L0-7X | Body, Front Lower 2 |
| 08 | 30X-2139X-00-00 | • . Damper |
| 09 | 90480-13398-00 | • . Grommet |
| 10 | 3LE-28303-20-00 | • . Graphic Set,lower Cover 2 |
| 11 | 3LE-28338-20-00 | • . Emblem |
| 12 | 3LE-28315-00-00 | • . Emblem |
| 13 | 3LE-28368-00-00 | • . Emblem |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-2836K-50-P1 | Panel, Inner 1 |
| 02 | 90154-05059-00 | Screw, Binding |
| 03 | 90202-05180-00 | Washer, Plate |
| 04 | 90183-05024-00 | Nut, Spring |
| 05 | 90387-067N5-00 | Collar |
| 06 | 90154-06061-00 | Screw, Binding |
| 07 | 90183-05024-00 | Nut, Spring |
| 08 | 90202-05180-00 | Washer, Plate |
| 09 | 90154-05059-00 | Screw, Binding |
| 10 | 97707-50012-00 | Screw, Tapping |
| 11 | 3GM-2836A-00-0( | Bracket 1 |
| 12 | 3GM-2836E-50-0( | Bracket 2 |
| 13 | 3GM-2836F-00-0( | Bracket 3 |
| 14 | 3GM-2836G-00-0( | Bracket 4 |
| 15 | 90179-05523-00 | Nut |
| 16 | 90202-05180-00 | Washer, Plate |
| 17 | 90154-05059-00 | Screw, Binding |
| 18 | 90480-35526-00 | Grommet |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 2GH-81600-55-00 | A.c. Generator Assy |
| 02 | 3FV-81634-00-00 | • . Head Wire Assy |
| 03 | 36Y-81643-30-00 | •• .. Bearing |
| 04 | 2KT-81645-50-00 | • . Screw |
| 05 | 36Y-81643-50-00 | • . Bearing |
| 06 | 4BH-81970-00-00 | • . Rectifier Assy |
| 07 | 36Y-81910-50-00 | • . Voltage Regulator Assy |
| 08 | 3FV-81619-00-00 | • . Brush Holder Assy |
| 09 | 36Y-81972-50-00 | • . Cover, Rectifier |
| 10 | 3FV-81645-00-00 | • . Screw |
| 11 | 98507-05018-00 | • . Screw, Pan Head |
| 12 | 92901-05100-00 | • . Washer, Spring |
| 13 | 92901-05600-00 | • . Washer, Plate |
| 14 | 3FV-81604-00-00 | • . Cover Assy |
| 15 | 3FV-81675-00-00 | • . Washer, Special |
| 16 | 36Y-81638-50-00 | • . Oil Seal |
| 17 | 2KT-81642-50-00 | • . O-ring |
| 18 | 2GH-81660-52-00 | • . Field Coil Assy |
| 19 | 95817-08030-00 | Bolt, Flange |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-81670-00 | Pick-up Assy |
| 02 | 93210-19216-0 | O-ring |
| 03 | 95027-06012-0 | Bolt, Flange |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-81800-50-00 | Starting Motor Assy |
| 02 | 26H-81847-00-00 | • . O-ring |
| 03 | 11H-81844-00-00 | • . Gasket |
| 04 | 3GM-81815-50-00 | • . Cord, Starter Motor |
| 05 | 3KS-81840-00-00 | • . Brush Holder Assy |
| 06 | 3HE-81826-00-00 | • . Bolt |
| 07 | 95827-06025-00 | Bolt, Flange |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-83310-00-00 | Front Flasher Light Assy 1 |
| 02 | 306-83311-40-00 | • . Bulb, Flasher |
| 03 | 51L-83332-01-00 | • . Lens, Flasher |
| 04 | 97707-40620-00 | • . Screw, Tapping |
| 05 | 3GM-83320-00-00 | Front Flasher Light Assy 2 |
| 06 | 306-83311-40-00 | • . Bulb, Flasher (12v-21w) |
| 07 | 51L-83342-01-00 | • . Lens, Flasher 2 |
| 08 | 97707-40680-00 | • . Screw, Tapping |
| 09 | 95307-12600-00 | Nut |
| 10 | 51J-83330-00-00 | Rear Flasher Light Assy 1 |
| 11 | 1VU-83332-00-00 | • . Lens, Flasher |
| 12 | 97707-40620-00 | • . Screw, Tapping |
| 13 | 306-83311-40-00 | • . Bulb, Flasher (12v-21w) |
| 14 | 51J-83340-00-00 | Flasher Light Assy 2 |
| 15 | 1VU-83342-00-00 | • . Lens, Flasher 2 |
| 16 | 97707-40620-00 | • . Screw, Tapping |
| 17 | 306-83311-40-00 | • . Bulb, Flasher (12v-21w) |
| 18 | 95707-12500-00 | Nut, Flange |
| 19 | 18G-83365-00-00 | Cap |
| 20 | 90214-12033-00 | Washer, Claw |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4FM-83570-00-00 | Speedometer Assy |
| 02 | 3GM-83540-20-00 | Tachometer Assy |
| 03 | 4FM-83590-00-00 | Water Temperature Assy |
| 04 | 4FM-83359-00-00 | Washer, Special |
| 05 | 4FM-8353H-40-00 | Case, Under |
| 06 | 2GH-83578-00-00 | Knob, Trip Meter |
| 07 | 3GM-83509-10-00 | Socket Cord Assy |
| 08 | 4G1-84744-00-00 | Bulb (12v-3.4w) |
| 09 | 2GV-83517-00-00 | Bulb (12v-1.7w,t6.5) |
| 10 | 98507-04010-00 | Screw, Pan Head |
| 11 | 92907-04100-00 | Washer, Spring |
| 12 | 92907-04600-00 | Washer |
| 13 | 97902-04122-00 | Screw, With Washer |
| 14 | 98507-03010-00 | Screw, Pan Head |
| 15 | 92990-03100-00 | Washer, Spring |
| 16 | 90159-03012-00 | Screw, With Washer |
| 17 | 90164-04023-00 | Screw, Tapping |
| 18 | 4FM-83520-00-00 | Socket Cord Assy |
| 19 | 3GM-87278-A0-00 | Cover, Meter |
| 20 | 97707-40012-00 | Screw, Tapping |
| 21 | 90480-14585-00 | Grommet |
| 22 | 90201-06059-00 | Washer, Plate |
| 23 | 95307-06600-00 | Nut |
| 24 | 4FM-83550-00-00 | Speedometer Cable Assy |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4FM-84330-41-00 | Body Assy |
| 02 | 4FM-84320-10-00 | Lens Assy |
| 03 | 4FM-8432A-10-00 | Lens Assy |
| 04 | 2F9-84314-00-00 | Bulb, Headlight |
| 05 | 4JG-84397-00-00 | Cover, Socket |
| 06 | 51L-84344-00-00 | Washer, Plain |
| 07 | 90338-24112-00 | Plug |
| 08 | 3GM-84301-00-00 | Pilot Light Assy 1 |
| 09 | 3GM-84321-00-00 | • . Lens Assy |
| 10 | 3GM-84322-00-00 | • . Gasket, Lens |
| 11 | 2JE-84744-00-00 | • . Bulb (12v 5w) |
| 12 | 3GM-84192-00-00 | • . Screw, Special (m4,l=12) |
| 13 | 3GM-84367-50-00 | Damper, Headlight 2 |
| 14 | 97707-50012-00 | Screw, Tapping |
| 15 | 3GM-8431R-00-00 | Stay, Setting |
| 16 | 90480-10517-00 | Grommet |
| 17 | 90387-052U5-00 | Collar |
| 18 | 90167-05037-00 | Screw, Tapping |
| 19 | 3GM-84359-50-00 | Cord, Headlight |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3GM-84710-20-00 | Taillight Unit Assy |
| 02 | 31L-84714-00-00 | • . Bulb (12v-21/5w) |
| 03 | 3LK-8473A-00-00 | • . Cord Assy |
| 04 | 90480-18276-00 | Grommet |
| 05 | 90387-062W4-00 | Collar |
| 06 | 90201-06312-00 | Washer, Plate |
| 07 | 95307-06600-00 | Nut |
| 08 | 3YF-84751-00-00 | Bracket, License |
| 09 | 95027-06016-00 | Bolt, Flange |
| 10 | 90387-061M0-00 | Collar |
| 11 | 95607-06100-00 | Nut, U |
| 12 | 90480-15259-00 | Grommet |
| 13 | 90201-105J4-00 | Washer, Plate |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LF-82305-10-00 | Ignitor Unit Assy |
| 02 | 90110-06158-00 | Bolt, Hexagon Socket Head |
| 03 | 31A-14477-00-00 | Plate |
| 04 | 3GM-82310-00-00 | Ignition Coil Assy |
| 05 | 3GM-82320-00-00 | Ignition Coil Assy |
| 06 | 2KT-82370-00-00 | Plug Cap Assy |
| 07 | 1AE-82540-00-00 | Neutral Switch Assy |
| 08 | 93210-29196-00 | O-ring |
| 09 | 98507-06016-00 | Screw, Pan Head |
| 10 | 3GM-85720-00-00 | Oil Level Gauge Assy |
| 11 | 95027-06016-00 | Bolt, Flange |
| 12 | 4FM-82541-00-00 | Wire, Lead |
| 13 | 3LN-82560-00-00 | Thermo Switch Assy |
| 14 | 11H-83591-00-00 | Thermo Unit |
| 15 | 98507-05008-00 | Screw, Pan Head |
| 16 | 92901-05100-00 | Washer, Spring |
| 17 | 3GM-85820-00-00 | Servo Motor Assy |
| 18 | 90480-14412-00 | Grommet |
| 19 | 90387-065V1-00 | Collar |
| 20 | 95807-06035-00 | Bolt, Flange |
| 21 | 90464-30040-00 | Clamp |
| 22 | 3GM-83350-00-00 | Flasher Relay Assy |
| 23 | 4FM-83371-00-00 | Horn |
| 24 | 95807-06010-00 | Bolt, Flange |
| 25 | 3GM-85752-01-00 | Sender Unit Assy, Fuel Meter |
| 26 | 42X-85753-00-00 | Gasket, Sender Unit |
| 27 | 90149-06011-00 | Screw |
| 28 | 90202-05187-00 | Washer, Plate |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 36Y-81940-00-00 | Starter Relay Assy |
| 02 | 95707-06500-00 | Nut, Flange |
| 03 | 3XW-82100-00-00 | Battery Assy (ytx14-bs) |
| 04 | 5Y1-82122-00-00 | Seat, Battery |
| 05 | 2T4-82131-00-00 | Band, Battery |
| 06 | 3GM-82116-00-00 | Wire, Minus Lead |
| 07 | 3XW-82116-00-00 | Wire, Minus Lead |
| 08 | 4JH-82501-01-00 | Main Switch Steering Lock |
| 09 | 90109-080G5-00 | Bolt |
| 10 | 3GM-82530-11-00 | Stop Switch Assy |
| 11 | 3GM-82590-30-00 | Wire Harness Assy |
| 12 | 1AE-82151-00-00 | • . Fuse (30a-bl) |
| 13 | 42X-82151-00-00 | • . Fuse (10a-bl) |
| 14 | 2GH-82151-00-00 | • . Fuse (20a-bl) |
| 15 | 3GM-82509-00-00 | Wire, Sub Lead |
| 16 | 90464-13080-00 | Clamp |
| 17 | 90464-13073-00 | Clamp |
| 18 | 25G-83936-01-00 | Band, Switch Cord |
| 19 | 3EN-81950-00-00 | Relay Assy |
| 20 | 4BH-8195A-00-00 | Relay Assy |
| 21 | 98780-05016-00 | Screw, Flat Head |
| 22 | 95707-05500-00 | Nut, Flange |
| 23 | 3TJ-83964-00-00 | Switch |
| 24 | 2KT-82566-01-00 | Switch, Side Stand |
| 25 | 90152-05021-00 | Screw, Countersunk |
| 26 | 90159-06033-00 | Screw, With Washer |
| 27 | 5Y9-12491-00-00 | Clamp 1 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.