




Ref No	Part No	Description
01	3TJ-11101-00-00	Cylinder Head Assy
02	3TJ-11133-10-00	• . Guide, Intake Valve
03	93440-07149-00	• . Circlip
04	99510-08016-00	• . Pin, Dowel
05	90105-06384-00	• . Bolt, Washer Based
06	90340-12112-00	• . Plug, Straight Screw
07	90116-06437-00	Bolt, Stud
08	90338-08174-00	• . Plug
09	90201-090P4-00	Washer, Plate
10	90179-09612-00	Nut
11	94701-00330-00	Plug, Spark (ngk-r Cr8e)
11	94701-00329-00	Plug, Spark (u24esr-n)
12	3TJ-11181-00-00	Gasket, Cylinder Head 1
13	3TJ-11191-00-00	Cover, Cylinder Head 1
14	3TJ-11193-00-00	Gasket, Head Cover 1
15	90109-064F0-00	Bolt
16	90209-11262-00	Washer
17	2GH-1111G-00-00	Rubber, Mount 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-11310-00-00	Cylinder
02	93210-60737-00	O-ring
03	91810-08016-00	Pin, Dowel
04	3TJ-11351-00-00	Gasket, Cylinder
05	90153-06045-00	Screw, Hexagon
06	90430-06014-00	Gasket

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-11411-00-00	Crankshaft
02	93101-26154-00	Oil Seal
02	93101-26156-00	Oil Seal
03	1WG-11416-00-00	Plane Bearing, Crankshaft 1
03	1WG-11416-10-00	Plane Bearing, Crankshaft 1
03	1WG-11416-20-00	Plane Bearing, Crankshaft 1
03	1WG-11416-30-00	Plane Bearing, Crankshaft 1
03	1WG-11416-40-00	Plane Bearing, Crankshaft 1
04	3TJ-11631-01-00	Piston (std)
04	3TJ-11636-01-00	Piston (0.50mm O/s)
04	3TJ-11638-01-00	Piston (1.00mm O/s)
05	3TJ-11610-00-00	Piston Ring Set (std)
05	3TJ-11610-20-00	Piston Ring Set (0.50mm O/s)
05	3TJ-11610-40-00	Piston Ring Set (1.00mm O/s)
06	2TK-11633-00-00	Pin, Piston
07	93450-16068-00	Circlip
08	3TJ-11650-00-00	Connecting Rod Assy
09	1WG-11654-00-00	• . Bolt, Connecting Rod
10	90179-07531-00	• . Nut
11	1WG-11656-00-00	Plane Bearing, Connecting Rod
11	1WG-11656-10-00	Plane Bearing, Connecting Rod
11	1WG-11656-20-00	Plane Bearing, Connecting Rod
11	1WG-11656-30-00	Plane Bearing, Connecting Rod

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-12111-00-00	Valve, Intake
02	3TJ-12121-00-00	Valve, Exhaust
03	1WG-12116-00-00	Seat, Valve Spring
04	3TJ-12113-00-00	Spring, Valve Inner
05	3TJ-12117-00-00	Retainer, Valve Spring
06	1HX-12118-00-00	Cotter, Valve
07	1HX-12119-00-00	Seal, Valve Stem
08	1WG-12153-21-00	Lifter, Valve
08	1WG-12153-31-00	Lifter, Valve
08	1WG-12153-09-00	Lifter, Valve (o/s)
09	1HX-12168-00-00	Pad, Adjusting 2 (1.20)
09	1HX-12168-M1-00	Pad, Adjusting 2 (1.65)
09	1HX-12168-R1-00	Pad, Adjusting 2 (1.70)
09	1HX-12168-U1-00	Pad, Adjusting 2 (1.75)
09	1HX-12168-W1-00	Pad, Adjusting 2 (1.80)
09	1HX-12168-Y1-00	Pad, Adjusting 2 (1.85)
09	1HX-12169-11-00	Pad, Adjusting 2 (1.90)
09	1HX-12169-31-00	Pad, Adjusting 2 (1.95)
09	1HX-12169-50-00	Pad, Adjusting 2 (2.00)
09	1HX-12169-70-00	Pad, Adjusting 2 (2.05)
09	1HX-12169-90-00	Pad, Adjusting 2 (2.10)
09	1HX-12168-20-00	Pad, Adjusting 2 (1.25)
09	1HX-12169-E0-00	Pad, Adjusting 2 (2.15)
09	1HX-12169-G0-00	Pad, Adjusting 2 (2.20)
09	1HX-12169-J0-00	Pad, Adjusting 2 (2.25)
09	1HX-12169-L0-00	Pad, Adjusting 2 (2.30)
09	1HX-12169-N0-00	Pad, Adjusting 2 (2.35)
09	1HX-12169-T0-00	Pad, Adjusting 2 (2.40)
09	1HX-12168-40-00	Pad, Adjusting 2 (1.30)
09	1HX-12168-60-00	Pad, Adjusting 2 (1.35)
09	1HX-12168-80-00	Pad, Adjusting 2 (1.40)
09	1HX-12168-A0-00	Pad, Adjusting 2 (1.45)
09	1HX-12168-F0-00	Pad, Adjusting 2 (1.50)
09	1HX-12168-H1-00	Pad, Adjusting 2 (1.55)
09	1HX-12168-K1-00	Pad, Adjusting 2 (1.60)

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-12171-00-00	Camshaft 1
02	3TJ-12181-00-00	Camshaft 2
03	1WG-12176-00-00	Sprocket, Cam Chain
04	90105-07385-00	Bolt, Washer Based
05	94581-32110-00	Chain (d.i.d. 215f-110l)
06	94681-32021-00	• . Joint, Chain (d.i.d. 215f-lj)
07	3TJ-12241-00-00	Guide, Stopper 2
08	3TJ-12210-00-00	Tensioner Assy, Cam Chain
09	90109-112F1-00	Bolt
10	4BE-12213-00-00	Gasket, Tensioner Case
11	91311-06025-00	Bolt
12	3TJ-12251-00-00	Damper, Chain 1
13	3TJ-12252-00-00	Damper, Chain 2
14	90109-065A8-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-12420-00-00	Water Pump Assy
02	1WG-12439-00-00	• . O-ring
03	93210-33133-00	O-ring
04	91311-06035-00	Bolt, Hex Socket Head
05	3TJ-12481-10-00	Pipe 1
06	93210-21190-00	O-ring
07	90110-06145-00	Bolt, Hexagon Socket Head
08	1WG-12446-01-00	Joint
09	93210-17746-00	O-ring
10	91311-06040-00	Bolt
11	91311-06025-00	Bolt
12	3TJ-12482-00-00	Pipe 2
13	93210-15566-00	O-ring
14	90110-06145-00	Bolt, Hexagon Socket Head
15	3TJ-12576-00-00	Hose 1
16	90450-32051-00	Hose Clamp Assy
17	3TJ-12577-00-00	Hose 2
18	46X-12410-00-00	Thermostat Assy
19	3TJ-12417-00-00	Housing, Thermostat
20	3TJ-12413-00-00	Cover, Thermostat
21	91311-06020-00	Bolt, Hex Socket Head
22	3TJ-1244E-00-00	Bracket 1
23	95811-06020-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-12461-10-00	Radiator Assy
02	22W-12462-00-00	• . Cap, Radiator
03	3TJ-12405-10-00	Blower Assy
04	3FV-12611-00-00	• . Fan
05	98501-05008-00	• . Screw, Pan Head
06	92901-05600-00	• . Washer, Plate
07	3TJ-12578-10-00	Hose 3
08	90450-32051-00	Hose Clamp Assy
09	3TJ-12579-00-00	Hose 4
10	90450-22052-00	Hose Clamp Assy
11	3TJ-12588-00-00	Hose 5
12	90445-125G0-00	Hose
13	90467-11090-00	Clip
14	90480-18276-00	Grommet
15	90387-07037-00	Collar
16	95826-06020-00	Bolt, Flange
17	95816-06025-00	Bolt, Flange
18	90480-15363-00	Grommet
19	90387-07390-00	Collar
20	95826-06020-00	Bolt, Flange
21	90201-06697-00	Washer, Plate
22	90445-091E9-00	Hose
23	90467-08003-00	Clip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1WG-13330-01-00	Pump Shaft Assy
02	1WG-13316-00-00	Cover, Pump
03	90201-113K2-00	Washer, Plate
04	93603-17070-00	Pin, Dowel
05	1WG-13310-00-00	Rotor Assy 1
06	93603-09106-00	Pin, Dowel
07	1WG-13336-00-00	Housing, Rotor
08	98501-06020-00	Screw Pan Head
09	99510-08012-00	Pin, Dowel
10	1WG-13329-00-00	Gasket, Pump Cover
11	90110-06130-00	Bolt, Hexagon Socket Head
12	3TJ-13412-00-00	Housing, Strainer
13	4H7-13411-02-00	Strainer, Oil
14	90110-06099-00	Bolt, Hexagon Socket Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-13470-00-00	Oil Cooler Assy
02	3TJ-13340-00-00	By-pass Valve Assy
03	93210-87723-00	O-ring
04	3FV-13440-00-00	Element Assy, Oil Cleaner
05	11H-13490-00-00	Relief Valve Assy
06	93210-10096-00	O-ring
07	3TJ-13417-01-00	Cover, Strainer
08	3HE-13414-10-00	Gasket, Strainer Cover
09	91311-06025-00	Bolt
10	99510-08016-00	Pin, Dowel
11	3VD-13455-00-00	Plug
12	214-11198-01-00	Gasket
13	3TJ-13161-00-00	Pipe, Delivery 1
14	90110-06145-00	Bolt, Hexagon Socket Head
15	90401-10106-00	Bolt, Union
16	90430-10171-00	Gasket
17	3TJ-2836A-00-00	Bracket 1
18	3TJ-2836E-00-00	Bracket 2

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-13586-00-00	Joint, Carburetor 1
02	90430-06014-00	• . Gasket
03	98502-06016-00	• . Screw, Pan Head
04	3TJ-13596-00-00	Joint, Carburetor 2
05	90430-06014-00	• . Gasket
06	98502-06016-00	• . Screw, Pan Head
07	3TJ-13597-00-00	Joint, Carburetor 3
08	90430-06014-00	• . Gasket
09	98502-06016-00	• . Screw, Pan Head
10	3TJ-13598-00-00	Joint, Carburetor 4
11	90430-06014-00	• . Gasket
12	98502-06016-00	• . Screw, Pan Head
13	91316-06020-00	Bolt
14	90450-49020-00	Hose Clamp Assy
15	3TJ-14411-00-00	Case, Air Cleaner 1
16	3TJ-14421-00-00	Case, Air Cleaner 2
17	3TJ-14457-00-00	Seal
18	97780-50125-00	Screw, Tapping
19	3TJ-14451-00-00	Element, Air Cleaner
20	3TJ-14412-00-00	Cap, Cleaner Case 1
21	5T0-14457-00-00	Seal
22	3TJ-14453-00-00	Joint, Air Cleaner 1
23	90460-58015-00	Clamp, Hose
24	90445-11452-00	Hose
25	90467-10008-00	Clip
26	4X7-2149Y-00-00	Filter Assy
27	90445-075G7-00	Hose
28	98501-05016-00	Screw, Pan Head
29	92901-05600-00	Washer, Plate
30	90480-14023-00	Grommet
31	90387-060M9-00	Collar
32	91011-06025-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-14900-01-00	Carburetor Assy
02	3TJ-14901-01-00	• . Carburetor Assy 1
03	3TJ-14902-01-00	• . Carburetor Assy 2
04	3TJ-14903-01-00	• . Carburetor Assy 3
05	3TJ-14904-01-00	• . Carburetor Assy 4
06	3FV-14147-00-00	•• .. O-ring
07	3GM-14985-00-00	•• .. Float
08	53L-14186-00-00	•• .. Pin, Float
09	3EN-14147-00-00	•• .. O-ring
10	98501-05012-00	•• .. Screw, Pan Head
11	98506-05016-00	•• .. Screw, Pan Head
12	92906-05100-00	•• .. Washer, Spring
13	92906-05600-00	•• .. Washer, Plate
14	98501-05018-00	•• .. Screw, Pan Head
15	1HX-14565-00-00	•• .. Screw
16	3GM-14997-00-00	•• .. Seal
17	3LF-14147-00-00	•• .. O-ring
18	1AE-14147-00-00	•• .. O-ring
19	137-14153-00-00	•• .. Washer, Main Jet
20	1AE-14227-00-00	•• .. Washer
21	3TJ-14933-00-00	•• .. Spring, Diaphragm
22	3EN-1411E-00-00	•• .. Block, Jet
23	3TJ-14940-00-00	•• .. Diaphragm Assy
24	98501-05016-00	•• .. Screw, Pan Head
25	92990-05100-00	•• .. Washer, Spring
26	256-14997-00-00	•• .. Seal
27	3FV-14191-00-00	•• .. Plug, Drain
28	3G2-14231-20-00	•• .. Jet, Main (100)
28	3G2-1423A-70-00	•• .. Jet, Main (97.5)
29	3TJ-14141-06-00	•• .. Nozzle, Main
30	4G0-14142-32-A0	•• .. Jet, Pilot (32.5)
31	830-14231-22-00	•• .. Jet, Main (110)
32	12R-14105-00-00	•• .. Pilot Screw Set
33	3G2-14231-10-00	•• .. Jet Power (50)
34	3TJ-1411A-00-00	•• .. Block Jet Assy
35	3TJ-1490J-20-00	•• .. Needle Set
35	3TJ-1490J-30-00	•• .. Needle Set
36	3EN-1410A-00-00	•• .. Starter Set
37	3GM-14107-10-00	•• .. Needle Valve Set
38	3EN-1490K-00-00	• . Stop Screw Set
39	3TJ-14103-00-00	• . Throttle Screw Set
40	17A-14251-00-00	• . Nipple
41	3EN-14997-00-00	• . Seal
42	3EN-14163-00-00	• . Spacer
43	8U9-14139-00-00	• . Clip, Pipe
44	1KT-14994-00-00	• . Net, Filter
45	3LN-14251-00-00	• . Nipple
46	822-14147-00-00	• . O-ring
47	3TJ-14197-00-00	• . Pipe
48	98501-05008-00	• . Screw, Pan Head
49	3LK-14147-00-00	• . O-ring
50	3GM-14251-00-00	• . Nipple
51	3GM-14974-00-00	• . Lever, Connect
52	95303-06600-00	• . Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
53	92990-06600-00	• . Washer,plate
54	3EN-14261-00-00	• . Holder
55	3TJ-14986-00-00	• . Lever, Starter
56	95303-05600-00	• . Nut
57	2GV-14953-00-00	• . Washer
58	90445-144G3-00	Hose
59	90467-13123-00	Clip
60	3LN-14197-00-00	Pipe

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-14610-00-00	Exhaust Pipe Assy 1
02	90101-06576-00	• . Bolt
03	92906-06600-00	• . Washer, Plate
04	3FH-14821-01-00	• . Arm, Shaft (valve)
05	3LN-14811-00-00	• . Housing
06	3FH-14815-00-00	• . Gasket
07	2TK-14845-00-00	• . Dust Seal Assy
08	3LN-14867-00-00	• . Bracket
09	90119-06115-00	• . Bolt, With Washer
10	90201-106M5-00	• . Washer, Plate
11	90380-10197-00	• . Bush, Solid
12	3LN-14865-00-00	• . Pulley
13	92990-05200-00	• . Washer, Plain
14	97011-05012-00	• . Bolt
15	90387-106U7-00	• . Collar
16	3LN-14826-00-00	Protector, Exhaust
17	3LN-14624-00-00	Cover, Exhaust
18	90119-06131-00	Bolt, With Washer
19	3YF-14613-01-00	Gasket,exhaust Pipe
20	90179-06499-00	Nut
21	95816-08030-00	Bolt, Flange
22	90201-08730-00	Washer, Plate
23	3TJ-14710-02-00	Muffler Assy 1
24	3HE-14755-00-00	• . Gasket, Silencer
25	91011-08025-00	• . Bolt, Flange
26	3TJ-14725-00-00	• . Band, Muffler
27	95811-06020-00	• . Bolt, Flange
28	90387-064T3-00	• . Collar
29	95811-08035-00	Bolt, Flange
30	95701-08500-00	Nut, Flange
31	90201-08753-00	Washer, Plate
32	3TJ-1133E-00-00	Cable, Pulley 1
33	3TJ-1133F-00-00	Cable, Pulley 2

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-15100-01-00	Crankcase Assy
02	11H-15138-00-00	• . Nozzle 1
03	2H7-15138-00-00	• . Nozzle 1
04	1HX-15138-00-00	• . Nozzle 1
05	99510-12016-00	• . Pin, Dowel
06	93210-15152-00	• . O-ring
07	371-11167-01-00	• . Pipe, Breather 2
08	36Y-15189-00-00	• . Plug
09	93210-16629-00	• . O-ring
10	2H7-15361-00-00	• . Gauge, Level
11	90201-237K5-00	• . Washer, Plate
12	93315-32516-00	• . Bearing, Cylindrical
13	91810-08016-00	• . Pin, Dowel
14	90116-09543-00	Bolt, Stud
15	90116-09542-00	Bolt, Stud
16	90105-08630-00	Bolt, Washer Based
17	90201-087K3-00	Washer, Plate
18	95811-06040-00	Bolt, Flange
19	95811-06050-00	Bolt, Flange
20	95811-06070-00	Bolt, Flange
21	95811-06080-00	Bolt, Flange
22	95811-06090-00	Bolt, Flange
23	95811-08070-00	Bolt, Flange
24	90430-06166-00	Gasket
25	90465-10307-00	Clamp
26	90465-10308-00	Clamp
27	1WG-11165-00-00	Plate, Breather
28	98501-06012-00	Screw, Pan Head
29	1WG-11145-00-00	Plate, Breather 2
30	98501-06012-00	Screw, Pan Head
31	1WG-11166-00-00	Pipe, Breather 1
32	90467-14015-00	Clip
33	90445-116G3-00	Hose
34	90465-06289-00	Clamp
35	90467-10038-00	Clip
36	1WG-15381-00-00	Plate, Bearing Cover
37	90110-06145-00	Bolt, Hexagon Socket Head
38	3HE-15105-00-00	Nozzle Assy
39	93210-06632-00	O-ring
40	90465-10290-00	Clamp
41	3TJ-15189-00-00	Plug
42	93210-16629-00	O-ring

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2TK-15411-00-00	Cover, Crankcase 1
02	1L9-15417-00-00	Cover, Cap
03	1WG-15316-00-00	Damper, Engine Mount 1
04	1WG-15427-00-00	Cover, Cap 2
05	98901-05008-00	Screw, Bind
06	3HE-15451-10-00	Gasket, Crankcase Cover 1
07	3HE-15467-10-00	Gasket
08	99510-08016-00	Pin, Dowel
09	90110-06149-00	Bolt, Hexagon Socket Head
10	90110-06148-00	Bolt, Hexagon Socket Head
11	2TK-15421-00-00	Cover, Crankcase 2
12	3HE-15461-10-00	Gasket, Crankcase Cover 2
13	99510-08016-00	Pin, Dowel
14	91311-06025-00	Bolt
15	91311-06035-00	Bolt, Hex Socket Head
16	91311-06045-00	Bolt
17	3TJ-15431-01-00	Cover, Crankcase 3
18	1WG-15425-00-00	Cover, Generator 2
19	1WG-15326-00-00	Damper, Engine Mount 2
20	98901-05008-00	Screw, Bind
21	3HE-15462-10-00	Gasket, Crankcase Cover 3
22	99510-08016-00	Pin, Dowel
23	91311-06025-00	Bolt
24	91311-06035-00	Bolt, Hex Socket Head
25	90465-08028-00	Clamp
26	3F9-15362-00-00	Plug, Oil Level
27	93210-27194-00	O-ring
28	3TJ-15415-00-00	Cover, Generator
29	90340-08M04-00	Plug, Straight Screw
30	4DX-15455-00-00	Gasket 1
31	99510-08016-00	Pin, Dowel
32	91311-06025-00	Bolt
33	91311-06035-00	Bolt, Hex Socket Head
34	90462-10182-00	Clamp
35	98501-06010-00	Screw, Pan Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3HE-15521-00-00	Shaft 1
02	3HE-15512-00-00	Gear, Idler 1
03	3HE-15517-00-00	Gear, Idler 2
04	4H7-15521-00-00	Shaft 1
05	1WG-15570-00-00	Starter Clutch Assy
06	1WG-15515-00-00	Gear 3
07	90280-16053-00	Key, Woodruff
08	90201-107K6-00	Washer, Plate
09	90105-10445-00	Bolt, Washer Based
10	93306-20006-00	Bearing (b6200)

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1WG-16150-01-00	Primary Driven Gear Comp.
02	1WG-16154-00-00	Plate, Thrust 1
03	1WG-16371-01-00	Boss, Clutch
04	21V-16321-00-00	Plate, Friction
05	131-16324-00-00	Plate, Clutch
06	37F-16351-00-00	Plate, Pressure 1
07	90501-227E0-00	Spring, Compression
08	90119-05001-00	Bolt, With Washer
09	1WG-16356-00-00	Rod, Push 1
10	93210-48364-00	O-ring
11	90215-18225-00	Washer, Lock
12	90170-18221-00	Nut
13	93109-08058-00	Oil Seal (sd0708-21-5.5 Hs)
14	1WG-16357-01-00	Rod, Push 2
15	93505-16006-00	Ball
16	1WG-16340-01-00	Push Lever Assy
17	1WG-16304-00-00	Ball Screw Housing Assy
18	90113-08021-00	Bolt, Set
19	90179-08179-00	Nut
20	90506-09232-00	Spring, Tension
21	90157-05065-00	Screw, Pan Head
22	132-16346-00-00	Hook, Spring
23	90387-212R3-00	Collar
24	1WG-16164-00-00	Plate, Thrust 2
25	1WG-16181-00-00	Spacer 1
26	93310-345R8-00	Bearing, Cylindrical

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1WG-17411-00-00	Axle, Main (13t)
02	1WG-17151-00-00	Gear, 5th Pinion (22t)
03	90209-18208-00	Washer
04	93410-22039-00	Circlip
05	3EN-17131-00-00	Gear, 3rd Pinion (21t/23t)
06	1WG-17161-00-00	Gear, 6th Pinion (23t)
07	1WG-17121-01-00	Gear, 2nd Pinion (18t)
08	93306-37205-00	Bearing (83b285c3)
09	93440-54152-00	Circlip
10	93399-99933-00	Bearing
11	278-17425-00-00	Circlip 2
12	3TJ-17421-00-00	Axle, Drive
13	93306-30550-00	Bearing
14	1WG-17221-00-00	Gear, 2nd Wheel (40t)
15	90209-27192-00	Washer
16	93440-30077-00	Circlip
17	1WG-17261-00-00	Gear, 6th Wheel (27t)
18	1WG-17231-00-00	Gear, 3rd Wheel (36t)
19	3EN-17241-00-00	Gear, 4th Wheel (33t)
20	90209-22191-00	Washer
21	93440-25084-00	Circlip
22	1WG-17251-00-00	Gear, 5th Wheel (28t)
23	1WG-17211-00-00	Gear, 1st Wheel (43t)
24	90387-253X3-00	Collar
25	93102-35109-00	Oil Seal (sd-35-62-6 Hs)
26	3FH-17460-00-00	Sprocket, Drive (19t)
27	90215-21022-00	Washer, Lock
28	90179-18020-00	Nut
29	90201-20276-00	Washer, Plate (1.0t)
30	93311-42045-00	Bearing (20ng3315ne)
31	278-17424-01-00	Circlip 1
32	278-17425-00-00	Circlip 2
33	4G0-17433-01-00	Nozzle

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1WG-18540-01-00	Shift Cam Assy
02	90501-06022-00	• . Spring, Compression
03	278-18542-00-00	• . Point, Neutral
04	278-18566-00-00	• . Plate, Side 2
05	98701-05012-00	• . Screw, Flat Head
06	1WG-18531-00-00	Bar, Shift Fork Guide 1 (l 102)
07	1WG-18535-00-00	Bar, Shift Fork Guide 2 (l 108)
08	1WG-18511-00-00	Fork, Shift 1
09	1WG-18512-00-00	Fork, Shift 2
10	1WG-18513-00-00	Fork, Shift 3
11	1WG-18536-00-00	Stopper, Shift Bar
12	1HX-18127-00-00	Stopper, Screw
13	90508-23707-00	Spring, Torsion
14	1WG-18562-00-00	Plate, Stopper 2
15	36Y-18140-00-00	Stopper Lever Assy
16	90109-063F7-00	Bolt
17	95811-06016-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3EN-18101-01-00	Shift Shaft Assy
02	90508-32682-00	• . Spring, Torsion
03	93102-12106-00	Oil Seal (sd 12-22-5 Hs)
04	90560-12211-00	Spacer
05	93109-12053-00	Oil Seal (sdo 12/18/4-1)
06	3HE-18110-00-00	Shift Pedal Assy
07	2H9-18154-00-00	• . Cover, Dust
08	132-18113-01-00	• . Cover, Shift Pedal
09	1WG-18112-01-00	Arm, Shift
10	2H9-18154-00-00	• . Cover, Dust
11	97011-06020-00	Bolt
12	46X-18115-00-00	Rod, Shift
13	90170-06228-00	Nut (counter Clockwise)
14	95303-06700-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4DX-21110-00-P0	Frame Comp.
02	4DX-21190-00-00	Rear Frame Comp.
03	90387-111X8-00	Collar
04	90480-14100-00	Grommet
05	90110-10189-00	Bolt, Hexagon Socket Head
06	95023-08030-00	Bolt, Flange
07	90110-10188-00	Bolt, Hexagon Socket Head
08	92990-10600-00	Washer
09	3TJ-21315-00-00	Stay, Engine 2
10	3TJ-21459-00-00	Spacer
11	95811-10265-00	Bolt, Flange
12	95821-08020-00	Bolt, Flange
13	95611-10200-00	Nut, Self-locking
14	90105-10063-00	Bolt, Washer Based
15	91312-08018-00	Bolt
16	91311-08030-00	Bolt, Hex Socket Head
17	3TJ-2142K-00-00	Bracket, Radiator
18	95816-06016-00	Bolt, Flange
19	3TJ-21446-00-00	Stay, Muffler 2
20	3TJ-2137Y-00-00	Guide, Air
21	3TJ-2137F-00-00	Stay 1
22	3TJ-21249-00-00	Bracket
23	97002-08012-00	Bolt
24	92902-08100-00	Washer, Spring
25	3TJ-2138K-00-00	Bracket, 1
26	3TJ-2138L-00-00	Bracket 2
27	3TJ-2139U-00-00	Damper 2
28	3TJ-82131-00-00	Band, Battery

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-W2151-00-GE	Front Fender Comp.
02	3GM-21512-00-00	• . Bracket, Fender
03	90267-32071-00	• . Rivet, Blind
04	90105-06564-00	• . Bolt, Washer Based
05	90387-065T2-00	Collar
06	4DX-21610-00-00	Rear Fender Comp.
06	2MY-21611-00-00	Fender, Rear
07	2MY-21671-00-00	Reinf., Rear Fender
08	95616-06100-00	Nut, U
09	2KR-21689-00-00	Bracket, Rear Stay 2
10	95816-06016-00	Bolt, Flange
11	3TJ-21629-00-00	Guard, Mud
12	97702-60520-00	Screw, Tapping
13	4N0-28186-00-00	Pouch
14	4K5-2814E-10-00	Hook
15	4DX-21651-00-GE	Cover, Rear Fender
16	99234-00020-00	Emblem, Yamaha
17	1KT-21746-00-00	Damper
18	90159-05172-00	Screw, With Washer
19	3TJ-28100-00-00	Tool Kit
20	2T4-82131-00-00	Band, Battery

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-Y2171-00-0X	Cover, Side 1
02	3TJ-2173E-00-00	• . Graphic 1
03	3TJ-21737-00-00	• . Emblem
04	3TJ-Y2172-00-0X	Cover, Side 2
05	3TJ-2173F-00-00	• . Graphic 2
06	3TJ-21737-00-00	• . Emblem
07	90480-01401-00	Grommet
08	2GH-2834H-00-00	Mole 6
09	90159-05172-00	Screw, With Washer
10	90183-05024-00	Nut, Spring
11	98580-05014-00	Screw, Pan Head
12	92901-05600-00	Washer, Plate
13	95303-05800-00	Nut
14	3TJ-2177G-00-00	Box, Battery
15	50W-82121-00-00	Pad, Battery
16	1KH-21717-00-00	Damper, Side Cover
17	90119-06100-00	Bolt, With Washer
18	2T4-82131-00-00	Band, Battery
19	3EN-21871-00-00	Tank, Recovery
20	90119-06085-00	Bolt, With Washer
21	4L0-21875-00-00	Cap
22	1AA-21874-00-00	Gasket
23	3TJ-21816-00-00	Pipe 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4DX-22110-00-P0	Rear Arm Comp.
02	3MA-22184-00-00	Bush
03	93317-52865-00	Bearing
04	3GM-22128-00-00	Cover, Thrust 1
05	3GM-22127-00-00	Shim
06	3MA-22141-01-00	Shaft, Pivot
07	95601-18200-00	Nut, Self-locking
08	93317-21746-00	Bearing, Cylindrical
09	93109-17048-00	Oil Seal (sdo 17-24-4)
10	90387-122R5-00	Collar
11	3TJ-2217A-00-00	Arm, Relay
12	93317-21746-00	Bearing, Cylindrical
13	90387-122R5-00	Collar
14	93317-31701-00	Bearing
15	90387-102R4-00	Collar
16	93109-17048-00	Oil Seal (sdo 17-24-4)
17	3GM-2217M-00-00	Arm 1
18	90105-10323-00	Bolt, Washer Based
19	90101-10658-00	Bolt
20	90101-10659-00	Bolt
21	90201-101J1-00	Washer, Plate
22	95611-10100-00	Nut, U
23	95611-10200-00	Nut, Self-locking
24	3TJ-22151-00-00	Seal, Guard
25	90387-06681-00	Collar
26	98516-06020-00	Screw, Pan Head
27	3MA-22311-00-00	Case, Chain
28	3TJ-22321-00-00	Stay, Chain Case 1
29	90267-48117-00	Rivet, Blind
30	90159-06084-00	Screw, With Washer
31	3TJ-25875-00-00	Holder, Brake Hose 1
32	98503-06014-00	Screw, Pan Head
33	95023-06016-00	Bolt
34	3TJ-25886-00-00	Holder, Brake Hose
35	3GM-2218A-70-00	Emblem, Rear Arm
36	90387-127W0-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-22210-20-00	Shock Absorber Assy, Rear
02	90101-10659-00	Bolt
03	90201-101J1-00	Washer, Plate
04	95611-10100-00	Nut, U
05	3TJ-22219-00-00	Bracket, Upper
06	90185-16127-00	Nut, Self-locking
07	90201-164H4-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	93332-00001-00	Bearing
02	93332-00008-00	Bearing
03	3LN-23415-60-00	Cover, Ball Race 1
04	90179-25033-00	Nut, Pop
05	90202-26142-00	Washer, Plate
06	26H-23418-01-00	Washer, Special
07	90176-22050-00	Nut, Crown
08	3TJ-23435-00-00	Crown, Handle
09	91311-08030-00	Bolt, Hex Socket Head
10	3TJ-2317E-00-00	Stay
10	4DX-2317E-00-00	Stay
11	91316-06025-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-23102-00-00	Front Fork Assy (l.h)
02	3TJ-23126-00-00	• . Tube, Outer (left)
03	4H7-23119-00-00	•• .. Plug, Drain
04	122-23129-00-00	•• .. Gasket, Drain Plug
05	4V4-23153-L0-00	• . Ring, Snap
06	3GM-23145-00-00	• . Oil Seal
07	3XJ-23125-L0-00	• . Metal, Slide 1
08	3GM-23144-00-00	• . Seal, Dust
09	4V4-23146-L0-00	• . Washer, Oil Seal
10	3TJ-23110-00-00	• . Inner Tube Comp.1
11	3GM-23173-00-00	• . Spindle, Taper
12	3TJ-23170-00-00	• . Cylinder Comp., Front Fork
13	3TJ-23141-00-00	• . Spring, Front Fork
14	3TJ-23111-00-00	• . Bolt, Cap
15	4V4-23158-L1-00	• . Gasket
16	3GM-23142-00-00	• . Seat, Spring Upper
17	1LX-23118-M0-00	• . Spacer (l=135mm)
18	4V4-23188-L0-00	• . O-ring
19	4V4-23181-L0-00	• . Bolt, Hexagon Socket Head
20	3TJ-23103-00-00	Front Fork Assy (r.h)
21	3TJ-23136-00-00	• . Tube, Outer (right)
22	4H7-23119-00-00	•• .. Plug, Drain
23	122-23129-00-00	•• .. Gasket, Drain Plug
24	4V4-23153-L0-00	• . Ring, Snap
25	3GM-23145-00-00	• . Oil Seal
26	3XJ-23125-L0-00	• . Metal, Slide 1
27	3GM-23144-00-00	• . Seal, Dust
28	4V4-23146-L0-00	• . Washer, Oil Seal
29	3TJ-23110-00-00	• . Inner Tube Comp.1
30	3GM-23173-00-00	• . Spindle, Taper
31	3TJ-23170-00-00	• . Cylinder Comp., Front Fork
32	3TJ-23141-00-00	• . Spring, Front Fork
33	3TJ-23111-00-00	• . Bolt, Cap
34	4V4-23158-L0-00	• . Gasket
35	3GM-23142-00-00	• . Seat, Spring Upper
36	1LX-23118-M0-00	• . Spacer (l=135mm)
37	4V4-23188-L0-00	• . O-ring
38	4V4-23181-L0-00	• . Bolt, Hexagon Socket Head
39	91311-08045-00	• . Bolt
40	90201-08085-00	• . Washer, Plate
41	3TJ-23340-00-00	Under Bracket Comp.
42	91311-12030-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-24110-00-05	Fuel Tank Comp.
02	99224-00040-00	• . Emblem, Yamaha
03	3TJ-24240-01-00	• . Graphic Set
04	3WP-24602-00-00	Cap Assy
05	90110-05112-00	Bolt, Hexagon Socket Head
06	91311-05010-00	Bolt, Hex Socket Head
07	2GH-24181-00-00	Damper, Locating
08	2GH-24183-00-00	Damper, Locating
09	2GH-24186-00-00	Washer, Special
10	90387-06299-00	Collar
11	97001-06025-00	Bolt, Hex
12	92990-06100-00	Washer
13	2GH-24191-00-00	Bracket, Fuel Tank 1
14	95811-06075-00	Bolt, Flange
15	95303-06800-00	Nut, Crown
16	90445-105G5-00	Hose
17	90467-09006-00	Clip
18	1HX-24181-00-00	Damper, Locating 1
19	90387-061W9-00	Collar
20	91311-06140-00	Bolt
21	92901-06600-00	Washer, Plate
22	90179-06333-00	Nut
23	26H-24500-00-00	Fuel Cock Assy 1
24	214-24512-00-00	• . Gasket
25	90149-06011-00	Screw
26	90202-05193-00	Washer, Plate
27	3TJ-24312-00-00	Pipe 2
28	1FK-24560-00-00	Filter Assy
29	3TJ-24313-00-00	Pipe 3
30	3LN-24398-00-00	Band 1
31	90467-12124-00	Clip
32	3TJ-24182-00-00	Damper, Locating 2
33	3MA-27491-00-00	Protector
34	3YX-13907-01-00	Fuel Pump Comp.

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-24710-00-00	Single Seat Assy
02	3TJ-24711-00-00	• . Cover, Single Seat
03	2J2-24723-00-00	• . Damper, Seat
04	22W-24741-00-00	• . Pad, Seat
05	95701-06500-00	• . Nut,flange
06	2TK-24718-00-00	• . Bracket, Seat
07	95026-08040-00	Bolt, Flange
08	90201-086A3-00	Washer, Plate
09	90480-17507-00	Grommet
10	90387-084L1-00	Collar
11	3TJ-24750-00-00	Tandem Seat Assy
12	3TJ-24744-00-00	Plate, Seat Fitting
13	51Y-21639-00-00	Damper 2
14	91316-06035-00	Bolt
15	3HE-24705-02-00	Seat Lock Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-25168-00-UJ	Cast Wheel, Front
02	93102-23252-00	Oil Seal
03	93306-20310-00	Bearing (b6203du)
04	90560-17358-00	Spacer
05	341-25149-00-00	Clutch, Meter
06	341-25846-00-00	Retainer, Clutch
07	93105-45017-00	Oil Seal
08	94112-170X7-00	Tire (120/60r17 55h D201f)
09	93900-00030-00	Valve, Rim
10	29L-25398-00-00	Balancer, Wheel (10g)
10	29L-25398-10-00	Balancer, Wheel (20g)
10	29L-25398-20-00	Balancer, Wheel (30g)
11	3MA-25190-00-00	Gear Unit Assy
12	90387-177V5-00	Collar
13	3GM-25181-00-00	Axle, Wheel

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3HE-2581T-00-00	Disc Brake Assy (left)
02	90109-08718-00	Bolt
03	3TJ-2580U-00-00	Caliper Assy (right)
04	3GM-W0057-00-00	• . Piston Assy, Caliper
05	3GM-W0047-00-00	•• .. Caliper Seal Kit
06	3MA-W0057-10-00	• . Piston Assy, Caliper
07	3MA-W0047-10-00	•• .. Caliper Seal Kit
08	3TJ-W0045-00-00	• . Brake Pad Kit
09	3MA-25919-00-00	• . Support, Pad
10	3MA-25924-00-00	• . Pin, Pad
11	3MA-25925-00-00	• . Clip
12	1J3-W0048-00-00	• . Breed Screw Kit
13	3TJ-2580T-00-00	Caliper Assy (left)
14	3GM-W0057-00-00	• . Piston Assy, Caliper
15	3GM-W0047-00-00	•• .. Caliper Seal Kit
16	3MA-W0057-10-00	• . Piston Assy, Caliper
17	3MA-W0047-10-00	•• .. Caliper Seal Kit
18	3TJ-W0045-00-00	• . Brake Pad Kit
19	3MA-25919-00-00	• . Support, Pad
20	3MA-25924-00-00	• . Pin, Pad
21	3MA-25925-00-00	• . Clip
22	1J3-W0048-00-00	• . Breed Screw Kit
23	90105-10308-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-25338-00-UJ	Cast Wheel, Rear
02	90560-20254-00	Spacer
03	93306-00418-00	Bearing
04	93306-20421-00	Bearing (b6204)
05	93102-28022-00	Oil Seal
06	1KT-25364-00-00	Damper
07	94116-170X9-00	Tire (160/60r17 69h D201)
08	93900-00030-00	Valve, Rim
09	29L-25398-00-00	Balancer, Wheel (10g)
09	29L-25398-10-00	Balancer, Wheel (20g)
09	29L-25398-20-00	Balancer, Wheel (30g)
10	3MA-25366-00-00	Clutch, Hub
11	93306-20509-00	Bearing (b6205z)
12	93102-32298-00	Oil Seal
13	1HX-25455-20-00	Sprocket, Driven (55t)
14	90116-08552-00	Bolt, Stud
15	95611-08200-00	Nut, Self-locking
16	90387-207V8-00	Collar
17	3TJ-25381-01-00	Axle, Wheel
18	90171-18051-00	Nut, Castle
19	91401-40040-00	Pin, Cotter
20	90201-186M4-00	Washer, Plate
21	90387-206W8-00	Collar
22	90387-207V7-00	Collar
23	3GM-25388-00-00	Puller, Chain 1
24	3GM-25389-00-00	Puller, Chain 2
25	90101-08705-00	Bolt
26	95303-08600-00	Nut
27	94571-41130-00	Chain (rk428smo-130le)

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1WG-25831-50-00	Disc, Brake
02	90109-08718-00	Bolt
03	3TJ-2580W-02-00	Caliper Assy, Rear 2
04	51L-W0057-00-00	• . Piston Assy, Caliper
05	51L-W0047-11-00	•• .. Caliper Seal Kit
06	51L-25919-00-00	• . Support, Pad
07	3TJ-W0046-00-00	• . Brake Pad Kit 2
08	51L-25924-00-00	• . Pin, Pad
09	51L-W0048-00-00	• . Bleed Screw Kit
10	47X-25827-00-00	• . Shim, Caliper
11	47X-25827-10-00	• . Shim, Caliper
12	3TJ-25819-01-00	Bracket, Caliper
13	90105-10561-00	Bolt, Washer Based
14	90105-10636-00	Bolt, Washer Based
15	91401-25020-00	Pin, Cotter
16	90201-106F2-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-26121-00-00	Handle Bar (left)
02	3TJ-26122-00-00	Handle Bar (right)
03	91311-08030-00	Bolt, Hex Socket Head
04	3HX-26246-00-00	End, Grip
05	47X-26241-00-00	Grip (left)
06	3FV-26240-00-00	Grip Assy
07	91311-06020-00	Bolt, Hex Socket Head
08	34K-26281-00-00	Cap, Grip Upper
09	1VJ-26282-00-00	Cap, Grip Lower
10	98506-05020-00	Screw, Pan Head
11	98506-05025-00	Screw, Pan Head
12	3TJ-26302-00-00	Throttle Cable Assy
13	3TJ-26335-00-00	Cable, Clutch
14	90179-08316-00	Nut
15	90123-08083-00	Bolt
16	3EN-26331-00-00	Cable, Starter 1
17	3TJ-83940-01-00	Starter Assy
18	1WG-83941-00-00	• . Lever, Starter
19	1WG-83942-00-00	• . Cover, Starter
20	98906-03006-00	• . Screw, Bind
21	90209-10131-00	• . Washer
22	98906-06008-00	• . Screw, Binding
23	91006-06008-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-W2587-00-00	Master Cylinder Sub Assy
02	3TJ-W0041-50-00	• . Cylinder Kit, Master
03	93210-15620-00	• . O-ring
04	2VN-25866-00-00	• . Circlip
05	3FV-2589A-00-00	• . Cover, Dust
06	56A-25867-00-00	Bracket, Master Cylinder
07	97016-06025-00	Bolt
08	92906-06600-00	Washer, Plate
09	3TJ-83922-00-00	Lever 2
10	3FV-2589F-00-00	Bolt, Lever
11	95616-06100-00	Nut, U
12	3FV-25894-00-00	Tank, Reservoir
13	3FV-25852-00-00	Cap, Reservoir
14	3FV-25854-00-00	Diaphragm, Reservoir
15	2J2-25855-50-00	Bush,diaphragm
16	3FV-2589G-00-00	Holder
17	3FV-83980-00-00	Front Stop Switch Assy
18	98511-04012-00	Screw, Pan Head
19	92902-04100-00	Washer, Spring
20	92901-04600-00	Washer, Plate
21	3TJ-2582F-01-00	Hose
22	90467-12085-00	Clip
23	98511-04012-00	Screw, Pan Head
24	92902-04100-00	Washer, Spring
25	92901-04600-00	Washer, Plate
26	3TJ-26292-00-00	Stay
27	3TJ-26131-00-00	Guide, Cable 1
28	91316-06016-00	Bolt
29	10L-23469-00-00	Cap, Bolt
30	3TJ-25872-01-00	Hose, Brake 1
31	3TJ-25873-01-00	Hose, Brake 2
32	1J7-25885-01-00	Joint
32	11U-25885-00-00	Joint
33	90401-10095-00	Bolt, Union
34	90401-10096-00	Bolt, Union
35	90201-10118-00	Washer, Plate
36	3EN-25875-00-00	Holder, Brake Hose 1
37	2R8-25876-00-00	Holder, Brake Hose 2
38	95023-06025-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2KT-27311-00-00	Stand, Side
02	90109-10474-00	Bolt
03	90185-10037-00	Nut, Self-locking
04	90506-18224-00	Spring, Tension
05	90506-26225-00	Spring, Tension
06	2KT-27315-00-00	Link, Side Stand
07	1TX-27351-00-00	Guide, Side Stand
08	3TJ-27321-00-00	Bracket, Side Stand
09	95811-10020-00	Bolt, Flange
10	1WG-27410-00-00	Front Footrest Assy (left)
11	2GH-27413-00-00	• . Cover, Footrest
12	90157-05079-00	• . Screw, Pan Head
13	90109-082A4-00	• . Bolt
14	1WG-27420-00-00	Front Footrest Assy (right)
15	2GH-27413-00-00	• . Cover, Footrest
16	90157-05079-00	• . Screw, Pan Head
17	90109-082A4-00	• . Bolt
18	46X-27442-01-00	Bracket 2
19	46X-27443-01-00	Bracket 3
20	1HX-27431-00-00	Footrest, Rear 1
21	1HX-27441-00-00	Footrest, Rear 2
22	90501-12743-00	Spring, Compression
23	93501-04011-00	Ball
24	1HX-27437-00-00	Washer, Special
25	91701-06040-00	Pin, Clevis
26	91401-20020-00	Pin, Cotter
27	90387-064H8-00	Collar
28	3TJ-2741L-00-00	Bracket 4
29	3TJ-2742L-00-00	Bracket 5
30	46X-14737-00-00	Damper, Muffler
31	1HX-27415-00-00	Plate, Footrest
32	91311-08020-00	Bolt
33	91311-08030-00	Bolt, Hex Socket Head
34	90109-103A9-00	Bolt
35	90206-17084-00	Washer, Wave
36	90110-08199-00	Bolt, Hexagon Socket Head
37	3TJ-27445-00-00	Plate 1
38	3TJ-27446-00-00	Plate 2
39	95023-06016-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1WG-27200-00-00	Pedal, Brake
02	90508-20737-00	Spring, Torsion
03	90446-17267-00	Hose
04	3TJ-2583V-00-00	Rr. Master Cylinder Assy.
05	3LN-W0042-50-00	• . Cylinder Kit, Master
06	3LN-2582A-00-00	• . Joint
07	3LN-2585F-00-00	• . O-ring
08	3LN-2585G-00-00	• . Circlip
09	3LN-2585H-00-00	• . Screw,set
10	92016-08030-00	Screw
11	47X-27222-00-00	Joint
12	95303-08700-00	Nut
13	90240-08013-00	Pin, Clevis
14	90201-08083-00	Washer, Plate
15	91401-20020-00	Pin, Cotter
16	31A-25894-01-00	Tank, Reservoir
17	360-25854-00-00	Diapfragm, Reservoir
18	2GU-25855-00-00	Bush,diaphragm
19	2KF-25852-50-00	Cap, Reservoir
20	98501-06025-00	Screw, Pan Head
21	92990-06100-00	Washer
22	92901-06600-00	Washer, Plate
23	31A-14477-00-00	Plate
24	3PJ-25888-00-00	Cover, Reservoir Tank
25	3TJ-25895-00-00	Hose, Reservoir
26	90467-14057-00	Clip
27	3TJ-2581J-01-00	Hose, Brake 4
28	90401-10096-00	Bolt, Union
29	90201-10118-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-28381-01-00	Windshield
02	95706-05500-00	Nut, Flange
03	90149-05273-00	Screw
04	3JJ-2835Y-00-00	Label, Caution
04	3JJ-2835Y-10-00	Label, Caution
05	3TJ-W2834-01-1X	Body, Cowling
06	99234-00025-00	• . Emblem, Yamaha (black, H 25)
07	3TJ-28390-01-00	• . Graphic Set, Cowling
08	90480-14229-00	Grommet
09	90179-06499-00	Nut
10	4DX-28356-00-00	Stay 1
11	90105-08652-00	Bolt, Washer Based
12	90109-060E9-00	Bolt
13	3TJ-2835U-10-00	Panel 1
14	3TJ-2835V-10-00	Panel 2
15	90167-05041-00	Screw, Tappi Ng
16	90202-05180-00	Washer
17	90149-05299-00	Screw
18	90179-05523-00	Nut
19	3HE-26280-00-00	Rear View Mirrot Assy (left)
20	3HE-26290-00-00	Rear View Mirror Assy(right)
21	90176-06055-00	Nut, Crown
22	3CV-26299-00-00	Plate, Mirror Fitting 2
23	3TJ-2831W-00-00	Stay, Mirror 1
24	91316-06012-00	Bolt, Hex Socket Head
25	3CV-26298-00-00	Plate, 1
26	3TJ-Y283J-00-0X	Body, Front Lower 1
27	3TJ-28315-00-00	• . Emblem
28	3TJ-2836V-01-00	• . Graphic Set 3, Cowling
29	99236-00055-00	• . Emblem, Yamaha
30	3TJ-28368-00-00	• . Emblem
31	90480-13398-00	• . Grommet
32	90480-35526-00	• . Grommet
33	3TJ-Y283K-00-0X	Body, Front Lower 2
34	3TJ-28315-00-00	• . Emblem
35	3TJ-2836W-01-00	• . Graphic Set 4, Cowling
36	99236-00055-00	• . Emblem, Yamaha
37	3TJ-28368-00-00	• . Emblem
38	90480-13398-00	• . Grommet
39	90480-35526-00	• . Grommet
40	3TJ-2836K-00-GE	Panel, Inner 1
41	90183-05024-00	Nut, Spring
42	90179-05523-00	Nut
43	90110-06202-00	Bolt, Hexagon Socket Head
44	90387-067N5-00	Collar
45	95802-06060-00	Bolt, Flange
46	3TJ-2836F-00-00	Bracket 3
47	90387-067W1-00	Collar
48	95701-06500-00	Nut,flange
49	90110-05201-00	Bolt, Hexagon Socket Head
50	3TJ-2838N-00-00	Duct 1
51	90167-05041-00	Screw, Tappi Ng
52	3TJ-2838R-00-00	Duct 2
53	90464-13073-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
54	1A8-21518-00-00	Holder, Cable
55	36Y-28348-00-00	Mole 4
56	3HX-28215-00-00	Washer, Special
57	90387-060E7-00	Collar
58	98706-06030-00	Screw, Flat Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-81450-00-00	Rotor Assy
02	3TJ-81410-00-00	Stator Assy
03	91311-06035-00	Bolt, Hex Socket Head
04	98501-05016-00	Screw, Pan Head
05	92901-05100-00	Washer, Spring
06	92901-05600-00	Washer, Plate
07	90280-03047-00	Key, Woodruff
08	90105-10430-00	Bolt, Washer Based
09	90201-107K6-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3HW-81800-00-00	Starting Motor Assy
02	3HE-81840-00-00	• . Brush Holder Assy
03	1HX-81815-00-00	• . Cord, Starter Motor
04	3HE-81850-00-00	• . Armature Assy
05	3AJ-81809-00-00	• . Washer Kit
06	3HE-81830-00-00	• . Front Bracket Assy
07	3HE-81826-00-00	• . Bolt
08	4G0-81871-00-00	• . Cap
09	11H-81844-00-00	• . Gasket
10	26H-81847-00-00	• . O-ring
11	95023-06025-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	3GM-83310-00-00	Front Flasher Light Assy 1
02	306-83311-40-00	• . Bulb, Flasher (12v-21w)
03	51L-83332-01-00	• . Lens, Flasher
04	97706-40620-00	• . Screw, Tapping
05	3GM-83320-00-00	Front Flasher Light Assy 2
06	306-83311-40-00	• . Bulb, Flasher (12v-21w)
07	51L-83342-01-00	• . Lens, Flasher 2
08	97706-40620-00	• . Screw, Tapping
09	51J-83330-00-00	Rear Flasher Light Assy 1
10	1VU-83332-00-00	• . Lens, Flasher
11	97706-40620-00	• . Screw, Tapping
12	306-83311-40-00	• . Bulb, Flasher (12v-21w)
13	51J-83340-00-00	Rear Flasher Light Assy 2
14	1VU-83342-00-00	• . Lens, Flasher 2
15	97706-40620-00	• . Screw, Tapping
16	306-83311-40-00	• . Bulb, Flasher (12v-21w)
17	95701-12500-00	Nut, Flange
18	18G-83365-00-00	Cap


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4DX-83570-10-00	Speedometer Assy
01	4DX-83570-00-00	Compteur De Vitesse Cplt
02	3TJ-83540-00-00	Tachometer Assy
03	3EN-83590-50-00	Water Temperature Assy
04	3GM-83559-00-00	Cover, Meter
05	3LG-8353H-10-00	Case, Under
06	2GH-83578-00-00	Knob, Trip Meter
07	4DX-83509-10-00	Socket Cord Assy
07	4DX-83509-00-00	Cordon De Fil Cplt
08	4G1-84744-00-00	Bulb (12v-3.4w)
09	3GM-83517-00-00	Bulb (12v-1.7w)
10	2GV-83517-00-00	Null (12v-1.7w, T 6.5)
11	98580-04010-00	Screw, Pan Head
12	92902-04100-00	Washer, Spring
13	92901-04600-00	Washer, Plate
14	90167-04057-00	Screw, Tapping
15	98580-03010-00	Screw, Pan Head
16	92990-03100-00	Washer, Spring
17	90159-03102-00	Screw, With Washer
18	90164-04008-00	Screw, Tapping
19	90167-03058-00	Screw, Tapping
20	3GM-83520-00-00	Socket Cord Assy
21	3GM-83513-00-00	Damper
22	3GM-83525-00-00	Clip
23	90480-14229-00	Grommet
24	90201-06059-00	Washer, Plate
25	90387-07391-00	Collar
26	95316-06600-00	Nut
27	34X-83550-01-00	Speedometer Cable Assy
28	3SX-8352K-00-00	Plug, Blind

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.

FOR ENGLAND




FOR FRANCE




Ref No	Part No	Description
01	3TJ-84310-00-00	Headlight Unit Assy
02	3TJ-84334-00-00	• . Nut, Adjusting
03	3MA-8413H-00-00	• . Plate, Spring
04	3TJ-84314-00-00	Bulb, Headlight (12v-55/40w)
05	3TJ-84112-00-00	Socket
06	3TJ-84397-00-00	Cover, Socket
07	3TJ-84526-00-00	Screw
08	3HE-84320-40-00	Lens Assy
09	2L2-84314-20-00	Bulb, Headlight (12v-60/55w)
10	36Y-84397-00-00	Cover, Socket
11	4E2-84347-00-00	Bulb (12v-4w)
12	3HE-84312-40-00	Holder, Socket

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	47X-84710-E0-00	Taillight Unit Assy
02	47X-84721-00-00	• . Lens, Taillight
03	47X-84723-00-00	• . Gasket, Tail Lens
04	47X-84735-00-00	• . Cord Assy
05	31L-84714-00-00	• . Bulb, Taillight (12v-21/5w)
06	90480-18276-00	Grommet
07	90201-063J2-00	Washer, Plate
08	90387-060A7-00	Collar
09	95303-06600-00	Nut
10	90480-15259-00	Grommet
11	92906-10200-00	Washer
12	3Y6-85130-01-00	Rear Reflector Assy
12	3G1-85130-01-00	Rear Reflector Assy
13	95701-05500-00	Nut, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



FOR FRANCE




FWD

4DX310-2440


Ref No	Part No	Description
01	3TJ-83969-00-00	Switch, Handle 5
01	4DX-83969-00-00	Switch, Handle 5
02	98506-05030-00	• . Screw Pan Head
03	98506-05040-00	• . Screw, Pan Head
04	3LN-83975-60-00	Switch, Handle 2
05	90157-05057-00	Screw, Pan Head
06	29L-82911-01-00	Holder Lever, Assy
07	3HE-83912-00-00	Lever 1
08	31A-83913-00-00	Collar, Lever 1
09	31A-82917-00-00	Switch
10	31A-83945-00-00	Bolt, Lever
11	98702-03008-00	Screw, Flat Head
12	95616-06100-00	Nut, U
13	97001-06025-00	Bolt, Hex
14	92906-06100-00	Washer, Spring
15	90338-09012-00	Plug

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	3TJ-82310-00-00	Ignition Coil Assy
02	3TJ-82320-00-00	Ignition Coil Assy
03	1WG-82370-00-00	Plug Cap Assy
04	4DX-82305-00-00	Ignitor Unit Assy
05	36Y-81940-00-00	Starter Relay Assy
06	95701-06500-00	Nut,flange
07	3PK-82100-00-00	Battery Assy (ytx9-bs 12v-8ah)
08	3TJ-82115-00-00	Wire, Plus Lead
09	3TJ-82116-00-00	Wire, Minus Lead
10	90461-10093-00	Clamp
11	90465-13169-00	Clamp
12	3TJ-82530-01-00	Stop Switch Assy
13	4DX-82590-10-00	Wire Harness Assy
13	4DX-82590-00-00	Wire Harness Assy
14	1AE-82151-00-00	• . Fuse (12v 30a)
15	2GH-82151-00-00	• . Fuse (20a)
16	42X-82151-00-00	• . Fuse (10a)
17	J45-83936-00-00	Band, Switch Cord
18	5Y9-12491-00-00	Clamp 1
19	90464-14117-00	Clamp
20	3TJ-81960-01-00	Rectifier & Regulator Assy
21	98501-06030-00	Screw, Pan Head
22	92990-06100-00	Washer
23	92990-06600-00	Washer,plate
24	3TJ-82501-00-00	Main Switch Steering Lock
24	4DX-82501-00-00	Main Switch Steering Lock
25	90149-06228-00	Screw
25	90109-06614-00	Bolt
26	90464-13073-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	1AE-82540-00-00	Neutral Switch Assy
02	93210-29196-00	O-ring
03	98502-06016-00	Screw, Pan Head
04	3TJ-82583-00-00	Wire, Sub Lead
05	11H-83591-00-00	Thermo Unit
06	3TJ-82509-00-00	Wire, Sub Lead
07	3TJ-82504-00-00	Oil Pressure Switch Assy
08	3KS-85370-00-00	Resistor Assy
09	97701-60512-00	Screw, Tapping
10	3EN-81950-00-00	Relay Assy
11	3MD-82566-00-00	Switch Side Stand Relay
12	90157-05079-00	Screw, Pan Head
13	3TJ-85752-00-00	Sender Unit Assy, Fuel Meter
14	42X-85753-00-00	Gasket, Sender Unit
15	90149-06011-00	Screw
16	90202-05193-00	Washer, Plate
17	2EL-82560-00-00	Thermo Switch Assy
18	3TJ-85820-00-00	Servo Motor Assy
19	1FK-85821-00-00	• . Pulley, Drive
20	90149-05245-00	• . Screw
21	90480-14412-00	Grommet
22	90387-065V1-00	Collar
23	91001-06030-00	Bolt, Flange
24	3TJ-83964-00-00	Switch
25	98702-05014-00	Screw, Flat Head
26	95701-05500-00	Nut, Flange
27	3YA-83350-00-00	Flasher Relay Assy
28	3TJ-83371-00-00	Horn
28	3HE-83371-00-00	Horn
29	91026-06012-00	Bolt
30	437-83936-11-00	Band, Switch Cord

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.