




Ref No	Part No	Description
01	2GV-11102-01-00	Cylinder Head Assy
02	4H7-11133-10-00	• . Guide, Intake Valve
03	93440-12052-00	• . Circlip
04	99510-17016-00	Pin, Dowel
05	90387-226G7-00	Collar
06	90430-24184-00	Gasket
07	2GV-11181-00-00	Gasket, Cylinder Head 1
08	2GV-11127-00-00	Absorber 3
09	90179-10395-00	Nut
10	90201-10131-00	Washer, Plate
11	90179-10279-00	Nut
12	2GV-11142-00-00	Bracket, Cylinder Head Cover 2
13	2GV-11152-00-00	Bracket, Cylinder Head Cover
14	95707-08500-00	Nut, Flange
15	90201-094G1-00	Washer, Plate
16	91314-08030-00	Bolt
17	95617-08630-00	Bolt, Stud
18	2GV-11185-00-00	Cover, Cylinder Head Side 1
19	2GV-1111H-00-00	Cover, Cylinder Head Side 4
20	22U-11165-00-00	Plate, Breather
21	93210-89568-00	O-ring
22	2GV-11166-00-00	Pipe, Breather 1
23	90467-14015-00	Clip
24	93211-00612-00	O-ring
25	91314-06025-00	Bolt
26	22U-11186-00-00	Cover, Cylinder Head Side 2
27	22U-11187-00-00	Cover, Cylinder Head Side 3
28	93210-62446-00	O-ring
29	97027-06016-00	Bolt
30	92907-06600-00	Washer, Plate
31	97024-06016-00	Bolt
32	92990-06600-00	Washer, Plate
33	90401-16073-00	Bolt, Union
34	90430-17168-00	Gasket
35	22U-1111F-01-00	Plate
36	90215-08229-00	Washer, Lock
37	90109-08781-00	Bolt
38	90109-08781-00	Bolt
39	94701-00218-00	Plug, Spark
40	2NT-11186-00-00	Cover, Cylinder Head Side 2
41	2NT-1110M-00-00	Cover Assy 1
42	2NT-11187-00-00	Cover, Cylinder Head Side 3
43	90480-18411-00	Grommet
44	90480-18411-00	Grommet
45	90110-06198-00	Bolt, Hexagon Socket Head
46	90387-06518-00	Collar
47	90387-072W2-00	Collar
48	90201-06697-00	Washer, Plate
49	3BT-11195-00-00	Gasket
50	3BT-11196-00-00	Gasket, Cylinder Head Side

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2GV-11310-00-00	Cylinder
02	2GV-11320-00-00	Cylinder 2
03	93210-81411-00	O-ring
04	15A-11162-00-00	Absorber 2
05	91317-06085-00	Bolt
06	3BT-11351-00-00	Gasket, Cylinder

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	22U-11411-00-00	Crankshaft
02	2GV-11631-00-00	Piston (std)
02	2GV-11636-00-00	Piston (0.50mm O/s)
02	2GV-11638-00-00	Piston (1.00mm O/s)
03	2GV-11610-00-00	Piston Ring Set (std)
03	2GV-11610-20-00	Piston Ring Set
03	2GV-11610-40-00	Piston Ring Set
04	22U-11633-01-00	Pin, Piston
05	93450-19052-00	Circlip
06	22U-11650-00-00	Connecting Rod Assy
07	22U-11654-00-00	• . Bolt, Connecting Rod
08	90179-08327-00	• . Nut
09	22U-11656-00-00	Plane Bearing, Connecting Rod
09	22U-11656-10-00	Plane Bearing, Connecting Rod
09	22U-11656-20-00	Plane Bearing, Connecting Rod
09	22U-11656-30-00	Plane Bearing, Connecting Rod
10	90280-05048-00	Key, Woodruff


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



22U110-3050


Ref No	Part No	Description
01	22U-12111-00-00	Valve, Intake
02	22U-12121-01-00	Valve, Exhaust
03	3Y1-12116-00-00	Seat, Valve Spring
04	22U-12113-00-00	Spring, Valve Inner
05	22U-12114-00-00	Spring, Valve Outer
06	1J7-12119-01-00	Seal, Valve Stem
07	3Y1-12117-01-00	Retainer, Valve Spring
08	1J7-12118-00-00	Cotter, Valve
09	22U-12151-00-00	Arm, Valve Rocker
10	22U-12156-01-00	Shaft, Rocker 2
11	22U-12159-00-00	Screw, Valve Adjusting
12	90170-06128-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	22U-12171-01-00	Camshaft 1
02	22U-12181-01-00	Camshaft 2
03	22U-11145-00-00	Plate, Breather 2
04	90101-10303-00	Bolt
05	93605-10108-00	Pin, Dowel
06	90380-28110-00	Bush, Solid
07	94590-27118-00	Chain
08	22U-12176-01-00	Sprocket, Cam Chain
09	11H-12210-02-00	Tensioner Assy, Cam Chain
10	3BT-12213-00-00	Gasket, Tensioner Case
11	91314-06025-00	Bolt
12	22U-12231-00-00	Guide, Stopper 1
13	22U-12241-00-00	Guide, Stopper 2
14	97027-06016-00	Bolt
15	92907-06600-00	Washer, Plate
16	90201-10774-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	22U-13300-00-00	Oil Pump Assy
02	93210-10096-00	O-ring
03	91317-06030-00	Bolt
04	22U-13325-00-00	Gear, Pump Driven
05	99009-11400-00	Circlip
06	22U-13324-00-00	Gear, Pump Drive
07	22U-13410-00-00	Strainer Housing Assy
08	2GV-13417-00-00	Cover, Strainer
09	22U-13415-00-00	Seal, Oil Strainer
10	93210-15151-00	O-ring
11	91317-06025-00	Bolt
12	3VD-13455-00-00	Plug
13	214-11198-01-00	Gasket

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4X7-13440-90-00	Element Assy, Oil Cleaner
02	2NT-13447-00-00	Cover, Oil Element
02	3JB-13447-00-00	Cover, Oil Element
03	93210-64297-00	O-ring
04	91314-06060-00	Bolt
05	91314-06095-00	Bolt
06	91314-06025-00	Bolt

FWD


2GV110-7070

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2GV-13586-01-00	Joint, Carburetor 1
01	4MC-13586-00-00	Joint, Carburetor 1
02	2GV-13596-00-00	Joint, Carburetor 2
02	4MC-13596-00-00	Joint, Carburetor 2
03	16G-13569-00-00	Plug, Blind
04	90467-10039-00	Clip
05	93210-36549-00	O-ring
06	91317-06020-00	Bolt
07	90460-52210-00	Clamp, Hose
08	90445-111F3-00	Hose
09	90460-52210-00	Clamp, Hose
10	2GV-14197-00-00	Pipe
11	2GV-14987-00-00	Hose
12	2GV-14451-00-00	Element, Air Cleaner
13	2GV-14412-00-00	Cap, Cleaner Case 1
14	52W-14452-00-00	Seal
15	22U-14469-00-00	Funnel, Air
16	90460-58015-00	Clamp, Hose
17	98517-06160-00	Screw, Pan Head
18	90201-06067-00	Washer, Plate
19	90387-062T3-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3BT-14900-30-00	Carburetor Assy
01	4MC-14900-20-00	Carburetor Assy
01	3BT-14900-20-00	Carburetor Assy
01	4MC-14900-30-00	Carburetor Assy
02	3BT-14901-30-00	• . Carburetor Assy 1
02	4MC-14901-20-00	• . Carburetor Assy 1
02	3BT-14901-20-00	• . Carburetor Assy 1
02	4MC-14901-30-00	• . Carburetor Assy 1
03	3BT-14902-30-00	• . Carburetor Assy 2
03	4MC-14902-20-00	• . Carburetor Assy 2
03	3BT-14902-20-00	• . Carburetor Assy 2
03	4MC-14902-30-00	• . Carburetor Assy 2
04	1FK-14933-00-00	• . Spring, Diaphragm
05	3G2-14231-34-00	•• .. Jet, Main
06	22U-1490H-00-00	•• .. Diaphragm Set 5
07	41R-14940-00-00	•• .. Diaphragm Assy
08	2JV-1490J-00-00	•• .. Needle Set
08	2JV-1490J-10-00	•• .. Needle Set
09	11H-1410A-00-00	•• .. Starter Set
10	3JB-14536-00-00	•• .. Gasket
11	22U-14565-00-00	•• .. Screw
12	137-14153-00-00	•• .. Washer, Main Jet
13	2JU-14141-90-00	•• .. Nozzle, Main
13	2JU-14141-08-00	•• .. Nozzle, Main
14	22U-14147-00-00	•• .. O-ring
15	98506-04018-00	•• .. Screw, Pan Head
16	92902-04100-00	•• .. Washer, Spring
17	3G2-14231-14-00	•• .. Jet, Main
18	1FK-14190-15-00	•• .. Needle Valve Assy
19	1FK-14985-00-00	•• .. Float
20	4G0-14142-35-A0	•• .. Jet, Pilot
20	4HR-14142-35-00	•• .. Jet, Pilot
21	98511-04012-00	•• .. Screw, Pan Head
22	92901-04100-00	•• .. Washer, Spring
23	22U-14968-00-00	•• .. Cap
24	22V-14968-00-00	•• .. Cap
25	98580-05014-00	•• .. Screw, Pan Head
26	98580-05014-00	•• .. Screw, Pan Head
27	92901-04100-00	•• .. Washer, Spring
28	90157-05050-00	•• .. Screw, Pan Head
29	2JU-1414G-00-00	•• .. Pipe, Main Breed
30	22V-14147-00-00	O-ring
31	3G2-14231-27-00	Jet, Main
32	98501-05012-00	Screw, Pan Head
33	341-14991-00-00	Screw
34	26H-14952-00-00	Washer
35	22U-14952-00-00	Washer
36	93210-03119-00	O-ring
37	98701-06010-00	•• .. Screw, Flat Head
38	341-14954-00-00	•• .. Washer
39	12R-14105-00-00	•• .. Pilot Screw Set
40	22F-14991-00-00	•• .. Screw
41	127-14198-00-00	•• .. Gasket
42	98902-08014-00	•• .. Screw, Bind
43	2L1-14191-00-00	•• .. Plug, Drain

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
44	214-14147-00-00	•• .. O-ring
45	3JB-1490L-00-00	• . Starter Lever Set, 1
46	98501-05010-00	• . Screw, Pan Head
47	90467-10008-00	• . Clip
48	31H-14987-00-00	• . Hose
49	3EN-1490K-00-00	• . Stop Screw Set
50	22U-14103-00-00	• . Throttle Screw Set
51	98580-06012-00	• . Screw, Pan Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2YL-14703-10-00	Muffler Comp. 1
02	90101-06576-00	• . Bolt
03	92907-06600-00	• . Washer, Plate
04	98507-06020-00	• . Screw, Pan Head
05	92907-06600-00	• . Washer, Plate
06	90179-08410-00	Nut
07	4BE-14613-00-00	Gasket, Exhaust Pipe
08	97027-08030-00	Bolt
09	92907-08100-00	Washer, Spring
10	92907-08600-00	Washer, Plate
11	4BR-14613-00-00	Gasket, Exhaust Pipe
12	2GV-14625-00-00	Joint, Exhaust 2
13	91317-06025-00	Bolt
14	90185-08097-00	Nut, Self-locking
15	95317-08700-00	Nut
16	2GV-14663-00-00	Plate, Air Cleaner
17	95807-06016-00	Bolt, Flange
18	2GV-14603-00-00	Cover 1
19	97704-40012-00	Screw, Tapping
20	90163-04003-00	Screw, Tapping
21	90183-04027-00	Nut, Spring
22	2GV-14484-00-00	Plate, Cleaner Case Fitting
23	2GV-2138L-00-00	Bracket 2
24	95807-08016-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2GV-15100-00-00	Crankcase Assy
02	22U-11416-80-00	• . Plane Bearing, Crankshaft 1
02	22U-11416-90-00	• . Plane Bearing, Crankshaft 1
03	91810-17016-00	• . Pin, Dowel
04	90116-10406-00	Bolt, Stud
05	90116-10405-00	Bolt, Stud
06	90116-08404-00	Bolt, Stud
07	95617-10680-00	Bolt, Stud
08	99530-14016-00	Pin, Dowel
09	90387-16547-00	Collar
10	93210-18322-00	O-ring
11	90116-10406-00	Bolt, Stud
12	90116-10405-00	Bolt, Stud
13	90116-08404-00	Bolt, Stud
14	99530-14016-00	Pin, Dowel
15	90387-16547-00	Collar
16	93210-18322-00	O-ring
17	90387-16547-00	Collar
18	93210-18322-00	O-ring
19	91314-08060-00	Bolt
20	91317-08080-00	Bolt
21	91314-08100-00	Bolt
22	91317-06095-00	Bolt
23	91317-06045-00	Bolt
24	91314-06055-00	Bolt
25	11H-15383-01-00	Plate, Bearing Cover
26	90151-08022-00	Screw, Countersunk
27	90149-08152-00	Screw
28	22U-15441-01-00	Holder, Clutch Cable
29	22U-15123-00-00	Plate, Buffle 1
30	98507-06012-00	Screw, Pan Head
31	92907-06600-00	Washer, Plate
32	91314-06045-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2NT-15411-01-00	Cover, Crankcase 1
01	3JB-15411-00-00	Cover, Crankcase 1
02	3BT-15451-00-00	Gasket, Crankcase Cover 1
03	2H7-15361-00-00	Gauge, Level
04	3F9-15362-00-00	Plug, Oil Level
05	93210-27778-00	O-ring
06	90340-14068-00	Plug, Straight Screw
06	90340-14139-00	Plug, Straight Screw
07	93210-14369-00	O-ring
08	90340-32088-00	Plug, Straight Screw
08	90340-32140-00	Plug, Straight Screw
09	93210-32172-00	O-ring
10	99530-10014-00	Pin, Dowel
11	91314-06040-00	Bolt
12	91314-06025-00	Bolt
13	91314-06055-00	Bolt
14	91314-06030-00	Bolt
15	3BT-15484-00-00	Clamp 2
16	2GV-15316-00-00	Damper, Engine Mount 1
17	2NT-15415-00-00	Cover, Generator
17	3JB-15415-00-00	Cover, Generator
18	93210-74316-00	O-ring
19	91314-06018-00	Bolt
20	2NT-15421-00-00	Cover, Crankcase 2
20	3JB-15421-00-00	Cover, Crankcase 2
21	3BT-15461-00-00	Gasket, Crankcase Cover 2
22	93101-14089-00	Oil Seal
23	99009-25500-00	Circlip
24	99530-10020-00	Pin, Dowel
25	91314-06040-00	Bolt
26	91314-06055-00	Bolt
27	91314-06025-00	Bolt
28	90462-10115-00	Clamp
29	93210-15566-00	O-ring
30	91810-17016-00	Pin, Dowel
31	90462-10118-00	Clamp
32	90462-10118-00	Clamp
33	98507-06010-00	Screw, Pan Head
34	91380-06025-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	22U-15512-00-00	Gear, Idler 1
02	5H0-15521-00-00	Shaft 1
03	22U-15580-00-00	Starter Clutch Outer Assy
04	90501-04623-00	• . Spring, Compression
05	341-15583-05-00	• . Cap, Starter Clutch Spring
06	93615-12088-00	• . Pin, Dowel
07	91317-08012-00	Bolt
08	22U-15517-00-00	Gear, Idler 2
09	90201-256K6-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	22U-16111-01-00	Gear, Primary Drive
02	90280-07036-00	Key, Woodruff
03	90214-16026-00	Washer, Claw
04	90215-16222-00	Washer, Lock
05	90170-16311-00	Nut
06	22U-16150-01-00	Primary Driven Gear Comp.
07	22U-16154-00-00	Plate, Thrust 1
08	22U-16371-00-00	Boss, Clutch
09	4X7-16384-00-00	Plate, Seat
10	4X7-16383-01-00	Spring, Clutch Boss
11	4X7-16324-00-00	Plate, Clutch 1
12	4X7-16385-00-00	Ring, Clutch Boss
13	22U-16321-00-00	Plate, Friction
14	4X7-16325-00-00	Plate, Clutch 2
15	22U-16351-00-00	Plate, Pressure 1
16	90501-23738-00	Spring, Compression
17	90159-06016-00	Screw, With Washer
18	1W1-16358-01-00	Plate, Push
19	5Y1-16356-00-00	Rod, Push 1
20	93210-09525-00	O-ring
21	92907-06200-00	Washer
22	95307-06600-00	Nut
23	90215-22244-00	Washer, Lock
24	90170-20310-00	Nut
25	93315-21813-00	Bearing
26	93102-18278-00	Oil Seal
27	22U-16380-00-00	Push Lever Assy
28	90508-16577-00	Spring, Torsion
29	90201-18262-00	Washer, Plate
30	90201-08087-00	Washer, Plate
31	90149-08067-00	Screw
32	22U-16357-00-00	Rod, Push 2
33	93515-32029-00	Ball

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	22U-17411-00-00	Axle, Main (14z)
02	22U-17141-00-00	Gear, 4th Pinion (24z)
03	90209-22191-00	Washer
04	93440-25084-00	Circlip
05	22U-17131-00-00	Gear, 3rd Pinion (24z)
06	11H-17151-01-00	Gear, 5th Pinion (30z)
07	11H-17121-00-00	Gear, 2nd Pinion (20z)
08	93306-30525-00	Bearing (b6305)
09	93306-00401-00	Bearing (b6305)
10	22U-17402-00-00	Drive Axle Assy
11	22U-17221-00-00	Gear, 2nd Wheel (38z)
12	90209-27192-00	Washer
13	93440-30077-00	Circlip
14	11H-17251-00-00	Gear, 5th Wheel (29z)
15	22U-17231-00-00	Gear, 3rd Wheel
16	90209-22191-00	Washer
17	93440-25084-00	Circlip
18	22U-17241-00-00	Gear, 4th Wheel (28z)
19	22U-17211-00-00	Gear, 1st Wheel (38z)
20	93306-00428-00	Bearing


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



22U110-3180


Ref No	Part No	Description
01	22U-Y1754-00-00	Middle Gear Comp.
02	93306-20711-00	Bearing
03	4H7-17537-00-20	Shim, Thrust (0.20t)
03	4H7-17537-00-30	Shim, Thrust (0.30t)
03	4H7-17537-00-40	Shim, Thrust 90.40t))
04	90179-18396-00	Nut
05	22U-17553-01-00	Shaft, Middle Driven
06	4H7-W1752-10-00	Houshing Comp.
07	93210-71360-00	O-ring
08	93101-35097-00	Oil Seal
09	22U-17556-00-00	Yoke, Joint
10	90201-14633-00	Washer, Plate
11	90185-14070-00	Nut, Self-locking
12	22U-17527-00-00	Cam, Driven
13	90501-60716-00	Spring, Compression
14	22U-17524-00-00	Holder
15	3H5-17529-00-00	Washer, Thrust
16	93306-00435-00	Bearing
17	3JB-17531-00-00	Shim, Pinion (0.10t)))
17	3JB-17531-10-00	Shim, Pinion (0.15t)))
17	3JB-17531-20-00	Shim, Pinion (0.20t)
17	3JB-17531-30-00	Shim, Pinion (0.30t)
17	3JB-17531-40-00	Shim, Pinion (0.40t)
17	3JB-17531-50-00	Shim, Pinion (0.50t)
18	95827-08030-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	22U-18540-00-00	Shift Cam Assy
02	93306-90602-00	• . Bearing
03	16G-18185-00-00	• . Segment
04	93604-16092-00	• . Pin, Dowel
05	93604-16092-00	• . Pin, Dowel
06	98701-05035-00	• . Screw, Flat Head
07	90501-06022-00	• . Spring, Compression
08	278-18542-00-00	• . Point, Neutral
09	278-18566-00-00	• . Plate, Side 2
10	98701-05016-00	• . Screw, Flat Head
11	11H-18511-00-00	Fork, Shift 1
12	11H-18512-00-00	Fork, Shift 2
13	11H-18513-00-00	Fork, Shift 3
14	3YF-18531-00-00	Bar, Shift Fork Guide 1
15	22U-18535-00-00	Bar, Shift Fork Guide 2

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	90215-18178-00	Washer, Lock
02	4G0-18127-00-00	Stopper, Screw
03	11H-18140-00-00	Stopper Lever Assy
04	90508-29519-00	Spring, Torsion
05	93102-12106-00	Oil Seal (sd 12-22-5 Hs)
06	22U-18120-01-00	Shift Lever Assy
07	90506-08227-00	Spring, Tension
08	90508-32536-00	Spring, Torsion
09	99006-10600-00	Circlip
10	90201-12588-00	Washer, Plate
11	90201-12575-00	Washer, Plate
12	99006-10600-00	Circlip
13	99006-10600-00	Circlip
14	132-18113-01-00	• . Cover, Shift Pedal
15	2H9-18154-00-00	• . Cover, Dust
16	97024-06020-00	Bolt
17	2GV-18112-00-00	Arm, Shift
18	2GV-18115-00-00	Rod, Shift
19	90170-06228-00	Nut
20	95304-06700-00	Nut
21	90201-124E4-00	Washer, Plate
22	99009-12400-00	Circlip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KU-21110-00-33	Frame Comp.
02	3JB-21105-00-33	Back Stay Sub Comp. 1
03	90105-08177-00	Bolt, Washer Based
04	90201-08326-00	Washer, Plate
05	90109-08718-00	Bolt
06	2GV-21317-00-00	Stay, Engine 3
07	90105-10183-00	Bolt, Washer Based
08	90179-10321-00	Nut
09	90179-10279-00	Nut
10	90201-10131-00	Washer, Plate
11	90201-10437-00	Washer, Plate
12	22U-21315-00-00	Stay, Engine 2
13	22U-21316-00-00	Stay, Engine 3
14	90105-10186-00	Bolt, Washer Based
15	90201-105H3-00	Washer, Plate
16	90387-100E2-00	Collar
17	4X7-21485-00-00	Damper, Rubber 1
18	90149-10238-00	Screw
19	90149-10238-00	Screw
20	4KU-21458-00-00	Bracket, Side Stand
21	90116-12495-00	Bolt, Stud
22	90179-12248-00	Nut
23	2GV-2171E-00-00	Cover, Side 5
24	95307-12800-00	Nut
25	95027-06016-00	Bolt, Flange
26	90105-06069-00	Bolt, Washer Based
27	90202-06010-00	Washer, Plate
28	90338-07043-00	Plug
29	2GV-2139R-00-00	Cover 2
30	97707-60514-00	Screw, Tapping
31	1AA-2143A-00-00	Cap
32	2GV-21359-00-00	Bracket, Coil
33	95807-06012-00	Bolt, Flange
34	3JB-2139R-00-00	Cover 2
35	90480-10334-00	Grommet

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2GV-Y2151-80-MX	Front Fender Comp.
01	2GV-Y2151-70-4B	Front Fender Comp.
01	2GV-Y2151-50-2X	Front Fender Comp. (xv535s Model)
02	4KU-21570-00-00	• . Graphic Set, Front Fender
02	4KU-21570-10-00	• . Graphic Set, Front Fender
02	3JB-21570-50-00	• . Graphic Set, Front Fender
03	95027-08012-00	Bolt, Flange
04	2NT-21597-01-00	Holder,wire 1
05	3JB-21598-00-00	Holder, Wire 2
06	3BR-Y2161-J0-MX	Rear Fender C0mp.
06	3BR-Y2161-H0-4B	Rear Fender C0mp.
06	3BR-Y2161-L0-1X	Rear Fender C0mp. (xv535s Model)
07	99236-00080-00	• . Emblem, Yamaha
07	99235-00080-00	• . Emblem, Yamaha
08	3JB-2165A-50-00	• . Graphic Set,rear Fender
08	4KU-2165A-00-00	• . Graphic Set,rear Fender
08	4KU-2165A-10-00	• . Graphic Set,rear Fender
09	95807-08012-00	Bolt, Flange
10	95807-06010-00	Bolt, Flange
11	2GV-21629-00-MX	Guard, Mud
11	2GV-21629-00-4B	Guard, Mud
11	2GV-21629-00-KM	Guard, Mud
12	90119-06123-00	Bolt, With Washer
13	2GV-2160E-00-00	Box
14	90159-06059-00	Screw, With Washer
15	2GV-2163A-00-00	Cover, Rear Fender 1
16	2GV-2163E-00-00	Cover, Rear Fender 2
17	98904-08014-00	Screw, Bind
18	90560-08326-00	Spacer
19	93210-71360-00	O-ring
20	92990-08200-00	Washer, Plain
21	26H-21308-00-00	Helmet Hanger Assy
22	90149-06154-00	Screw
23	3BR-21621-00-00	Flap
24	4G0-21639-00-00	Damper 2
25	98507-06012-00	Screw, Pan Head
26	92907-06600-00	Washer, Plate
27	90202-05187-00	Washer, Plate
28	92907-06200-00	Washer
29	95307-06600-00	Nut
30	2AE-21641-+0-00	Bracket, Reflector
31	90267-40076-00	Rivet, Blind
32	90201-044A2-00	Washer, Plate
33	449-85131-02-00	Reflector, Rear 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2GV-21711-00-MX	Cover, Side 1
01	2GV-21711-00-4B	Cover, Side 1
01	2GV-21711-00-KM	Cover, Side 1
02	90480-12320-00	Grommet
03	90119-06123-00	Bolt, With Washer
04	2GV-21721-00-MX	Cover, Side 2
04	2GV-21721-00-4B	Cover, Side 2
04	2GV-21721-00-KM	Cover, Side 2
05	2GV-21731-00-93	Cover, Side 3
06	97704-40012-00	Screw, Tapping
07	90183-04027-00	Nut, Spring
08	2GV-2172A-00-00	Panel 1
09	2GV-2172F-00-00	Panel 2
10	2GV-2174E-+0-00	Stay, Side Cover 2
11	95807-06040-00	Bolt, Flange
12	2GV-21171-00-00	Box
13	31A-14477-00-00	Plate
14	90480-22362-00	Grommet
15	90480-22362-00	Grommet
16	90387-07391-00	Collar
17	90201-06059-00	Washer, Plate
18	97007-06025-00	Bolt
19	92907-06100-00	Washer, Spring
20	99237-00080-00	Emblem, Yamaha
20	99235-00080-00	Emblem, Yamaha
21	3JB-2176E-00-00	Plate
22	98507-06035-00	Screw, Pan Head
23	92907-06600-00	Washer, Plate
24	3JB-28185-00-00	Lid

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2GV-22110-00-35	Rear Arm Comp.
02	93320-32403-00	Bearing
03	4X7-22124-00-00	Bush 2
04	4X7-22129-00-00	Cover, Thrust 2
05	90201-244A8-00	Washer, Plate (1.95t)
06	4X7-22141-00-00	Shaft, Pivot
07	90215-16181-00	Washer, Lock
08	22U-22189-00-00	Boot, Rubber
09	97004-08035-00	Bolt
10	92990-08100-00	Washer, Spring
11	2YL-22210-00-00	Shock Absorber Assy, Rear
12	2GV-22216-00-00	• . Bush, Rear Shock Absorber
13	2GV-22253-00-00	• . Collar, Distance
14	2GV-22226-00-00	• . Bush, Shock Absorber Lower
15	2YL-22220-00-00	Shock Absorber Assy, Rear
16	2GV-22226-00-00	• . Bush, Shock Absorber Lower
17	5M0-22253-00-00	• . Collar, Distance
18	95807-08012-00	Bolt, Flange
19	90201-08753-00	Washer, Plate
20	90201-105R9-00	Washer, Plate
21	90176-10073-00	Nut, Crown
22	92990-10100-00	Washer, Spring
23	90106-10052-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	2NT-46101-00-00	Rear Axle Gear Case Assy
02	90116-10593-00	• . Bolt, Stud
03	90119-08126-00	• . Bolt, With Washer
04	22U-46153-00-00	• . Collar, Guide
05	93101-30084-00	• . Oil Seal
06	93311-43729-00	• . Bearing
07	2H7-46122-00-00	• . Race, Inner
08	93317-41510-00	• . Bearing
09	1J7-17537-Y0-30	• . Shim, Thrust (0.30t)
09	1J7-17537-Y0-40	• . Shim, Thrust (0.40t)
09	1J7-17537-Y0-50	• . Shim, Thrust (0.50t)
10	93306-30539-00	• . Bearing
11	4H7-46125-00-00	• . Retainer, Bearing
12	93210-60426-00	• . O-ring
13	93101-38098-00	• . Oil Seal
14	90387-256G9-00	• . Collar
15	90116-10249-00	• . Bolt, Stud
16	22U-46136-00-00	• . Seal 1
17	22U-46152-00-00	• . Housing, Bearing
18	22U-46117-00-25	• . Shim, Ring Gear (0.25t)
18	22U-46117-00-30	• . Shim, Ring Gear (0.30t)
18	22U-46117-00-40	• . Shim, Ring Gear (0.40)
18	22U-46117-00-50	• . Shim, Ring Gear (0.50t)
19	93316-01301-00	• . Bearing
20	22U-46118-00-12	• . Washer, Thrust (1.2t)
20	22U-46118-00-14	• . Washer, Thrust (1.4t)
20	22U-46118-00-16	• . Washer, Thrust (1.6t)
20	22U-46118-00-18	• . Washer, Thrust (1.8t)
20	22U-46118-00-20	• . Washer, Thrust (2.0t)
21	93211-39569-00	• . O-ring
22	90105-10285-00	• . Bolt, Washer Based
23	93102-65277-00	• . Oil Seal
24	11H-13455-00-00	• . Plug
25	214-11198-01-00	• . Gasket
26	2H7-17590-00-00	• . Breather Comp.
27	1J7-25319-01-00	• . Seal, Hub Dust
28	22U-46123-00-00	Coupling, Gear
29	2GV-46172-00-00	Shaft, Drive
30	93440-19112-00	Circlip
31	22U-46137-00-00	Seal 2
32	93410-22039-00	Circlip
33	90501-15722-00	Spring, Compression
34	4X7-46180-00-00	Cross Joint Comp.
35	93399-99926-00	Bearing
36	93440-20088-00	Circlip
37	95314-10600-00	Nut
38	92990-10100-00	Washer, Spring
39	90387-156G8-00	Collar


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4KU8332-5240


Ref No	Part No	Description
01	156-23412-00-00	Race, Ball 2
02	183-23411-00-00	Race, Ball 1
03	183-23412-00-00	Race, Ball 2
04	93501-04011-00	Ball
05	4K0-23415-00-00	Cover, Ball Race 1
06	90179-25033-00	Nut
07	90105-14102-00	Bolt, Washer Based
08	2GV-W2341-00-38	Crown, Handle
09	95024-08024-00	Bolt, Flange
10	3JC-23317-00-00	Holder, Cable
11	2GV-2317F-00-00	Stay 2
12	42X-23442-00-38	Holder, Handle Lower
13	90201-100A1-00	Washer, Plate
14	95607-10100-00	Nut, U
15	4H7-23441-00-38	Holder, Handle Upper
16	91314-08030-00	Bolt
17	90338-08163-00	Plug
18	2GV-23174-00-00	Stay, Headlight
19	437-83936-11-00	Band, Switch Cord
20	2NT-23164-00-00	Stay, Light Guard
21	95027-06020-00	Bolt, Flange
22	2GV-2317M-00-00	Stay 3
23	3WF-2153E-40-00	Emblem, Yamaha
24	95024-06008-00	Bolt, Flange
25	2GV-2317E-00-00	Stay
26	91317-06016-00	Bolt
28	134-23484-10-00	Cap, Handle Lock
29	90269-04003-00	Rivet
30	90208-04029-00	Washer, Conical Spring

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KU-23102-00-00	Front Fork Assy (l.h) (links)
01	4KU-23102-10-00	Front Fork Assy (l.h) (links)
02	3JB-23126-10-00	• . Tube, Outer (left)
03	2GV-23110-00-93	• . Inner Tube Comp.1
04	2GV-23171-+0-10	• . Piston, Front Fork
05	1GU-23157-00-00	• . Ring, Piston
06	1GU-23151-00-00	• . Spring, Rebound
07	1GU-23173-00-00	• . Spindle, Taper
08	2GV-23125-00-00	• . Metal, Slide 1
09	2AJ-23145-00-00	• . Oil Seal
10	1HX-23156-00-00	• . Clip, Oil Seal
11	2GV-23144-00-00	• . Seal, Dust
12	90430-08155-00	• . Gasket
13	91317-08025-00	• . Bolt
14	2GV-23141-00-00	• . Spring, Front Fork
15	1HX-23111-00-00	• . Bolt, Cap
16	93210-24709-00	• . O-ring
17	93450-32116-00	• . Circlip
18	1HX-23154-00-00	• . Plug, Inner Tube
18	3JB-23154-00-00	• . Plug, Inner Tube
19	91314-08035-00	• . Bolt
20	4KU-23103-00-00	Front Fork Assy (r.h) (rechts)
20	4KU-23103-10-00	Front Fork Assy (r.h) (rechts)
21	3JB-23136-10-00	• . Tube, Outer (right)
22	2GV-23110-00-93	• . Inner Tube Comp.1
23	2GV-23171-01-00	• . Piston, Front Fork
24	1GU-23157-00-00	• . Ring, Piston
25	1GU-23151-00-00	• . Spring, Rebound
26	1GU-23173-00-00	• . Spindle, Taper
27	2GV-23125-00-00	• . Metal, Slide 1
28	2AJ-23145-00-00	• . Oil Seal
29	1HX-23156-00-00	• . Clip, Oil Seal
30	2GV-23144-00-00	• . Seal, Dust
31	90430-08155-00	• . Gasket
32	91317-08025-00	• . Bolt
33	2GV-23141-00-00	• . Spring, Front Fork
34	1HX-23111-00-00	• . Bolt, Cap
35	93210-24709-00	• . O-ring
36	93450-32116-00	• . Circlip
37	1HX-23154-00-00	• . Plug, Inner Tube
37	3JB-23154-00-00	• . Plug, Inner Tube
38	3BR-23340-00-00	Under Bracket Comp.
39	164-23462-00-00	• . Seal, Steering
40	156-23411-00-00	• . Race, Ball 1
41	90105-12353-00	Bolt, Washer Based
42	3JB-25886-00-00	Holder, Brake Hose
43	95807-06010-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3BR-Y2428-60-0X	Sub Tank Assy
01	3BR-Y2428-50-4B	Sub Tank Assy
01	3BR-Y2428-90-1X	Sub Tank Assy
02	3JB-24240-51-00	• . Graphic Set
02	4KU-24240-01-00	• . Graphic Set
02	4KU-24240-11-00	• . Graphic Set
03	1FK-24182-00-00	Damper, Locating 2
04	23T-24724-01-00	Damper, Seat
05	1FK-24186-00-00	Washer, Special
06	90387-06387-00	Collar
07	90201-066M2-00	Washer, Plate
08	95024-06025-00	Bolt, Flange
09	3JB-24182-00-00	Damper, Locating 2
10	42X-24183-00-00	Damper, Locating 3
11	90201-08569-00	Washer, Plate
12	97007-08016-00	Bolt
13	4X7-24602-04-00	Cap Assy
14	4X7-24612-00-00	• . Gasket, Cap
15	91317-05010-00	Bolt
16	3JB-24316-00-00	Pipe 6
17	90450-25037-00	Hose Clamp Assy
18	3JB-24317-00-00	Pipe 7
19	90501-101J4-00	Spring, Compression
20	90450-22017-00	Hose Clamp Assy
21	3JB-24135-00-00	Clamp 1
22	3JB-24110-01-33	Fuel Tank Comp.
23	2GV-24181-00-00	Damper, Locating 1
24	1FK-24182-00-00	Damper, Locating 2
25	23T-24724-01-00	Damper, Seat
26	1FK-24186-00-00	Washer, Special
27	90387-06387-00	Collar
28	90201-065G8-00	Washer, Plate
29	97027-06030-00	Bolt
30	92907-06100-00	Washer, Spring
31	2GV-24184-00-00	Damper, Locating 4
32	1FK-24560-00-00	Filter Assy
33	1FK-24566-00-00	Bracket, Filter
34	2GV-24311-00-00	Pipe, Fuel 1
35	2GV-24312-00-00	Pipe 2
36	90467-10135-00	Clip
37	90467-10135-00	Clip
38	2GV-24491-00-00	Bracket, Fuel Pump
39	90387-062L2-00	Collar
40	95807-06016-00	Bolt, Flange
41	90480-13163-00	Grommet
42	98507-05016-00	Screw, Pan Head
43	2GV-24191-00-00	Bracket, Fuel Tank 1
44	90119-06123-00	Bolt, With Washer
45	437-83936-11-00	Band, Switch Cord
46	3JB-24500-02-00	Fuel Cock Assy 1
47	3AJ-24534-00-00	Seal, Cock
48	3AJ-24534-00-00	Seal, Cock
49	98503-03008-00	Screw, Pan Head
50	4X8-24512-00-00	Gasket
51	90149-06008-00	Screw

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
52	90202-05193-00	Washer, Plate
53	90480-14023-00	Grommet
54	90387-06388-00	Collar
55	95807-06025-00	Bolt, Flange
56	3JB-24314-00-00	Pipe 4
57	90467-10008-00	Clip
58	90467-11044-00	Clip
59	3JB-24161-10-00	Emblem 1
60	3JB-24162-10-00	Emblem 2
61	90501-100F8-00	Spring, Compression
62	1HX-13907-00-00	Fuel Pump Comp.

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3JB-24710-00-00	Single Seat Assy
01	3JB-24710-10-00	Single Seat Assy
02	3JB-24711-00-00	• . Cover, Single Seat
02	3JB-24711-10-00	• . Cover, Single Seat
03	18A-24724-00-00	• . Damper, Seat
04	95817-06012-00	Bolt, Flange
05	3JB-24750-00-00	Tandem Seat Assy
05	3JB-24750-10-00	Tandem Seat Assy
06	3JB-24751-00-00	• . Cover, Tandem Seat
06	3JB-24751-10-00	• . Cover, Tandem Seat
07	3JB-24754-00-00	• . Hook, Seat
08	90201-06067-00	• . Washer, Plate
09	95707-06500-00	• . Nut, Flange
10	3JB-24718-00-00	• . Bracket, Seat
11	3JB-24728-00-00	• . Bracket, Seat
12	3JB-24776-00-00	• . Lever, Seat
13	3JB-2478F-00-00	• . Rod, Connecting
14	92907-03200-00	• . Washer
15	18A-24724-00-00	• . Damper, Seat
16	51X-24705-00-00	Seat Lock Assy
17	97007-06014-00	Bolt
18	92907-06100-00	Washer, Spring
19	51Y-24796-00-00	Cover
20	2GV-28100-00-00	Tool Kit

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KU-25111-00-00	Hub, Front
02	93105-45017-00	Oil Seal
03	93306-30309-00	Bearing
04	93306-30309-00	Bearing
05	93102-28022-00	Oil Seal
06	90560-17126-00	Spacer
07	341-25149-00-00	Clutch, Meter
08	341-25846-00-00	Retainer, Clutch
09	156-25398-00-00	Balancer, Wheel
10	94418-19531-00	Rim (1.85-19)
11	3JB-25104-00-00	Spoke Set, Front
12	94130-197N1-00	Tire (3.00-19)
12	94130-197N0-00	Tire (3.00-19)
13	94227-19177-00	Tube (2.75-19)
14	94335-19026-00	Band, Rim (3.50-19)
15	1FK-25190-00-00	Gear Unit Assy
16	90387-177R1-00	Collar
17	2GV-25181-00-00	Axle, Wheel

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3JB-2582U-00-00	Disc, Brake (right)
02	90109-081F0-00	Bolt
03	3JB-2580U-10-00	Caliper Assy (right)
04	3JB-W0057-00-00	• . Piston Assy, Caliper
05	3JB-W0047-00-00	•• .. Caliper Seal Kit
06	5R2-25937-00-00	• . Boot 2
07	3YX-25937-00-00	• . Boot 2
08	4BP-W0045-00-00	• . Brake Pad Kit
09	3YX-25919-00-00	• . Support, Pad
10	3YX-25929-00-00	• . Spring, Anti Rattle
11	51L-W0048-00-00	• . Bleed Screw Kit
12	90105-10638-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	2GV-25311-00-35	Hub, Rear
02	2GV-25317-00-00	Spacer, Bearing
03	146-25115-00-00	Flange, Spacer 1
04	93306-30209-00	Bearing
05	93306-30202-00	Bearing (b63027)
06	2GV-25366-00-00	Clutch, Hub
07	90105-10200-00	Bolt, Washer Based
08	2GV-25319-00-00	Seal, Hub Dust
09	98507-05012-00	Screw, Pan Head
10	92907-05100-00	Washer, Spring
11	92907-05600-00	Washer, Plate
12	2NT-25321-00-00	Plate, Brake Shoe
13	3DR-W2536-00-00	Brake Shoe Set
14	90507-20002-00	Spring, Tension
15	4H7-25351-00-00	Camshaft
16	214-25351-00-00	Camshaft
17	90201-14218-00	Washer, Plate
18	4H7-2533A-02-00	Plate, Indicator
19	90101-06764-00	Bolt
20	94430-15477-00	Rim
21	2GV-25304-00-00	Spoke Set, Rear
22	94114-156U2-00	Tire (140/90-15m/c70sk425)
22	94114-156U1-00	Tire (140/90-15m/c7sk425)
23	94214-15223-00	Tube (3.00-15)
24	94330-15134-00	Band, Rim (3.00-15)
25	156-25398-00-00	Balancer, Wheel
26	2GV-25381-00-00	Axle, Wheel
27	90387-157R0-00	Collar
28	90201-146R0-00	Washer, Plate
29	90171-14029-00	Nut, Castle
30	90171-14029-00	Nut, Castle
31	4E7-25188-00-00	Cap
32	22U-25377-00-00	Collar, Wheel
33	42X-25371-00-00	Bar, Tension
34	90109-08406-00	Bolt
35	92990-08600-00	Washer, Plate
36	92990-08100-00	Washer, Spring
37	95304-08700-00	Nut
38	91401-20015-00	Pin, Cotter
39	90109-08368-00	Bolt


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4KU8332-5310

Ref No	Part No	Description
01	2GV-26111-10-00	Handlebar
02	3JB-26241-00-00	Grip (left)
03	3JB-26273-00-00	Rotor
04	3JB-26240-00-00	Grip Assy
05	3JC-26311-00-00	Cable, Throttle 1
06	5H0-26393-00-00	Holder
07	98507-05008-00	Screw, Pan Head
08	3JC-26312-00-00	Cable, Throttle 2
09	3JB-26335-20-00	Cable, Clutch
10	95304-08700-00	Nut
11	3JB-2628J-00-00	Cap, Grip
12	90179-08148-00	Nut
13	90123-08046-00	Bolt
14	1J7-26290-F0-00	Rear View Mirror Assy(right)
15	1J7-26290-G0-00	Rear View Mirror Assy(right)


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



3JCG100-5330


Ref No	Part No	Description
01	4H7-25850-02-00	Master Cylinder Assy
02	4H7-W0041-00-00	• . Cylinder Kit, Master
03	4L0-25854-00-00	• . Diaphragm, Reservoir
04	4H7-25852-00-00	• . Cap, Reservoir
05	98707-04012-00	• . Screw, Flat Head
06	4L0-25867-00-00	• . Bracket, Master Cylinder
07	4KU-25872-00-00	Hose, Brake 1
07	3JB-25872-40-00	Hose, Brake 1
08	90401-10159-00	Bolt, Union
09	90201-10118-00	Washer, Plate
10	97007-06025-00	Bolt
11	92907-06100-00	Washer, Spring

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2GV-27211-00-93	Pedal, Brake
02	90201-152L1-00	Washer, Plate
03	99009-15400-00	Circlip
04	90101-06288-00	Bolt
05	95307-06600-00	Nut
06	90506-20380-00	Spring, Tension
07	2GV-26351-00-00	Cable, Brake
08	91701-06022-00	Pin, Clevis
09	92907-06200-00	Washer
10	91401-20015-00	Pin, Cotter
11	90501-10245-00	Spring, Compression
12	90249-12008-00	Pin
13	90179-06411-00	Nut
14	1RM-27410-00-93	Front Footrest Assy (left)
15	1NH-27413-00-00	• . Cover, Footrest
16	95607-06100-00	• . Nut, U
17	90508-18696-00	• . Spring, Torsion
18	91701-08038-00	• . Pin, Clevis
19	91401-25015-00	• . Pin, Cotter
20	90387-087K5-00	• . Collar
21	1RM-27420-00-93	• . Front Footrest Assy (right)
22	1NH-27413-00-00	• . Cover, Footrest
23	95607-06100-00	• . Nut, U
24	90508-18696-00	• . Spring, Torsion
25	91701-08038-00	• . Pin, Clevis
26	91401-25015-00	• . Pin, Cotter
27	90387-087K5-00	• . Collar
28	4X7-27414-00-00	Damper, Footrest
29	90387-107A7-00	Collar
30	90201-100A1-00	Washer, Plate
31	2GV-27491-00-00	Protector
32	90109-100G0-00	Bolt
33	2GV-27471-00-00	Bar, Footrest 1
34	2GV-27472-00-00	Bar, Footrest 2
35	90465-13169-00	Clamp
36	90338-09161-00	Plug
37	90105-10312-00	Bolt, Washer Based
38	95704-10500-00	Nut, Flange
39	2NT-27430-01-00	Rear Footrest Assy 1
40	1NH-27433-00-00	• . Cover, Rear Footrest
41	92016-06012-00	• . Bolt, Button Head
42	2NT-27437-00-00	• . Washer, Special
43	91701-06032-00	• . Pin, Clevis
44	91401-20015-00	• . Pin, Cotter
45	90501-12743-00	• . Spring, Compression
46	93501-04011-00	• . Ball
47	2NT-27440-01-00	Rear Footrest Assy 2
48	1NH-27433-00-00	• . Cover, Rear Footrest
49	92016-06012-00	• . Bolt, Button Head
50	2NT-27437-00-00	• . Washer, Special
51	91701-06032-00	• . Pin, Clevis
52	91401-20015-00	• . Pin, Cotter
53	90501-12743-00	• . Spring, Compression
54	93501-04011-00	• . Ball
55	95804-10016-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
56	4KU-27311-00-00	Stand, Side
57	90105-10188-00	Bolt, Washer Based
58	95617-10100-00	Nut, U
59	90387-1003G-00	Collar
60	92907-10200-00	Washer, Plain
61	5HO-27315-00-00	Link, Side Stand
62	90506-29491-00	Spring, Tension
63	90506-23439-00	Spring, Tension

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3BT-81450-00-00	Rotor Assy
02	2GV-81410-20-00	Stator Assy
03	98507-06025-00	Screw, Pan Head
04	92907-06100-00	Washer, Spring
05	90201-107K6-00	Washer, Plate
06	90105-10152-00	Bolt, Washer Based
07	3BT-81670-00-00	Pick-up Assy
08	98507-06020-00	Screw, Pan Head
09	92907-06100-00	Washer, Spring

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3JB-81800-00-00	Starting Motor Assy
02	26H-81847-00-00	• . O-ring
03	3HE-81826-00-00	• . Bolt
04	3KS-81840-00-00	• . Brush Holder Assy
05	11H-81844-00-00	• . Gasket
06	97027-06025-00	• . Bolt
07	92907-06600-00	• . Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LS-83311-00-00	Bulb, Flasher
02	1KT-83311-00-00	• . Bulb, Flasher (12v-21w)
03	42X-83312-00-00	• . Lens, Flasher
04	42X-83313-00-00	• . Gasket, Flasher Lens
05	42X-83363-+7-00	• . Lens, Rim
06	341-83333-70-00	• . Screw, Lens Fitting
07	42X-83359-00-00	• . Washer, Special
08	1AA-83318-00-00	Stay, Flasher 1
09	95307-12600-00	Nut
10	97004-06030-00	Bolt
11	95704-06500-00	Nut, Flange
12	2EN-83330-00-00	Rear Flasher Light Assy 1
13	1KT-83311-00-00	• . Bulb, Flasher
14	2AE-83312-00-00	• . Lens, Flasher
15	42X-83313-00-00	• . Gasket, Flasher Lens
16	42X-83363-00-00	• . Lens, Rim
17	341-83333-70-00	• . Screw, Lens Fitting
18	42X-83359-00-00	• . Washer, Special
19	1AA-83318-00-00	Stay, Flasher 1
20	18G-83365-00-00	Cap
21	95307-12600-00	Nut
22	97004-06030-00	Bolt
23	95704-06500-00	Nut, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	1FK-83507-00-00	Cover, Speedometer
02	2GV-83519-00-00	Bracket, Meter
03	2JV-8351A-F0-00	Meter Assy
03	3JB-8351A-10-00	Meter Assy
04	12R-83513-00-00	Damper
05	90201-05031-00	Washer, Plate
06	95307-05600-00	Nut
07	90164-04009-00	Screw, Tapping
08	2GV-83509-00-00	Socket Cord Assy
09	42X-83517-00-00	Bulb (12v-3w)
10	34L-83550-01-00	Speedometer Cable Assy
11	3BT-83530-10-00	Pilot Light Assy
12	42X-83517-00-00	• . Bulb (12v-3w)
13	2GV-83517-00-00	• . Bulb (12v-1.7w)
14	90164-03010-00	Screw, Tapping
15	98507-04025-00	Screw, Pan Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.






3BT3300-9400


Ref No	Part No	Description
01	42X-84315-01-00	Rim, Headlight
02	5Y3-84395-00-00	Ring, Retaining
03	2AE-84320-G0-00	Lens Assy
04	2F9-84314-00-00	Bulb, Headlight (12v-60/55w)
05	2F9-84375-00-00	Fitting Plate, Bulb
06	2F9-84397-00-00	Cover, Socket
07	20X-84331-00-00	Screw, Rim Adjusting
08	1A0-84332-60-00	Spring, Screw
09	198-84334-60-00	Nut, Adjusting
10	42X-84124-60-00	Spring, Set
11	4E2-84347-00-00	Bulb (12w-4w)
12	34L-84346-00-00	Socket, Pilot Light
13	42X-84330-01-00	Body Assy
14	42X-84345-00-00	• . Damper, Headlight
15	42X-84366-00-00	• . Damper, Headlight 1
16	42X-84338-00-00	• . Collar, Body Fitting
17	90157-05084-00	Screw, Pan Head
18	90201-06073-00	Washer, Plate
19	97007-06016-00	Bolt
20	92907-06100-00	Washer, Spring
21	95027-08040-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2YL-84700-E0-00	Taillight Assy
02	31L-84714-00-00	• . Bulb (12v-21/5w)
03	2AE-84721-00-00	• . Lens, Taillight
04	42X-84723-01-00	• . Gasket, Tail Lens
05	1RM-84704-00-00	• . Gasket, Taillight
06	97780-40525-00	• . Screw, Tapping
07	2GV-84717-00-00	• . Cord, Taillight
08	90119-06097-00	Bolt, With Washer
09	90387-06026-00	Collar
10	90480-14229-00	Grommet
11	90480-16501-00	Grommet
12	90480-01502-00	Grommet
13	2YL-84751-00-00	Bracket, License
14	95807-06016-00	Bolt, Flange
15	92907-06200-00	Washer
16	95307-06600-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	10M-82911-00-00	Holder, Lever 1
03	2GV-82917-00-00	Switch
04	90109-06799-00	Bolt
05	95607-06100-00	Nut, U
06	93210-11368-00	O-ring
07	97007-06025-00	Bolt
08	92907-06100-00	Washer, Spring
09	2W1-83922-00-00	Lever 2
10	90149-06153-00	Screw
11	90170-06010-00	Nut
12	90501-10312-00	Spring, Compression
13	90109-06577-00	Bolt
14	95607-06100-00	Nut, U
15	2YL-83972-00-00	Switch, Handle 4
16	98507-05035-00	• . Screw, Pan Head
17	3LP-83972-00-00	Switch, Handle 4
18	98506-05040-00	• . Screw, Pan Head
19	98506-05045-00	• . Screw, Pan Head
20	437-83936-01-00	Band, Switch Cord

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	42X-81960-A1-00	Rectifier & Regulator Assy
02	3JB-81975-00-00	Plate, Rectifier Fitting
03	3LR-83364-00-00	Wire, Earth Lead 2
04	98507-06016-00	Screw, Pan Head
05	92907-06600-00	Washer, Plate
06	95304-06800-00	Nut, Crown
07	95807-06012-00	Bolt, Flange
08	25G-81950-01-00	Relay Assy
09	3AY-81940-00-00	Starter Relay Assy
10	95707-06500-00	Nut, Flange
11	4H7-81980-M0-00	Diode Assy
12	1VJ-82110-60-00	Battery Assy (gm12ax-3a-2)
13	90445-08248-00	Hose
14	120-82131-00-00	Band, Battery
15	2GV-82115-00-00	Wire, Plus Lead
16	2GV-82116-00-00	Wire, Minus Lead
17	3BM-82510-00-00	Main Switch Assy
18	92017-08016-00	Bolt, Button Head
19	2GV-82530-10-00	Stop Switch Assy
20	3BT-82590-25-00	Wire Harness Assy
21	36Y-82151-00-00	• . Fuse (15a-bl)
22	1AE-82151-00-00	• . Fuse (30a-bl)
23	98507-06010-00	Screw, Pan Head
24	92907-06600-00	Washer, Plate
25	3LD-82566-70-00	Switch, Side Stand
26	12R-82591-00-00	Band
27	90157-05079-00	Screw, Pan Head
28	1A0-83980-30-00	Front Stop Switch Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	2GV-82310-30-00	Ignition Coil Assy
02	98507-05016-00	Screw, Pan Head
03	92907-05100-00	Washer, Spring
04	92907-05600-00	Washer, Plate
05	2GV-82320-30-00	Ignition Coil Assy
06	98507-05016-00	Screw, Pan Head
07	92907-05100-00	Washer, Spring
08	92907-05600-00	Washer, Plate
09	2GV-82370-00-00	Plug Cap Assy
10	1L9-82540-00-00	Neutral Switch Assy
11	93210-29196-00	O-ring
12	98707-05012-00	Screw, Flat Head
13	2JX-82541-00-00	Wire, Lead
14	3BT-82305-00-00	Ignitor Unit Assy
15	98507-06020-00	Screw, Pan Head
16	92907-06100-00	Washer, Spring
17	92907-06600-00	Washer, Plate
18	47G-83350-41-00	Flasher Relay Assy
19	35J-83371-30-00	Horn
19	3JB-83371-00-00	Horn
20	95827-06010-00	Bolt, Flange
21	3BT-83790-00-00	Heater Assy
22	3BT-82103-00-00	Terminal 1
23	90201-081K4-00	Washer, Plate
24	3UH-14146-00-00	Plate
25	3BT-82560-00-00	Thermo Switch Assy
26	3JC-82509-00-00	Wire, Sub Lead
27	437-83936-01-00	Band, Switch Cord

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.