YAMAHA


GENUINE

PARTS CATALOGUE

MOTORCYCLE

A1

CYLINDER HEAD




34K100-3010

Ref. No.	Part Number	Description	Qty	Remarks
1	34K-11101-03-00	CYLINDER HEAD ASSEMBLY .	1	
2	4H7-11133-10-00	. GUIDE, INTAKE VALVE	4	
3	93440-12052-00	. CIRCLIP	4	
4	90116-06475-00	. BOLT, STUD	4	
5	90116-10387-00	. BOLT, STUD	2	
6	99510-10114-00	. PIN, DOWEL	2	
7	90340-14079-00	PLUG, STRAIGHT SCRW	1	
8	93210-14369-00	O-RING	1	
9	583-11127-00-00	ABSORBER 3	2	
10	NGK-DP7EA-90-00	NGKDP7EA910PK (94701-00263)	1	
11	91316-06125-00	BOLT	2	
12	91316-06025-00	BOLT	4	
13	91316-06040-00	BOLT, SOCKET HEAD	3	
14	91316-06055-00	BOLT, SOCKET HEAD	7	
15	91316-06050-00	BOLT, SOCKET HEAD	1	
16	92906-06600-00	WASHER	2	
17	1H2-11186-00-00	PLUG, VIEWER	2	
18	93210-32172-00	O-RING	2	
19	5Y1-11187-00-00	COVER, CYLINDER HEAD SIDE 3	1	
20	93210-62446-00	O-RING	1	
21	91316-06018-00	BOLT, SOCKET HEAD	2	
22	34K-12215-01-00	CAP, TENSIONER CASE	1	
23	93210-19522-00	O-RING	1	
24	91316-06020-00	BOLT, SOCKET HEAD	1	
25	5Y1-12288-00-00	CAM, DCOMP	1	
26	90508-18551-00	SPRING, TORSION	1	
27	90109-06418-00	BOLT	1	

CONTINUED ON NEXT FRAME ➤


CYLINDER HEAD



34K100-3010

Ref. No.	Part Number	Description	Qty	Remarks
28	90430-06014-00	GASKET	1	
29	93102-12321-00	OIL SEAL, SD-TYPE	1	
30	5Y1-12292-00-00	CABLE, DCOMP	1	


CYLINDER



34K100-3020

Ref. No.	Part Number	Description	Qty	Remarks
1	99999-01957-00	CYLINDER ASSEMBLY	1	
2	34K-11312-09-00	. SLEEVE, CYLINDER	1	
3	93210-97524-00	O-RING	1	
4	583-11127-00-00	ABSORBER 3	2	
5	1VJ-11351-00-00	GASKET, CYLINDER	1	
6	90201-080L8-00	WASHER, PLATE	2	
7	90176-08026-00	NUT, CROWN	2	
8	90201-10590-00	WASHER, PLATE	2	
9	90179-10201-00	NUT	2	
10	90201-10124-00	WASHER, PLATE	2	
11	90179-10279-00	NUT	2	
12	90110-06138-00	BOLT, HEX SKT HEAD	2	
13	1JK-11181-02-00	GASKET, CYLINDER HEAD	1	
14	91810-05018-00	PIN, DOWEL	2	
15	90105-08464-00	BOLT, WASHER BASED	2	
16	90105-08465-00	BOLT, WASHER BASED	2	
17	90201-080L7-00	WASHER, PLATE	4	
18	90430-08178-00	GASKET	1	
19	99510-08016-00	PIN, DOWEL	1	

CRANKSHAFT-PISTON




43F300-4030

Ref. No.	Part Number	Description	Qty	Remarks
1	34K-11400-00-00	CRANKSHAFT ASSEMBLY ...	1	
2	34K-W1141-00-00	. CRANK 1	1	
3	34K-11422-00-00	. CRANK 2	1	
4	34K-11681-00-00	. PIN, CRANK 1	1	
5	93310-634K2-00	. BEARING, CYLINDER.# 0 ...	1	
6	90209-34254-00	. WASHER, SPEC''L SHAP ...	2	
7	34K-11651-00-00	. ROD, CONNECTING	1	
8	90280-16053-00	KEY, WOODRUFF	1	
9	90201-140A6-00	WASHER, PLATE	1	
10	90179-14317-00	NUT, SPEC''L SHAPE	1	
11	93306-30702-00	BEARING (B6307)	1	
12	34K-11631-02-Y0	PISTON (STD)	1	
13	34K-11610-01-00	PISTON RING SET	1	
14	34K-11633-01-00	PIN, PISTON	1	
15	93450-24028-00	CIRCLIP	2	
16	90201-301F4-00	WASHER, PLATE	1	
17	34K-11565-02-00	WASHER, BEARING COVER ..	2	
18	5Y1-11496-01-00	BOSS, BUFFER	1	
19	90501-22721-00	SPRING, COMPRESSION	8	
20	93605-10090-00	PIN, DOWEL	4	
21	2JT-11536-00-00	GEAR, DRIVE	1	
22	5Y1-11531-00-00	GEAR, BALANCE WT 44T	1	
23	34K-11454-00-00	WEIGHT 1	1	
24	93306-30525-00	BEARING (B6305)	1	
25	93306-30541-00	BEARING	1	
26	93101-25106-00	OIL SEAL	1	
27	90282-05065-00	KEY, STRAIGHT	1	
28	34K-11145-00-00	PLATE, BREATHER 2	1	
29	90170-16343-00	NUT	1	

CONTINUED ON NEXT FRAME ➤


CRANKSHAFT-PISTON



43F300-4030


Ref. No.	Part Number	Description	Qty	Remarks
30	90215-16242-00	WASHER, LOCK	1	

CAMSHAFT-CHAIN




Ref. No.	Part Number	Description	Qty	Remarks
1	34K-12171-00-00	CAMSHAFT ASSEMBLY 1 (34K-12170-00)	1	
2	34K-12176-00-00	SPROCKET, CAM CHAIN	1	
3	90105-07087-00	BOLT, WASHER BASED	2	
4	94590-27126-00	CHAIN	1	
5	34K-12231-00-00	GUIDE, STOPPER 1	1	
6	34K-12241-00-00	GUIDE, STOPPER 2	1	
7	97011-06016-00	BOLT	2	
8	90201-061A5-00	WASHER, PLATE	2	
9	34K-12210-00-00	TENSNR ASSEMBLY, CAM CHN	1	
10	91316-06025-00	BOLT	2	
11	4DW-12213-00-00	GASKET, TENSIONER CASE	1	
12	1JK-12283-00-00	BRACKET, DCOMP (5Y1-12283-00)	1	

VALVE



Ref. No.	Part Number	Description	Qty	Remarks
1	5Y1-12111-00-00	VALVE, INTAKE	2	
2	34K-12121-00-00	VALVE, EXHAUST	2	
3	5Y1-12113-00-00	SPRING, VALVE INNER	4	
4	5Y1-12114-00-00	SPRING, VALVE OUTER	4	
5	4H7-12116-00-00	SEAT, VALVE SPRING	4	
6	1J7-12119-01-00	SEAL, VALVE STEM	4	
7	2F3-12117-00-00	RETAINER, VALVE SPRING	4	
8	1J7-12118-00-00	COTTER, VALVE	8	
9	34K-12151-00-00	ARM, VALVE ROCKER	1	
10	34K-12161-00-00	ARM, VALVE ROCKER 2	1	
11	34K-12162-00-00	ARM, VALVE ROCKER 3	1	
12	34K-12163-00-00	ARM, VALVE ROCKER 4	1	
13	2NX-12146-00-00	SHAFT, ROCKER	1	
14	5Y1-12156-00-00	SHAFT, ROCKER	1	
15	5Y1-12166-00-00	SHAFT, ROCKER 3	1	
16	93210-08521-00	O-RING	2	
17	90110-06138-00	BOLT, HEX SKT HEAD	2	
18	3Y1-12159-00-00	SCREW, VALVE ADJUSTING	4	
19	90170-06128-00	NUT	4	
20	90206-12074-00	WASHER, WAVE	4	

OIL PUMP




36A700-4060

Ref. No.	Part Number	Description	Qty	Remarks
1	99999-01858-00	OIL PUMP KIT (3AJ)	1	
2	93210-13361-00	O-RING	2	
3	91316-06035-00	BOLT	3	
4	99999-01925-00	OIL PUMP GEAR KIT	1	
5	99009-11400-00	CIRCLIP	1	
6	5Y1-W1343-00-00	STRAINER COMP.	1	
7	4DW-13415-00-00	SEAL, OIL STRAINER	1	
8	98503-06014-00	SCREW, PAN HEAD (92502-06016)	2	
9	5Y1-15427-01-00	COVER, CAP 2	1	
10	98503-06014-00	SCREW, PAN HEAD (92502-06016)	1	
11	3VD-13455-00-00	PLUG	1	
12	214-11198-01-00	GASKET	1	
13	4X7-13440-90-00	ELMNT ASSEMBLY, OIL CLNR	1	
14	583-13447-01-00	COVER, OIL ELEMENT	1	
15	93210-64297-00	O-RING	1	
16	93210-07135-00	O-RING	1	
17	90109-06419-00	BOLT	1	
18	91316-06080-00	BOLT	2	
19	90149-05110-00	SCREW	1	
20	90430-05126-00	GASKET	1	
21	583-13113-00-00	SEAT, CHECK BALL	1	
22	93503-08007-00	BALL	1	
23	90501-043E0-00	SPRING, COMPRESSION	1	
24	34K-13464-00-00	HOSE, OIL 1	1	
25	93210-10197-00	O-RING	1	
26	91316-06016-00	BOLT, SOCKET HEAD	2	
27	34K-13465-00-00	HOSE, OIL 2	1	

CONTINUED ON NEXT FRAME ➤


OIL PUMP



36A700-4060

Ref. No.	Part Number	Description	Qty	Remarks
28	90464-20064-00	CLAMP	1	
29	93210-15171-00	O-RING	1	
30	91316-06016-00	BOLT, SOCKET HEAD	2	
31	5Y1-13371-00-00	PLATE	1	

AIR FILTER




55U110-5070

Ref. No.	Part Number	Description	Qty	Remarks
1	43F-13586-01-00	JOINT, CARBURETOR 1	1	
2	43F-13596-01-00	JOINT, CARBURETOR 2	1	
3	93210-36549-00	O-RING	2	
4	16G-13569-00-00	PLUG, BLIND	1	
5	90467-10039-00	CLIP	1	
6	91316-06020-00	BOLT, SOCKET HEAD	4	
7	90460-46206-00	CLAMP, hose	2	
8	34K-14401-01-00	AIR CLNR CASE ASSEMBLYASSY	1	
9	34K-14451-01-00	ELEMENT, AIR CLNR	1	
10	34K-14458-02-00	GUIDE, ELEMENT	1	
11	34K-14473-02-00	GUIDE, ELEMENT	1	
12	43F-14453-00-00	JOINT, AIR CLNR 1	1	
13	43F-14454-00-00	JOINT	1	
14	34K-14412-01-00	CAP, CLEANER CASE 1	1	
15	90480-13398-00	GROMMET	1	
16	34K-21621-01-00	FLAP	1	
17	34K-14426-00-00	DAMPER 2	1	
18	26A-14436-00-00	HOOK	1	
19	34K-14484-00-00	PLATE, CLNR CS FTNGFITTING	2	
20	90267-40073-00	RIVET, BLIND	6	
21	92990-04200-00	WASHER, PLAIN	4	
22	34K-14493-01-00	STAY 1	1	
23	90122-05010-00	BOLT, WING	1	
24	1W4-14457-00-00	SEAL	1	
25	90467-20030-00	CLIP	1	
26	51Y-14462-00-00	SEAL	1	
27	90201-047A2-00	WASHER, PLATE	7	
28	92990-04200-00	WASHER, PLAIN	7	

CONTINUED ON NEXT FRAME ➤


AIR FILTER



55U110-5070

Ref. No.	Part Number	Description	Qty	Remarks
29	34K-14455-00-00	BAND	1	
30	90267-40073-00	RIVET, BLIND	7	
31	90460-51059-00	CLAMP, HOSE	2	
32	95811-06012-00	BOLT, FLANGE	3	
33	98586-05016-00	SCREW, PAN HEAD	6	
34	92906-05600-00	WASHER, PLATE	6	

CARBURETOR




34K100-3080

Ref. No.	Part Number	Description	Qty	Remarks
1	55U-14301-01-00	CARBURETOR ASSEMBLY 1 .	1	
2	5Y1-14198-00-00	. GASKET	1	
3	98503-04014-00	. SCREW, PAN HEAD	6	
4	92901-04100-00	. WASHER, SPRING	6	
5	5Y3-14341-00-00	. NOZZLE, MAIN	1	
6	360-24512-00-00	. GASKET	2	
7	288-14343-68-00	. JET, MAIN #1 6	1	
8	43F-14342-24-00	. JET, PILOT (# 48)	1	
9	5Y1-14385-00-00	. FLOAT	1	
10	1JK-14107-01-00	. NEEDLE VALVE SET	1	
11	5Y1-14357-00-00	. WASHER, PLAIN	1	
12	6E5-14386-01-00	. PIN, FLOAT	1	
13	55U-1490J-10-00	. NEEDLE SET	1	
14	(34K-14312-55-00)	VALVE, THROTTLE 1	1	
15	5Y1-14203-00-00	. CABLE CONNECT SET	1	
16	50M-14105-00-00	. PILOT SCREW SET (43F-14105-00)	1	
17	5Y1-14384-00-00	. GASKET, FLOAT CHAMBER .	1	
18	98580-04010-00	. SCREW, PAN HEAD	2	
19	34K-14103-00-00	. THROTTLE SCREW SET	1	
20	98580-05010-00	. SCREW, PAN HEAD	6	
21	5Y1-14286-00-00	. SPRING	1	
22	43F-1490J-01-00	. NEEDLE SET	1	
23	5Y1-14398-00-00	. GASKET	1	
24	5Y1-14355-00-00	. NOZZLE, MAIN	1	
25	5Y1-14115-00-00	. PLUG, SCREW	1	
26	5Y1-14397-00-00	. O-RING	1	
27	5Y1-14396-00-00	. PIPE	1	
28	5Y1-14349-00-00	. PIPE	1	

CONTINUED ON NEXT FRAME ➤


CARBURETOR



34K100-3080

Ref. No.	Part Number	Description	Qty	Remarks
29	5Y1-14536-00-00	. GASKET	1	
30	5Y1-14197-00-00	. PIPE, AIRVENT	1	
31	5Y1-14131-00-00	. SPRING, THRTL VALVE	1	
32	34K-14305-00-00	. THROTTLE LVR COMP	1	
33	5Y1-14356-00-00	. WASHER, SPRING	1	
34	5Y1-14358-00-00	. NUT	1	
35	34K-1490K-00-00	. STOP SCREW SET	1	
36	5Y1-14343-68-00	. JET, MAIN #1 6	1	
37	98901-04006-00	. SCREW, BIND	1	
38	98580-04020-00	. SCREW, PAN HEAD	2	
39	5Y1-14572-00-00	. PLATE, STAY	2	
40	5Y1-1490A-00-00	. DIAPHRAGM SET, 1	1	
41	98580-04010-00	. SCREW, PAN HEAD	2	
42	5Y1-14293-01-00	. COVER 1	1	
43	5Y1-14556-00-00	. SPRING	1	
44	5Y1-14148-00-00	. PIPE	1	
45	5Y1-14137-00-00	. CLIP	2	
46	5Y1-14149-00-00	. PIPE	1	
47	5Y1-14159-00-00	. CLIP	2	
48	34K-14370-00-00	. PLUNGER, STARTERASSEMBLY	1	


EXHAUST



34K100-3080


Ref. No.	Part Number	Description	Qty	Remarks
1	34K-14611-01-00	PIPE, EXHAUST 1	1	
2	34K-14711-02-00	MUFFLER L	1	
3	34K-14752-00-00	PIPE, OUTLET	1	
4	54G-14628-01-00	PROTC, EXHAUST PIPEEXHAUST PIPE	1	
5	90164-06017-00	SCREW, TAPPING	2	
6	30X-14766-00-00	WASHER, PROTECTOR	4	
7	90206-06090-00	WASHER, WAVE	2	
8	98580-06008-00	SCREW, PAN HEAD	1	
9	92995-06100-00	WASHER, SPRING	1	
10	3YF-14755-00-00	GASKET, SILENCER	1	
11	95816-08045-00	BOLT, FLANGE	1	
12	3YF-14613-01-00	GASKET, EXHAUST PIPE	2	
13	90179-06499-00	NUT	4	
14	95811-08012-00	BOLT, FLANGE	1	
15	95821-08020-00	BOLT, FLANGE (95801-08020)	1	
16	90201-08326-00	WASHER, PLATE	2	

CRANKCASE



Ref. No.	Part Number	Description	Qty	Remarks
1	34L-15100-05-00	CRANKCASE ASSEMBLY	1	
2	90387-17783-00	. COLLAR	1	
3	90387-16782-00	. COLLAR	1	
4	99510-12016-00	. PIN, DOWEL	2	
5	99510-08016-00	. PIN, DOWEL	1	
6	93210-07135-00	. O-RING	1	
7	90110-06138-00	BOLT, HEX SKT HEAD	9	
8	91316-06045-00	BOLT, SOCKET HEAD	4	
9	91316-06060-00	BOLT	1	
10	34L-11166-00-00	PIPE, BREATHER 1	1	
11	90467-14015-00	CLIP	2	
12	5Y1-15383-00-00	PLATE, BEARING COVER	1	
13	98603-06012-00	SCREW, OVAL HEAD (92701-06012)	3	
14	90116-10087-00	BOLT, STUD	2	
15	99530-14016-00	PIN, DOWEL	2	
16	90116-10263-00	BOLT, STUD	2	
17	99510-08016-00	PIN, DOWEL	1	
18	90430-08178-00	GASKET	1	


CRANKCASE COVER



Ref. No.	Part Number	Description	Qty	Remarks
1	34K-15411-00-00	COVER, CRANKCASE L	1	
2	3SW-15451-00-00	GASKET, CRANKCASE	1	
3	99510-12016-00	PIN, DOWEL	2	
4	91316-06020-00	BOLT, SOCKET HEAD	1	
5	91316-06025-00	BOLT	6	
6	91316-06040-00	BOLT, SOCKET HEAD	1	
7	91316-06050-00	BOLT, SOCKET HEAD	1	
8	93210-13361-00	O-RING	2	
9	5Y1-15441-00-00	HOLDER, CLCH CABLE	1	
10	90340-14079-00	PLUG, STRAIGHT SCRW	1	
11	93210-14369-00	O-RING	1	
12	90340-36078-00	PLUG, STRAIGHT SCREW	1	
13	93210-36510-00	O-RING	1	
14	90462-16102-00	CLAMP	1	
15	98580-06012-00	SCREW, PAN HEAD	1	
16	90462-10107-00	CLAMP	1	
17	5Y1-15421-02-00	COVER, CRANKCASE R	1	
18	91316-06016-00	BOLT, SOCKET HEAD	2	
19	5Y1-15431-03-00	COVER, CRANKCASE 3	1	
20	4DW-15462-00-00	GASKET, CRANKCASE COVER 3	1	
21	99510-12016-00	PIN, DOWEL	2	
22	91316-06025-00	BOLT	7	
23	90110-06138-00	BOLT, HEX SKT HEAD	1	
24	91316-06035-00	BOLT	2	
25	93101-14092-00	OIL SEAL (S7-14-25-5.5-1-HS)	1	
26	5Y1-15417-01-00	COVER, CAP	1	
27	91316-06016-00	BOLT, SOCKET HEAD	2	
28	5Y1-15645-00-00	SHIM, KICK SHAFT	1	


CONTINUED ON NEXT FRAME ➤

CRANKCASE COVER




Ref. No.	Part Number	Description	Qty	Remarks
29	5Y1-1562F-01-00	PLATE, DECOMP	1	

GENERATOR



Ref. No.	Part Number	Description	Qty	Remarks
1	55U-85560-50-00	BASE ASSEMBLY	1	
2	(55U-85550-50-00)	ROTOR ASSEMBLY	1	
3	98580-06030-00	SCREW PAN HEAD	2	
4	98580-06012-00	SCREW, PAN HEAD	2	
5	98580-06012-00	SCREW, PAN HEAD	2	
6	90201-06643-00	WASHER, PLATE	2	


STARTER



5Y1110-2130

Ref. No.	Part Number	Description	Qty	Remarks
1	5Y1-15660-01-00	KICK CRANK ASSEMBLY	1	
2	34K-15641-00-00	GEAR, KICK	1	
3	90201-20685-00	WASHER, PLATE (0.5T)	1	
4	93410-20038-00	CIRCLIP	1	
5	5Y1-15671-01-00	WHEEL, RATCHET (5Y1-15671-00)	1	
6	90501-16107-00	SPRING, COMPRESSION	1	
7	90201-155K6-00	WASHER, PLATE	1	
8	99009-15400-00	CIRCLIP	1	
9	90508-32529-00	SPRING, TORSION	1	
10	90201-15701-00	WASHER, PLATE (1.0T)	1	
11	2NX-15668-00-00	STOPPER	1	
12	2NX-15674-00-00	GUIDE, RATCHET WHEEL	1	
13	214-15686-00-00	WASHER, LOCK	1	
14	97011-06016-00	BOLT	2	
15	248-15668-00-00	STOPPER	1	
16	93102-20108-00	OIL SEAL	1	
17	5Y1-15651-01-00	GEAR, KICK IDLE	1	
18	90201-20276-00	WASHER, PLATE (1.0T)	2	
19	99009-20400-00	CIRCLIP	2	
20	5Y1-15620-02-00	KICK CRANK ASSEMBLY	1	
21	5Y1-15621-01-00	. BOSS, KICK CRANK	1	
22	90501-12081-00	. SPRING, COMPRESSION	1	
23	93507-32031-00	. BALL	1	
24	90157-06048-00	. SCREW, PAN HEAD - (90152-06010)	1	
25	90336-18038-00	. PLUG, TAPER	1	
26	97313-08030-00	BOLT, HEXAGON	1	
27	3Y1-1561A-02-00	LEVER DCOMP ASSEMBLY ..	1	

CONTINUED ON NEXT FRAME ➤




5Y1110-2130

STARTER

Ref. No.	Part Number	Description	Qty	Remarks
28	93102-10207-00	OIL SEAL (SD 10-21-5 HS)	1	
29	90201-105J4-00	WASHER, PLATE (90201-106H1)	1	
30	99009-10400-00	CIRCLIP	1	
31	90508-14524-00	SPRING, TORSION	1	
32	5Y1-1561G-00-00	LEVER, CABLE	1	
33	90201-061A5-00	WASHER, PLATE	1	
34	95311-06700-00	NUT	1	

CLUTCH




34K100-3130

Ref. No.	Part Number	Description	Qty	Remarks
1	34K-16111-00-00	GEAR, PRI DRIVE	1	
2	90282-07042-00	KEY, STRAIGHT	1	
3	90215-20197-00	WASHER, LOCK	1	
4	90170-20274-00	NUT, HEXAGON	1	
5	1JK-16150-00-00	PRI DRVN GEAR (34K-16150-00)	1	
6	3Y1-16154-00-00	PLATE, THRUST 1	1	
7	34K-16371-00-00	BOSS, CLUTCH	1	
8	5Y1-16321-00-00	PLATE, FRICTION	6	
9	360-16325-00-00	PLATE, CLUTCH 2	7	
10	5Y1-16331-01-00	PLATE, FRICTION 2	2	
11	5Y1-16351-00-00	PLATE, PRESSURE 1	1	
12	90501-26148-00	SPRING, COMPRESSION	5	
13	90159-06016-00	SCREW, WITH WASHER	5	
14	30X-16358-00-00	PLATE, PUSH	1	
15	34K-16356-00-00	ROD, PUSH 1	1	
16	92990-06200-00	WASHER	1	
17	95380-06600-00	NUT	1	
18	5Y1-16383-00-00	SPRING, CLUTCH BOSS	1	
19	90215-20231-00	WASHER, LOCK	1	
20	90170-20327-00	NUT	1	
21	5Y1-16380-00-00	PUSH LEVER COMP.	1	
22	214-16389-00-00	JOINT	1	
23	90243-06016-00	PIN	1	
24	93317-11020-00	BEARING	1	
25	93315-11720-00	BEARING	1	
26	93102-17357-00	OIL SEAL	1	
27	90201-08087-00	WASHER, PLATE	1	
28	90149-08067-00	SCREW	1	

CONTINUED ON NEXT FRAME ➤


CLUTCH



34K100-3130


Ref. No.	Part Number	Description	Qty	Remarks
29	90201-17327-00	WASHER, PLATE	1	
30	90508-14526-00	SPRING, TORSION	1	
31	5Y1-16357-00-00	ROD, PUSH 2	1	
32	93515-32029-00	BALL	1	

TRANSMISSION



Ref. No.	Part Number	Description	Qty	Remarks
1	34K-17410-00-00	MAIN AXLE	1	
2	5Y1-17411-00-00	. AXLE, MAIN	1	
3	34K-17141-00-00	. GEAR, 4TH PINION (22T)	1	
4	90209-22191-00	. WASHER	1	
5	93440-25084-00	. CIRCLIP	1	
6	1VJ-17131-00-00	. GEAR, 3RD PINION (20T)	1	
7	1VJ-17151-01-00	. GEAR, 5TH PINION	1	
8	34K-17121-01-00	. GEAR, 2ND PINION (17T)	1	
9	93306-30540-00	BEARING (6305NRX1C3)	1	
10	93306-00431-00	BEARING	1	
11	34K-17402-01-00	DRIVE AXLE ASSEMBLY	1	
12	5Y1-17221-01-00	GEAR, 2ND WHEEL	1	
13	5Y1-17251-00-00	GEAR, 5TH WHEEL	1	
14	1VJ-17231-00-00	GEAR, 3RD WHEEL (24T)	1	
15	90209-22191-00	WASHER	1	
16	93440-25084-00	CIRCLIP	1	
17	55U-17241-00-00	GEAR, 4TH WHEEL	1	
18	34K-17211-00-00	GEAR, 1ST WHEEL	1	
19	90201-20276-00	WASHER, PLATE (1.0T)	1	
20	99009-20400-00	CIRCLIP	1	
21	90201-253K0-00	WASHER, PLATE (T=1.0)	1	
22	93306-30535-00	BEARING	1	
23	93102-25226-00	OIL SEAL	1	
24	5Y1-17471-00-00	PLATE, COVER	1	
25	97011-06016-00	BOLT	2	
26	93306-00426-00	BEARING	1	
27	93834-14052-00	SPROCKET, DRIVE	1	
28	3Y1-17456-00-00	HOLDER, SPROCKET	1	
29	97011-06010-00	BOLT	2	

SHIFT CAM-FORK






34K100-3150

Ref. No.	Part Number	Description	Qty	Remarks
1	3YF-18540-00-00	SHIFT CAM ASSEMBLY	1	
2	93316-00503-00	. BEARING, CYLINDER.#16 (93316-00504)	1	
3	93604-10011-00	. PIN, DOWEL	2	
4	5Y1-18185-00-00	. SEGMENT	1	
5	90151-06017-00	. SCREW, COUNTERSUNK	1	
6	5Y1-18511-00-00	FORK, SHIFT 1	1	
7	5Y1-18512-00-00	FORK, SHIFT 2	1	
8	5Y1-18513-00-00	FORK, SHIFT 3	1	
9	3YF-18531-00-00	BAR, SHIFT FORK GUIDE 1	1	
10	34K-18535-00-00	BAR, SHIFT FORK GUIDE 2	1	
11	34K-18140-00-00	STOPPER LEVER ASSEMBLY	1	
12	90508-29527-00	SPRING, TORSION	1	
13	90387-063F7-00	COLLAR	1	
14	90159-06078-00	SCREW, WITH WASHER	1	


SHIFT SHAFT



55U110-5160


Ref. No.	Part Number	Description	Qty	Remarks
1	43F-18102-02-00	SHIFT SHAFT ASSEMBLY 2 . .	1	
2	5Y1-18101-02-00	SHIFT SHAFT ASSEMBLY	1	
3	99006-10600-00	. CIRCLIP	1	
4	90201-12474-00	WASHER, PLATE	1	
5	34K-18120-00-00	SHIFT LEVER ASSEMBLY	1	
6	90508-29629-00	. SPRING, TORSION	1	
7	99001-09600-00	CIRCLIP	1	
8	93102-12321-00	OIL SEAL, SD-TYPE	1	
9	93608-33046-00	PIN, DOWEL	1	
10	34K-18110-02-00	SHIFT PEDAL ASSEMBLY	1	
11	97011-06025-00	BOLT (97001-06025)	1	

FRAME



Ref. No.	Part Number	Description	Qty	Remarks
1	(55U-21110-00-FH)	FRAME	1	FIRE RED
2	(34K-21316-00-FH)	STAY, ENGINE 3	1	FIRE RED
3	90105-10286-00	BOLT, WASHER BASED	4	
4	90185-10060-00	NUT, SELF-LOCKING	4	
5	34K-21315-00-00	STAY, ENGINE 2	2	
6	97011-10080-00	BOLT	3	
7	92990-10100-00	WASHER, SPRING	3	
8	90185-10060-00	NUT, SELF-LOCKING	3	
9	95811-10110-00	BOLT, FLANGE	1	
10	90185-10060-00	NUT, SELF-LOCKING	1	
11	(34K-2176E-00-00)	PLATE	1	
12	34K-21471-00-FH	PROTECTOR, ENGINE	1	FIRE RED
13	95811-08012-00	BOLT, FLANGE	2	
14	90201-06778-00	WASHER, PLATE	2	
15	97011-06020-00	BOLT	2	
16	92995-06100-00	WASHER, SPRING	2	
17	34K-21485-00-00	DAMPER, RUBBER 1	1	
18	90267-40075-00	RIVET, BLIND	2	
19	90201-044H9-00	WASHER, PLAIN	2	
20	4N0-27114-00-00	STOPPER, MAIN STAND	2	
21	34K-21486-00-00	DAMPER 2	1	
22	30X-22178-00-00	TENSIONER	2	
23	4V4-22184-00-00	BUSH	2	
24	90109-08705-00	BOLT	1	
25	90201-13202-00	WASHER, PLATE	1	
26	90387-085E1-00	COLLAR	1	
27	90201-08753-00	WASHER, PLATE	2	
28	95811-08016-00	BOLT, FLANGE	1	


FENDER



55U110-5180


Ref. No.	Part Number	Description	Qty	Remarks
1	34K-21511-00-00	FENDER, FRONT	1	CLEAN WHITE
2	90201-06067-00	WASHER, PLATE	4	
3	97303-06020-00	BOLT (91201-06020)	4	
4	92995-06100-00	WASHER, SPRING	4	
5	90209-06187-00	WASHER	4	
6	34K-21610-00-00	FENDER, REAR	1	CLEAN WHITE
7	2H7-21628-00-00	DAMPER 1 (4U5-2317J-00)	1	
8	90119-06056-00	BOLT, WITH WASHER	3	
9	97313-06016-00	BOLT, HEXAGON	1	
10	92995-06100-00	WASHER, SPRING	1	
11	34K-21615-00-00	WASHER, SPECIAL 1	1	
12	90480-13018-00	GROMMET	1	

SIDE COVER



Ref. No.	Part Number	Description	Qty	Remarks
1	34K-21711-00-2X	COVER, SIDE 1	1	WHITE/RED
2	90480-01401-00	GROMMET	2	
3	90480-13398-00	GROMMET	1	
4	55U-21781-00-00	EMBLEM 1	1	
5	34K-21732-00-00	SEAL 1	1	
6	34K-21721-00-2X	COVER, SIDE 2	1	WHITE/RED
7	90480-01401-00	GROMMET	2	
8	90480-13398-00	GROMMET	1	
9	55U-21781-00-00	EMBLEM 1	1	
10	30X-24768-00-00	STOPPER	1	
11	34K-2174A-00-00	INSULATOR, SIDE CVR	1	
12	34K-21751-00-00	TANK, OIL	1	
13	90201-08087-00	WASHER, PLATE	1	
14	95811-08012-00	BOLT, FLANGE	1	
15	90430-27124-00	GASKET	1	
16	34K-21771-00-00	BODY, CAP	1	
17	90445-11748-00	HOSE	1	
18	90467-10008-00	CLIP	2	
19	95826-08205-00	BOLT, FLANGE	1	
20	90387-081J3-00	COLLAR	1	
21	95706-08500-00	NUT, flange	1	
22	95811-08012-00	BOLT, FLANGE	1	
23	34K-21778-00-00	DAMPER, LOCATING 1	1	

SWING ARM




34K100-3200

Ref. No.	Part Number	Description	Qty	Remarks
1	(34K-22110-00-00)	REAR ARM	1	
2	93317-32231-00	BEARING	2	
3	90380-22111-00	BUSH, SOLID	2	
4	93106-22019-00	OIL SEAL (DC 22-28-8)	2	
5	93342-22208-00	BEARING, FLAT # 2	2	
6	93108-35004-00	OIL SEAL (35-41-8)	2	
7	3R4-22129-00-00	COVER, THRUST 2	2	
8	90380-16126-00	BUSH, SOLID	1	
9	90380-16127-00	BUSH, SOLID	1	
10	240-22127-00-00	SHIM	1	U.N.
11	5X6-22151-10-00	SEAL, GUARD	1	
12	90387-440G3-00	COLLAR	1	
13	34K-22141-01-00	SHAFT, PIVOT	1	
14	90185-14070-00	NUT, SELF-LOCKING	1	
15	90201-15238-00	WASHER, PLATE	1	
16	23X-22199-00-00	SUPPORT, CHAIN	1	
17	95811-08055-00	BOLT, FLANGE	2	
18	95601-08200-00	NUT, U	2	
19	5X6-22147-01-00	PROTECTOR, CHAIN	1	
20	95811-06016-00	BOLT, FLANGE (95822-06016)	2	
21	(34K-2217A-00-00)	ARM, RELAY	1	
22	93317-32034-00	BEARING, CYLINDER.# 7	1	
23	93109-20029-00	OIL SEAL, SDO-TYPE	2	
24	90387-147G6-00	COLLAR	1	
25	90387-147G7-00	COLLAR	1	
26	90109-12701-00	BOLT	1	
27	93700-06M03-00	NIPPLE, GREASE	1	
28	90201-120A5-00	WASHER, PLATE	1	
29	90201-142M6-00	WASHER, PLATE	1	

CONTINUED ON NEXT FRAME ➤


SWING ARM



34K100-3200

Ref. No.	Part Number	Description	Qty	Remarks
30	90185-12119-00	NUT, SELF-LOCKING	1	
31	23X-2217F-00-00	ROD, CONNECTING 1	1	
32	93315-31732-00	BEARING, CYLINDRICAL	2	
33	55K-22129-00-00	COVER, THRUST 2	4	
34	90387-121H1-00	COLLAR	2	
35	90109-10702-00	BOLT	1	
36	93700-06005-00	NIPPLE, GREASE	1	
37	90201-120E6-00	WASHER, PLATE	1	
38	90201-100E9-00	WASHER, PLATE	1	
39	90185-10120-00	NUT, SELF-LOCKING	1	
40	90109-10703-00	BOLT	1	
41	93700-06M03-00	NIPPLE, GREASE	1	
42	90201-100F7-00	WASHER, PLATE	1	
43	95611-10100-00	NUT, U	1	
44	5X3-2218A-00-00	EMBLEM, REAR ARM	2	
45	34K-22311-00-00	CASE, CHAIN	1	
46	90159-06058-00	SCREW, WITH WASHER	2	
47	34K-21629-01-00	GUARD, MUD	1	
48	91316-06012-00	BOLT, SOCKET HEAD	1	
49	90201-06059-00	WASHER, PLATE	1	


REAR SHOCKS



55U110-5210

Ref. No.	Part Number	Description	Qty	Remarks
1	3SW-22210-00-6W	SHK/ABS ASSEMBLY, REARASSEMBLY, REAR	1	NATIVE RED
2	93440-30113-00	. CIRCLIP	2	
3	93104-18077-00	. OIL SEAL	2	
4	34K-22212-20-6W	. SPRING, MXS HARD	1	
5	23X-22214-00-00	. GUIDE, SPRING 1	2	
6	90109-10690-00	BOLT	1	
7	90185-10120-00	NUT, SELF-LOCKING	1	
8	90201-100F7-00	WASHER, PLATE	1	
9	90380-12094-00	BUSH, SOLID	1	
10	90109-10700-00	BOLT	1	
11	90201-120E6-00	WASHER, PLATE	1	
12	90201-100E9-00	WASHER, PLATE	1	
13	90185-10120-00	NUT, SELF-LOCKING	1	
14	90387-126H8-00	COLLAR	2	
15	34K-22262-00-00	HOLDER, SUB TANK	1	
16	95811-06012-00	BOLT, FLANGE	1	

FRONT FORK




55U110-5230

Ref. No.	Part Number	Description	Qty	Remarks
1	(55U-23102-00-00)	FRONT FORK ASSEMBLY L . .	1	
2	(55U-23126-00-00)	TUBE, OUTER 1	1	CLEAR BUFFING
3	4V4-23153-L0-00	. RING, SNAP	1	
4	23X-23145-L0-00	. OIL SEAL	1	
5	3XJ-23125-L0-00	. METAL, SLIDE 1	1	
6	23X-23144-L0-00	. SEAL, DUST	1	
7	4V4-23146-L0-00	. WASHER, OIL SEAL	1	
8	55U-23110-00-00	. INNER TUBE COMP.	1	
9	4V4-23171-L0-00	. . PISTON, FRONT FORK	1	
10	(55U-23170-00-00)	CYLINDER, FRT FORK	1	
11	4V4-23173-L0-00	. SPINDLE, TAPER	1	
12	55U-23141-00-00	. SPRING, FRONT FORK	1	
13	4V4-23142-L0-00	. SEAT, SPRING UPPER	1	
14	5X6-23118-M0-00	. SPACER (L=110)	1	
15	4V4-23158-L0-00	. GASKET	1	
16	122-23129-00-00	. GASKET, DRAIN PLUG	1	
17	4H7-23119-00-00	. PLUG, DRAIN - (122-23119-01)	1	
18	43M-23111-L0-00	. BOLT, CAP	1	
19	23X-23190-L0-00	. AIR VALVE COMP	1	
20	4V4-23188-L0-00	. O-RING	1	
21	3J2-23147-00-00	. O-RING	1	
22	34K-23181-00-00	. BOLT, HEX SCKT HEADSOCKET HEAD	1	
23	55U-23103-00-00	FRONT FORK ASSEMBLY R (R.H)	1	
24	55U-23136-00-38	. TUBE, OUTER RH	1	CLEAR BUFFING
25	4V4-23153-L0-00	. RING, SNAP	1	
26	23X-23145-L0-00	. OIL SEAL	1	
27	3XJ-23125-L0-00	. METAL, SLIDE 1	1	


CONTINUED ON NEXT FRAME ➤

FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
28	23X-23144-L0-00	. SEAL, DUST	1	
29	4V4-23146-L0-00	. WASHER, OIL SEAL	1	
30	55U-23110-00-00	. INNER TUBE COMP.	1	
31	4V4-23171-L0-00	. . PISTON, FRONT FORK	1	
32	(55U-23170-00-00)	CYLINDER, FRT FORK	1	
33	4V4-23173-L0-00	. SPINDLE, TAPER	1	
34	55U-23141-00-00	. SPRING, FRONT FORK	1	
35	4V4-23142-L0-00	. SEAT, SPRING UPPER	1	
36	5X6-23118-M0-00	. SPACER (L=110)	1	
37	4V4-23158-L0-00	. GASKET	1	
38	122-23129-00-00	. GASKET, DRAIN PLUG	1	
39	4H7-23119-00-00	. PLUG, DRAIN - (122-23119-01)	1	
40	43M-23111-L0-00	. BOLT, CAP	1	
41	23X-23190-L0-00	. AIR VALVE COMP	1	
42	4V4-23188-L0-00	. O-RING	1	
43	3J2-23147-00-00	. O-RING	1	
44	34K-23181-00-00	. BOLT, HEX SCKT HEADSOCKET HEAD	1	
45	43M-23167-L0-00	. HOLDER, AXLE	1	
46	92995-06100-00	. WASHER, SPRING	4	
47	95311-06600-00	. NUT	4	
48	55U-23191-00-00	BOOT	2	CHAPPY RED
49	43M-23192-L0-00	BAND	2	
50	3LD-23489-00-00	BAND	2	
51	34K-23340-00-39	UNDER BRACKETCOMP (26A-23340-L0-39)	1	CLEAR NO BUFFING
52	90101-08340-00	BOLT	4	
53	92901-08600-00	WASHER	3	
54	92990-08100-00	WASHER	4	


CONTINUED ON NEXT FRAME ➤



FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
55	95333-08600-00	NUT	4	
56	4V5-23389-00-00	GUIDE, CABLE	1	
57	98506-04018-00	SCREW, PAN HEAD	2	


STEERING



55U110-5220

Ref. No.	Part Number	Description	Qty	Remarks
1	34K-23389-00-00	GUIDE, CABLE	1	
2	93332-00008-00	BEARING	1	
3	23X-W2341-00-00	CROWN, HANDLE	1	LOW GLOSS BLK
4	3R4-23317-00-00	HOLDER, CABLE	1	
5	1E6-23442-00-00	HOLDER, HANDLE LWR	2	
6	307-22123-00-00	BUSH 1	2	
7	90201-123E8-00	WASHER, PLATE	2	
8	90201-100A1-00	WASHER, PLATE	2	
9	90387-121E8-00	COLLAR	2	
10	90202-14077-00	WASHER, PLATE	2	
11	90185-10037-00	NUT, SELF-LOCKING	2	
12	91490-20020-00	PIN, COTTER	2	
13	90105-08091-00	BOLT, WASHER BASED	4	
14	90179-22330-00	NUT, SPEC''L SHAPE	1	
15	34K-2319U-00-00	CAP	1	
16	1E6-23441-00-00	HOLDER, HANDLE UPR	2	
17	95811-08035-00	BOLT, FLANGE (95821-08035)	4	
18	93332-00001-00	BEARING	1	
19	3HE-23416-00-00	COVER, BALL RACE 2	1	
20	90179-25033-00	NUT	1	
21	26A-23318-00-00	HOLDER, CABLE 1	1	
22	98503-05025-00	SCREW, PAN HEAD (98501-05025)	1	
23	92901-05600-00	WASHER, PLATE	1	
24	90387-064W1-00	COLLAR (90387-066J9)	1	
25	95380-05600-00	NUT	1	
26	90465-16258-00	CLAMP	2	
27	91316-06012-00	BOLT, SOCKET HEAD	2	


FUEL TANK



55U110-5240

Ref. No.	Part Number	Description	Qty	Remarks
1	34K-24110-00-03	FUEL TANK	1	WHITE
2	55U-24254-00-00	. GRAPHIC, FUELTANK 7	1	
3	55U-24255-00-00	. GRAPHIC, FUELTANK 8	1	
4	1W1-24182-01-00	DAMPER, LOCATING 2	2	
5	1W1-24144-01-00	HOLDER, DAMPER	2	
6	34K-2413X-00-00	PLATE	2	
7	97313-06016-00	BOLT, HEXAGON	4	
8	92995-06100-00	WASHER, SPRING	4	
9	90201-061A5-00	WASHER, PLATE	4	
10	90387-07393-00	COLLAR (308-84557-00)	2	
11	90201-06407-00	WASHER, PLATE (90201-06747-00)	2	
12	90119-06022-00	BOLT, WITH WASHER	2	
13	59V-24173-00-00	BAND, TANK FITTING 1	1	
14	34K-24500-01-00	FUEL COCK ASSEMBLY 1	1	
15	(357-24529-10-00)	SPRING	1	
16	4X8-24534-00-00	. SEAL, COCK	1	
17	98580-06008-00	. SCREW, PAN HEAD	2	
18	4X8-24512-00-00	. O-RING	1	
19	90202-05187-00	WASHER, PLATE	2	
20	90149-06011-00	SCREW	2	
21	90445-10456-00	HOSE	1	
22	90467-09006-00	CLIP	2	
23	1UY-24610-00-00	CAP ASSEMBLY	1	
24	3R9-24612-00-00	GASKET, CAP	1	
25	90445-09777-00	HOSE	1	
26	34K-24181-00-00	DAMPER, LOCATING 1	1	

SEAT






55U110-5250

Ref. No.	Part Number	Description	Qty	Remarks
1	34K-24710-11-00	SINGLE SEAT ASSEMBLY . . .	1	
2	34K-24731-10-00	. COVER, SEAT	1	CHAPPY RED
3	1L9-24741-00-00	PAD, SEAT	1	
4	97313-06016-00	BOLT, HEXAGON	2	
5	90201-06M02-00	WASHER, PLATE	2	
6	4V5-24850-00-00	CARRIER BOX ASSEMBLY . . .	1	
7	4V5-24833-00-00	BRACKET, CARRIER 2	1	
8	98580-06020-00	SCREW	4	
9	90201-06571-00	WASHER, PLATE	6	
10	34K-21615-00-00	WASHER, SPECIAL 1	2	
11	95601-06100-00	NUT, U	4	
12	1LN-W2810-00-00	TOOL KIT (34K-28100-00)	1	


FRONT WHEEL



55U110-5260


Ref. No.	Part Number	Description	Qty	Remarks
1	34X-25111-02-98	HUB, FRONT	1	LOW GLOSS BLK
2	93306-20209-00	BEARING (B6202)	2	
3	90560-15290-00	SPACER	1	
4	93102-20281-00	OIL SEAL (SD 20-35-5)	1	
5	94416-21430-00	RIM (1.60-21)	1	SILVER
6	4V5-25194-00-00	SPACER, BEAD	1	
7	55U-25104-00-00	SPOKE SET, FRONT	1	
8	(94110-213E7-00)	100/80-21 M2E (TT)	1	INOUE
9	94230-21126-00	TUBE (3.00-21)	1	INOUE
10	(94330-21088-00)	BAND, RIM	1	INOUE
11	55U-25181-01-00	AXLE, WHEEL	1	
12	90387-15600-00	COLLAR	1	
13	322-25118-00-00	COVER, HUB DUST	1	
14	1W2-25190-00-00	GEAR UNIT ASSEMBLY	1	

FRONT BRAKE CALIPER



Ref. No.	Part Number	Description	Qty	Remarks
1	55U-25831-00-00	DISC, BRAKE	1	
2	90109-06757-00	BOLT	6	
3	55U-25810-10-00	CALIPER ASSEMBLY	1	
4	34X-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
5	34X-W0047-00-00	. . CALIPER SEAL KIT	1	
6	5R2-25937-00-00	. BOOT 2	1	
7	34X-25937-00-00	. BOOT 2	1	
8	51L-W0048-00-00	. BLEED SCREW KIT	1	
9	34X-W0046-00-00	. BRAKE PAD KIT REAR	1	
10	34X-25919-00-00	. SUPPORT, PAD	1	
11	2GV-25926-00-00	. BOLT	1	
12	34X-25845-00-00	. CAP, INDICATOR	1	
13	55U-25818-00-00	BOLT, CALIPER	2	
14	55U-25715-00-00	COVER 1	1	
15	90149-06194-00	SCREW	2	
16	55U-25716-00-00	COVER 2	1	
17	55U-25719-00-00	BAND	1	
18	98580-05016-00	SCREW, PAN HEAD	1	
19	92901-05600-00	WASHER, PLATE	1	
20	95380-05600-00	NUT	1	

REAR WHEEL




55U110-5280

Ref. No.	Part Number	Description	Qty	Remarks
1	56A-25311-00-98	HUB, REAR	1	LOW GLOSS BLK
2	90560-20226-00	SPACER	1	
3	93306-00418-00	BEARING	2	
4	93306-00406-00	BEARING (B6004Z)	2	
5	93106-28023-00	OIL SEAL	1	
6	26A-25321-00-98	PLATE, BRAKE SHOE	1	LOW GLOSS BLK
7	437-W2536-00-00	BRAKESHOE SET-2PCS	2	
8	90506-17328-00	SPRING, TENSION	2	
9	26A-25351-00-00	CAMSHAFT	1	
10	34L-25355-00-00	LEVER, CAMSHAFT	1	
11	90101-06291-00	BOLT	1	
12	148-25359-00-00	SEAL, CAMSHAFT	1	
13	1W2-27237-00-00	PIN, CLEVIS	1	
14	90201-12631-00	WASHER, PLATE	1	
15	91401-25030-00	PIN, COTTER	1	
16	94425-18409-00	RIM 2. 0	1	SILVER
17	56A-25304-00-00	SPOKE SET, REAR	1	
18	94114-186G1-00	140/90-18 M2A (TT)	1	INOUE
19	94245-18125-00	TUBE (4.50-18)	1	INOUE
20	94345-18081-00	BAND, RIM (4.50-18)	1	INOUE
21	2X5-25394-00-00	SPACER, BEAD	2	
22	26A-25450-50-00	SPROCKET, DRIVEN (50T)	1	YAMAHA BLK
23	90109-08706-00	BOLT	6	
24	95601-08200-00	NUT, U	6	
25	26A-25383-00-00	COLLAR, WHEEL	1	
26	4V5-25388-01-00	PULLER, CHAIN 1	1	
27	26A-25381-01-00	AXLE, WHEEL	1	
28	92901-18100-00	WASHER, SPRING	1	
29	92901-20600-00	WASHER, WAVE	1	

CONTINUED ON NEXT FRAME ➤


REAR WHEEL



55U110-5280

Ref. No.	Part Number	Description	Qty	Remarks
30	90179-18332-00	NUT	1	
31	91701-05045-00	PIN, CLEVIS	2	
32	91490-16020-00	PIN, COTTER	2	
33	94580-40112-00	CHAIN (25Y)	1	
34	94680-50011-00	. JOINT, CHAIN (34L) (D.I.D.50HDS)	1	


HANDLEBAR-CABLE



55U110-5290


Ref. No.	Part Number	Description	Qty	Remarks
1	34K-26111-00-00	HANDLEBAR	1	
2	1LX-26242-01-00	GRIP (RIGHT)	1	
3	3Y1-26243-01-00	TUBE, THROTTLE GUIDE	1	
4	3Y1-26249-00-00	RING, LEAF	1	
5	1LX-26241-01-00	GRIP (LEFT)	1	
6	34K-26281-00-00	CAP, GRIP UPPER	1	
7	1VJ-26282-00-00	CAP, GRIP LOWER	1	
8	98506-05020-00	SCREW, PAN HEAD	1	
9	98506-05025-00	SCREW, PAN HEAD	1	
10	34K-26302-00-00	THROTTLE CABLE ASSEMBLYASSY	1	
11	90468-15009-00	CLIP	1	
12	90464-20031-00	CLAMP	1	
13	90387-227H7-00	COLLAR	1	
14	55U-26335-01-00	CABLE, CLUTCH	1	
15	1E6-26342-00-00	BOOT, CABLE	1	
16	90123-08090-00	BOLT	1	
17	90179-08401-00	NUT	1	
18	3Y0-26141-00-00	GUARD, BRUSH 1	1	CLEAN WHITE
19	(34L-26142-10-00)	XT600L BUSH GD RH	1	CLEAN WHITE
20	98503-06014-00	SCREW, PAN HEAD (92502-06016)	1	
21	90201-061A5-00	WASHER, PLATE	1	
22	92990-06200-00	WASHER	1	
23	95380-06700-00	NUT	1	
24	90387-06500-00	COLLAR	1	

FRONT MASTER CYLINDER



Ref. No.	Part Number	Description	Qty	Remarks
1	55U-25850-00-00	MSTR CYLINDER ASSEMBLYASSY	1	
2	56A-W0041-00-00	. CYLINDER KIT, MASTER	1	
3	55U-25854-00-00	. DIAPHRAGM, RESERVOIR	1	
4	2KF-25852-01-00	. CAP, RESERVOIR	1	
5	98706-04012-00	. SCREW, FLAT HEAD	2	
6	56A-25867-00-00	BRACKET, MASTER CYLINDER	1	
7	90338-09012-00	PLUG	1	
8	97016-06025-00	BOLT	2	
9	92906-06100-00	WASHER, SPRING	2	
10	55U-25872-00-00	HOSE, BRAKE 1	1	
11	90401-10034-00	BOLT, UNION	2	
12	90201-10118-00	WASHER, PLATE	4	


STAND-FOOTREST



55U110-5310

Ref. No.	Part Number	Description	Qty	Remarks
1	36A-27211-01-90	PEDAL, BRAKE	1	
2	3R8-27242-00-00	PEDAL, BRAKE	1	
3	90508-14429-00	SPRING, TORSION	1	
4	91701-06028-00	PIN, CLEVIS	1	
5	90201-061A5-00	WASHER, PLATE	1	
6	91490-20020-00	PIN, COTTER	1	
7	90101-06288-00	BOLT	1	
8	95380-06600-00	NUT	1	
9	91401-30020-00	PIN, COTTER	1	
10	90201-14411-00	WASHER, PLATE	1	
11	34K-27231-00-00	ROD, BRAKE	1	
12	90240-06103-00	PIN, CLEVIS	1	
13	92990-06200-00	WASHER	1	
14	91490-20020-00	PIN, COTTER	1	
15	90506-18305-00	SPRING, TENSION	1	
16	90501-10245-00	SPRING, COMPRESSION	1	
17	1W2-27239-00-00	SEAT, SPRING	1	
18	90179-06411-00	NUT	1	
19	23X-27411-02-00	FOOTREST 1	1	
20	34K-27412-00-R4	BRACKET, FOOTREST 1	1	BLACK
21	90508-20583-00	SPRING, TORSION	1	
22	90240-10101-00	PIN, CLEVIS	1	
23	91401-25020-00	PIN, COTTER	1	
24	34K-27421-00-00	FOOTREST 2	1	
25	34K-27422-00-R4	BRACKET, FOOTREST 2	1	
26	90508-20583-00	SPRING, TORSION	1	
27	90240-10101-00	PIN, CLEVIS	1	
28	91401-25020-00	PIN, COTTER	1	
29	95811-10025-00	BOLT, FLANGE	4	

CONTINUED ON NEXT FRAME ➤




55U110-5310

STAND-FOOTREST

Ref. No.	Part Number	Description	Qty	Remarks
30	55U-27311-00-R4	STAND, SIDE	1	YAMAHA BLK
31	90105-12616-00	BOLT, WASHER BASED	1	
32	90185-12119-00	NUT, SELF-LOCKING	1	
33	90507-29008-00	SPRING, TENSION	1	

METER




FWD

55U110-5330

Ref. No.	Part Number	Description	Qty	Remarks
1	4V5-83505-60-00	TRIP METER CMPLT	1	MILE
2	4V5-83578-00-00	. KNOB, TRIP METER	1	
3	4V5-83513-00-00	DAMPER	1	
4	26A-83519-00-00	BRACKET, METER	1	
5	1M1-83526-00-00	DAMPER 2	2	
6	90201-052E2-00	WASHER, PLATE	2	
7	90468-10050-00	CLIP	2	
8	97013-06012-00	BOLT	2	
9	92995-06100-00	WASHER, SPRING	2	
10	4V5-83550-01-00	SPEEDOMETER CABLE	1	


HEADLIGHT



55U110-5340

Ref. No.	Part Number	Description	Qty	Remarks
1	55U-84311-00-00	BODY, HEADLIGHT	1	WHITE
2	55U-84320-00-00	LENS ASSEMBLY	1	
3	55U-84397-00-00	COVER, SOCKET	1	
4	55U-84314-H0-00	BULB, H.L.12V55W (12V-55W) .	1	
5	55U-84324-00-00	SPRING, REFLECTOR	1	
6	55U-84332-00-00	SPRING, SCREW	1	
7	50W-84334-00-00	NUT, ADJUSTING	1	
8	55U-84331-00-00	SCREW, RIM ADJUSTNG	1	
9	55U-84337-00-00	BOLT, SPECIAL	2	
10	55U-84328-00-00	SPACER	2	
11	90480-12053-00	GROMMET	2	
12	4V5-83592-00-00	DAMPER	1	
13	55U-84141-00-00	EMBLEM, HEADLIGHT	1	GLOSS BLACK


TAILLIGHT



34K100-3330


Ref. No.	Part Number	Description	Qty	Remarks
1	4V5-84536-00-00	SOCKET CORD ASSEMBLY . .	1	
2	256-84714-61-00	. BULB (12V-27/8W)	1	
3	26A-84521-00-00	LENS, TAILLIGHT	1	
4	98511-04020-00	SCREW, PAN HEAD	4	
5	437-83936-01-00	BAND, SWITCH CORD	2	

ELECTRICAL 1



Ref. No.	Part Number	Description	Qty	Remarks
1	55U-85540-51-00	CDI UNIT ASSEMBLY	1	
2	122-82131-00-00	BAND, BATTERY	1	
3	43F-82310-51-00	IGNITION COIL ASSEMBLY	1	
4	98580-06020-00	SCREW	2	
5	371-82370-00-00	PLUG CAP ASSEMBLY	1	
6	90340-10003-00	PLUG, STRAIGHT SCRW	1	
7	90430-10171-00	GASKET	1	
8	82F-81910-A0-00	VOLTAGE REGULATOR ASSEMBLY	1	
9	98580-06012-00	SCREW, PAN HEAD	1	
10	(55U-82590-00-00)	WIRE HARNESS ASSEMBLY	1	
11	25G-83936-01-00	BAND, SWITCH CORD	2	
12	437-83936-11-00	BAND, SWITCH CORD	1	

HANDLE SWITCH-LEVER



55U110-5360

Ref. No.	Part Number	Description	Qty	Remarks
1	38V-82911-00-00	HOLDER, LEVER 1	1	
2	38V-82913-00-00	HOLDER, LEVER LOWER 1	1	
3	23X-83912-00-00	LEVER 1	1	
4	90109-06797-00	BOLT	1	
5	90201-082A9-00	WASHER, PLATE	1	
6	95616-06100-00	NUT, U	1	
7	98506-05018-00	SCREW, PAN HEAD	2	
8	92906-05100-00	WASHER, SPRING	2	
9	55Y-83922-00-00	LEVER 2	1	
10	90109-062A8-00	BOLT	1	
11	95616-06100-00	NUT, U	1	
12	90149-06153-00	SCREW, SPEC''L SHAPE	1	
13	90170-06010-00	NUT	1	
14	90501-10312-00	SPRING, COMPRESSION	1	
15	23X-83976-00-00	SWITCH, HANDLE 1	1	
16	437-83936-01-00	BAND, SWITCH CORD	2	
17	4V5-82520-00-00	LIGHT SWITCH ASSEMBLY	1	
17-1	(4V5-00000-00-XX)	KNOB AND SCREW SET	1	

MOTORCYCLE	DATE 1/24/86

TT600S
1986 SERVICE DATA

MODEL - ISM I.D. NUMBER	TT600S	55U
Initial Engine Number / Frame Number	55U-005101 / JYA55U00( )005101	
Fuel Type / Total Fuel Tank Capacity / Reserve Cap.	Regular / 11.0 Lit (2.9 gal) / 3.0 Lit (0.8 gal)	

ENGINE TYPE	4-Stroke, SOHC, 4-Valve, YDIS
Bore / Stroke / Number Cylinders / Displacement	95.0mm / 84.0mm / 1 / 595cc
Compression Ratio/Compression Pressure Min~Max	8.5:1 / 10.0 ~ 14.0 kg/cm² (142 ~ 199 psi)
Piston Skirt Clearance New / Max	0.045 ~ 0.065mm / 0.10mm
Ring End Gap Top / 2nd / 3rd	0.30 ~ 0.45mm / 0.30 ~ 0.45mm / 0.20 ~ 0.70mm
Valve Clearance (Cold) Intake / Exhaust	0.05 ~ 0.10mm / 0.12 ~ 0.17mm
Oiling System	Dry Sump
Capacity: Dry	2400cc (2.5 qt)
Oil and Filter Change/Oil Change Only	2100cc (2.2 qt) / 2000cc (2.1 qt)
Oil Filter Part Number	4X7-13440-90-00
Lubricant: Temp Above 5°C (40°F)	Yamalube 4* or SAE 20W40 SE or SF
Temp Below 15°C (60°F)	SAE 10W30 SE or SF
Cooling System / Capacity / Cap Opening Pressure	Air / Φ / Φ
Coolant Type / Mixing Ratio	Φ / Φ

AUTOLUBE - Min Stroke / Color Code	Φ
Minimum Output @ 200 Cycles	Φ
Maximum Output @ 200 Cycles	Φ

CARBURETOR - Manufacturer / Type / I.D. Number	T-K / Y27PV / 55U-00
Main Jet / Pilot Jet / Pilot Screw (Turns Out)	Primary: 135 / 48 / 2-3/4 Secondary: 135 / Φ / Φ
Needle Jet / Jet Needle-Clip Position	Primary: 2.60 / 5C3B-3 Secondary: 2.60 / 4A71-3
Slide Cutaway	5.5
Float Height / Fuel Level	27.0 ±0.5mm / 7.0 ±1.0mm (with special tool)
Idle rpm	1350 ± 50 rpm
Max CO⊕ / Max HC⊕ / Set CO	Φ / Φ / 5.0 ± 1.5%

SUSPENSION	
Front: Oil Type / Level / Qty	10 Wt. Fork Oil* / 150mm / 578cc
Gas Pressure Min ~ Max / Standard	0 ~ 1.2 kg/cm² (0~17 psi) 0 kg/cm² (0 psi)
Spring Length Standard	527mm
Rear: Gas Pressure Min ~ Max / Standard	Φ / 20 kg/cm² (284 psi)
Minimum Brake Lining Thickness Front / Rear	0.8mm / 2.0mm
Tire Size (Nominal Pressure) Front	100/80-21 / 1.0 kg/cm² (14 psi)
Rear	140/80-18 / 1.0 kg/cm² (14 psi)

TRANSMISSION - Oil Type / Qty Change / Qty Dry	See ENGINE Above
Secondary Drive Type / Teeth / Chain / Freeplay	Chain / 50-14 / 520VS-112L / 20~30mm
Middle Gear Case Capacity	Φ
Final Gear Case Capacity	Φ
Gear Case Lubricant	Φ

SERVICE COPY	SER MGR	MECH	MECH	MECH	BINDER
OFFICE COPY	GEN MGR	SALES	PARTS	BINDER	PAGE 1 OF 2

CHARGING SYSTEM	AC Magneto
Battery: Model / Specific Gravity / Charge Rate	Φ
Maximum Output	Φ
Field Coil Color Code / Ω	Φ
Stator Coil Color Code / Ω	Φ
Charge Coil Color Code / Ω	Φ

IGNITION SYSTEM	Capacitor Discharge
Ignition Timing	12° @ 1600 rpm Full Adv: 36° @ 4500 rpm
Spark Plug Type	NGK DP7EA-9
Spark Plug Gap / Torque / Cap Ω	0.8 ~ 0.9mm / 1.8 m-kg (13 ft-lbs) / 10KΩ
Ignition Coil Test Gap / Primary Ω / Secondary Ω	6mm / 0.5Ω ±25% / 6KΩ ±20%
Pulser Coil or Pickup Coil Color Code / Ω	Blk-Yel~Blu-Yel, Blk-Yel~Grn-Wht / 110 Ω ±18%
Source Coil Color Code / Ω	Blk-Red~Grn / 140Ω ±21%

LIGHTING SYSTEM	
Headlight / Taillight / Signal Rating	12V55W / 12V8W / Φ
Lighting Coil Color Code / Ω	Blk~Yel / 0.3Ω ± 33%

TORQUE VALUES	
Front Axle Nut	M14: 5.8 m-kg (41.9 ft-lbs)
Front Axle Holder Nut	M8: 0.8 m-kg (5.8 ft-lbs)
Rear Axle Nut	M18: 10.5 m-kg (76 ft-lbs)
Rear Axle Pinch Bolt	Φ
Clutch Nut	M20: 7.0 m-kg (50.6 ft-lbs)
Drain Plug	M14: 3.0 m-kg (21.7 ft-lbs)
Flywheel Nut	M14: 9.0 m-kg (65.1 ft-lbs)
Cylinder Head Cover	M6: 1.0 m-kg (7.2 ft-lbs)
Cylinder Head: Nut	M8: 2.5 m-kg (18.1 ft-lbs)
Stud	M6: 0.7 m-kg (5.0 ft-lbs) M10: 2.0 m-kg (14.5 ft-lbs)
Engine Mounting Bolts: Front Upper	M10: 6.4 m-kg (46.3 ft-lbs)
Front Bracket	M10: 6.4 m-kg (46.3 ft-lbs)
Rear Lower	M10: 6.4 m-kg (46.3 ft-lbs)

Φ = Does Not Apply to This Model
NA = Information Not Available
* = Available from YPDI
⊕ = For Diagnostic Use Only

SERVICE LITERATURE

PUBLICATION	PART NUMBER	REMARKS
Owner's Manual	LIT-11626-05-16	
Service Manual	LIT-11616-04-55	Same as TT600N
Assembly Manual	LIT-11666-04-55	Supp. to SR/XT/TT/MX/DT Basic Assembly Manual (03-86)

PAGE 2 OF 2

CHARGING SYSTEM	AC Magneto
Battery: Model / Specific Gravity / Charge Rate	Φ
Maximum Output	Φ
Field Coil Color Code / Ω	Φ
Stator Coil Color Code / Ω	Φ
Charge Coil Color Code / Ω	Φ

IGNITION SYSTEM	Capacitor Discharge
Ignition Timing	12° @ 1600 rpm Full Adv: 36° @ 4500 rpm
Spark Plug Type	NGK DP7EA-9
Spark Plug Gap / Torque / Cap Ω	0.8 ~ 0.9mm / 1.8 m-kg (13 ft-lbs) / 10KΩ
Ignition Coil Test Gap / Primary Ω / Secondary Ω	6mm / 0.5Ω ±25% / 6KΩ ±20%
Pulser Coil or Pickup Coil Color Code / Ω	Blk-Yel~Blu-Yel, Blk-Yel~Grn-Wht / 110 Ω ±18%
Source Coil Color Code / Ω	Blk-Red~Grn / 140Ω ±21%

LIGHTING SYSTEM	
Headlight / Taillight / Signal Rating	12V55W / 12V8W / Φ
Lighting Coil Color Code / Ω	Blk~Yel / 0.3Ω ± 33%

TORQUE VALUES	
Front Axle Nut	M14: 5.8 m-kg (41.9 ft-lbs)
Front Axle Holder Nut	M8: 0.8 m-kg (5.8 ft-lbs)
Rear Axle Nut	M18: 10.5 m-kg (76 ft-lbs)
Rear Axle Pinch Bolt	Φ
Clutch Nut	M20: 7.0 m-kg (50.6 ft-lbs)
Drain Plug	M14: 3.0 m-kg (21.7 ft-lbs)
Flywheel Nut	M14: 9.0 m-kg (65.1 ft-lbs)
Cylinder Head Cover	M6: 1.0 m-kg (7.2 ft-lbs)
Cylinder Head: Nut	M8: 2.5 m-kg (18.1 ft-lbs)
Stud	M6: 0.7 m-kg (5.0 ft-lbs) M10: 2.0 m-kg (14.5 ft-lbs)
Engine Mounting Bolts: Front Upper	M10: 6.4 m-kg (46.3 ft-lbs)
Front Bracket	M10: 6.4 m-kg (46.3 ft-lbs)
Rear Lower	M10: 6.4 m-kg (46.3 ft-lbs)

Φ = Does Not Apply to This Model
NA = Information Not Available

* = Available from YPDI
⊕ = For Diagnostic Use Only

SERVICE LITERATURE

PUBLICATION	PART NUMBER	REMARKS
Owner's Manual	LIT-11626-05-16	
Service Manual	LIT-11616-04-55	Same as TT600N
Assembly Manual	LIT-11666-04-55	Supp. to SR/XT/TT/MX/DT Basic Assembly Manual (03-86)