




Ref No	Part No	Description
01	3TB-11101-01-00	Cylinder Head Assy
02	4H7-11133-10-00	• . Guide, Intake Valve
03	93440-12052-00	• . Circlip
04	90116-06475-00	Bolt, Stud
05	90116-10378-00	Bolt, Stud
06	99510-10114-00	Pin, Dowel
07	90340-14068-00	Plug, Straight Screw
08	93210-13657-00	O-ring
09	583-11127-00-00	Absorber 3
10	94701-00241-00	Plug, Spark
11	91317-06125-00	Bolt
12	91317-06115-00	Bolt
13	91317-06025-00	Bolt
14	91317-06040-00	Bolt
15	91317-06055-00	Bolt
16	90109-063E9-00	Bolt
17	91317-06050-00	Bolt
18	92907-06600-00	Washer, Plate
19	1L9-11186-00-00	Cover, Cylinder Head Side 2
20	93210-32172-00	O-ring
21	5Y1-11187-00-00	Cover, Cylinder Head Side 3
22	93210-62446-00	O-ring
23	91317-06018-00	Bolt
24	3YF-17800-00-00	Gear Unit Assy, Tacho. Drive
25	98707-06030-00	Screw, Flat Head
26	91317-06025-00	Bolt
27	90462-20217-00	Clamp
28	90109-06418-00	Bolt
29	90430-06014-00	Gasket
30	90338-22207-00	Plug

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TB-11310-00-00	Cylinder
02	93210-97524-00	O-ring
03	583-11127-00-00	Absorber 3
04	1VJ-11351-00-00	Gasket, Cylinder
05	90201-080L8-00	Washer, Plate
06	90176-08026-00	Nut, Crown
07	90201-10590-00	Washer, Plate
08	90179-10201-00	Nut
09	90201-10124-00	Washer, Plate
10	90179-10279-00	Nut
11	91317-06035-00	Bolt
12	2KF-11181-01-00	Gasket, Cylinder Head 1
13	91810-05018-00	Pin, Dowel
14	90105-08505-00	Bolt, Washer Based
15	90201-085L3-00	Washer, Plate
16	90430-08178-00	Gasket
17	99510-08016-00	Pin, Dowel

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TB-11400-00-00	Crankshaft Assy
02	1VJ-W1141-00-00	• . Crank 1
03	1VJ-11681-00-00	• . Pin, Crank 1
04	93310-635D4-00	• . Bearing
05	3TB-11651-00-00	• . Rod, Connecting
06	90280-16053-00	Key, Woodruff
07	90201-140A6-00	Washer, Plate
08	90179-14317-00	Nut
09	93306-30702-00	Bearing
10	3TB-11631-00-Y0	Piston (std)
10	3TB-11636-00-00	Piston (0.50mm O/s)
10	3TB-11638-00-00	Piston (1.00mm O/s)
11	34L-11610-00-00	Piston Ring Set
11	34L-11610-20-00	Piston Ring Set
11	34L-11610-40-00	Piston Ring Set
12	1JK-11633-01-00	Pin, Piston
13	93450-24028-00	Circlip
14	90201-301F4-00	Washer, Plate
15	34K-11565-02-00	Washer, Bearing Cover
16	3Y1-11496-01-00	Boss, Buffer
17	90501-22721-00	Spring, Compression
18	93605-10090-00	Pin, Dowel
19	2JT-11536-00-00	Gear, Drive
20	5Y1-11531-00-00	Gear, Balance Wt
21	34K-11454-00-00	Weight 1
22	93306-30525-00	Bearing
23	93306-30541-00	Bearing
24	93101-25106-00	Oil Seal
25	90282-05013-00	Key, Straight
26	34K-11145-00-00	Plate, Breather 2
27	90170-16343-00	Nut
28	90215-16242-00	Washer, Lock

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1VJ-12111-00-00	Valve, Intake
02	1VJ-12121-00-00	Valve, Exhaust
03	5Y1-12113-00-00	Spring, Valve Inner
04	5Y1-12114-00-00	Spring, Valve Outer
05	4H7-12116-00-00	Seat, Valve Spring
06	1J7-12119-01-00	Seal, Valve Stem
07	2F3-12117-00-00	Retainer, Valve Spring
08	1J7-12118-00-00	Cotter, Valve
09	34K-12151-00-00	Arm, Valve Rocker
10	34K-12161-00-00	Arm, Valve Rocker 2
11	34K-12162-00-00	Arm, Valve Rocker 3
12	34K-12163-00-00	Arm, Valve Rocker 4
13	2NX-12146-00-00	Shaft, Rocker
14	2NX-12156-00-00	Shaft, Rocker 2
15	2NX-12166-00-00	Shaft, Rocker 3
16	93210-08521-00	O-ring
17	90109-063E8-00	Bolt
18	2NX-12159-00-00	Screw, Valve Adjusting
19	90170-06128-00	Nut
20	90206-12075-00	Washer, Wave

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1JK-12171-00-00	Camshaft 1
02	3TB-12176-00-00	Sprocket, Cam Chain
03	90105-07087-00	Bolt, Washer Based
04	94590-27126-00	Chain
05	34K-12231-00-00	Guide, Stopper 1
06	34K-12241-00-00	Guide, Stopper 2
07	97017-06016-00	Bolt
08	92907-06600-00	Washer, Plate
09	3TB-12210-00-00	Tensioner Assy, Cam Chain
10	91317-06025-00	Bolt
11	4DW-12213-00-00	Gasket, Tensioner Case

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3AJ-13300-01-00	Oil Pump Assy
02	93210-13361-00	O-ring
03	91317-06035-00	Bolt
04	3AJ-13325-00-00	Gear, Pump Driven
05	99009-11400-00	Circlip
06	5Y1-W1343-00-00	Strainer Comp.
07	4DW-13415-00-00	Seal, Oil Strainer
08	98507-06016-00	Screw, Pan Head
09	5Y1-15427-01-00	Cover, Cap 2
10	98507-06016-00	Screw, Pan Head
11	90340-14132-00	Plug, Straight Screw
12	3SX-13329-00-00	Gasket, Pump Cover
13	214-11198-01-00	Gasket
14	4X7-13440-90-00	Element Assy, Oil Cleaner
15	4PT-13447-00-00	Cover, Oil Element
16	93210-64297-00	O-ring
17	93210-07135-00	O-ring
18	90109-06419-00	Bolt
19	91317-06080-00	Bolt
20	90149-05110-00	Screw
21	90430-05126-00	Gasket
22	3AJ-13161-00-00	Pipe, Delivery 1
23	90401-08133-00	Bolt, Union
24	90430-08204-00	Gasket
25	583-13113-00-00	Seat, Check Ball
26	93503-08007-00	Ball
27	90501-043E0-00	Spring, Compression
28	3TB-13464-00-00	Hose, Oil 1
29	93210-10197-00	O-ring
30	91317-06016-00	Bolt
31	90450-22052-00	Hose Clamp Assy
32	4PT-13465-00-00	Hose, Oil 2
33	93210-15171-00	O-ring
34	91317-06016-00	Bolt
35	90450-22052-00	Hose Clamp Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	43F-13586-01-00	Joint, Carburetor 1
02	1VJ-13596-00-00	Joint, Carburetor 2
02	2NF-13596-10-00	Joint, Carburetor 2
03	93210-36549-00	O-ring
04	16G-13569-00-00	Plug, Blind
05	90467-10039-00	Clip
06	90467-10039-00	Clip
07	90465-06020-00	Clamp
08	90460-46206-00	Clamp, Hose
09	3TB-14411-01-00	Case, Air Cleaner 1
10	3TB-81953-00-00	Stay, Relay
11	90267-40080-00	Rivet, Blind
12	92907-04600-00	Washer
13	3TB-14453-00-00	Joint, Air Cleaner 1
14	3TB-14454-00-00	Joint
15	3TB-1441A-00-00	Cover, Cleaner Case 1
16	90480-12325-00	Grommet
17	43G-14436-00-00	Hook
18	90267-40080-00	Rivet, Blind
19	92907-04600-00	Washer
20	97707-50520-00	Screw, Tapping
21	3TB-14451-01-00	Element, Air Cleaner
22	3TB-14412-00-00	Cap, Cleaner Case 1
23	3TB-14457-00-00	Seal
24	97707-50520-00	Screw, Tapping
25	3TB-1441E-00-00	Cover, Cleaner Case 2
26	3TB-1446R-00-00	Seal
27	98507-05020-00	Screw, Pan Head
28	92907-05600-00	Washer, Plate
29	5Y1-14419-00-00	Pipe
30	3TB-21621-00-00	Flap
31	90267-40077-00	Rivet, Blind
32	90201-047A2-00	Washer, Plate
33	92907-04200-00	Washer
34	3TB-14452-00-00	Seal
35	90445-126G6-00	Hose
36	90467-12052-00	Clip
37	34X-1443E-00-00	Pipe, Drain
38	90467-11106-00	Clip
39	90338-08174-00	Plug
40	90460-51059-00	Clamp, Hose
41	90460-58015-00	Clamp, Hose
42	95817-06020-00	Bolt, Flange
43	90387-06033-00	Collar
44	90480-14329-00	Grommet
45	95827-06025-00	Bolt, Flange
46	90387-074X3-00	Collar
47	90480-15064-00	Grommet
48	34X-21691-00-00	Flap
49	4PT-14462-00-00	Seal
50	89A-77214-00-00	Trim, Lower

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3YP-14301-12-00	Carburetor Assy 1
01	4AE-14301-02-00	Carburetor Assy 1
02	5Y1-14198-00-00	• . Gasket
03	360-24512-00-00	• . Gasket
04	2JN-14385-00-00	• . Float
05	6E5-25386-01-00	• . Collar, Sprocket Axle
06	5Y1-14384-00-00	• . Gasket, Float Chamber
07	98580-04016-00	• . Screw, Pan Head
08	98580-04014-00	• . Screw, Pan Head
09	92990-04100-00	• . Washer, Spring
10	1VJ-14197-00-00	• . Pipe
11	1JK-14357-00-00	• . Washer, Plain
12	214-24535-00-00	• . Screw, Lever Fitting
13	5Y1-14572-00-00	• . Plate, Stay
14	1XL-14131-00-00	• . Spring, Throttle Valve
15	5Y1-14356-00-00	• . Washer, Spring
16	5Y1-14358-00-00	• . Nut
17	5Y1-14536-00-00	• . Gasket
18	98580-04010-00	• . Screw, Pan Head
19	98580-04020-00	• . Screw, Pan Head
20	30X-14358-00-00	• . Nut
21	14T-14323-00-00	• . Screw, Air Adjusting
22	1VJ-14197-00-00	• . Pipe
23	1KJ-14940-01-00	• . Diaphragm Assy
24	2JN-14293-00-00	• . Cover 1
25	1JK-14291-00-00	• . Bracket 1
26	7KF-14227-00-00	• . Washer
27	92990-04100-00	• . Washer, Spring
28	1VJ-14286-00-00	• . Spring
29	4KF-14162-00-00	• . Bolt, Holding
30	5Y1-14349-00-00	• . Pipe
31	30X-14148-00-00	• . Pipe
32	98507-05010-00	• . Screw, Pan Head
33	98580-04010-00	• . Screw, Pan Head
34	5Y1-14149-00-00	• . Pipe
35	5Y1-14159-00-00	• . Clip
36	288-14343-68-00	• . Jet, Main (135)
36	283-14343-65-00	• . Jet, Main (130)
36	288-14343-60-00	• . Jet, Main (120)
36	288-14343-70-00	• . Jet, Main (140)
37	2KF-14341-00-00	• . Nozzle, Main
38	1JK-14313-55-00	• . Valve, Throttle 2
39	43F-14342-24-00	• . Jet, Pilot (48)
40	30X-14343-55-00	• . Jet, Main (110)
41	2KF-14355-00-00	• . Nozzle, Main 2
42	51Y-14105-00-00	• . Pilot Screw Set
43	2JN-14107-00-00	• . Needle Valve Set
44	3GV-1490K-00-00	• . Stop Screw Set
45	2NX-14103-00-00	• . Throttle Screw Set
46	1JK-1490A-00-00	• . Diaphragm Set, 1
47	3UW-1490J-10-00	• . Needle Set
48	3UW-1490J-00-00	• . Needle Set
49	2KF-1410A-00-00	• . Starter Set
50	3TD-14197-10-00	• . Pipe

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	34K-14611-01-00	Pipe, Exhaust 1
02	34K-14628-01-00	Protector, Exhaust Pipe
03	90164-06017-00	Screw, Tapping
04	4BD-14766-00-00	Washer, Protector
05	90206-06090-00	Washer, Wave
06	4PT-14711-00-00	Muffler 1
07	3YF-14755-00-00	Gasket, Silencer
08	91317-06012-00	Bolt
09	95027-08040-00	Bolt, Flange
10	1UJ-27114-00-00	Stopper, Main Stand
11	3TB-14728-00-00	Protector, Muffler 2
12	98980-06010-00	Screw, Bind
13	90206-06090-00	Washer, Wave
14	4BD-14766-00-00	Washer, Protector
15	4BD-14755-00-00	Gasket, Silencer
16	90109-082G0-00	Bolt
17	90105-10186-00	Bolt, Washer Based
18	90201-08326-00	Washer, Plate
19	90201-102J5-00	Washer, Plate
20	90179-06668-00	Nut
21	3YF-14613-01-00	Gasket, Exhaust Pipe
22	3TB-14752-10-00	Pipe, Outlet

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-15100-00-00	Crankcase Assy
02	90387-17783-00	Collar
03	90387-16782-00	Collar
04	99510-12016-00	Pin, Dowel
05	99510-08016-00	Pin, Dowel
06	93210-07135-00	O-ring
07	91317-06030-00	Bolt
08	91317-06045-00	Bolt
09	91317-06060-00	Bolt
10	90465-08344-00	Clamp
11	3TB-11166-00-00	Pipe, Breather 1
12	90467-14015-00	Clip
13	90467-17128-00	Clip
14	5Y1-15383-00-00	Plate, Bearing Cover
15	98707-06012-00	Screw, Flat Head
16	90116-10506-00	Bolt, Stud
17	99510-14016-00	Pin, Dowel
18	90116-10263-00	Bolt, Stud
19	99510-08016-00	Pin, Dowel
20	90430-08178-00	Gasket
21	3Y6-15167-00-00	Plug, Blind 1
22	3Y6-15144-00-00	Plate, Lock
23	97017-06016-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-15411-00-00	Cover, Crankcase 1
02	4DW-15451-00-00	Gasket, Crankcase Cover 1
03	99510-12016-00	Pin, Dowel
04	91317-06035-00	Bolt
05	91317-06025-00	Bolt
06	91317-06050-00	Bolt
07	91317-06050-00	Bolt
08	93210-13361-00	O-ring
09	90340-08M04-00	Plug, Straight Screw
10	90430-18143-00	Gasket
11	90340-36076-00	Plug, Straight Screw
12	93210-36510-00	O-ring
13	98507-06012-00	Screw, Pan Head
14	90462-16102-00	Clamp
15	4PT-15421-00-00	Cover, Crankcase 2
16	91317-06016-00	Bolt
17	4PT-15430-00-00	Crankcase Cover Assy 3
18	4PT-15418-00-00	Cover, Chain Case
19	1JK-15449-00-00	Ring, Rubber
20	1JK-15486-00-00	Grommet
21	90209-05279-00	Washer
22	98507-05010-00	Screw, Pan Head
23	4DW-15462-00-00	Gasket, Crankcase Cover 3
24	99510-12016-00	Pin, Dowel
25	91317-06025-00	Bolt
26	91317-06030-00	Bolt
27	91317-06035-00	Bolt
28	93101-14092-00	Oil Seal
29	4PT-15415-00-00	Cover, Generator
30	99510-08016-00	Pin, Dowel
31	91317-06035-00	Bolt
32	91317-06025-00	Bolt
33	4DW-15455-00-00	Gasket 1
34	90338-30096-00	Plug
35	90338-21100-00	Plug

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3YF-15515-00-00	Gear 3
02	90201-303P4-00	Washer, Plate
03	1VJ-15522-00-00	Shaft 2
04	93310-217R7-00	Bearing
05	1VJ-15517-00-00	Gear, Idler 2
06	1VJ-15521-00-00	Shaft 1
07	93310-212R6-00	Bearing
08	1VJ-15512-00-00	Gear, Idler 1
09	93310-530C7-00	Bearing
10	3TB-15590-01-00	Starter One-way Assy
11	3TB-15594-00-00	Race, One-way Bearing
12	93306-20006-00	Bearing
13	3TB-81800-01-00	Starting Motor Assy
14	1VJ-15511-00-00	• . Gear, Starting Motor
15	93440-11024-00	• . Circlip
16	3AJ-81801-00-00	• . Brush Set
17	26H-81847-00-00	• . O-ring
18	3AJ-81850-00-00	• . Armature Assy
19	3AJ-81830-00-00	• . Front Bracket Assy
20	3AJ-81820-00-00	• . Rear Bracket Assy
21	3AJ-81809-00-00	• . Washer Kit
22	4G0-81871-00-00	• . Cap
23	11H-81844-00-00	• . Gasket
24	95817-06030-00	• . Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3AJ-16111-00-00	Gear, Primary Drive (34z)
02	90282-07042-00	Key, Straight
03	90215-20197-00	Washer, Lock
04	90170-20274-00	Nut
05	3AJ-16150-00-00	Primary Driven Gear Comp. (71z)
06	2JN-16154-00-00	Plate, Thrust 1
07	4PT-16371-00-00	Boss, Clutch
08	5Y1-16321-00-00	Plate, Friction
09	360-16325-00-00	Plate, Clutch 2
10	5Y1-16331-01-00	Plate, Friction 2
11	5Y1-16331-01-00	Plate, Friction 2
12	90501-23142-00	Spring, Compression
13	90159-06010-00	Screw, With Washer
14	1W1-16358-01-00	Plate, Push
15	4PT-16356-00-00	Rod, Push 1
16	92907-06200-00	Washer
17	95317-06600-00	Nut
18	5Y1-16383-00-00	Spring, Clutch Boss
19	90215-20231-00	Washer, Lock
20	90170-20327-00	Nut
21	1VJ-16380-01-00	Push Lever Assy
22	93317-11020-00	Bearing
23	93315-11720-00	Bearing
24	93102-17357-00	Oil Seal
26	90149-08067-00	Screw
27	90201-17327-00	Washer, Plate
28	90508-14710-00	Spring, Torsion
29	5Y1-16357-00-00	Rod, Push 2
30	93515-32029-00	Ball

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4PT-17411-00-00	Axle, Main (12z)
02	34K-17141-00-00	Gear, 4th Pinion (22z)
03	90209-22191-00	Washer
04	93440-25084-00	Circlip
05	1VJ-17131-00-00	Gear, 3rd Pinion (20z)
06	2JT-17151-00-00	Gear, 5th Pinion (24z)
07	34K-17121-01-00	Gear, 2nd Pinion (17z)
08	93306-30540-00	Bearing (6305nrx1c3)
09	93306-00431-00	Bearing
10	2RW-17402-00-00	Drive Axle Assy
11	2JT-17221-00-00	Gear, 2nd Wheel (27z)
12	2JT-17251-00-00	Gear, 5th Wheel (19z)
13	1VJ-17231-00-00	Gear, 3rd Wheel (24z)
14	90208-22191-00	Washer, Conical Spring
15	93440-25084-00	Circlip
16	3AJ-17241-00-00	Gear, 4th Wheel (21z)
17	3AJ-17211-00-00	Gear, 1st Wheel (31z)
18	90201-20276-00	Washer, Plate (1.0d)
19	99009-20400-00	Circlip
20	90560-25283-00	Spacer
21	93306-30535-00	Bearing
22	93102-25226-00	Oil Seal
23	5Y1-17471-00-00	Plate, Cover
25	93306-00426-00	Bearing
26	99999-01798-00	
27	90215-23265-00	Washer, Lock
28	90179-18552-00	Nut
29	90560-20199-00	Spacer
30	99009-20400-00	Circlip


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4PT351-5150


Ref No	Part No	Description
01	3YF-18540-00-00	Shift Cam Assy
02	136-18542-00-00	• . Point, Neutral
03	93316-00501-00	• . Bearing
04	93604-10011-00	• . Pin, Dowel
05	90151-06017-00	Screw, Countersunk
06	4PT-18511-00-00	Fork, Shift 1
07	4PT-18512-00-00	Fork, Shift 2
08	4PT-18513-00-00	Fork, Shift 3
09	3YF-18531-00-00	Bar, Shift Fork Guide 1
10	3XV-18535-00-00	Bar, Shift Fork Guide 2
11	4PT-18140-00-00	Stopper Lever Assy
12	90508-26691-00	Spring, Torsion
13	4PT-18175-00-00	Spacer
14	90159-06078-00	Screw, With Washer

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	43F-18102-02-00	Shift Shaft Assy 2
02	5Y1-18101-02-00	Shift Shaft Assy
03	99006-10600-00	• . Circlip
04	90201-12474-00	Washer, Plate
05	34K-18120-00-00	Shift Lever Assy
06	90508-29629-00	• . Spring, Torsion
07	99001-09600-00	Circlip
08	93102-12016-00	Oil Seal (sd 12-22-5-hs)
09	93608-33046-00	Pin, Dowel
10	1VJ-18110-01-00	Shift Pedal Assy
11	1W6-18113-00-00	• . Cover, Shift Pedal
12	97027-06020-00	Bolt
13	97027-06020-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-21110-00-WL	Frame Comp.
02	95817-08012-00	• . Bolt, Flange
03	90201-08087-00	• . Washer, Plate
04	3TB-21756-00-00	• . Net, Filter
05	90430-22123-00	• . Gasket
06	95817-10070-00	Bolt, Flange
07	3TB-21316-00-90	Stay, Engine 3
08	95617-10200-00	Nut, Self-locking
09	34L-21315-00-00	Stay, Engine 2
10	97017-10080-00	Bolt
11	92907-10600-00	Washer, Plate
12	95617-10200-00	Nut, Self-locking
13	95817-10100-00	Bolt, Flange
14	95617-10200-00	Nut, Self-locking
15	3TB-W2147-00-WL	Protector, Engine
16	34K-21485-00-00	• . Damper, Rubber 1
17	34K-21486-00-00	• . Damper 2
18	90267-40080-00	• . Rivet, Blind
19	92907-04200-00	• . Washer
20	90480-15363-00	Grommet
21	90387-07391-00	Collar
22	95827-06025-00	Bolt, Flange
23	5Y1-21441-00-00	Bracket, Stop Switch
24	95027-06010-00	Bolt, Flange
25	3TB-22178-00-00	Tensioner
26	4V4-22184-00-00	Bush
27	90201-08753-00	Washer, Plate
28	95027-08016-00	Bolt, Flange
29	30X-22178-00-00	Tensioner
30	4V4-22184-00-00	Bush
31	90109-08075-00	Bolt
32	90201-13409-00	Washer, Plate
33	90201-08753-00	Washer, Plate
34	90387-085E1-00	Collar
35	3TB-21771-00-00	Body, Cap
36	90430-27124-00	Gasket
37	90445-115G3-00	Hose
38	90467-10008-00	Clip
39	3TB-28415-01-00	Damper 1


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	3TB-21511-60-00	Fender, Front
01	3TB-21511-70-00	Fender, Front
02	4PT-21569-00-00	Graphic 1
02	4PT-21569-10-00	Graphic 1
03	90387-06681-00	Collar
04	90119-06097-00	Bolt, With Washer
05	3TB-21521-01-00	Flap, Front Fender
06	90267-32071-00	Rivet, Blind
07	92907-03200-00	Washer
08	4PT-21611-00-00	Fender, Rear
08	4PT-21611-10-00	Fender, Rear
09	95027-06016-00	Bolt, Flange
10	90387-064J1-00	Collar
11	90119-06228-00	Bolt, With Washer
12	90176-06065-00	Nut, Crown
13	90387-06022-00	Collar
14	2KF-21685-11-00	Bracket, License
15	90119-06060-00	Bolt, With Washer
16	90387-066M3-00	Collar
17	42U-21639-00-00	Damper 2
18	4PT-2163A-00-00	Cover, Rear Fender 1
19	97007-06025-00	Bolt
20	97007-06025-00	Bolt
21	95617-06100-00	Nut, U
22	90480-13398-00	Grommet
23	1VJ-21621-00-00	Flap
24	98507-04012-00	Screw, Pan Head
25	92907-04200-00	Washer
26	95607-04100-00	Nut, U
27	3Y6-85130-02-00	Rear Reflector Assy
28	95707-05500-00	Nut, Flange
29	3YF-84751-00-00	Bracket, License
30	95027-06012-00	Bolt, Flange
31	90201-065F3-00	Washer, Plate
32	95317-06600-00	Nut
33	3TB-2164F-00-00	Stay 1
34	92017-08050-00	Bolt, Button Head
35	4PT-2174T-00-00	Insulator, Side Cover 2
36	99246-00080-00	Emblem, Yamaha
36	99247-00080-00	Emblem, Yamaha


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.






Ref No	Part No	Description
01	4PT-21711-00-00	Cover, Side 1
01	4PT-21711-10-00	Cover, Side 1
02	4PT-2173E-00-00	Graphic 1
02	4PT-2173E-10-00	Graphic 1
03	90387-07717-00	Collar
04	90149-06223-00	Screw
05	90480-01401-00	Grommet
06	4PT-21717-00-00	Damper
07	4PT-21721-00-00	Cover, Side 2
07	4PT-21721-10-00	Cover, Side 2
08	4PT-2174L-00-00	Graphic Set 2
08	4PT-2174L-10-00	Graphic Set 2
09	90201-06049-00	Washer, Plate
10	90387-06026-00	Collar
11	98907-06026-00	Screw, Bind
12	90480-01401-00	Grommet
13	4PT-2174A-00-00	Insulator, Side Cover
14	4PT-2174A-10-00	Insulator, Side Cover
15	4PT-2174A-20-00	Insulator, Side Cover
16	4PT-21717-00-00	Damper
17	3TB-28100-00-00	Tool Kit
18	46X-21376-00-00	Band, Tool

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-22110-00-35	Rear Arm Comp.
02	93315-22251-00	Bearing
03	90380-22111-00	Bush, Solid
04	93106-22019-00	Oil Seal (dc 22-28-8)
05	2K6-22128-01-00	Cover, Thrust 1
06	93108-35004-00	Oil Seal (35-41-8)
07	3YF-22149-00-00	Washer
08	1VJ-22123-00-00	Bush 1
09	38V-22199-00-00	Support, Chain
10	97027-06020-00	Bolt
11	90387-06737-00	Collar
12	4PT-22151-00-00	Seal, Guard
13	95807-06016-00	Bolt, Flange
14	90387-07789-00	Collar
15	90338-06143-00	Plug
16	91317-06060-00	Bolt
17	92907-06600-00	Washer, Plate
18	3TB-2217A-00-00	Arm, Relay
19	90387-20120-00	Collar
20	90380-14095-00	Bush, Solid
21	34L-22128-00-00	Cover, Thrust 1
22	90105-12668-00	Bolt, Washer Based
23	90201-140G9-00	Washer, Plate
24	90201-120A5-00	Washer, Plate
25	95617-12100-00	Nut, U
26	34L-2217F-00-00	Rod, Connecting 1
27	93315-31750-00	Bearing
28	90387-1206D-00	Collar
29	55K-22129-00-00	Cover, Thrust 2
30	90101-12498-00	Bolt
31	92907-12600-00	Washer
32	95617-12100-00	Nut, U
33	90386-20123-00	Bush
34	90387-122J6-00	Collar
35	90109-102G8-00	Bolt
36	90201-100F7-00	Washer, Plate
37	90185-10060-00	Nut, Self-locking
38	93700-06005-00	Nipple, Grease
39	93700-06M03-00	Nipple, Grease
40	3TB-22311-00-00	Case, Chain
42	1VJ-22141-00-00	Shaft, Pivot
43	90201-15238-00	Washer, Plate
44	90185-14070-00	Nut, Self-locking
45	3TB-22189-00-00	Boot, Rubber
46	34L-22117-00-00	Cap
47	90201-251F6-00	Washer, Plate (0.3d)
48	90461-12110-00	Clamp
49	95817-06012-00	Bolt, Flange
50	2KF-27491-00-00	Protector
51	95817-06010-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-22210-00-33	Shock Absorber Assy, Rear
02	34L-22226-01-00	• . Bush, Shock Absorber Lower
03	34L-22226-01-00	• . Bush, Shock Absorber Lower
04	90380-14130-00	• . Bush, Solid
05	90101-12295-00	Bolt
06	95617-12100-00	Nut, U
07	34L-22129-00-00	Cover, Thrust 2
08	90240-14106-00	Pin, Clevis
09	92907-14600-00	Washer
10	91490-30030-00	Pin, Cotter

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TB-2331E-00-00	Guide, Cable
02	93332-00079-00	Bearing
03	93332-00008-00	Bearing
04	4DN-23416-20-00	Cover, Ball Race 2
05	90179-25615-00	Nut
06	90202-26142-00	Washer, Plate
07	3YF-23418-00-00	Washer, Special
08	90176-22050-00	Nut, Crown
09	3LD-23318-00-00	Holder, Cable 1
10	98507-05020-00	Screw, Pan Head
11	92907-05600-00	Washer, Plate
12	95307-05600-00	Nut
13	4PT-Y2343-00-00	Crown, Handle
14	5A8-23434-01-00	• . Holder, Damper
15	95027-08040-00	• . Bolt, Flange
16	1E6-23441-00-00	Holder, Handle Upper
17	3Y6-23442-00-98	Holder, Handle Lower
18	90201-100A1-00	Washer, Plate
19	95617-10100-00	Nut, U
20	95817-08035-00	Bolt, Flange
21	4PT-23389-00-00	Guide, Cable

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-23102-00-00	Front Fork Assy (l.h)
02	4PT-23126-00-00	• . Tube, Outer (left)
03	26H-23156-00-00	• . Clip, Oil Seal
04	3BN-23145-00-00	• . Oil Seal
05	3JD-23125-L0-00	• . Metal, Slide 1
06	43F-23144-10-00	• . Seal, Dust
07	36Y-23146-10-00	• . Washer, Oil Seal
08	4PT-23110-00-00	• . Inner Tube Comp.1
09	3JD-23171-L0-00	•• .. Piston, Front Fork
10	3GM-23173-00-00	• . Spindle, Taper
11	4PT-23170-00-00	• . Cylinder Comp., Front Fork
12	4PT-23141-00-00	• . Spring, Front Fork
13	4DW-23149-00-00	• . Washer, Spring Upper
14	4PT-23118-00-00	• . Spacer
15	3EN-23111-50-00	• . Bolt, Cap
16	43F-23188-10-00	• . O-ring
17	509-23158-L0-00	• . Gasket
18	278-23181-50-00	• . Bolt, Hexagon Socket Head
19	4PT-23103-00-00	Front Fork Assy (r.h)
20	4PT-23136-00-00	• . Tube, Outer (right)
21	26H-23156-00-00	• . Clip, Oil Seal
22	3BN-23145-00-00	• . Oil Seal
23	3JD-23125-L0-00	• . Metal, Slide 1
24	43F-23144-10-00	• . Seal, Dust
25	36Y-23146-10-00	• . Washer, Oil Seal
26	4PT-23110-00-00	• . Inner Tube Comp.1
27	3JD-23171-L0-00	•• .. Piston, Front Fork
28	3GM-23173-00-00	• . Spindle, Taper
29	4PT-23170-00-00	• . Cylinder Comp., Front Fork
30	4PT-23141-00-00	• . Spring, Front Fork
31	4DW-23149-40-00	• . Washer, Spring Upper
32	4PT-23118-00-00	• . Spacer
33	3EN-23111-50-00	• . Bolt, Cap
34	43F-23188-10-00	• . O-ring
35	509-23158-L0-00	• . Gasket
36	278-23181-50-00	• . Bolt, Hexagon Socket Head
37	3XJ-23167-L0-00	• . Holder, Axle
38	2KF-23127-01-00	• . Nut, Outer Tube
39	2KF-23191-11-00	Boot
39	3TB-23191-11-00	Boot
40	43M-23192-L0-00	Band
41	98507-04018-00	Screw, Pan Head
42	4PT-23340-00-00	Under Bracket Comp.
43	95817-08055-00	Bolt, Flange
44	95701-08500-00	Nut, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4PT-24110-10-01	Fuel Tank Comp.
01	4PT-24110-10-02	Fuel Tank Comp.
02	4PT-24240-00-00	• . Graphic Set
02	4PT-24240-10-00	• . Graphic Set
03	3FY-24500-00-00	Fuel Cock Assy 1
04	3AJ-24523-00-00	• . Valve
05	3AJ-24534-00-00	• . Seal, Cock
06	98503-03008-00	• . Screw, Pan Head
07	4X8-24512-00-00	• . Gasket
08	95027-06016-00	Bolt, Flange
09	90202-05187-00	Washer, Plate
10	90445-10638-00	Hose
11	90467-09006-00	Clip
12	11H-24602-03-00	Cap Assy
13	3TB-24188-00-00	Mold, Fuel Tank
14	3TB-24181-00-00	Damper, Locating 1
15	4PT-24182-00-00	Damper, Locating 2
16	30X-24186-01-00	Washer, Special
17	95807-06016-00	Bolt, Flange
18	90387-060U2-00	Collar
19	30X-2137W-00-00	Scoop, Air 1
20	4PT-2137W-00-00	Scoop, Air 1
21	4PT-24246-00-00	Graphic 3
21	4PT-24246-10-00	Graphic 3
22	4PT-2137X-00-00	Scoop, Air 2
23	4PT-24247-00-00	Graphic
23	4PT-24247-10-00	Graphic
24	4PT-24181-00-00	Damper, Locating 1
25	4PT-24162-00-00	Emblem 2
26	90149-05299-00	Screw
27	90179-05523-00	Nut
28	3TB-2137Y-00-00	Guide, Air
29	90387-064J1-00	Collar
30	90149-06223-00	Screw
31	90480-13428-00	Grommet
32	4PT-2416F-00-00	Insulator, Fuel Tank 1
33	4PT-2416G-00-00	Insulator, Fuel Tank 2
34	4PT-2416F-10-00	Insulator, Fuel Tank 1
35	4PT-2414H-00-00	Damper, Plate 1
36	4PT-2414J-00-00	Damper, Plate 2
37	34M-2139X-00-00	Damper

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-24770-00-00	Semi-double Seat Assy
01	4PT-24770-10-00	Semi-double Seat Assy
02	4PT-24731-00-00	• . Cover, Seat
02	4PT-24731-10-00	• . Cover, Seat
03	3TB-24723-00-00	• . Damper, Seat
04	90119-06063-00	Bolt, With Washer
05	26H-21308-00-00	Helmet Hanger Assy
06	90149-06154-00	Screw

FWD


4PT351-5250

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3YF-25111-00-98	Hub, Front
02	90560-15240-00	Spacer
03	93306-20209-00	Bearing (b6202)
04	93102-20281-00	Oil Seal (2d 20-35-5)
05	3LP-2582T-00-00	Disc, Brake
06	90109-081F0-00	Bolt
07	94418-21492-00	Rim (1.85-21)
08	3TB-25104-00-00	Spoke Set, Front
09	94109-213X0-00	Tire (mcs 90/90-21 54s Tw41)
09	94109-213X1-00	Tire (90/90-21 54s Trailmax)
10	94209-21277-00	Tube (mcs 90/90-21 Tr-4)
11	94330-21084-00	Band, Rim (3.00-21)
12	90338-09130-00	Plug
13	156-25398-00-00	Balancer, Wheel
14	3YF-25336-00-00	Ring 2
15	90387-152J3-00	Collar
16	322-25118-00-00	Cover, Hub Dust
17	55U-25181-01-00	Axle, Wheel
18	34L-25190-01-00	Gear Unit Assy
19	4PT-2580T-00-00	Caliper Assy (left)
20	3TB-W0057-00-00	• . Piston Assy, Caliper
21	3GD-W0047-00-00	•• .. Caliper Seal Kit
22	1UY-25937-51-00	• . Boot 2
23	3JD-25917-00-00	• . Boot, Caliper
24	3TB-25919-00-00	• . Support, Pad
25	36Y-W0048-00-00	• . Bleed Screw Kit
26	4PT-W0045-00-00	• . Brake Pad Kit
27	3TB-25933-00-00	• . Pin, Pad
28	90105-10316-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2KF-25311-00-98	Hub, Rear
02	90387-173M5-00	Collar
03	146-25315-00-00	Flange, Spacer
04	93306-20310-00	Bearing (b6203du)
05	93102-25311-00	Oil Seal (fpj 25-44-8 Ts)
06	1VJ-25366-01-98	Clutch, Hub
07	93306-30416-00	Bearing (b6304)
08	1VJ-25377-00-00	Collar, Wheel
09	93106-30029-00	Oil Seal
10	4DN-25445-20-00	Sprocket, Driven (45z)
11	90116-10348-00	Bolt, Stud
12	90170-10219-00	Nut
13	5Y1-25412-00-00	Washer
14	5Y1-25364-00-00	Damper
15	3TB-25304-00-00	Spoke Set, Rear
16	94425-17491-00	Rim (2.50-17)
17	94112-173X2-00	Tire (mcs 120/90-17 64s Tw42)
17	94112-173X3-00	Tire (120/90-17-64s Trailmax)
18	94212-17264-00	Tube ((mcs 120/90
18	94212-17281-00	Tube (120/90.130/80-17)
19	94330-17158-00	Band, Rim (3.00-17)
20	156-25398-00-00	Balancer, Wheel
21	90338-09130-00	Plug
22	94581-45106-00	Chain (did520v2-106le)
23	3AJ-25381-00-00	Axle, Wheel
24	3Y1-25388-01-00	Puller, Chain 1
25	3Y1-25389-00-00	Puller, Chain 2
26	1VJ-25383-00-00	Collar, Wheel
27	90387-174F0-00	Collar
28	36R-25367-00-00	Cover, Hub Dust
29	2KF-25819-00-00	Bracket, Caliper
30	95817-10030-00	Bolt, Flange
31	90201-10437-00	Washer, Plate
32	90171-16024-00	Nut, Castle
33	91490-30030-00	Pin, Cotter
34	521-25188-00-00	Cap
35	90209-16138-00	Washer
36	4PT-2539F-00-00	Plate 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2KF-25831-50-00	Disc, Brake
02	90109-06757-00	Bolt
03	3TB-2580W-00-00	Caliper Assy, Rear 2
04	2KF-W0057-00-00	• . Piston Assy, Caliper
05	34X-W0047-00-00	•• .. Caliper Seal Kit
06	5R2-25937-00-00	• . Boot 2
07	34X-25937-00-00	• . Boot 2
08	51L-W0048-00-00	• . Bleed Screw Kit
09	34X-W0046-02-00	• . Brake Pad Kit 2
10	2GV-25926-00-00	• . Bolt
11	34X-25845-00-00	• . Cap, Indicator
12	2KF-25827-00-00	• . Shim, Caliper
13	2KF-25828-00-00	• . Shim, Caliper
14	4MA-25919-00-00	• . Support, Pad
15	90105-10638-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-26111-00-00	Handlebar
02	1LX-26242-00-00	Grip (right)
03	3Y1-26243-00-00	Tube, Throttle Guide
04	3Y1-26249-00-00	Ring, Leaf
05	55V-26241-00-00	Grip (left)
06	4PT-26302-00-00	Throttle Cable Assy
07	34K-26281-00-00	Cap, Grip Upper
08	1VJ-26282-00-00	Cap, Grip Lower
09	98507-05020-00	Screw, Pan Head
10	98507-05025-00	Screw, Pan Head
11	1E6-26342-00-00	Boot, Cable
12	3TB-26334-01-00	Cable, Starter 2
13	91317-06010-00	Bolt
14	90123-08046-00	Bolt
15	90179-08148-00	Nut
16	3TB-26280-00-00	Rear View Mirror Assy(left)
17	3TB-26290-00-00	Rear View Mirror Assy(right)
18	3BN-26141-20-00	Guard, Brush 1
18	2KF-26141-00-00	Guard, Brush 1
19	3TB-26142-60-00	Guard, Brush 2
19	3TB-26142-70-00	Guard, Brush 2
20	98517-06030-00	Screw, Pan Head
21	92907-06600-00	Washer, Plate
22	95307-06800-00	Nut
23	90387-06500-00	Collar
24	4PT-26246-00-00	End, Grip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TB-25870-00-00	Master Cylinder Sub Assy
02	23L-W0041-00-00	• . Cylinder Kit, Master
03	4L0-25854-00-00	• . Diaphragm, Reservoir
04	4H7-25852-00-00	• . Cap, Reservoir
05	98707-04012-00	• . Screw, Flat Head
06	4L0-25867-00-00	Bracket, Master Cylinder
07	3TB-25872-02-00	Hose, Brake 1
08	99999-02107-00	
09	95027-06025-00	Bolt, Flange
10	90401-10159-00	Bolt, Union
11	90201-10118-00	Washer, Plate
12	90461-16124-00	Clamp
13	95807-06016-00	Bolt, Flange
14	3TB-23318-00-00	Holder, Cable 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	214-27421-00-00	Footrest 2
02	34L-27412-00-00	Bracket, Footrest 1
03	90508-20023-00	Spring, Torsion
04	90240-08096-00	Pin, Clevis
05	91490-25020-00	Pin, Cotter
06	214-27413-00-00	Cover, Footrest
07	90105-10285-00	Bolt, Washer Based
08	214-27421-00-00	Footrest 2
09	2KF-27422-00-R4	Bracket, Footrest 2
10	90508-20023-00	Spring, Torsion
11	90240-08096-00	Pin, Clevis
12	91490-25020-00	Pin, Cotter
13	214-27413-00-00	Cover, Footrest
14	90105-10285-00	Bolt, Washer Based
15	4PT-27311-00-00	Stand, Side
16	90105-12616-00	Bolt, Washer Based
17	90185-12119-00	Nut, Self-locking
18	5Y1-27315-00-00	Link, Side Stand
19	90506-18224-00	Spring, Tension
20	90506-26225-00	Spring, Tension
21	1TX-28351-00-00	Body, Cowling
22	4PT-2741L-00-00	Bracket 4
23	90109-087F1-00	Bolt
24	4PT-2742L-00-00	Bracket 5
25	90109-087F1-00	Bolt
26	2GV-27431-00-00	Footrest, Rear 1
27	120-27433-00-00	Cover, Rear Footrest
30	91701-06040-00	Pin, Clevis
31	91490-20025-00	Pin, Cotter

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3UW-27211-02-00	Pedal, Brake
02	90201-14215-00	Washer, Plate
03	91401-30020-00	Pin, Cotter
04	90507-18055-00	Spring, Tension
05	4PT-2580E-00-00	Rear Master Cylinder Assy
06	4BA-W0042-50-00	Cylinder Kit, Master
07	95333-08600-00	Nut
08	2YK-27222-00-00	Joint
09	2YK-2582A-00-00	Joint
10	93210-15620-00	O-ring
11	2VN-25866-00-00	Circlip
12	3KW-27234-00-00	Pin, Brake Rod
13	92017-08020-00	Bolt, Button Head
14	90240-08124-00	Pin, Clevis
15	90201-08083-00	Washer, Plate
16	91490-16020-00	Pin, Cotter
17	4PT-25895-00-00	Hose, Reservoir
18	90467-14057-00	Clip
19	47X-25894-00-00	Tank, Reservoir
20	98517-06020-00	Screw, Pan Head
21	92907-06600-00	Washer, Plate
22	2KF-25852-50-00	Cap, Reservoir
23	3AJ-25888-00-00	Cover, Reservoir Tank
24	360-25854-00-00	Diaphragm, Reservoir
25	2GU-25855-00-00	Bush,diaphragm
26	4PT-25873-00-00	Hose, Brake 2
27	90401-10159-00	Bolt, Union
28	90201-10118-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4PT-W2834-00-00	Body, Cowling
01	4PT-W2834-10-00	Body, Cowling
02	4PT-28390-00-00	• . Graphic Set, Cowling
02	4PT-28390-10-00	• . Graphic Set, Cowling
03	8V7-21961-00-00	Patch 1
04	4PT-28217-00-00	Damper 1
05	90480-12053-00	Grommet
06	90149-06263-00	Screw
07	4PT-28365-00-00	Cover

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TB-81410-01-00	Stator Assy
02	3TB-81450-01-00	Rotor Assy
03	98517-06025-00	Screw, Pan Head
04	92907-06100-00	Washer, Spring
05	98507-05016-00	Screw, Pan Head
06	92907-05100-00	Washer, Spring
07	92907-05600-00	Washer, Plate
08	90110-08193-00	Bolt, Hexagon Socket Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TB-88310-01-00	
02	47J-88312-00-00	• .
03	306-83311-40-00	• . Bulb, Flasher (12v-21w)
04	97707-40620-00	• . Screw, Tapping
05	3TB-83320-01-00	Front Flasher Light Assy 2
06	47J-83322-00-00	• . Lens, Flasher 2
07	306-83311-40-00	• . Bulb, Flasher (12v-21w)
08	97707-40620-00	• . Screw, Tapping
09	18G-83365-00-00	Cap
10	4PT-83330-00-00	Rear Flasher Light Assy 1
11	2KF-83332-00-00	• . Lens, Flasher
12	97707-40620-00	• . Screw, Tapping
13	47J-83313-00-00	• . Gasket, Flasher Lens
14	306-83311-40-00	• . Bulb, Flasher (12v-21w)
15	4PT-83340-00-00	Flasher Light Assy 2
16	2KF-83342-00-00	• . Lens, Flasher 2
17	97707-40620-00	• . Screw, Tapping
18	47J-83313-00-00	• . Gasket, Flasher Lens
19	306-83311-40-00	Bulb, Flasher (12v-21w)
20	95317-12700-00	Nut
21	10V-83365-00-00	Cap

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	34L-83570-F1-00	Speedometer Assy
02	4G1-84744-00-00	• . Bulb (12v-3.4w)
03	5E2-83509-20-00	• . Socket Cord Assy
04	1VJ-83540-41-00	Tachometer Assy
05	4G1-84744-00-00	• . Bulb (12v-3.4w)
06	30X-83520-00-00	• . Socket Cord Assy
07	5Y1-83513-00-00	Damper
08	5Y1-83541-00-00	Damper
09	5Y1-83519-00-00	Bracket, Meter
10	1M1-83526-00-00	Damper 2
11	90201-05033-00	Washer, Plate
12	90468-10050-00	Clip
13	3ET-83550-01-00	Speedometer Cable Assy
14	4PT-83560-00-00	Tachometer Cable Assy
15	93210-14104-00	O-ring

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	3TB-84320-10-00	Lens Assy
02	2F9-84314-00-00	• . Bulb, Headlight (12v-60/55w)
03	4E2-84347-00-00	• . Bulb (`12v-4w)
04	3TB-84312-00-00	• . Holder, Socket
05	3TB-84325-00-00	• . Screw, Rim Fitting
06	341-84332-60-00	• . Spring, Screw
07	198-84334-60-00	• . Nut, Adjusting
08	3TB-8431R-00-00	• . Stay, Setting
09	4PT-84311-00-00	Body, Headlight
10	92017-08025-00	Bolt, Button Head
11	3TB-84329-00-00	Bolt, Wing 1
12	90202-06013-00	Washer, Plate
13	90468-12120-00	Clip
14	3TB-84137-00-00	Bolt, Special
15	90119-06097-00	Bolt, With Washer
16	90387-06388-00	Collar
17	90387-07391-00	Collar
18	90480-14023-00	Grommet

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1XL-84710-E0-00	Taillight Unit Assy
02	31L-84714-00-00	• . Bulb (12v-21/5w)
03	53V-84721-40-00	• . Lens, Taillight
04	34Y-84723-E0-00	• . Gasket, Tail Lens
05	97706-40530-00	• . Screw, Tapping
06	3TB-84717-01-00	Cord, Taillight
07	34X-84527-00-00	Damper
08	90387-07391-00	Collar
09	95707-06500-00	Nut, Flange

FWD

3T8351-0380


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.

HANDLE SWITCH. LEVER




Ref No	Part No	Description
01	1LN-82911-00-00	Holder, Lever 1
02	33G-82913-00-00	Holder, Lever Lower 1
03	3FY-83912-01-00	Lever 1
04	90109-06799-00	Bolt
05	95617-06100-00	Nut, U
06	98507-05020-00	Screw, Pan Head
07	92907-05100-00	Washer, Spring
08	3YR-83922-00-00	Lever 2
09	90109-062A8-00	Bolt
10	95617-06100-00	Nut, U
11	90149-06131-00	Screw
12	90170-06010-00	Nut
13	90501-10312-00	Spring, Compression
14	1MY-83969-00-00	Switch, Handle 5
15	98507-05030-00	• . Screw, Pan Head
16	98506-05040-00	• . Screw, Pan Head
17	4DW-83975-00-00	Switch, Handle 2
18	98507-05018-00	• . Screw, Pan Head
19	3WP-83980-00-00	Front Stop Switch Assy
20	437-83936-01-00	Band, Switch Cord

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	3TB-82305-10-00	Ignitor Unit Assy
02	4FL-85546-00-00	Band
03	3TB-82310-00-00	Ignition Coil Assy
04	90179-05523-00	Nut
05	97017-05025-00	Bolt
06	3TB-82316-01-00	Bracket, Ignition Coil
07	95817-06010-00	Bolt, Flange
08	371-82370-00-00	Plug Cap Assy
09	3TJ-81960-01-00	Rectifier & Regulator Assy
10	98517-06025-00	Screw, Pan Head
11	3PK-82100-00-00	Battery Assy Ytx9-bs 12v-8ah))
12	2T4-82131-00-00	Band, Battery
13	4PT-82115-00-00	Wire, Plus Lead
14	4PT-82116-00-00	Wire, Minus Lead
15	2UJ-82150-02-00	Fuse Holder Assy
16	148-82151-00-00	• . Fuse (20a)
17	4PU-82501-00-00	Main Switch Steering Lock
18	90109-080G5-00	Bolt
19	4PT-82590-10-00	Wire Harness Assy
20	8Y0-82599-00-00	Cover, Connecter
21	12R-82591-00-00	Band
22	90465-13355-00	Clamp
23	5Y1-82122-00-00	Seat, Battery

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4GY-82540-10-00	Neutral Switch Assy
02	90430-10148-00	Gasket
03	34L-82530-02-00	Stop Switch Assy
04	3LD-82566-40-00	Switch, Side Stand
05	98507-05016-00	Screw, Pan Head
06	3AY-81940-00-00	Starter Relay Assy
07	95707-06500-00	Nut, Flange
08	2GV-82917-00-00	Switch
09	25G-83936-00-00	Band, Switch Cord
10	90464-25217-00	Clamp
11	4MY-83350-00-00	Flasher Relay Assy
12	3BN-83371-00-00	Horn
13	95027-06010-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.