
PARTS CATALOGUE
MODEL YEAR 1995
YZF600RG (4NA1)
NON-CALIFORNIA MODEL


Frame Serial No.	4NA-000101 and following
Engine Serial No.	4NA-000101 and following

PUBLICATION	PART NUMBER	REMARKS
OWNER'S MANUAL	LIT-11626-09-23	
ASSEMBLY	LIT-11666-09-23	
SERVICE MANUAL	LIT-11616-09-23	



YAMAHA ONLINE Parts & Accessories

A1




4JH351-4010

CYLINDER HEAD

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-11101-00-00	CYLINDER HEAD ASSEMBLY .	1	
2	3TJ-11133-10-00	. GUIDE, INTAKE VALVE	16	
3	93440-07149-00	. CIRCLIP	16	
4	99510-08016-00	. PIN, DOWEL	12	
5	90340-12112-00	. PLUG, STRAIGHT SCREW ...	6	
6	90105-06384-00	. BOLT, WASHER BASED	24	
7	90338-08174-00	. PLUG	12	
8	90116-06437-00	BOLT, STUD	8	
9	90201-090P4-00	WASHER, PLATE	12	
10	90179-09612-00	NUT	12	
11	NGK-CR9E0-00-00	PLUG, SPARK (NGK R CR9E) .	4	
12	4JH-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
13	3TJ-11191-00-00	COVER, CYLINDER HEAD 1 ..	1	
14	3TJ-11193-00-00	GASKET, HEAD COVER 1	1	
15	90109-064F0-00	BOLT	8	
16	90209-11262-00	WASHER	8	
17	2GH-1111G-00-00	RUBBER, MOUNT 1	8	


CYLINDER



4JH351-4020

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-11311-00-00	CYLINDER 1	1	
2	91810-08016-00	PIN, DOWEL	2	
3	3TJ-11351-00-00	GASKET, CYLINDER	1	
4	90153-06045-00	SCREW, HEXAGON	2	
5	90430-06014-00	GASKET	2	


CRANKSHAFT



4JH351-4030

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-11411-00-00	CRANKSHAFT	1	
2	93101-29165-00	OIL SEAL	1	UR
	93101-29166-00	OIL SEAL	1	UR
3	1WG-11416-00-00	PLANE BEARING, CRANKSHAFT 1	12	UR BLUE
	1WG-11416-10-00	PLANE BEARING, CRANKSHAFT 1	12	UR BLACK
	1WG-11416-20-00	PLANE BEARING, CRANKSHAFT 1	12	UR BROWN
	1WG-11416-30-00	PLANE BEARING, CRANKSHAFT 1	12	UR GREEN
	1WG-11416-40-00	PLANE BEARING, CRANKSHAFT 1	12	UR YELLOW
	1WG-11416-50-00	PLANE BEARING, CRANKSHAFT 1	12	UR PINK
4	4JH-11631-00-00	PISTON (STD)	4	
5	4JH-11603-00-00	PISTON RING SET (STD)	4	
6	4JH-11633-00-00	PIN, PISTON	4	
7	90468-12069-00	CLIP	8	
8	4JH-11650-00-00	CONNECTING ROD ASSEMBLY	4	
9	4JH-11654-00-00	. BOLT, CONNECTING ROD	2	
10	90179-07652-00	. NUT	2	
11	1WG-11656-00-00	PLANE BEARING, CONNECTING ROD	8	UR BLUE
	1WG-11656-10-00	PLANE BEARING, CONNECTING ROD	8	UR BLACK
	1WG-11656-20-00	PLANE BEARING, CONNECTING ROD	8	UR BROWN
	1WG-11656-30-00	PLANE BEARING, CONNECTING ROD	8	UR GREEN

VALVE




1WG010-6040

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-12111-00-00	VALVE, INTAKE	8	
2	4JH-12121-00-00	VALVE, EXHAUST	8	
3	1WG-12116-00-00	SEAT, VALVE SPRING	16	
4	4JH-12113-00-00	SPRING, VALVE INNER	16	
5	3TJ-12117-00-00	RETAINER, VALVE SPRING	16	
6	1HX-12118-00-00	COTTER, VALVE	32	
7	1HX-12119-00-00	SEAL, VALVE STEM	16	
8	3FV-12153-09-00	LIFTER, VALVE (O/S)	16	UR GREEN
	3FV-12153-10-00	LIFTER, VALVE	16	UR YELLOW
9	1HX-12168-00-00	PAD, ADJUSTING 2 (1.20)	16	UR
	1HX-12168-20-00	PAD, ADJUSTING 2 (1.25)	16	UR
	1HX-12168-40-00	PAD, ADJUSTING 2 (1.30)	16	UR
	1HX-12168-60-00	PAD, ADJUSTING 2 (1.35)	16	UR
	1HX-12168-80-00	PAD, ADJUSTING 2 (1.40)	16	UR
	1HX-12168-A0-00	PAD, ADJUSTING 2 (1.45)	16	UR
	1HX-12168-F0-00	PAD, ADJUSTING 2 (1.50)	16	UR
	1HX-12168-H1-00	PAD, ADJUSTING 2 (1.55)	16	UR
	1HX-12168-K1-00	PAD, ADJUSTING 2 (1.60)	16	UR
	1HX-12168-M1-00	PAD, ADJUSTING 2 (1.65)	16	UR
	1HX-12168-R1-00	PAD, ADJUSTING 2 (1.70)	16	UR
	1HX-12168-U1-00	PAD, ADJUSTING 2 (1.75)	16	UR
	1HX-12168-W1-00	PAD, ADJUSTING 2 (1.80)	16	UR
	1HX-12168-Y1-00	PAD, ADJUSTING 2 (1.85)	16	UR
	1HX-12169-11-00	PAD, ADJUSTING 2 (1.90)	16	UR
	1HX-12169-31-00	PAD, ADJUSTING 2 (1.95)	16	UR
	1HX-12169-50-00	PAD, ADJUSTING 2 (2.00)	16	UR
	1HX-12169-70-00	PAD, ADJUSTING 2 (2.05)	16	UR
	1HX-12169-90-00	PAD, ADJUSTING 2 (2.10)	16	UR
	1HX-12169-E0-00	PAD, ADJUSTING 2 (2.15)	16	UR

CONTINUED ON NEXT FRAME ➤


VALVE




1WG010-6040

Ref. No.	Part Number	Description	Qty	Remarks
9	1HX-12169-G0-00	PAD, ADJUSTING 2 (2.20)	16	UR
	1HX-12169-J0-00	PAD, ADJUSTING 2 (2.25)	16	UR
	1HX-12169-L0-00	PAD, ADJUSTING 2 (2.30)	16	UR
	1HX-12169-N0-00	PAD, ADJUSTING 2 (2.35)	16	UR
	1HX-12169-T0-00	PAD, ADJUSTING 2 (2.40)	16	UR

CAMSHAFT






4JH351-4050

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-12171-00-00	CAMSHAFT 1	1	
2	4JH-12181-00-00	CAMSHAFT 2	1	
3	1WG-12176-00-00	SPROCKET, CAM CHAIN	2	
4	90105-07385-00	BOLT, WASHER BASED	4	
5	94581-32118-00	CHAIN (D.I.D. 215F DHA 118L)	1	
6	94681-32021-00	. JOINT, CHAIN (D.I.D.215F-LJ)	1	
7	3TJ-12241-00-00	GUIDE, STOPPER 2	1	
8	3GM-12210-00-00	TENSIONER ASSEMBLY, CAM CHAIN (1WG-12210-02-00)	1	
9	90109-112F1-00	BOLT	1	
10	4BE-12213-00-00	GASKET, TENSIONER CASE	1	
11	91316-06025-00	BOLT	2	
12	3HE-12251-00-00	DAMPER, CHAIN 1	1	
13	4JH-12252-00-00	DAMPER, CHAIN 2	1	
14	90109-065A8-00	BOLT	2	


WATER PUMP



4JH351-4060

Ref. No.	Part Number	Description	Qty	Remarks
1	3TJ-Y1242-00-00	WATER PUMP ASSEMBLY ...	1	
2	1WG-12439-00-00	. O-RING	1	
3	91311-06025-00	. BOLT, SOCKET HEAD	2	
4	95026-06012-00	. BOLT, FLANGE	1	
5	90430-06014-00	. GASKET	1	
6	93210-33133-00	. O-RING	1	
7	91316-06035-00	BOLT	2	
8	4JH-12481-00-00	PIPE 1	1	
9	93210-21190-00	O-RING	2	
10	91317-06010-00	BOLT	2	
11	1WG-12446-01-00	JOINT	1	
12	93210-17746-00	O-RING	2	
13	91316-06040-00	BOLT, SOCKET HEAD	3	
14	91316-06025-00	BOLT	1	
15	4JH-12482-00-00	PIPE 2	1	
16	93210-15566-00	O-RING	2	
17	91316-06010-00	BOLT, SOCKET HEAD	2	
18	3TJ-12576-00-00	HOSE 1	1	
19	90450-32051-00	HOSE CLAMP ASSEMBLY ...	2	
20	4JH-12577-00-00	HOSE 2	1	
21	90450-32051-00	HOSE CLAMP ASSEMBLY ...	2	
22	4JH-12410-00-00	THERMOSTAT ASSEMBLY ...	1	
23	3TJ-12417-00-00	HOUSING, THERMOSTAT	1	
24	3TJ-12413-00-00	COVER, THERMOSTAT	1	
25	91311-06020-00	BOLT, SOCKET HEAD	2	


RADIATOR - HOSE



4JH351-4070

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-12461-00-00	RADIATOR ASSEMBLY	1	
2	4JH-12462-00-00	CAP, RADIATOR	1	
3	4JH-12405-00-00	BLOWER ASSEMBLY	1	
4	95811-06010-00	BOLT, FLANGE	3	
5	4JH-12578-00-00	HOSE 3	1	
6	90450-32051-00	HOSE CLAMP ASSEMBLY	2	
7	3TJ-12579-00-00	HOSE 4	1	
8	90450-17036-00	HOSE CLAMP ASSEMBLY	2	
9	4JH-12588-00-00	HOSE 5	1	
10	90450-17036-00	HOSE CLAMP ASSEMBLY	2	
11	4JH-1243A-00-00	HOSE 1	1	
12	90467-11090-00	CLIP	2	
13	90480-15363-00	GROMMET	3	
14	90387-07391-00	COLLAR	3	
15	95816-06025-00	BOLT, FLANGE	3	
16	90201-063J2-00	WASHER, PLATE	3	
17	90445-095E9-00	HOSE	1	
18	90467-08003-00	CLIP	2	
19	4JH-1244F-00-00	BRACKET 1	1	
20	4JH-2142K-00-00	BRACKET, RADIATOR	1	
21	95811-06012-00	BOLT, FLANGE	2	


OIL PUMP



4JH351-4080

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-13330-00-00	PUMP SHAFT ASSEMBLY	1	
2	1WG-13316-00-00	COVER, PUMP	1	
3	90201-113K2-00	WASHER, PLATE	1	
4	93603-17070-00	PIN, DOWEL	1	
5	1WG-13310-00-00	ROTOR ASSEMBLY 1	1	
6	93603-09106-00	PIN, DOWEL	2	
7	1WG-13336-00-00	HOUSING, ROTOR	1	
8	98580-06020-00	SCREW	1	
9	99510-08012-00	PIN, DOWEL	1	
10	1WG-13329-00-00	GASKET, PUMP COVER	1	
11	90110-06130-00	BOLT, HEXAGON SOCKET HEAD	3	
12	3TJ-13412-00-00	HOUSING, STRAINER	1	
13	4H7-13411-02-00	STRAINER, OIL	1	
14	90110-06225-00	BOLT, HEXAGON SOCKET HEAD	2	


OIL COOLER



4JH351-4090


Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-13470-00-00	OIL COOLER ASSEMBLY	1	
2	90401-20158-00	BOLT, UNION	1	
3	3FV-13440-00-00	ELEMENT ASSEMBLY, OIL CLEANER	1	
4	11H-13490-00-00	RELIEF VALVE ASSEMBLY	1	
5	93210-10096-00	O-RING	1	
6	4JH-13417-00-00	COVER, STRAINER	1	
7	3HE-13414-10-00	GASKET, STRAINER COVER	1	
8	91316-06025-00	BOLT	14	
9	99510-08016-00	PIN, DOWEL	2	
10	3VD-13455-00-00	PLUG	1	
11	214-11198-01-00	GASKET	1	
12	90465-10306-00	CLAMP	1	
13	3HE-13161-00-00	PIPE, DELIVERY 1	1	
14	91316-06012-00	BOLT, SOCKET HEAD	1	
15	90401-10106-00	BOLT, UNION	2	
16	90430-10171-00	GASKET	4	

INTAKE



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-13586-00-00	JOINT, CARBURETOR 1	2	
2	4JH-13596-00-00	JOINT, CARBURETOR 2	2	
3	91316-06020-00	BOLT, SOCKET HEAD	8	
4	90450-52074-00	HOSE CLAMP ASSEMBLY	4	
5	4JH-14411-00-00	CASE, AIR CLEANER 1	1	
6	4JH-14421-00-00	CASE, AIR CLEANER 2	1	
7	4FM-14452-00-00	SEAL	1	
8	97780-50125-00	SCREW, TAPPING	10	
9	4JH-14451-00-00	ELEMENT, AIR CLEANER	1	
10	4JH-14412-00-00	CAP, CLEANER CASE 1	1	
11	36F-14452-00-00	SEAL	1	
12	4JH-14453-00-00	JOINT, AIR CLEANER 1	4	
13	90460-59213-00	CLAMP, HOSE	4	
14	90445-11452-00	HOSE	1	
15	90467-10008-00	CLIP	3	
16	4X7-2149Y-00-00	FILTER ASSEMBLY	1	
17	90445-075G7-00	HOSE	1	
18	98580-05530-00	SCREW, PAN HEAD	2	
19	92901-05600-00	WASHER, PLATE	2	
20	4JH-14467-00-00	SEAL	1	
21	90445-09488-00	HOSE	1	
22	90445-09496-00	HOSE	1	
23	90467-08092-00	CLIP	1	
24	90445-09683-00	HOSE	1	
25	90445-090E5-00	HOSE	1	
26	90338-05240-00	PLUG	3	
27	90467-08017-00	CLIP	7	


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
1	4NA-14901-00-00	CARBURETOR ASSEMBLY 1 .	1	
2	4NA-14902-00-00	CARBURETOR ASSEMBLY 2 .	1	
3	4NA-14903-00-00	CARBURETOR ASSEMBLY 3 .	1	
4	4NA-14904-00-00	CARBURETOR ASSEMBLY 4 .	1	
5	4JH-14216-00-00	. SCREW	3	UR #3
	4JH-14216-00-00	. SCREW	4	4
6	4JH-14933-00-00	. SPRING, DIAPHRAGM	1	
7	4JH-14940-00-00	. DIAPHRAGM ASSEMBLY . . .	1	
8	4JH-14515-00-00	. JET	1	
9	4JH-14936-00-00	. SEAT, SPRING	1	
10	4NA-14916-00-00	. NEEDLE	1	
11	4JH-1414G-00-00	. PIPE, MAIN BLEED	1	
12	3TJ-14943-81-00	. JET, MAIN (#118)	1	
13	4JH-14948-01-00	. JET (#35)	1	
14	4NA-14105-00-00	. PILOT SCREW SET	1	
15	4JH-14107-00-00	. NEEDLE VALVE SET	1	
16	3TJ-14216-40-00	. SCREW	1	
17	4JH-14985-00-00	. FLOAT	1	
18	663-14548-00-00	. PIN, FLOAT ARM	1	
19	98580-04008-00	. SCREW, PAN HEAD	1	
20	4JH-14984-00-00	. GASKET, FLOAT CHAMBER .	1	
21	3TJ-14191-40-00	. PLUG, DRAIN	1	
22	98503-04014-00	. SCREW, PAN HEAD	4	
23	4JH-1410A-00-00	. STARTER SET	1	
24	4MM-14118-00-00	. CAP	1	
25	4JH-14922-00-00	SCREW, THROTTLE	1	
26	4JH-14934-00-00	SPRING, THROTTLE STOP . . .	1	
27	4JH-14429-00-00	SCREW	1	
28	4JH-14162-00-00	BOLT, HOLDING	1	

CONTINUED ON NEXT FRAME ➤


CARBURETOR



4NA110-5110

Ref. No.	Part Number	Description	Qty	Remarks
29	4JH-14358-00-00	NUT	1	
30	4JH-14325-00-00	SCREW, PAN HEAD	8	
31	4JH-14121-00-00	SCREW, THROTTLE STOP	3	
32	7A9-14555-00-00	SPRING	3	
33	4JH-14133-00-00	SPRING, THROTTLE STOP	3	
34	4JH-14487-00-00	SPRING	2	
35	90202-06056-00	WASHER, PLATE	6	
36	3TJ-14245-40-00	SCREW, GUIDE	3	
37	4JH-14565-00-00	SCREW	1	
38	4JH-14264-00-00	COLLAR	1	
39	4JH-14567-00-00	SCREW	1	
40	4JH-14935-00-00	SPRING	1	
41	4JH-14350-00-00	PIPE ADAPTOR ASSEMBLY	2	
42	4JH-13918-00-00	PIPE T	1	
43	4JH-14197-00-00	PIPE	2	
44	4JH-14294-00-00	HOSE	1	
45	4JH-14298-00-00	PIPE	1	
46	4JH-14137-00-00	CLIP	4	
47	3TJ-14148-40-00	PIPE	2	
48	3TJ-14937-40-00	CLIP	2	
49	4JH-1440F-00-00	JOINT, AIR FILTER 1	4	
50	4JH-14561-00-00	O-RING	4	
51	4JH-14245-00-00	SCREW, GUIDE	8	
52	90445-142H0-00	HOSE	1	
53	90467-13123-00	CLIP	2	


EXHAUST



4JH351-4120

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-14602-00-00	EXHAUST PIPE COMP.	1	
2	90101-06576-00	. BOLT	4	
3	92907-06600-00	. WASHER, PLATE	4	
4	3YF-14613-01-00	GASKET, EXHAUST PIPE	4	
5	90179-06499-00	NUT	8	
6	95816-08030-00	BOLT, FLANGE	1	
7	90201-08730-00	WASHER, PLATE	1	
8	4NA-14710-00-00	MUFFLER ASSEMBLY 1	1	
9	3XW-14714-00-00	. GASKET, MUFFLER	1	
10	95816-08025-00	. BOLT, FLANGE	1	
11	95821-08020-00	BOLT, FLANGE (95801-08020)	1	

CRANKCASE




4JH351-4130

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-15100-00-00	CRANKCASE ASSEMBLY	1	
2	11H-15138-00-00	. NOZZLE 1	1	
3	26H-15138-00-00	. NOZZLE 1	1	
4	99510-12016-00	. PIN, DOWEL	1	
5	4JH-15138-00-00	. NOZZLE 1	1	
6	93210-12152-00	. O-RING	1	
7	2H7-15361-00-00	. GAUGE, LEVEL	1	
8	36Y-15189-00-00	. PLUG	2	
9	93210-16629-00	. O-RING	2	
10	90201-237K5-00	. WASHER, PLATE	1	
11	93315-32516-00	. BEARING	1	
12	91810-08016-00	PIN, DOWEL	2	
13	90116-09583-00	BOLT, STUD	2	
14	90116-09584-00	BOLT, STUD	10	
15	90105-08630-00	BOLT, WASHER BASED	12	
16	90201-087K3-00	WASHER, PLATE	12	
17	95816-06040-00	BOLT	10	
18	95816-06050-00	BOLT, FLANGE	5	
19	95816-06070-00	BOLT, FLANGE	3	
20	95816-06080-00	BOLT, FLANGE	1	
21	95816-06090-00	BOLT, FLANGE	2	
22	95816-08070-00	BOLT, FLANGE	1	
23	90430-06166-00	GASKET	1	
24	90465-10307-00	CLAMP	1	
25	90465-10308-00	CLAMP	1	
26	4JH-11165-00-00	PLATE, BREATHER	1	
27	98511-06012-00	SCREW, PAN HEAD	2	
28	3HE-11145-00-00	PLATE, BREATHER 2	1	
29	98511-06012-00	SCREW, PAN HEAD	4	


CONTINUED ON NEXT FRAME ➤

CRANKCASE



Ref. No.	Part Number	Description	Qty	Remarks
30	1WG-11166-00-00	PIPE, BREATHER 1	1	
31	90467-14015-00	CLIP	2	
32	90445-116E9-00	HOSE	1	
33	90465-06289-00	CLAMP	1	
34	90467-10038-00	CLIP	1	
35	4JH-15381-00-00	PLATE, BEARING COVER	1	
36	91316-06012-00	BOLT, SOCKET HEAD	2	
37	3HE-15105-00-00	NOZZLE ASSEMBLY (3HE-15105-01-00)	2	
38	93210-06632-00	O-RING	2	

CRANKCASE COVER 1




4JH351-4140

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-15411-00-00	COVER, CRANKCASE 1	1	
2	1L9-15417-00-00	COVER, CAP	1	
3	1WG-15316-00-00	DAMPER, ENGINE MOUNT 1	1	
4	1WG-15427-00-00	COVER, CAP 2	1	
5	98901-05008-00	SCREW, BIND	4	
6	3HE-15451-10-00	GASKET, CRANKCASE COVER 1	1	
7	3HE-15467-10-00	GASKET	1	
8	99510-08016-00	PIN, DOWEL	2	
9	90110-06149-00	BOLT, HEXAGON SOCKET HEAD	4	
10	90110-06148-00	BOLT, HEXAGON SOCKET HEAD	1	
11	4JH-15421-00-00	COVER, CRANKCASE 2	1	
12	4JH-15461-00-00	GASKET, CRANKCASE COVER 2	1	
13	99510-08016-00	PIN, DOWEL	2	
14	91311-06025-00	BOLT, SOCKET HEAD	2	
15	91311-06035-00	BOLT, SOCKET HEAD	4	
16	91311-06045-00	BOLT	1	
17	4JH-15431-00-00	COVER, CRANKCASE 3	1	
18	1WG-15425-00-00	COVER, GENERATOR 2	1	
19	1WG-15326-00-00	DAMPER, ENGINE MOUNT 2	1	
20	98901-05008-00	SCREW, BIND	4	
21	4JH-15462-00-00	GASKET, CRANKCASE COVER 3	1	
22	99510-08016-00	PIN, DOWEL	2	
23	91311-06025-00	BOLT, SOCKET HEAD	8	
24	91311-06035-00	BOLT, SOCKET HEAD	2	
25	3F9-15362-00-00	PLUG, OIL LEVEL	1	


CONTINUED ON NEXT FRAME ➤

CRANKCASE COVER 1



4JH351-4140

Ref. No.	Part Number	Description	Qty	Remarks
26	93210-27778-00	O-RING	1	
27	4JH-15415-00-00	COVER, GENERATOR	1	
28	90340-08M04-00	PLUG, STRAIGHT SCREW	1	
29	99510-08016-00	PIN, DOWEL	2	
30	91311-06025-00	BOLT, SOCKET HEAD	3	
31	91311-06035-00	BOLT, SOCKET HEAD	1	
32	91311-06035-00	BOLT, SOCKET HEAD	1	
33	90462-10182-00	CLAMP	1	
34	98580-06010-00	SCREW, PAN HEAD (92503-06010)	1	
35	4JH-14413-00-00	STAY	1	




3HE332-9160

STARTER


Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-15521-00-00	SHAFT 1	1	
2	3HE-15512-00-00	GEAR, IDLER 1	1	
3	3HE-15517-00-00	GEAR, IDLER 2	1	
4	3TJ-15521-00-00	SHAFT 1	2	
5	3HE-15590-01-00	STARTER ONE-WAY ASSEMBLY	1	
6	3HE-15524-00-00	WHEEL, STARTER	1	
7	91316-08020-00	BOLT	3	
8	4JH-15515-00-00	GEAR 3	1	
9	90280-16053-00	KEY, WOODRUFF	1	
10	90201-107K6-00	WASHER, PLATE	1	
11	90105-10445-00	BOLT, WASHER BASED	1	
12	93306-20005-00	BEARING (B6200)	1	NTN

CLUTCH



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-16150-00-00	PRIMARY DRIVEN GEAR COMP.	1	
2	1WG-16154-00-00	PLATE, THRUST 1	1	
3	4JH-16371-00-00	BOSS, CLUTCH	1	
4	4JH-16321-00-00	PLATE, FRICTION	9	
5	1LX-16324-00-00	PLATE, CLUTCH 1	8	
6	93306-00105-00	BEARING (B6001)	1	
7	4JH-16351-00-00	PLATE, PRESSURE 1	1	
8	90501-224J9-00	SPRING, COMPRESSION	6	
9	90159-06092-00	SCREW, WITH WASHER	6	
10	4JH-16356-00-00	ROD, PUSH 1	1	
11	93210-48364-00	O-RING	1	
12	90215-18225-00	WASHER, LOCK	1	
13	90170-18221-00	NUT	1	
14	93109-08058-00	OIL SEAL (SD07 8-21-5.5 HS)	1	
15	4JH-16357-00-00	ROD, PUSH 2	1	
16	93505-16006-00	BALL	1	
17	4JH-16340-00-00	PUSH LEVER ASSEMBLY	1	
18	1WG-16304-00-00	BALL SCREW HOUSING ASSEMBLY	1	
19	90113-08021-00	BOLT, SET	1	
20	90179-08179-00	NUT	1	
21	90506-11488-00	SPRING, TENSION	1	
22	90157-05065-00	SCREW, PAN HEAD	2	
23	132-16346-00-00	HOOK, SPRING	1	
24	90387-212R3-00	COLLAR	1	
25	1WG-16164-00-00	PLATE, THRUST 2	1	
26	1WG-16181-00-00	SPACER 1	1	
27	93310-345R8-00	BEARING	1	

TRANSMISSION




4JH351-4170

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-17411-00-00	AXLE, MAIN (13T)	1	
2	4JH-17151-00-00	GEAR, 5TH PINION (21T)	1	
3	90209-22191-00	WASHER	1	
4	93440-25084-00	CIRCLIP	1	
5	4JH-17131-00-00	GEAR, 3RD/4TH PINION (22T/21T)	1	
6	4JH-17161-00-00	GEAR, 6TH PINION (27T)	1	
7	4JH-17121-00-00	GEAR, 2ND PINION (19T)	1	
8	93306-37208-00	BEARING	1	
9	93440-54152-00	CIRCLIP	1	
10	93306-20464-00	BEARING	1	
11	4JH-17421-00-00	AXLE, DRIVE	1	
12	93305-20509-00	BEARING	1	
13	90201-25291-00	WASHER, PLATE	1	
14	4JH-17221-00-00	GEAR, 2ND WHEEL (37T)	1	
15	90209-27336-00	WASHER	1	
16	93440-30077-00	CIRCLIP	1	
17	4JH-17261-00-00	GEAR, 6TH WHEEL (29T)	1	
18	4JH-17231-00-00	GEAR, 3RD WHEEL (34T)	1	
19	4JH-17241-00-00	GEAR, 4TH WHEEL (28T)	1	
20	90209-22191-00	WASHER	1	
21	93440-25084-00	CIRCLIP	1	
22	4JH-17251-00-00	GEAR, 5TH WHEEL (25T)	1	
23	4JH-17211-00-00	GEAR, 1ST WHEEL (37T)	1	
24	90387-2504A-00	COLLAR	1	
25	93102-35368-00	OIL SEAL	1	
26	3HE-17460-00-00	SPROCKET, DRIVE (15T)	1	
27	90215-21022-00	WASHER, LOCK	1	
28	90179-18020-00	NUT	1	

CONTINUED ON NEXT FRAME ➤


TRANSMISSION



4JH351-4170

Ref. No.	Part Number	Description	Qty	Remarks
29	93440-52014-00	CIRCLIP	1	
30	90201-20276-00	WASHER, PLATE (1.0T)	1	
31	93311-42045-00	BEARING (20NG3315NE)	1	
32	278-17425-00-00	CIRCLIP 2	1	
33	4G0-17433-01-00	NOZZLE	1	


SHIFT CAM



4JH351-4180

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-18540-00-00	SHIFT CAM ASSEMBLY	1	
2	90501-06022-00	. SPRING, COMPRESSION	1	
3	278-18542-00-00	. POINT, NEUTRAL	1	
4	278-18566-00-00	. PLATE, SIDE 2	1	
5	98701-05012-00	. SCREW, FLAT HEAD	1	
6	4JH-18531-00-00	BAR, SHIFT FORK GUIDE 1	1	
7	4JH-18535-00-00	BAR, SHIFT FORK GUIDE 2	1	
8	4JH-18511-00-00	FORK, SHIFT 1	1	
9	4JH-18512-00-00	FORK, SHIFT 2	1	
10	4JH-18513-00-00	FORK, SHIFT 3	1	
11	1WG-18536-00-00	STOPPER, SHIFT BAR	1	
12	1HX-18127-00-00	STOPPER, SCREW	1	
13	90508-23707-00	SPRING, TORSION	1	
14	1WG-18562-00-00	PLATE, STOPPER 2	1	
15	36Y-18140-00-00	STOPPER LEVER ASSEMBLY	1	
16	90109-063F7-00	BOLT	1	
17	95811-06016-00	BOLT, FLANGE (95822-06016)	2	


SHIFT SHAFT



4JH351-4190

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-18101-00-00	SHIFT SHAFT ASSEMBLY	1	
2	90508-32682-00	. SPRING, TORSION	1	
3	93102-12321-00	OIL SEAL, SD-TYPE	1	
4	90560-12211-00	SPACER	1	
5	93109-12053-00	OIL SEAL (SDO 12/18/4-1)	2	
6	4JH-18110-00-00	SHIFT PEDAL ASSEMBLY	1	
7	2H9-18154-00-00	. COVER, DUST	1	
8	132-18113-01-00	. COVER, SHIFT PEDAL	1	
9	4JH-18130-00-00	SHIFT SHAFT ASSEMBLY	1	
10	2H9-18154-00-00	. COVER, DUST	1	
11	97011-06020-00	BOLT	1	
12	4JH-18115-00-00	ROD, SHIFT	1	
13	90170-08358-00	NUT	1	
14	95303-08700-00	NUT	1	

FRAME




Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-21110-00-T9	FRAME COMP.	1	COMPETITION SILVER
2	4FM-21645-01-00	STAY, REAR	1	
3	90338-16148-00	PLUG	2	
4	95811-08016-00	BOLT, FLANGE	2	
5	95811-08035-00	BOLT, FLANGE (95821-08035)	2	
6	91311-10045-00	BOLT	2	
7	91311-10050-00	BOLT	2	
8	95811-10025-00	BOLT, FLANGE	2	
9	90387-115V8-00	COLLAR	2	
10	90105-10130-00	BOLT, WASHER BASED	1	
11	95701-10500-00	NUT, FLANGE (95702-10500)	3	
12	95822-10175-00	BOLT, FLANGE	1	
13	90201-10774-00	WASHER, PLATE	1	
14	4JH-21359-00-00	BRACKET, COIL	2	
15	95811-06012-00	BOLT, FLANGE	4	
16	4JH-21488-00-00	DAMPER	2	
17	3TJ-82131-00-00	BAND, BATTERY	2	
18	4JH-2117M-00-00	COVER 2	1	
19	4JH-21208-00-00	SEAL SET, 1	1	
20	4JH-21209-00-00	SEAL SET, 2	1	
21	4JH-2117N-01-00	COVER 3	1	
22	4JH-21446-00-00	STAY, MUFFLER 2	1	
23	36Y-21639-00-00	DAMPER 2	4	
24	98506-06016-00	SCREW, PANHEAD	2	
25	92906-06600-00	WASHER	2	
26	90480-18171-00	GROMMET	1	
27	4FM-21871-00-00	TANK, RECOVERY	1	
28	90159-06033-00	SCREW, WITH WASHER	2	
29	4L0-21875-00-00	CAP	1	


CONTINUED ON NEXT FRAME ➤

FRAME

Ref. No.	Part Number	Description	Qty	Remarks
30	1AA-21874-00-00	GASKET	1	
31	90445-08786-00	HOSE	1	
32	90467-08003-00	CLIP	1	



FENDER




4NA110-5220

Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-Y2151-11-P1	FRONT FENDER COMP.	1	DARK BLUE COCKTAIL 2
2	4FM-21569-30-00	. GRAPHIC 1	1	
3	90154-06061-00	SCREW, BINDING	2	
4	95811-06016-00	BOLT, FLANGE (95822-06016) .	2	
5	90480-12072-00	GROMMET	2	
6	90387-065J6-00	COLLAR	2	
7	90387-087L0-00	COLLAR	2	
8	4FM-28372-00-00	DAMPER	2	
9	4FM-21611-12-00	FENDER, REAR	1	
10	90119-06118-00	BOLT, WITH WASHER	2	
11	90119-06205-00	BOLT, WITH WASHER	2	
12	3VD-21366-00-00	HOOK, TOOL BAND	2	
13	90267-40054-00	RIVET, BLIND	4	
14	90201-044A2-00	WASHER, PLATE	4	
15	3YX-21376-00-00	BAND, TOOL	1	
16	35T-24724-00-00	DAMPER, SEAT	2	
17	90338-10132-00	PLUG	1	
18	5H0-8235Y-M0-00	DAMPER, LOCATING 5 (2GH-24185-00-00)	2	
19	4G0-21639-00-00	DAMPER 2	1	
20	3XV-21778-00-00	DAMPER, LOCATING 1	1	
21	90464-09130-00	CLAMP	1	
22	1VJ-14426-00-00	DAMPER 2	1	
23	4FM-85132-00-00	BRACKET, REFLECTOR 1	1	
24	90267-40076-00	RIVET, BLIND	2	
25	90201-044A2-00	WASHER, PLATE	2	
26	90480-10258-00	GROMMET	2	
27	1WG-28100-01-00	TOOL KIT	1	


CONTINUED ON NEXT FRAME ➤

FENDER



Ref. No.	Part Number	Description	Qty	Remarks
28	4JH-21650-00-00	REAR FENDER COMP.	1	
29	90119-06194-00	BOLT, WITH WASHER	3	
30	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	1	
31	95701-05500-00	NUT, FLANGE	1	
32	4FM-21688-00-00	BRACKET, REAR STAY	2	
33	90267-40076-00	RIVET, BLIND	4	
34	90201-044A2-00	WASHER, PLATE	4	
35	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	2	
36	95701-05500-00	NUT, FLANGE	2	


SIDE COVER



4NA110-5230

Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-Y2171-11-P3	COVER, SIDE 1	1	DARK BLUE COCKTAIL 2
2	3GM-21575-00-00	. SEAL 1	1	
3	4FM-2173T-00-00	. TAPE 1	1	
4	90480-13398-00	. GROMMET	2	
5	4FM-2173L-30-00	. GRAPHIC SET 1	1	
6	4FM-21781-10-00	. EMBLEM 1	1	
7	90150-06036-00	SCREW, ROUND HEAD	2	
8	90159-06093-00	SCREW, WITH WASHER	1	
9	4FM-Y2172-11-P3	COVER, SIDE 2	1	DARK BLUE COCKTAIL 2
10	3GM-21576-00-00	. SEAL 2	1	
11	4FM-2173T-00-00	. TAPE 1	1	
12	90480-13398-00	. GROMMET	2	
13	4FM-2174L-30-00	. GRAPHIC SET 2	1	
14	4FM-21781-10-00	. EMBLEM 1	1	
15	3TU-2178A-00-00	LABEL	1	
16	3TU-2178A-00-00	LABEL	1	
17	90150-06036-00	SCREW, ROUND HEAD	2	
18	90159-06093-00	SCREW, WITH WASHER	1	
19	90183-04064-00	NUT, SPRING	1	
20	97707-40010-00	SCREW, TAPPING	1	
21	90480-04166-00	GROMMET	2	
22	4NA-2179V-00-00	PLATE, EPA 1	1	

REAR ARM




4JH351-4230

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-22110-00-T9	REAR ARM COMP.	1	COMPETITION SILVER
2	47X-22184-00-00	BUSH	1	
3	93320-32403-00	BEARING	2	
4	90201-161J3-00	WASHER, PLATE	2	
5	4X7-22129-00-00	COVER, THRUST 2	2	
6	1UY-22141-00-00	SHAFT, PIVOT	1	
7	90185-16127-00	NUT, SELF-LOCKING	1	
8	90201-160F6-00	WASHER, PLATE	1	
9	3GM-2217A-00-00	ARM, RELAY	1	
10	3GM-2217M-00-00	ARM 1	2	
11	90101-12673-00	BOLT	2	
12	90387-126T1-00	COLLAR	2	
13	90201-126A7-00	WASHER, PLATE	2	
14	95611-12100-00	NUT, U	2	
15	93317-41761-00	BEARING	4	
16	90105-10727-00	BOLT, WASHER BASED	1	
17	90387-100T8-00	COLLAR	1	
18	93317-42060-00	BEARING	1	
19	90101-10659-00	BOLT	1	
20	90387-124W2-00	COLLAR	2	
21	90201-101J1-00	WASHER, PLATE	2	
22	95601-10100-00	NUT, U (95602-10100-00)	2	
23	93101-16131-00	OIL SEAL	2	
24	93399-99919-00	BEARING	1	
25	4JH-22311-00-00	CASE, CHAIN	1	
26	90119-06194-00	BOLT, WITH WASHER	1	
27	90154-05013-00	SCREW, BINDING	2	
28	90183-05024-00	NUT, SPRING	2	
29	4JH-22151-00-00	SEAL, GUARD	1	

CONTINUED ON NEXT FRAME ➤


REAR ARM



4JH351-4230

Ref. No.	Part Number	Description	Qty	Remarks
30	97313-06014-00	BOLT, HEXAGON	2	
31	90387-062M9-00	COLLAR	2	

REAR SUSPENSION




Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-22210-10-00	SHOCK ABSORBER ASSEMBLY, REAR	1	
2	90387-124T2-00	COLLAR	1	
3	90109-10554-00	BOLT	1	
4	90201-101J1-00	WASHER, PLATE	1	
5	95601-10100-00	NUT, U (95602-10100-00)	1	

FWD

4JH351-4240


STEERING



4JH351-4250

Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00001-00	BEARING	1	
2	93332-00008-00	BEARING	1	
3	3HE-23416-00-00	COVER, BALL RACE 2	1	
4	90179-25033-00	NUT	2	
5	90202-26142-00	WASHER, PLATE	1	
6	26H-23418-01-00	WASHER, SPECIAL	1	
7	90176-22050-00	NUT, CROWN	1	
8	4JH-23435-00-00	CROWN, HANDLE	1	
9	91311-08030-00	BOLT	2	


FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-23102-00-00	FRONT FORK ASSEMBLY (L.H)	1	
2	4JH-23126-00-00	. TUBE, OUTER (LEFT)	1	
3	4JH-23110-00-00	. INNER TUBE COMP 1	1	
4	4JH-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
5	3GM-23125-50-00	. METAL, SLIDE 1	1	
6	36Y-23146-10-00	. WASHER, OIL SEAL	1	
7	3SP-23145-L0-00	. OIL SEAL	1	
8	26H-23156-00-00	. CLIP, OIL SEAL	1	
9	3XV-23144-50-00	. SEAL, DUST	1	
10	3GM-23173-00-00	. SPINDLE, TAPER	1	
11	509-23158-L0-00	. GASKET	1	
12	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
13	4JH-23141-00-00	. SPRING, FRONT FORK	1	
14	3EN-23149-50-00	. WASHER, SPRING UPPER	1	
15	3FW-23118-00-00	. SPACER	1	
16	4JH-23149-00-00	. WASHER, SPRING UPPER	1	
17	4JH-23111-00-00	. BOLT, CAP	1	
18	43F-23188-10-00	. O-RING	1	
19	91311-10045-00	. BOLT	1	
20	4JH-23103-00-00	FRONT FORK ASSEMBLY (R.H)	1	
21	4JH-23136-00-00	. TUBE, OUTER (RIGHT)	1	
22	4JH-23110-00-00	. INNER TUBE COMP 1	1	
23	4JH-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
24	3GM-23125-50-00	. METAL, SLIDE 1	1	
25	36Y-23146-10-00	. WASHER, OIL SEAL	1	
26	3SP-23145-L0-00	. OIL SEAL	1	
27	26H-23156-00-00	. CLIP, OIL SEAL	1	


CONTINUED ON NEXT FRAME ➤

FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
28	3XV-23144-50-00	. SEAL, DUST	1	
29	3GM-23173-00-00	. SPINDLE, TAPER	1	
30	509-23158-L0-00	. GASKET	1	
31	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
32	4JH-23141-00-00	. SPRING, FRONT FORK	1	
33	3EN-23149-50-00	. WASHER, SPRING UPPER	1	
34	3FW-23118-00-00	. SPACER	1	
35	4JH-23149-00-00	. WASHER, SPRING UPPER	1	
36	4JH-23111-00-00	. BOLT, CAP	1	
37	43F-23188-10-00	. O-RING	1	
38	91311-10045-00	. BOLT	1	
39	4JH-23340-00-00	UNDER BRACKET COMP.	1	
40	91311-12030-00	BOLT	2	

FUEL TANK




4NA110-5280

Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-24110-30-04	FUEL TANK COMP.	1	DARK BLUE COCKTAIL 2
2	4FM-24240-11-00	. GRAPHIC SET	1	
3	99227-00160-00	. EMBLEM, YAMAHA	2	
4	4FM-24191-00-00	BRACKET, FUEL TANK 1	1	
5	90176-06055-00	NUT, CROWN	1	
6	2GH-24181-00-00	DAMPER, LOCATING 1	1	
7	2GH-24183-00-00	DAMPER, LOCATING 3	1	
8	2GH-24186-00-00	WASHER, SPECIAL	1	
9	90387-06553-00	COLLAR	2	
10	97011-06025-00	BOLT (97001-06025)	2	
11	92995-06100-00	WASHER, SPRING	2	
12	95816-06075-00	BOLT, FLANGE	1	
13	33M-24182-01-00	DAMPER, LOCATING 2	1	
14	3Y6-24183-00-00	DAMPER, LOCATING 3	1	
15	4FM-24187-00-00	WASHER, SPECIAL	1	
16	95811-08035-00	BOLT, FLANGE (95821-08035) .	1	
17	4JH-24183-00-00	DAMPER, LOCATING 3	2	
18	3FV-24500-01-00	FUEL COCK ASSEMBLY 1 . . .	1	
19	4X8-24512-00-00	. O-RING	1	
20	90149-06008-00	SCREW	2	
21	90202-05187-00	WASHER, PLATE	2	
22	4FM-13910-00-00	FUEL PUMP ASSEMBLY	1	
23	4FM-2414G-00-00	SEAL	1	
24	98580-05016-00	SCREW, PAN HEAD	6	
25	92990-05100-00	WASHER, SPRING	6	
26	92901-05600-00	WASHER, PLATE	6	
27	4FM-24602-00-00	CAP ASSEMBLY	1	
28	90110-05112-00	BOLT, HEXAGON SOCKET HEAD	3	

CONTINUED ON NEXT FRAME ➤


FUEL TANK



4NA110-5280


Ref. No.	Part Number	Description	Qty	Remarks
29	91311-05010-00	BOLT, SOCKET HEAD	1	
30	90445-107H3-00	HOSE	1	
31	90467-09006-00	CLIP	1	

SEAT



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-24710-00-00	SINGLE SEAT ASSEMBLY ...	1	
2	4JH-24711-00-00	. COVER, SINGLE SEAT	1	
3	278-27114-00-00	. STOPPER, MAIN STAND	4	
4	4FM-24780-00-00	SEAT LOCK ASSEMBLY	1	
5	91002-06016-00	BOLT, FLANGE	2	
6	88T-77198-00-00	DAMPER 1	1	
7	4FM-24750-00-00	TANDEM SEAT ASSEMBLY ...	1	
8	4FM-24751-00-00	. COVER, TANDEM SEAT	1	
9	509-24724-00-00	. DAMPER, SEAT	2	
10	4BP-24780-00-00	SEAT LOCK ASSEMBLY	1	
11	4BP-24792-00-00	PLATE	1	
12	95701-06500-00	NUT, FLANGE	2	
13	4FM-2478E-00-00	CABLE, SEAT LOCK	1	
14	3CK-W2470-00-00	SEAT LOCK ASSEMBLY	1	
15	4FM-2117K-00-00	STAY, LOCK	1	
16	90149-06308-00	SCREW	2	
17	4FM-Y2479-30-P3	COVER, SEAT	1	DARK BLUE COCKTAIL 2
18	4FM-2478M-10-00	. GRAPHIC, SEAT	1	
19	4FM-24786-10-00	. EMBLEM	2	
20	4FM-2475J-00-00	BRACKET, SEAT LEVER 2 ...	1	
21	4FM-2475H-00-00	BRACKET, SEAT LEVER 1 ...	1	


FRONT WHEEL



4JH351-4290

Ref. No.	Part Number	Description	Qty	Remarks
1	3TJ-25168-00-P0	CAST WHEEL, FRONT	1	UR DEEP REDDISH PURPLE SOLID 1
2	93102-23252-00	OIL SEAL	1	
3	93306-20314-00	BEARING (B6203)	2	
4	90560-17358-00	SPACER	1	
5	341-25149-00-00	CLUTCH, METER	1	
6	341-25846-00-00	RETAINER, CLUTCH	1	
7	93105-45017-00	OIL SEAL	1	
8	94112-1703B-00	TIRE (120/60ZR17 BT50F)	1	BRIDGESTONE
9	93900-00030-00	VALVE, RIM	1	
10	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UR
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	UR
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	UR
11	4HM-25190-00-00	GEAR UNIT ASSEMBLY	1	
12	90387-177V5-00	COLLAR	1	
13	4JH-25181-00-00	AXLE, WHEEL	1	
14	92990-14200-00	WASHER, PLAIN	1	
15	90170-14415-00	NUT	1	


FRONT BRAKE CALIPER



4JH351-4300

Ref. No.	Part Number	Description	Qty	Remarks
1	4HM-2581T-00-00	DISC BRAKE ASSEMBLY	2	
2	90109-08718-00	BOLT	12	
3	3HE-2580T-60-00	CALIPER ASSEMBLY (LEFT) ..	1	
4	3HE-W0057-50-00	. PISTON ASSEMBLY, CALIPER	2	
5	3HE-W0047-50-00	. . CALIPER SEAL KIT	2	
6	3GM-W0045-02-00	. BRAKE PAD KIT	1	
7	3GM-25919-00-00	. SUPPORT, PAD	1	
8	3HE-25924-00-00	. PIN, PAD	2	
9	3GM-25925-00-00	. CLIP	2	
10	1J3-W0048-00-00	. BLEED SCREW KIT	1	
11	1KT-25836-00-00	. COVER, DUST	1	
12	3HE-2580U-60-00	CALIPER ASSEMBLY (RIGHT) .	1	
13	3HE-W0057-50-00	. PISTON ASSEMBLY, CALIPER	2	
14	3HE-W0047-50-00	. . CALIPER SEAL KIT	2	
15	3GM-W0045-02-00	. BRAKE PAD KIT	1	
16	3GM-25919-00-00	. SUPPORT, PAD	1	
17	3HE-25924-00-00	. PIN, PAD	2	
18	3GM-25925-00-00	. CLIP	2	
19	1J3-W0048-00-00	. BLEED SCREW KIT	1	
20	1KT-25836-00-00	. COVER, DUST	1	
21	90105-10638-00	BOLT, WASHER BASED	4	
22	4FM-21596-00-00	HOLDER	1	

REAR WHEEL




4JH351-4310

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-25338-00-P0	CAST WHEEL, REAR	1	UR DEEP REDDISH PURPLE SOLID 1
2	93306-20469-00	BEARING	2	
3	93102-28022-00	OIL SEAL	1	
4	90387-2004F-00	COLLAR	1	
5	4FM-25364-00-00	DAMPER	6	
6	94116-1703F-00	TIRE (160/60ZR17 BT50R)	1	BRIDGESTONE
7	93900-00030-00	VALVE, RIM	1	
8	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UR
9	4FM-25366-00-00	CLUTCH, HUB	1	
10	93306-20644-00	BEARING	1	
11	93102-40211-00	OIL SEAL	1	
12	90387-2004E-00	COLLAR	1	
13	4JH-25447-00-00	SPROCKET, DRIVEN (47T)	1	
14	90116-10575-00	BOLT, STUD	6	
15	95601-10200-00	NUT, SELF-LOCKING	6	
16	94581-59108-00	CHAIN (DID50VA7-108LE)	1	
17	3XW-25388-00-00	PULLER, CHAIN 1	2	
18	4JH-22174-00-00	END 1	2	
19	92901-08600-00	WASHER	2	
20	95333-08600-00	NUT	4	
21	4JH-25371-00-00	BAR, TENSION	1	
22	90105-08321-00	BOLT, WASHER BASED	2	
23	95701-08500-00	NUT, FLANGE	2	
24	91490-20020-00	PIN, COTTER	2	
25	3GM-25381-A0-00	AXLE, WHEEL	1	
26	95601-18200-00	NUT, SELF-LOCKING	1	
27	4JH-25384-00-00	WASHER, WHEEL	1	
28	4JH-25384-10-00	WASHER, WHEEL	1	


CONTINUED ON NEXT FRAME ➤

REAR WHEEL



4JH351-4310

Ref. No.	Part Number	Description	Qty	Remarks
29	90387-2004C-00	COLLAR	1	
30	90387-2004D-00	COLLAR	1	




4JH351-4320

REAR BRAKE CALIPER

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-2582W-00-00	DISC, REAR BRAKE 2	1	
2	90109-081F0-00	BOLT	6	
3	3HE-2580W-10-00	CALIPER ASSEMBLY, REAR 2	1	
4	31A-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
5	31A-W0047-00-00	. . CALIPER SEAL KIT	1	
6	1FK-W0046-02-00	. BRAKE PAD KIT 2	1	
7	29L-25919-A0-00	. SUPPORT, PAD	1	
8	3HE-25924-00-00	. PIN, PAD	2	
9	3HE-25925-00-00	. CLIP	2	
10	1J3-W0048-00-00	. BLEED SCREW KIT	2	
11	42H-25836-00-00	. COVER, DUST	1	
12	1FK-25827-00-00	. SHIM, CALIPER	1	
13	1FK-25828-00-00	. SHIM, CALIPER	1	
14	4JH-25819-00-00	BRACKET, CALIPER	1	
15	90105-10638-00	BOLT, WASHER BASED	2	


STEERING HANDLE



4JH351-4330

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-26121-00-00	BOSS, HANDLEBAR (L.H)	1	
2	4JH-26122-00-00	BOSS, HANDLEBAR (R.H)	1	
3	91311-06020-00	BOLT, SOCKET HEAD	4	
4	4JH-26111-00-00	BAR, HANDLE (L.H)	1	
5	4JH-26112-00-00	BAR, HANDLE (R.H)	1	
6	91316-08025-00	BOLT, SOCKET HEAD	2	
7	341-23469-00-00	CAP, BOLT	2	
8	91311-06025-00	BOLT, SOCKET HEAD	2	
9	10L-23469-00-00	CAP, BOLT	2	
10	36Y-26246-00-00	END, GRIP	2	
11	4FM-26241-00-00	GRIP (LEFT)	1	
12	4JD-26240-00-00	GRIP ASSEMBLY	1	
13	4JH-26302-00-00	THROTTLE CABLE ASSEMBLY	1	
14	3LN-26270-01-00	CABLE CONNECTOR CAP ASSEMBLY	1	
15	98506-05020-00	. SCREW, PAN HEAD	1	
16	98586-05025-00	. SCREW, PAN HEAD (98506-05025-00)	1	
17	4JH-26335-00-00	CABLE, CLUTCH	1	
18	4JH-26331-00-00	CABLE, STARTER 1	1	
19	90179-08316-00	NUT	1	
20	90123-08083-00	BOLT	1	
21	4JH-83940-00-00	STARTER ASSEMBLY	1	
22	1WG-83941-00-00	. LEVER, STARTER	1	
23	90209-10131-00	. WASHER	1	
24	98906-06008-00	. SCREW, BIND	1	
25	95826-06010-00	BOLT, FLANGE	1	

FRONT MASTER CYLINDER




4NA110-5350

Ref. No.	Part Number	Description	Qty	Remarks
1	3GM-W2587-50-00	MASTER CYLINDER SUB ASSEMBLY	1	
2	3GM-W0041-50-00	. CYLINDER KIT, MASTER	1	
3	93210-15620-00	. O-RING	1	
4	2VN-25866-00-00	. CIRCLIP	1	
5	3FV-2589A-00-00	. COVER, DUST	1	
6	56A-25867-00-00	BRACKET, MASTER CYLINDER	1	
7	97016-06025-00	BOLT	2	
8	92906-06600-00	WASHER	2	
9	3TJ-83922-00-00	LEVER 2	1	
10	3FV-2589F-00-00	BOLT, LEVER	1	
11	95616-06100-00	NUT, U	1	
12	3FV-25894-00-00	TANK, RESERVOIR	1	
13	3GM-25852-50-00	CAP, RESERVOIR	1	
14	3FV-25854-00-00	DIAPHRAGM, RESERVOIR	1	
15	2J2-25855-50-00	BUSH, DIAPHRAGM	1	
16	3FV-83980-00-00	FRONT STOP SWITCH ASSEMBLY	1	
17	98511-04012-00	SCREW, PAN HEAD	1	
18	92990-04100-00	WASHER, SPRING	1	
19	92901-04600-00	WASHER, PLATE	1	
20	3GM-2585F-00-00	HOSE	1	
21	3PA-24356-00-00	CLIP, PIPE 1	2	
22	3FV-2589G-00-00	HOLDER	1	
23	3GM-2589H-00-00	SCREW	1	
24	4JH-26292-00-00	STAY	1	
25	91316-06012-00	BOLT, SOCKET HEAD	2	
26	4JH-2134K-00-00	BRACKET, HORN	1	
27	95816-06012-00	BOLT, FLANGE	2	

CONTINUED ON NEXT FRAME ➤


FRONT MASTER CYLINDER



4NA110-5350

Ref. No.	Part Number	Description	Qty	Remarks
28	4JH-25872-00-00	HOSE, BRAKE 1	1	
29	4JH-25873-00-00	HOSE, BRAKE 2	1	
30	90461-10132-00	CLAMP	2	
31	95816-06012-00	BOLT, FLANGE	2	
32	90401-10160-00	BOLT, UNION	1	
33	90401-10159-00	BOLT, UNION	2	
34	90201-10118-00	WASHER, PLATE	7	
35	4NA-25875-00-00	HOLDER, BRAKE HOSE 1	1	
36	4NA-25876-00-00	HOLDER, BRAKE HOSE 2	1	
37	95816-06012-00	BOLT, FLANGE	2	

STAND




4JH351-4350

Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-27311-00-00	STAND, SIDE	1	
2	90109-104E6-00	BOLT	1	
3	90185-10037-00	NUT, SELF-LOCKING	1	
4	90506-18224-00	SPRING, TENSION	1	
5	90506-26225-00	SPRING, TENSION	1	
6	4FM-27315-00-00	LINK, SIDE STAND	1	
7	1TX-27351-00-00	GUIDE, SIDE STAND	1	
8	4JH-27410-00-00	FRONT FOOTREST ASSEMBLY (LEFT)	1	
9	3YX-27413-00-00	. COVER, FOOTREST	1	
10	90159-05122-00	. SCREW, WITH WASHER	2	
11	3HE-27435-00-00	. BOLT	1	
12	4JH-27420-00-00	FRONT FOOTREST ASSEMBLY (RIGHT)	1	
13	3YX-27413-00-00	. COVER, FOOTREST	1	
14	90159-05122-00	. SCREW, WITH WASHER	2	
15	3HE-27435-00-00	. BOLT	1	
16	4FM-27442-00-00	BRACKET 2	1	
17	4FM-27443-00-00	BRACKET 3	1	
18	4BP-27434-01-00	BOLT	1	
19	90201-08326-00	WASHER, PLATE	1	
20	90201-127J6-00	WASHER, PLATE	1	
21	90179-10247-00	NUT	2	
22	90506-20377-00	SPRING, TENSION	1	
23	90446-17346-00	HOSE	1	
24	91311-08025-00	BOLT, SOCKET HEAD	4	
25	3XV-27431-00-00	FOOTREST, REAR 1	1	
26	3XV-27441-10-00	FOOTREST, REAR 2	1	
27	90501-12743-00	SPRING, COMPRESSION	2	


CONTINUED ON NEXT FRAME ➤

STAND



Ref. No.	Part Number	Description	Qty	Remarks
28	93501-04011-00	BALL	2	
29	1HX-27437-00-00	WASHER, SPECIAL	4	
30	90387-064H8-00	COLLAR	2	
31	91311-06045-00	BOLT	2	
32	95601-06100-00	NUT, U	2	
33	1HX-27415-00-00	PLATE, FOOTREST	2	
34	4JH-2741L-01-00	BRACKET 4	1	
35	4JH-2742L-01-00	BRACKET 5	1	
36	95811-08035-00	BOLT, FLANGE (95821-08035)	2	


REAR MASTER CYLINDER



4JH351-4360

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-27211-00-00	PEDAL, BRAKE	1	
2	22N-18113-00-00	COVER, SHIFT PEDAL	1	
3	3YF-27261-00-00	SHAFT	1	
4	90201-104R2-00	WASHER, PLATE	1	
5	90206-14086-00	WASHER, WAVE	1	
6	4BH-2583V-00-00	RR. MASTER CYLINDER ASSEMBLY.	1	
7	4BH-W0042-50-00	. CYLINDER KIT, MASTER	1	
8	3LN-2585G-00-00	. . CIRCLIP	1	
9	4BP-2582A-00-00	. JOINT	1	
10	4BP-2585F-00-00	. BUSH	1	
11	47X-27222-00-00	JOINT	1	
12	95303-08700-00	NUT	1	
13	92011-08020-00	BOLT, BUTTON HEAD	2	
14	90240-08124-00	PIN, CLEVIS	1	
15	90201-08083-00	WASHER, PLATE	1	
16	91490-20020-00	PIN, COTTER	1	
17	4FM-2144G-00-00	STAY, STOP SWITCH	1	
18	98580-06010-00	SCREW, PAN HEAD (92503-06010)	1	
19	31A-25894-01-00	TANK, RESERVOIR	1	
20	360-25854-00-00	DIAPHRAGM, RESERVOIR	1	
21	2GU-25855-00-00	BUSH, DIAPHRAGM	1	
22	2KF-25852-50-00	CAP, RESERVOIR	1	
23	3PJ-25888-00-00	COVER, RESERVOIR TANK	1	
24	98516-06020-00	SCREW, PAN HEAD	1	
25	92906-06100-00	WASHER, SPRING	1	
26	4FM-2133G-00-00	BRACKET, RESERVER	1	
27	95811-06016-00	BOLT, FLANGE (95822-06016)	1	

CONTINUED ON NEXT FRAME ➤




4JH351-4360

REAR MASTER CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
28	4JH-25895-00-00	HOSE, RESERVOIR	1	
29	90467-14057-00	CLIP	2	
30	4JH-25874-01-00	HOSE, BRAKE	1	
31	90461-08031-00	CLAMP	1	
32	95816-06012-00	BOLT, FLANGE	1	
33	90401-10159-00	BOLT, UNION	1	
34	90201-10118-00	WASHER, PLATE	3	
35	3LC-25885-00-00	JOINT	1	

COWLING 1




FWD

4NA110-5380

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-28381-00-00	WINDSHIELD	1	
2	90150-05023-00	SCREW, ROUND HEAD	2	
3	90179-05523-00	NUT	2	
4	90149-05273-00	SCREW	4	
5	4FM-28215-00-00	WASHER, SPECIAL	4	
6	95706-05500-00	NUT, FLANGE	4	
7	4JH-Y2835-30-P1	COWLING ASS''Y	1	DARK BLUE COCKTAIL 2
8	89X-77167-00-00	. TRIM 3	2	
9	3MA-21649-00-00	. DAMPER	2	
10	90183-05024-00	. NUT, SPRING	6	
11	4NA-28390-01-00	. GRAPHIC SET, COWLING	1	
12	4JH-28356-00-00	STAY 1	1	
13	51L-28371-00-00	DAMPER	1	
14	95606-08200-00	NUT, U	2	
15	90154-05059-00	SCREW, BINDING	6	
16	95816-06030-00	BOLT, FLANGE	4	
17	95606-06200-00	NUT, U	4	
18	90480-14229-00	GROMMET	4	
19	90387-07391-00	COLLAR	4	
20	4FM-26280-10-00	REAR VIEW MIRROR ASSEMBLY (LEFT)	1	BLACK
21	4FM-26290-10-00	REAR VIEW MIRROR ASSEMBLY (RIGHT)	1	BLACK
22	4JH-2831W-00-00	STAY, MIRROR 1	1	
23	90480-13398-00	GROMMET	2	
24	90387-067N5-00	COLLAR	2	
25	95026-06016-00	BOLT, FLANGE	2	
26	4JH-2832W-00-00	STAY, MIRROR 2	1	
27	95026-06012-00	BOLT, FLANGE	2	

CONTINUED ON NEXT FRAME ➤

COWLING 1




FWD

4NA110-5380

Ref. No.	Part Number	Description	Qty	Remarks
28	4FM-26299-00-00	PLATE, MIRROR FITTING 2	2	
29	3XV-26298-00-00	PLATE, MIRROR FITTING 1	2	
30	98706-06025-00	SCREW, FLAT HEAD	4	
31	90176-06055-00	NUT, CROWN	4	


COWLING 2



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-Y283U-20-P0	PANEL ASSEMBLY 1	1	DARK BLUE COCKTAIL 2
2	90480-13398-00	. GROMMET	4	
3	4JH-2172A-00-00	. PANEL 1	1	
4	90183-03010-00	. NUT, SPRING	4	
5	90183-05024-00	. NUT, SPRING	3	
6	4NA-28301-00-00	. GRAPHIC SET, LOWER COVER 1	1	
7	4JH-Y283V-20-P0	PANEL ASSEMBLY 2	1	DARK BLUE COCKTAIL 2
8	90480-13398-00	. GROMMET	4	
9	4JH-2172F-00-00	. PANEL 2	1	
10	90183-03010-00	. NUT, SPRING	4	
11	90183-05024-00	. NUT, SPRING	3	
12	4NA-28303-01-00	. GRAPHIC SET, LOWER COVER 2	1	
13	4JH-2832U-00-00	STAY, SIDE 1	1	
14	95826-06010-00	BOLT, FLANGE	5	
15	4JH-2836H-00-00	BRACKET 5	1	
16	4BP-24188-00-00	MOLD, FUEL TANK	1	
17	1HX-24188-01-00	MOLD, FUEL TANK	1	
18	4JH-2836J-00-00	BRACKET 6	1	
19	90150-06036-00	SCREW, ROUND HEAD	4	
20	3FV-28365-00-00	COVER	1	
21	4JH-2836K-00-P1	PANEL, INNER 1	1	DARK BLUE COCKTAIL 2
22	1A8-21518-00-00	HOLDER, CABLE	1	
23	4JH-Y2808-30-P2	COVER ASSEMBLY, UNDER	1	VERY DARK VIOLET COCKTAIL 1
24	90480-13398-00	. GROMMET	3	
25	90183-05024-00	. NUT, SPRING	2	


CONTINUED ON NEXT FRAME ➤

COWLING 2



Ref. No.	Part Number	Description	Qty	Remarks
26	4NA-28304-00-00	. GRAPHICSET, LOWER COVER 3	1	
27	90150-06036-00	SCREW, ROUND HEAD	2	
28	90154-05059-00	SCREW, BINDING	8	
29	4JH-28396-00-00	PLATE 1	1	
30	4JH-28397-00-00	PLATE 2	1	
31	4DN-21669-00-00	SEAL	4	
32	90269-07036-00	RIVET	4	
33	4JH-2836F-00-00	BRACKET 3	1	
34	4JH-2836G-00-00	BRACKET 4	1	
35	90480-12320-00	GROMMET	2	
36	4JH-2831T-00-00	STAY, SUPPORT 1	1	
37	95826-06010-00	BOLT, FLANGE	1	

GENERATOR




Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-81450-00-00	ROTOR ASSEMBLY	1	
2	4JH-81410-00-00	STATOR ASSEMBLY	1	
3	91311-06035-00	BOLT, SOCKET HEAD	3	
4	98580-05016-00	SCREW, PAN HEAD	2	
5	92990-05100-00	WASHER, SPRING	2	
6	90201-05027-00	WASHER, PLATE	2	
7	90280-03047-00	KEY, WOODRUFF	1	
8	90105-10430-00	BOLT, WASHER BASED	1	
9	90201-107K6-00	WASHER, PLATE	1	

FWD

4JH351-4390


STARTING MOTOR



3HE332-9400

Ref. No.	Part Number	Description	Qty	Remarks
1	3HW-81800-00-00	STARTING MOTOR ASSEMBLY	1	
2	3HE-81840-00-00	. BRUSH HOLDER ASSEMBLY	1	
3	1HX-81815-00-00	. CORD, STARTER MOTOR	1	
4	3HE-81850-00-00	. ARMATURE ASSEMBLY	1	
5	3AJ-81809-00-00	. WASHER KIT	1	
6	3HE-81830-00-00	. FRONT BRACKET ASSEMBLY	1	
7	3HE-81826-00-00	. BOLT	1	
8	5H0-81871-00-00	. CAP	1	
9	11H-81844-00-00	. GASKET	2	
10	26H-81847-00-00	. O-RING	1	
11	95023-06025-00	BOLT, FLANGE	2	


FLASHER LIGHT



4NA110-5420

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-83310-10-00	FRONT FLASHER LIGHT ASSEMBLY 1	1	
2	256-84714-61-00	. BULB (12V-27/8W)	1	
3	4JH-83332-10-00	. LENS, FLASHER	1	
4	97702-40610-00	. SCREW, TAPPING	1	
5	4JH-83320-10-00	FRONT FLASHER LIGHT ASSEMBLY 2	1	
6	256-84714-61-00	. BULB (12V-27/8W)	1	
7	4JH-83342-10-00	. LENS, FLASHER 2	1	
8	97702-40610-00	. SCREW, TAPPING	1	
9	4JH-83318-00-00	STAY, FLASHER 1	2	
10	98506-04008-00	SCREW, PAN HEAD	2	
11	92906-04600-00	WASHER, PLATE	2	
12	4JH-83330-20-00	REAR FLASHER LIGHT ASSEMBLY 1	1	
13	256-83311-70-XX	. BULB, TS 12V27W	1	
14	4JH-83332-10-00	. LENS, FLASHER	1	
15	97702-40610-00	. SCREW, TAPPING	1	
16	4JH-83340-20-00	FLASHER LIGHT ASSEMBLY 2	1	
17	256-83311-70-XX	. BULB, TS 12V27W	1	
18	4JH-83342-10-00	. LENS, FLASHER 2	1	
19	97702-40610-00	. SCREW, TAPPING	1	
20	4FM-83345-00-00	PLUG, BLIND	2	
21	4FM-83369-00-00	STAY, FLASHER 2	2	
22	95701-06500-00	NUT, FLANGE	2	


METER



4JH351-4420

Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-83570-10-00	SPEEDOMETER ASSEMBLY	1	
2	4FM-83540-00-00	TACHOMETER ASSEMBLY	1	
3	4FM-83590-00-00	WATER TEMPERATURE ASSEMBLY	1	
4	4FM-83559-00-00	COVER, METER	1	
5	4FM-8353H-50-00	CASE, UNDER	1	
6	2GH-83578-00-00	KNOB, TRIP METER	1	
7	4FM-83509-00-00	SOCKET CORD ASSEMBLY	1	
8	4G1-84744-00-00	BULB, MTR.12V3.4W	5	
9	2GV-83517-00-00	BULB (12V-1.7W, T6.5)	4	
10	98580-04010-00	SCREW, PAN HEAD	4	
11	92990-04100-00	WASHER, SPRING	4	
12	92901-04600-00	WASHER, PLATE	4	
13	97902-04122-00	SCREW, WITH WASHER	2	
14	98580-03010-00	SCREW, PAN HEAD (98502-03010)	3	
15	92990-03100-00	WASHER, SPRING (92901-03100)	3	
16	90159-03102-00	SCREW, WITH WASHER	3	
17	90164-04023-00	SCREW, TAPPING	5	
18	4FM-83520-00-00	SOCKET CORD ASSEMBLY	1	
19	90480-14585-00	GROMMET	2	
20	90201-06059-00	WASHER, PLATE	2	
21	95316-06600-00	NUT	2	
22	3GM-87278-A0-00	COVER, METER	1	
23	97706-40012-00	SCREW, TAPPING	1	
24	4JH-83550-00-00	SPEEDOMETER CABLE ASSEMBLY	1	


HEADLIGHT



4NA110-5450

Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-84330-41-00	BODY ASSEMBLY	1	
2	4FM-84320-40-00	LENS ASSEMBLY	1	
3	4FM-8432A-40-00	LENS ASSEMBLY	1	
4	1ML-84314-00-XX	BULB (12V-35/35W) (1FM-84314-H0-00)	2	HALOGEN
5	4JG-84397-00-00	COVER, SOCKET	2	
6	51L-84334-00-00	NUT, ADJUSTING	4	
7	90338-24112-00	PLUG, SPEC''L SHAPE	1	
8	3LK-84378-00-P4	CAP	1	VERY DARK VIOLET COCKTAIL 1
9	90167-05041-00	SCREW, TAPPING	2	
10	4NA-84359-00-00	CORD, HEADLIGHT	1	
11	90464-13133-00	CLAMP	1	
12	90464-16021-00	CLAMP	1	
13	90464-13073-00	CLAMP	3	


TAILLIGHT




4HA700-3480

Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-84710-10-00	TAILLIGHT UNIT ASSEMBLY . .	1	
2	31L-84714-00-00	. BULB, TAILLIGHT (12V-21/5W)	2	
3	4FM-84735-00-00	. CORD ASSEMBLY	1	
4	90179-05523-00	NUT	4	
5	92906-05600-00	WASHER, PLATE	4	
6	90110-05112-00	BOLT, HEXAGON SOCKET HEAD	4	
7	4FM-84745-10-00	LICENCE LIGHT UNIT ASSEMBLY	1	
8	4FM-84749-10-00	. BODY, LICENCE LIGHT	1	
9	3F9-84744-00-XX	. BULB, METER 12V3.8W	2	
10	4FM-84742-00-00	SEAT, BASE	1	
11	3F9-84553-00-00	DAMPER	2	
12	90201-05033-00	WASHER, PLATE	2	
13	90387-0601Y-00	COLLAR	2	
14	95706-05500-00	NUT, FLANGE	2	
15	4FM-84751-00-00	BRACKET, LICENSE	1	
16	95026-06016-00	BOLT, FLANGE	2	
17	90201-06059-00	WASHER, PLATE	2	
18	95616-06100-00	NUT, U	2	
19	99237-00080-00	EMBLEM, YAMAHA	1	

HANDLE SWITCH




Ref. No.	Part Number	Description	Qty	Remarks
1	4DU-83973-00-00	SWITCH, HANDLE 3	1	
2	98506-05030-00	. SCREW, PAN HEAD	1	
3	98506-05040-00	. SCREW, PAN HEAD	1	
4	4FM-83975-00-00	SWITCH, HANDLE 2	1	
5	98506-05018-00	. SCREW, PAN HEAD	2	
6	29L-82911-01-00	HOLDER, LEVER 1	1	
7	3LN-83912-00-00	LEVER 1	1	
8	31A-83913-00-00	COLLAR, LEVER 1	1	
9	31A-82917-00-00	SWITCH	1	
10	31A-83945-00-00	BOLT, LEVER	1	
11	98702-03008-00	SCREW, FLAT HEAD	1	
12	95616-06100-00	NUT, U	1	
13	97011-06025-00	BOLT (97001-06025)	1	
14	92906-06100-00	WASHER, SPRING	1	
15	90338-09012-00	PLUG	1	



4JH351-4450


ELECTRICAL 1



4JH300-4470

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-82310-00-00	IGNITION COIL ASSEMBLY	1	
2	4JH-82320-00-00	IGNITION COIL ASSEMBLY	1	
3	1WG-82370-00-00	PLUG CAP ASSEMBLY	4	
4	1AE-82540-00-00	NEUTRAL SWITCH ASSEMBLY	1	
5	93210-29196-00	O-RING	1	
6	98580-06016-00	SCREW, PAN HEAD	2	
7	11H-83591-00-00	THERMO UNIT	1	
8	3TJ-82583-00-00	WIRE, SUB LEAD	1	
9	4JH-85720-00-00	OIL LEVEL GAUGE ASSEMBLY	1	
10	95026-06016-00	BOLT, FLANGE	2	
11	4JH-82305-00-00	IGNITOR UNIT ASSEMBLY	1	
12	97706-60016-00	SCREW, TAPPING	2	
13	90338-08226-00	PLUG	2	
14	2EL-82560-00-00	THERMO SWITCH ASSEMBLY	1	
15	1WG-82541-00-00	WIRE, LEAD	1	
16	3GM-83350-00-00	FLASHER RELAY ASSEMBLY	1	
17	34Y-83371-00-00	HORN	1	
18	95826-06010-00	BOLT, FLANGE	1	
19	11H-85110-01-00	REFLECTOR ASSEMBLY	2	
20	95701-05500-00	NUT, FLANGE	2	


ELECTRICAL 2



Ref. No.	Part Number	Description	Qty	Remarks
1	4DN-81940-00-00	STARTER RELAY ASSEMBLY	1	
2	95023-06008-00	BOLT	2	
3	BTY-YTX12-BS-00	BATTERY ASSEMBLY (YTX12-BS)	1	
4	4BP-82131-00-00	BAND, BATTERY	1	
5	4JH-82115-00-00	WIRE, PLUS LEAD	1	
6	4JH-82116-00-00	WIRE, MINUS LEAD	1	
7	1KT-82530-02-00	STOP SWITCH ASSEMBLY	1	
8	4NA-82590-00-00	WIRE HARNESS ASSEMBLY	1	
9	2GH-82151-00-00	. FUSE (20A-BL)	2	
10	2KW-82151-00-00	. FUSE (7.5A-BL)	3	
11	36Y-82151-00-00	. FUSE (15A-BL)	1	
12	4JH-81960-00-00	RECTIFIER & REGULATOR ASSEMBLY	1	
13	95811-06020-00	BOLT, FLANGE	2	
14	4NA-82501-00-00	MAIN SWITCH STEERING LOCK	1	
15	90109-080G5-00	BOLT	2	
16	3TJ-83964-10-00	SWITCH	1	
17	98780-05016-00	SCREW, FLAT HEAD	2	
18	95701-05500-00	NUT, FLANGE	2	
19	1UA-82591-00-00	BAND	2	
20	90464-13073-00	CLAMP	2	
21	90464-12089-00	CLAMP	5	
22	90464-10190-00	CLAMP	2	
23	90464-15192-00	CLAMP	1	
24	90464-15195-00	CLAMP	3	
25	3EN-81950-00-00	RELAY ASSEMBLY	1	
26	3LD-82566-50-00	SWITCH, SIDE STAND	1	
27	90157-05079-00	SCREW, PAN HEAD	2	

CONTINUED ON NEXT FRAME ➤

ELECTRICAL 2



4NA110-5500

Ref. No.	Part Number	Description	Qty	Remarks
28	90464-07121-00	CLAMP	2	
29	90464-08211-00	CLAMP	2	
30	25G-83936-01-00	BAND, SWITCH CORD	1	

Warranty Authorization Procedures

A reminder! The need for an authorization is now based on **total repair cost,** not on particular components. Simply add up the total warranty repair cost, including the dealer cost of parts, your parts handling charge, and the labor at your approved labor rate. If the total is:

- $500 or less - no authorization is needed
- Over $500 - call your toll-free RTA Hotline for authorization

Also, an autho is now easier to remember. Now instead of a lot of letters and numbers, all you have to remember is a three number combination like 695.

You no longer have to worry about accidentally getting your authorization with the wrong warranty request. You'll now enter the authorization number on your request, even if you use DOES PLUS.

Warranty Transfer Fees Dropped!

Yamaha's factory warranty has always been a strong selling point, even more so now that Y.E.S. is available on so many models.

Now we've found a way to make that coverage even more valuable. **Beginning May 1, 1994, Yamaha dropped the fees for transfer of coverage to the new owner!** You will no longer be charged the $10 for an in-warranty transfer or $25 for a Y.E.S. transfer.

* AUDIO WARRANTY - SERVICE PG - 1

Ref. No.	Part Number	Description	Qty	Remarks

Reformulated Gasoline (Cont'd.)

SUMMARY

More information will become available during the next year as RFG penetrates the market. If you want more information on gasoline, send for the technical manual, *Changes in Gasoline II* at:

Changes in Gasoline II
Technicians Manual
Downstream Alternatives, Inc.
PO Box 190
Bremen, IN 46506-0190

The cost of this manual is $2.00 each.

Areas Exceeding Federal Ozone Standards

The following charts show the areas of the country that exceed the Federal Ozone Standards. The nine cities in the **Extreme and Severe** areas are required to start selling RFG during 1995. This program is optional in the other listed areas.

RFG FUEL AREAS EXCEEDING FEDERAL OZONE STANDARDS

*Extreme Areas**	*Moderate Areas*	*Marginal Areas*	
Los Angeles*	Atlantic City, NJ	Albany, NY	South Bend, IN
	Bowling Green, KY	Allentown, PA-NJ	Stockton, CA
*Severe Areas**	Charleston, WV	Altoona, PA	Sussex County, DE
Baltimore, MD	Charlotte, NC-SC	Birmingham, AL	Tampa, FL
Chicago, IL-IN-WI	Cincinnatti, OH-KY-IN	Buffalo, NY	Waldo County, ME
Houston, TX	Cleveland, OH	Canton, OH	York, PA
Milwaukee, WI	Dallas, TX	Columbus, OH	Youngstown, OH-Sharon, PA
Muskegon, MI	Dayton-Springfield, OH	Erie, PA	
New York, NY-NJ-CT	Detroit, MI	Essex County, NY	
Philadelphia, PA-NJ-DE-MD	Grand Rapids, MI	Evansville, IN-KY	
San Diego, CA	Greensboro, NC	Fayetteville, NC	
	Jefferson County, NY	Greenbrier County, WV	
*Serious Areas**	Kewaunee County, WI	Greenville-Spartanburg, SC	
Atlanta, GA	Knox County, ME	Hancock County, ME	
Bakersfield, CA	Louisville, KY-IN	Harrisburg, PA	
Baton Rouge, LA	Memphis, TN-AR-MS	Indianapolis, IN	
Beaumont, TX	Miami, FL	Johnson City-Kingsport-Bristol, TN	
Boston, MA-NH	Modesto, CA	Johnstown, PA	
El Paso, TX	Nashville, TN	Kansas City, MO-KS	
Fresno, CA	Pittsburgh, PA	Knoxville, TN	
Hartford, CT	Portland, ME	Lake Charles, LA	
Huntington, WV-KY-OH	Raleigh-Durham, NC	Lancaster, PA	
Parkersburg, WV-OH	Reading, PA	Lewiston, ME	
Portsmouth, NH-ME	Richmond, VA	Lexington, KY	
Providence, RI	Salt Lake City, UT	Lincoln County, ME	
Sacramento, CA	San Francisco-Oakland-San Jose, CA	Manchester, NH	
Sheboygan, WI	Santa Barbara, CA	Montgomery, AL	
Springfield, MA	Smyth County, VA	Norfolk, VA	
Washington, DC-MD-VA	St. Louis, MO-IL	Owensboro, KY	
	Toledo, OH	Paducah, KY	
	Visalia, CA	Poughkeepsie, NY	
	Worcester, MA	Scranton, PA	

*Nine cities with highest ozone levels designated extreme or severe will be required to implement reformulated gasoline programs in 1995. Other ozone non-attainment areas may elect to "opt-in" to this program.

Oxygenated Fuel Sold Seasonally in These Areas Exceeding Federal Carbon Monoxide Standards

Albuquerque, NM	Fairbanks, AK	Memphis, TN	Reno, NV
Anchorage, AK	Ft Collins, CO	Minneapolis, MN	Sacramento, CA
Baltimore, MD	Fresno, CA	Missoula, MT	San Diego, CA
Boston, MA	Grants Pass, OR	Modesto, CA	San Francisco, CA
Chico, CA	Greensboro, NC	New York/Northern NJ	Seattle, WA
Cleveland, OH	Hartford, CT	Philadelphia, PA	Spokane, WA
Colorado Springs, CO	Klamath County, OR	Phoenix, AZ	Stockton, CA
Denver/Boulder, CO	Las Vegas, NV	Portland, OR	Syracuse, NY
Duluth, MN	Los Angeles, CA	Provo/Orem, UT	Washington, DC
El Paso, TX	Medford, OR	Raleigh, NC	

MOTORCYCLE | 12/21/94 | M94-008

TECH EXCHANGE

SUBJECTS:
1. **Oxygenated Fuels**
2. **Crease in YZ250G1/WR250ZG Silencer**
3. **Warranty Authorization Procedures**
4. **Warranty Transfer Fee Dropped**

Oxygenated Fuels

Beginning in 1992, all gasoline sold during the winter months (usually October through February) in 39 designated metropolitan areas (and **all** of California) must be oxygenated as mandated by the 1990 Amendments to the Federal Clean Air Act. The purpose of the oxygenated fuel is to reduce the amount of carbon monoxide in the air. Internal combustion engines tend to emit more carbon monoxide at low operating temperatures such as when first started and during longer warm-up times in the colder, winter months.

The following information is provided to clarify some concerns that customers and dealers may have about the use of oxygenated fuels in Yamaha motorcycles.

What is "Oxygenated Gasoline"?

Oxygenated gasoline is a blend of gasoline and one or more combustible liquids containing oxygen. Presently, two different classes of oxygenates are being added to gasoline: alcohol (both ethanol and methanol) and ethers (methyl tertiary-butyl-ether; MTBE). The oxygen content of the gasoline must be 2.7%.

Can oxygenated fuels be used in Yamaha motorcycles?

Oxygenated fuel can be used in Yamaha **street, dual-purpose, and off-road/play bike** motorcycles. This tech exchange addresses concerns regarding its use.

NOTE: Do not use oxygenated gasoline or, for that matter, any pump gasoline in Yamaha YZ or WR motorcycles. These models require racing fuel with a minimum octane rating of 95. For more information about recommended fuel for YZ and WR models, refer to the Owner's Service Manual for that model.

Service, Storage, Usage Information
PRACTICE GOOD FUEL MANAGEMENT. . .

Don't worry about instructing customers about testing or identifying oxygenated fuel. If they are in one of the mandated areas, oxygenated fuel is all they can purchase. Instead, educate your customers about oxygenated gasoline using the following tips:

- Match gasoline purchases to consumption. Don't buy more than will be used in one month.
- Store gasoline in a tightly-closed, approved container in a cool, dry place.
- Drain the fuel tank when you store your motorcycle for the off-season.

NOTE: Yamaha Ring Free Fuel Additive can be used with all oxygenated gasoline and is recommended for use in all Yamaha engines. For more information about Ring Free, refer to Technical Bulletin M92-007.

Carburetor Jetting

Yamaha's recommended jetting specifications are correct for use with oxygenated fuels. Poor performance and/or possible engine damage could result if you use a jet size smaller (leaner) than recommended on the Service Data or in the Service Manual.

Fuel Deicers Water Absorbing Additives

If the oxygenated gasoline being used contains an alcohol blend, **do not use** additional alcohol deicers or water absorbing additives. If there is water in the fuel tank prior to refueling, **do not use** oxygenated gasoline until all water has been removed from the tank.

Oxygenated Fuels - (Cont'd.)

If water is present in the fuel, additives combined with the alcohol in the oxygenated fuel will cause the alcohol in the fuel to separate, causing poor performance and possible engine damage.

Storage

Drain the gasoline from the tank and carburetors if the motorcycle will be stored for more than a month.

Leaving oxygenated gasoline in a motorcycle during storage is undesirable because the fuel can corrode metal parts. Also, alcohol oxygenated gasoline will absorb moisture from the air, resulting in phase separation and the problems associated with it.

⚠WARNING

Gasoline and oxygenated gasoline are extremely flammable and can be explosive under certain conditions. Follow the recommendations in the owner's and service manuals for handling and storing gasoline.

Phase Separation


Although small amounts of water in the fuel will normally not affect or interfere with engine operation, problems can develop if too much water is present in alcohol oxygenated gasoline. If there is enough water in the oxygenated fuel, the alcohol and gasoline will separate into two liquid phases: a top phase or layer which is almost entirely gasoline, (and oil, in the case of 2-stroke premix fuel) and a bottom phase of water and alcohol. Phase separation makes the engine difficult or often impossible to start. Replace the separated fuel with fresh gasoline.

Parts Information

Part Number	Description	Remarks	Dealer Cost
ACC-RNGFR-EE-12	Ring Free Fuel Additive	Case/12	

Crease in Bottom of YZ250G1/WR250ZG Silencer

There is a crease about 4 inches long on the bottom of the silencer on the 1995 YZ250G1 and WR250ZG. This crease looks like crate damage, but this is not the case. The crease is for ample rear brake caliper clearance in case the rear suspension bottoms out. **This crease is not a defect. Do not** replace the silencer. No warranty applies.



MOTORCYCLE | 3/1/95 | M95-006

TECH EXCHANGE

SUBJECTS: 1. Reformulated Gasoline
2. Areas Exceeding Federal Ozone Standards

Reformulated Gasoline

Beginning January 1, 1995, extreme and severe non-ozone attainment cities are required to sell only reformulated gasoline (RFG) year round, not seasonally like Oxygenated fuels. Topic number 2 in this Tech Exchange contains a list of affected cities. Other serious, moderate, and marginal attainment areas will phase in this gasoline to fulfill their individual agendas for pollution abatement.

What is RFG?

As the name indicates, it is the next generation of fuels reformulated to reduce pollutants and protect the environment. The main focus of RFG is to reduce pollutants that affect the ozone, however, it will contain the same Oxygenates used in fuels that are currently being used (seasonally) in various mandated areas to lower CO emissions. Oxygenated fuels are primarily used between the months of October and February in these selected areas. The following table illustrates the major ingredients of RFG that will be reformulated and the environmental benefits of reformulation.

FOCUS OF FUEL REFORMULATING

Potential Reformulation
Reduce Sulfur
Reduce Benzene
Reduce Aromatics & Olefins
Reduce fuel volatility
Increase oxygen contents
Alter distillation characteristics
Deposit control additives

Environmental Benefits
Reduces acid rain, improves vehicle catalyst efficiency
Reduces incidence of cancer, reduces toxicity of emissions
Reduces photochemical reactivity/smog formation
Reduces evaporative emissions/smog formation
Reduces tailpipe/exhaust CO emissions, replaces toxic components
Control of evaporative & exhaust emissions
Reduce engine deposits, thus reducing exhaust emissions

Can Yamaha Products Operate On Reformulated Gasoline?

Extensive testing has been done on the affects of RFG on lubricity and material compatibility, **particularly with 2-stroke engines.** Results show no adverse affects or catastrophic failures when using RFG. Tests also indicate that no increase in service intervals beyond the existing Yamaha recommendations were necessary.

RUNNING CHARACTERISTICS WITH RFG

Because RFG contains oxygenates, the fuel mixture can lean-out slightly causing a rougher than normal idle. This can usually be corrected by small adjustments to the idle mixture screws. **Be sure to refer to your Yamaha technical specifications for correct fuel mixture settings! Use an engine exhaust gas analyzer where applicable.**

GUIDELINES FOR RFG USAGE

- Become familiar with the areas where RFG is sold. Normally the gas station will post a sign about the type of fuel they sell.
- Storage life of RFG is shorter than the fuel sold in the past. Treat stored fuel with Yamaha Fuel Stabilizer and Conditioner. Be sure to store gasoline in an approved container and place in a cool, dry place.
- In the case of large fuel tanks (such as in a boat or a large touring motorcycle), be sure to keep the tank completely full to prevent water accumulation. The expanding and contracting of the fuel causes air to enter the fuel tank. Water in the air will condense in the tank if the tank is not kept full.
- Be sure to use fresh fuel when doing a tune-up on any unit that has been in storage for a long time.

If you have technical tips you think other dealers could use, let us know. You'll receive credit in the Tech Exchange for ideas we use, and we'll send you an exclusive Yamaha Tech Exchange hat as our thanks.
Send your tips to: Yamaha Motor Corporation, U.S.A., Attn: Tech Exchange, P.O. Box 6555, Cypress, CA 90630

©1995 YAMAHA MOTOR CORPORATION, U.S.A.