




| Ref No | Part No | Description |
|---|---|---|
| 01 | 1RT-11102-01-00 | Cylinder Head Assy |
| 02 | 93440-14086-00 | • . Circlip |
| 03 | 4X7-11133-10-00 | • . Guide, Intake Valve |
| 04 | 4X7-11127-00-00 | Absorber 3 |
| 05 | 91800-06030-00 | Pin, Dowel |
| 06 | 42X-11181-00-00 | Gasket, Cylinder Head 1 |
| 07 | 4X7-11363-01-00 | Bolt, Cylinder Holding 3 |
| 08 | 90116-12469-00 | Bolt, Stud |
| 09 | 90116-10344-00 | Bolt, Stud |
| 10 | 90179-12325-00 | Nut |
| 11 | 90201-125A3-00 | Washer, Plate |
| 12 | 90179-12325-00 | Nut |
| 13 | 90176-10075-00 | Nut, Crown |
| 14 | 90201-102G9-00 | Washer, Plate |
| 15 | 91314-08050-00 | Bolt |
| 16 | 95617-08640-00 | Bolt, Stud |
| 17 | 42X-11185-01-00 | Cover, Cylinder Head Side 1 |
| 18 | 91314-06016-00 | Bolt |
| 19 | 42X-11152-00-00 | Bracket, Cylinder Head Cover |
| 20 | 90202-05208-00 | Washer, Plate |
| 21 | 42X-1111H-01-00 | Cover, Cylinder Head Side 4 |
| 22 | 42X-11165-00-00 | Plate, Breather |
| 23 | 42X-11166-01-00 | Pipe, Breather 1 |
| 24 | 90467-14015-00 | Clip |
| 25 | 93210-92448-00 | O-ring |
| 26 | 91314-06025-00 | Bolt |
| 27 | 42H-11186-01-00 | Cover, Cylinder Head Side 2 |
| 28 | 4X7-11187-00-00 | Cover, Cylinder Head Side 3 |
| 29 | 93210-62446-00 | O-ring |
| 30 | 91314-06016-00 | Bolt |
| 31 | 4X7-1111F-00-00 | Plate |
| 32 | 97017-08020-00 | Bolt |
| 33 | 90401-16065-00 | Bolt, Union |
| 34 | 90430-16065-00 | Gasket |
| 35 | 1RM-1112E-00-00 | Cover, Cylinder Head 3 |
| 36 | 90480-23444-00 | Grommet |
| 37 | 91317-06010-00 | Bolt |
| 38 | 94701-00218-00 | Plug, Spark |
| 38 | 94701-00220-00 | Plug, Spark |


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




10L110-2020


| Ref No | Part No | Description |
|---|---|---|
| 01 | 1TR-11310-00-00 | Cylinder |
| 02 | 93210-89447-00 | O-ring |
| 03 | 4X7-11161-00-00 | Absorber 1 |
| 04 | 90387-087A5-00 | Collar |
| 05 | 91314-06040-00 | Bolt |
| 06 | 3JL-11351-00-00 | Gasket, Cylinder |
| 07 | 4X7-12215-00-00 | Cap, Tensioner Case |
| 08 | 4DW-12213-00-00 | Gasket, Tensioner Case |
| 09 | 91314-06025-00 | Bolt |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-11411-02-00 | Crankshaft |
| 02 | 93306-30808-00 | Bearing |
| 03 | 4X7-13354-00-00 | Sprocket, Drive |
| 04 | 93306-30808-00 | Bearing |
| 05 | 42Y-11631-00-A0 | Piston (std) |
| 05 | 42Y-11636-00-00 | Piston (0.50mm O/s) |
| 05 | 42Y-11638-00-00 | Piston (1.00mm O/s) |
| 06 | 4GB-11610-00-00 | Piston Ring Set |
| 06 | 4GB-11610-20-00 | Piston Ring Set |
| 06 | 4GB-11610-40-00 | Piston Ring Set |
| 07 | 4X7-11633-00-00 | Pin, Piston |
| 08 | 93450-22027-00 | Circlip |
| 09 | 4X7-11650-00-00 | Connecting Rod Assy |
| 10 | 4X7-11654-01-00 | • . Bolt, Connecting Rod |
| 11 | 90179-09379-00 | • . Nut |
| 12 | 4X7-11656-00-00 | Plane Bearing, Connecting Rod |
| 12 | 4X7-11656-10-00 | Plane Bearing, Connecting Rod |
| 12 | 4X7-11656-20-00 | Plane Bearing, Connecting Rod |
| 12 | 4X7-11656-40-00 | Plane Bearing, Connecting Rod |
| 13 | 90280-16053-00 | Key, Woodruff |
| 14 | 90201-165H4-00 | Washer, Plate |
| 15 | 90179-16448-00 | Nut |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-12111-00-00 | Valve, Intake |
| 02 | 4X7-12121-00-00 | Valve, Exhaust |
| 03 | 4X7-12116-00-00 | Seat, Valve Spring |
| 04 | 90501-31454-00 | Spring, Compression |
| 05 | 90501-44455-00 | Spring, Compression |
| 06 | 341-12119-02-00 | Seal, Valve Stem |
| 07 | 4X7-12117-00-00 | Retainer, Valve Spring |
| 08 | 4X7-12118-00-00 | Cotter, Valve |
| 09 | 42X-12151-00-00 | Arm, Valve Rocker |
| 10 | 4X7-12156-01-00 | Shaft, Rocker 2 |
| 11 | 4X7-12159-00-00 | Screw, Valve Adjusting |
| 12 | 90170-08173-00 | Nut |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-11536-00-00 | Gear, Drive |
| 02 | 4X7-11534-00-00 | Gear, Breaker Drive |
| 03 | 90501-21133-00 | Spring, Compression |
| 04 | 93605-10090-00 | Pin, Dowel |
| 05 | 4X7-11540-02-00 | Cam Chain Sprocket Assy 1 |
| 06 | 4X7-11550-01-00 | Cam Chain Sprocket Assy 2 |
| 07 | 4X7-12247-01-00 | Shaft, Tensioner |
| 08 | 90209-06205-00 | Washer |
| 09 | 90105-06154-00 | Bolt, Washer Based |
| 10 | 42X-12171-00-00 | Camshaft 1 |
| 11 | 42X-12181-00-00 | Camshaft 2 |
| 12 | 42X-11145-00-00 | Plate, Breather 2 |
| 13 | 90201-10774-00 | Washer, Plate |
| 14 | 90101-10303-00 | Bolt |
| 15 | 90380-25125-00 | Bush, Solid |
| 16 | 94590-45098-00 | Chain |
| 17 | 4X7-12176-00-00 | Sprocket, Cam Chain |
| 18 | 93604-10011-00 | Pin, Dowel |
| 19 | 4X7-12210-01-00 | Tensioner Assy, Cam Chain |
| 20 | 90338-06121-00 | • . Plug |
| 21 | 4X7-12231-00-00 | Guide, Stopper 1 |
| 22 | 4X7-12241-00-00 | Guide, Stopper 2 |
| 23 | 4X7-12221-00-00 | Guide, Stopper 3 |
| 24 | 90109-08592-00 | Bolt |
| 25 | 95307-08700-00 | Nut |
| 26 | 92907-06600-00 | Washer, Plate |
| 27 | 91314-06025-00 | Bolt |
| 28 | 4DW-12213-00-00 | Gasket, Tensioner Case |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 10L-13300-00-00 | Oil Pump Assy |
| 02 | 99510-08016-00 | Pin, Dowel |
| 03 | 93210-07438-00 | O-ring |
| 04 | 91317-06040-00 | Bolt |
| 05 | 4X7-13355-00-00 | Sprocket, Driven |
| 06 | 90105-06154-00 | Bolt, Washer Based |
| 07 | 10L-13327-00-00 | Cover, Pump Gear |
| 08 | 91317-06010-00 | Bolt |
| 09 | 94580-25066-00 | Chain |
| 10 | 4X7-13171-00-00 | Pipe, Delivery 2 |
| 11 | 93210-07438-00 | O-ring |
| 12 | 91317-06010-00 | Bolt |
| 13 | 4X7-13405-00-00 | Oil Pipe Comp. 1 |
| 14 | 4X7-15485-01-00 | Clamp |
| 15 | 4X7-15484-00-00 | Clamp 2 |
| 16 | 90468-05113-00 | Clip |
| 17 | 1RM-13406-00-00 | Oil Pipe Comp. 2 |
| 18 | 90401-16067-00 | Bolt, Union |
| 19 | 90430-17168-00 | Gasket |
| 20 | 90401-10102-00 | Bolt, Union |
| 21 | 90430-15169-00 | Gasket |
| 22 | 4X7-15485-01-00 | Clamp |
| 23 | 90468-05113-00 | Clip |
| 24 | 3JL-13455-00-00 | Plug |
| 25 | 214-11198-01-00 | Gasket |


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




5E3171-1070


| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-13440-90-00 | Element Assy, Oil Cleaner |
| 02 | 93210-56459-00 | O-ring |
| 03 | 93210-54452-00 | O-ring |
| 04 | 1RM-13447-00-00 | Cover, Oil Element |
| 05 | 93210-07135-00 | O-ring |
| 06 | 90109-06667-00 | Bolt |
| 07 | 91314-06020-00 | Bolt |
| 08 | 91314-06050-00 | Bolt |
| 09 | 11H-13490-00-00 | Relief Valve Assy |
| 10 | 93210-10096-00 | O-ring |
| 11 | 90462-10098-00 | Clamp |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 24M-13586-01-00 | Joint, Carburetor 1 |
| 02 | 16G-13569-00-00 | Plug, Blind |
| 03 | 90467-10035-00 | Clip |
| 04 | 42X-13564-01-00 | Cover, Manifold |
| 05 | 42X-13578-00-00 | Washer |
| 06 | 42X-13544-00-00 | Hose, Vacuum Sensing 2 |
| 07 | 90467-08092-00 | Clip |
| 08 | 93210-44545-00 | O-ring |
| 09 | 97027-06020-00 | Bolt |
| 10 | 92907-06600-00 | Washer, Plate |
| 11 | 16G-13569-00-00 | Plug, Blind |
| 12 | 90467-10025-00 | Clip |
| 13 | 1RV-13595-00-00 | Joint |
| 14 | 3CG-14197-00-00 | Pipe |
| 15 | 3CG-14987-00-00 | Hose |
| 16 | 90467-14057-00 | Clip |
| 17 | 3CG-14396-00-00 | Pipe |
| 18 | 90413-07023-00 | Way 3 |
| 19 | 1TA-14349-00-00 | Pipe |
| 20 | 4FY-14348-00-00 | Pipe 1 |
| 21 | 90467-10135-00 | Clip |
| 22 | 10L-14453-01-00 | Joint, Air Cleaner 1 |
| 23 | 10L-14407-00-00 | Cover, Joint |
| 24 | 90460-65195-00 | Clamp, Hose |
| 25 | 42X-14401-01-00 | Air Cleaner Case Assy |
| 26 | 92907-04600-00 | Washer |
| 27 | 42X-14477-00-00 | Plate |
| 28 | 97707-40112-00 | Screw, Tapping |
| 29 | 42X-14451-00-00 | Element, Air Cleaner |
| 30 | 1RM-14422-00-00 | Cap, Cleaner Case 2 |
| 31 | 42X-14452-00-00 | Seal |
| 32 | 4PW-1441A-00-00 | Cover, Cleaner Case 1 |
| 33 | 97707-50508-00 | Screw, Tapping |
| 34 | 98507-05012-00 | Screw, Pan Head |
| 35 | 92907-05600-00 | Washer, Plate |
| 36 | 98507-06080-00 | Screw, Pan Head |
| 37 | 98507-06050-00 | Screw, Pan Head |
| 38 | 92907-06600-00 | Washer, Plate |
| 39 | 1TA-1441E-00-00 | Cover, Cleaner Case 2 |
| 40 | 97707-50508-00 | Screw, Tapping |
| 41 | 4PW-1442A-00-00 | Cover, Cleaner Case 3 |
| 42 | 42X-14485-00-00 | Pipe, Joint |
| 43 | 90387-07598-00 | Collar |
| 44 | 91317-06030-00 | Bolt |
| 45 | 92907-06200-00 | Washer |
| 46 | 91317-06012-00 | Bolt |
| 47 | 90460-65195-00 | Clamp, Hose |
| 48 | 42X-14663-02-00 | Plate, Air Cleaner |
| 49 | 91317-06090-00 | Bolt |
| 50 | 92907-06200-00 | Washer |
| 51 | 42X-14484-00-00 | Plate, Cleaner Case Fitting |
| 52 | 95807-06025-00 | Bolt, Flange |
| 53 | 1RM-14603-00-00 | Cover 1 |
| 54 | 90480-14074-00 | Grommet |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 55 | 95807-06014-00 | Bolt, Flange |
| 56 | 12R-14484-01-00 | Plate, Cleaner Case Fitting |
| 57 | 91317-06035-00 | Bolt |
| 58 | 92907-06200-00 | Washer |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4PW-14900-00-00 | Carburetor Assy |
| 02 | 4PW-14901-00-00 | • . Carburetor Assy 1 |
| 03 | 4PW-14902-00-00 | • . Carburetor Assy 2 |
| 04 | 3CF-14984-01-00 | •• .. Gasket, Float Chamber |
| 05 | 3CF-14107-23-00 | •• .. Needle Valve Set |
| 06 | 3NC-1490J-00-00 | •• .. Needle Set |
| 07 | 3AL-14933-00-00 | •• .. Spring, Diaphragm |
| 08 | 3AL-14940-00-00 | •• .. Diaphragm Assy |
| 09 | 12R-14105-00-00 | • . Pilot Screw Set |
| 10 | 537-14186-00-00 | •• .. Pin, Float |
| 11 | 2VA-14185-00-00 | •• .. Float |
| 12 | 137-14153-00-00 | •• .. Washer, Main Jet |
| 13 | 620-14231-23-00 | •• .. Jet, Main |
| 14 | 3CF-14141-40-00 | •• .. Nozzle, Main |
| 15 | 4G0-14142-40-00 | •• .. Jet, Pilot |
| 16 | 3G2-14231-12-00 | •• .. Jet, Main |
| 17 | 98507-05010-00 | •• .. Screw, Pan Head |
| 18 | 98580-04008-00 | •• .. Screw, Pan Head |
| 19 | 3CF-1490H-00-00 | •• .. Diaphragm Set 5 |
| 20 | 1HX-14231-28-00 | •• .. Jet, Main |
| 21 | 3CF-1410A-00-00 | •• .. Starter Set |
| 22 | 98580-05100-00 | •• .. Screw, Pan Head |
| 23 | 92990-05100-00 | •• .. Washer, Spring |
| 24 | 12R-14191-00-00 | •• .. Plug, Drain |
| 25 | 2JU-14937-00-00 | •• .. Clip |
| 26 | 22F-14991-00-00 | •• .. Screw |
| 27 | 3CF-14251-00-00 | • . Nipple |
| 28 | 3CF-14937-00-00 | • . Clip |
| 29 | 3CG-14197-00-00 | • . Pipe |
| 30 | 98501-05012-00 | • . Screw, Pan Head |
| 31 | 3CF-1490K-00-00 | • . Stop Screw Set |
| 32 | 3CF-14919-00-00 | • . Clip |
| 33 | 3CF-14103-01-00 | • . Throttle Screw Set |
| 34 | 98580-05014-00 | • . Screw, Pan Head |
| 35 | 3CF-14197-00-00 | • . Pipe |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 42X-14611-00-00 | Pipe, Exhaust 1 |
| 02 | 3EG-14714-00-00 | Gasket, Muffler |
| 03 | 1RV-14621-00-00 | Pipe, Exhaust 2 |
| 04 | 4PW-14711-00-00 | Muffler 1 |
| 05 | 3YF-14755-00-00 | Gasket, Silencer |
| 06 | 95027-08045-00 | Bolt, Flange |
| 07 | 95027-08045-00 | Bolt, Flange |
| 08 | 42X-14748-01-00 | Protector, Muffler 4 |
| 09 | 4BD-14766-00-00 | Washer, Protector |
| 10 | 98904-06010-00 | Screw, Bind |
| 11 | 42X-1479H-00-00 | Cover, 1 |
| 12 | 92907-06200-00 | Washer |
| 13 | 42X-14612-00-00 | Nut, Ring |
| 14 | 42X-1468A-00-00 | Ring, Silencer 1 |
| 15 | 90179-08210-00 | Nut |
| 16 | 90179-08507-00 | Nut |
| 17 | 3EG-14613-00-00 | Gasket, Exhaust Pipe |
| 18 | 90101-06576-00 | Bolt |
| 19 | 90101-06576-00 | Bolt |
| 20 | 92907-06600-00 | Washer, Plate |
| 21 | 92907-06600-00 | Washer, Plate |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-15100-05-00 | Crankcase Assy |
| 02 | 99510-14016-00 | • . Pin, Dowel |
| 03 | 95617-10620-00 | Bolt, Stud |
| 04 | 95617-10670-00 | Bolt, Stud |
| 05 | 95617-10670-00 | Bolt, Stud |
| 06 | 93210-07438-00 | O-ring |
| 07 | 93210-07135-00 | O-ring |
| 08 | 90387-064E8-00 | Collar |
| 09 | 91317-10100-00 | Bolt |
| 10 | 91317-10070-00 | Bolt |
| 11 | 91317-10060-00 | Bolt |
| 12 | 91317-06080-00 | Bolt |
| 13 | 91317-06055-00 | Bolt |
| 14 | 91317-06030-00 | Bolt |
| 15 | 91314-06030-00 | Bolt |
| 16 | 90430-06014-00 | Gasket |
| 17 | 57A-15363-11-00 | Plug, Oil |
| 18 | 93210-29198-00 | O-ring |
| 19 | 90465-10168-00 | Clamp |
| 20 | 4X7-15491-00-00 | Protector |
| 21 | 4X7-13419-00-00 | Plug |
| 22 | 90480-20302-00 | Grommet |
| 23 | 42X-12264-00-00 | Sprocket, Idle |
| 24 | 90105-10275-00 | Bolt, Washer Based |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 1RM-15411-01-00 | Cover, Crankcase 1 |
| 02 | 4X7-15361-00-00 | Gauge, Level |
| 03 | 2H7-15361-00-00 | Gauge, Level |
| 04 | 90465-08309-00 | Clamp |
| 05 | 98507-06010-00 | Screw, Pan Head |
| 06 | 3EG-15451-00-00 | Gasket, Crankcase Cover 1 |
| 07 | 99530-10014-00 | Pin, Dowel |
| 08 | 91314-06040-00 | Bolt |
| 09 | 91314-06030-00 | Bolt |
| 10 | 91314-06020-00 | Bolt |
| 11 | 1L9-11186-00-00 | Cover, Cylinder Head Side 2 |
| 12 | 93210-32172-00 | O-ring |
| 13 | 90462-08076-00 | Clamp |
| 14 | 1RM-15415-01-00 | Cover, Generator |
| 15 | 1RM-15455-00-00 | Gasket 1 |
| 16 | 1RM-15425-00-00 | Cover, Generator 2 |
| 17 | 98704-06016-00 | Screw, Flat Head |
| 18 | 98707-06014-00 | Screw, Flat Head |
| 19 | 42X-15417-01-00 | Cover, Cap |
| 20 | 91314-06055-00 | Bolt |
| 21 | 91314-06016-00 | Bolt |
| 22 | 1RM-15419-00-00 | Cover, Shifter 1 |
| 23 | 3EG-15459-00-00 | Gasket, Shifter Cover |
| 24 | 91314-06016-00 | Bolt |
| 25 | 3CG-15429-00-00 | Cover, Shifter |
| 26 | 98507-06030-00 | Screw, Pan Head |
| 27 | 91314-06065-00 | Bolt |
| 28 | 42X-15441-00-00 | Holder, Clutch Cable |
| 29 | 1RM-W1542-01-00 | Cover, Crankcase 3 |
| 30 | 93102-14102-00 | Oil Seal |
| 31 | 4X7-15388-00-00 | Plate, Bearing Cover |
| 32 | 91317-06016-00 | Bolt |
| 33 | 3EG-15462-00-00 | Gasket, Crankcase Cover 3 |
| 34 | 99530-10020-00 | Pin, Dowel |
| 35 | 91314-06040-00 | Bolt |
| 36 | 91314-06025-00 | Bolt |
| 37 | 91380-06030-00 | Bolt |
| 38 | 90462-10143-00 | Clamp |
| 39 | 90462-10085-00 | Clamp |
| 40 | 90462-12142-00 | Clamp |
| 41 | 1RM-13161-00-00 | Pipe, Delivery 1 |
| 42 | 93210-07438-00 | O-ring |
| 43 | 90110-06093-00 | Bolt, Hexagon Socket Head |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LP-15570-00-00 | Starter Clutch Assy |
| 02 | 99009-13400-00 | Circlip |
| 03 | 4X7-15521-00-00 | Shaft 1 |
| 04 | 93210-14104-00 | O-ring |
| 05 | 3LP-15524-10-00 | Wheel, Starter |
| 06 | 1TA-15512-00-00 | Gear, Idler 1 |
| 07 | 3LP-15517-10-00 | Gear, Idler 2 |
| 08 | 90387-172E5-00 | Collar |
| 09 | 90501-15636-00 | Spring, Compression |
| 10 | 90387-170E3-00 | Collar |
| 11 | 5A8-15550-00-00 | Drive Lever Assy |
| 12 | 93102-10247-00 | Oil Seal |
| 13 | 5A8-15542-01-00 | Collar 2 |
| 14 | 90151-06013-00 | Screw, Countersunk |
| 15 | 5A8-15556-00-00 | Lever, Drive |
| 16 | 90508-26494-00 | Spring, Torsion |
| 17 | 90149-08166-00 | Screw |
| 18 | 3EG-15568-00-00 | Gasket |
| 19 | 95707-06500-00 | Nut, Flange |
| 20 | 90387-0801M-00 | Collar |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-16111-00-00 | Gear, Primary Drive |
| 02 | 90282-07042-00 | Key, Straight |
| 03 | 90214-20022-00 | Washer, Claw |
| 04 | 90215-20182-00 | Washer, Lock |
| 05 | 90170-20274-00 | Nut |
| 06 | 2H7-16396-00-00 | Housing, Push Screw |
| 07 | 93606-07082-00 | Pin, Dowel |
| 08 | 2H7-16395-01-00 | Retainer, Ball |
| 09 | 2H7-16341-00-00 | Screw, Push |
| 10 | 2H7-16343-00-00 | Screw, Adjusting |
| 11 | 93210-48364-00 | O-ring |
| 12 | 4X7-16340-00-00 | Push Lever Assy |
| 13 | 92907-08200-00 | Washer |
| 14 | 95307-08700-00 | Nut |
| 15 | 90506-10069-00 | Spring, Tension |
| 16 | 93104-14059-00 | Oil Seal |
| 17 | 4X7-16357-00-00 | Rod, Push 2 |
| 18 | 4X7-16356-00-00 | Rod, Push 1 |
| 19 | 93340-21505-00 | Bearing |
| 20 | 90201-154E9-00 | Washer, Plate |
| 21 | 4X7-16150-02-00 | Primary Driven Gear Comp. |
| 22 | 3Y1-16154-00-00 | Plate, Thrust 1 |
| 23 | 4X7-16371-00-00 | Boss, Clutch |
| 24 | 4X7-16384-00-00 | Plate, Seat |
| 25 | 4X7-16383-01-00 | Spring, Clutch Boss |
| 26 | 4X7-16324-00-00 | Plate, Clutch 1 |
| 27 | 4X7-16385-00-00 | Ring, Clutch Boss |
| 28 | 22U-16321-00-00 | Plate, Friction |
| 29 | 4X7-16325-00-00 | Plate, Clutch 2 |
| 30 | 4X7-16351-00-00 | Plate, Pressure 1 |
| 31 | 90501-25398-00 | Spring, Compression |
| 32 | 90159-06092-00 | Screw, With Washer |
| 33 | 90215-20231-00 | Washer, Lock |
| 34 | 90170-20327-00 | Nut |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-17411-00-00 | Axle, Main |
| 02 | 4X7-17141-00-00 | Gear, 4th Pinion |
| 03 | 92909-22191-00 | Washer |
| 04 | 93410-25010-00 | Circlip |
| 05 | 4X7-17151-00-00 | Gear, 5th Pinion |
| 06 | 42X-17151-00-00 | Gear, 5th Pinion |
| 07 | 90201-20276-00 | Washer, Plate |
| 08 | 99009-20400-00 | Circlip |
| 09 | 93306-30525-00 | Bearing |
| 10 | 93104-20068-00 | Oil Seal |
| 11 | 93306-30424-00 | Bearing |
| 12 | 4X7-17402-00-00 | Drive Axle Assy |
| 13 | 4X7-17221-00-00 | Gear, 2nd Wheel |
| 14 | 90209-27192-00 | Washer |
| 15 | 93440-30077-00 | Circlip |
| 16 | 42X-17251-00-00 | Gear, 5th Wheel |
| 17 | 4X7-17231-00-00 | Gear, 3rd Wheel |
| 18 | 90209-27192-00 | Washer |
| 19 | 93440-30077-00 | Circlip |
| 20 | 4X7-17241-00-00 | Gear, 4th Wheel |
| 21 | 4X7-17211-00-00 | Gear, 1st Wheel |
| 22 | 93306-20421-00 | Bearing |
| 23 | 93306-20550-00 | Bearing |
| 24 | 93306-20550-00 | Bearing |
| 25 | 4PW-17583-00-00 | Gear, Middle Driven |
| 26 | 93316-01201-00 | Bearing |
| 27 | 93306-91201-00 | Bearing |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 1TA-Y1757-00-00 | Middle Gear Comp. |
| 02 | 93306-20901-00 | Bearing |
| 03 | 90179-44328-00 | Nut |
| 04 | 42X-17526-01-00 | Cam, Drive |
| 05 | 31A-17527-00-00 | Cam, Driven |
| 06 | 90501-70762-00 | Spring, Compression |
| 07 | 4X7-17524-00-00 | Holder |
| 08 | 3H5-17529-00-00 | Washer, Thrust |
| 09 | 4X7-17531-00-15 | Shim, Pinion |
| 09 | 4X7-17531-00-30 | Shim, Pinion |
| 09 | 4X7-17531-00-90 | Shim, Pinion |
| 10 | 90179-88336-00 | Nut |
| 11 | 93317-22021-00 | Bearing |
| 12 | 93311-34050-00 | Bearing |
| 13 | 90201-225A6-00 | Washer, Plate |
| 14 | 1J7-46129-Y1-00 | Spacer, Expansion |
| 15 | 11H-17551-00-00 | Housing, Bearing |
| 16 | 93210-71360-00 | O-ring |
| 17 | 93306-20548-00 | Bearing |
| 18 | 4X7-17554-00-00 | Retainer, Bearing |
| 19 | 93210-52449-00 | O-ring |
| 20 | 93101-35099-00 | Oil Seal |
| 21 | 4X7-17558-00-00 | Plate, Bearing |
| 22 | 4X7-17556-00-00 | Yoke, Joint |
| 23 | 93210-14359-00 | O-ring |
| 24 | 90201-14633-00 | Washer, Plate |
| 25 | 90179-14317-00 | Nut |
| 26 | 90387-251E1-00 | Collar |
| 27 | 95827-08030-00 | Bolt, Flange |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-18540-01-00 | Shift Cam Assy |
| 02 | 93306-90602-00 | • . Bearing |
| 03 | 4G0-18185-01-00 | • . Segment |
| 04 | 93604-20156-00 | • . Pin, Dowel |
| 05 | 93604-16092-00 | • . Pin, Dowel |
| 06 | 98701-05035-00 | • . Screw, Flat Head |
| 07 | 136-18542-00-00 | • . Point, Neutral |
| 08 | 90201-30297-00 | Washer, Plate |
| 09 | 4X7-18511-00-00 | Fork, Shift 1 |
| 10 | 4X7-18512-00-00 | Fork, Shift 2 |
| 11 | 4X7-18513-00-00 | Fork, Shift 3 |
| 12 | 4X7-18531-00-00 | Bar, Shift Fork Guide 1 |
| 13 | 4X7-18536-00-00 | Stopper, Shift Bar |
| 14 | 98707-06016-00 | Screw, Flat Head |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4X7-18120-01-00 | Shift Lever Assy |
| 02 | 90506-08227-00 | • . Spring, Tension |
| 03 | 4X7-18140-00-00 | Stopper Lever Assy |
| 04 | 90508-32535-00 | Spring, Torsion |
| 05 | 99006-10600-00 | Circlip |
| 06 | 90508-29531-00 | Spring, Torsion |
| 07 | 90201-12588-00 | Washer, Plate |
| 08 | 90387-124F4-00 | Collar |
| 09 | 90201-12588-00 | Washer, Plate |
| 10 | 90201-12166-00 | Washer, Plate |
| 11 | 93102-12106-00 | Oil Seal |
| 12 | 42X-18110-01-00 | Shift Pedal Assy |
| 13 | 2H9-18154-00-00 | • . Cover, Dust |
| 14 | 132-18113-01-00 | • . Cover, Shift Pedal |
| 15 | 90201-124E4-00 | Washer, Plate |
| 16 | 99009-12400-00 | Circlip |
| 17 | 42X-18112-01-00 | Arm, Shift |
| 18 | 2H9-18154-00-00 | • . Cover, Dust |
| 19 | 97024-06020-00 | Bolt |
| 20 | 29L-18115-00-00 | Rod, Shift |
| 21 | 90170-06228-00 | Nut |
| 22 | 95304-06700-00 | Nut |
| 23 | 93608-50158-00 | Pin, Dowel |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LP-21110-00-33 | Frame Comp. |
| 02 | 42X-21317-00-00 | Stay, Engine 3 |
| 03 | 42X-21359-00-00 | Bracket, Coil |
| 04 | 95817-06012-00 | Bolt, Flange |
| 05 | 92907-06100-00 | Washer, Spring |
| 06 | 92907-06600-00 | Washer, Plate |
| 07 | 90105-10297-00 | Bolt, Washer Based |
| 08 | 90176-10075-00 | Nut, Crown |
| 09 | 90179-12248-00 | Nut |
| 10 | 90201-125A3-00 | Washer, Plate |
| 11 | 42X-21315-01-00 | Stay, Engine 2 |
| 12 | 42X-21316-01-00 | Stay, Engine 3 |
| 13 | 90105-10298-00 | Bolt, Washer Based |
| 14 | 90201-105H3-00 | Washer, Plate |
| 15 | 90387-100E2-00 | Collar |
| 16 | 4X7-21485-00-00 | Damper, Rubber 1 |
| 17 | 90105-10050-00 | Bolt, Washer Based |
| 18 | 90105-10300-00 | Bolt, Washer Based |
| 19 | 42X-21458-01-00 | Bracket, Side Stand |
| 20 | 90176-10075-00 | Nut, Crown |
| 21 | 90105-06069-00 | Bolt, Washer Based |
| 22 | 90202-05187-00 | Washer, Plate |
| 23 | 90338-07043-00 | Plug |
| 24 | 90462-08138-00 | Clamp |
| 25 | 97707-50508-00 | Screw, Tapping |
| 26 | 2AE-2139R-00-00 | Cover 2 |
| 27 | 90159-06058-00 | Screw, With Washer |
| 29 | 134-23484-10-00 | Cap, Handle Lock |
| 30 | 90269-04003-00 | Rivet |
| 31 | 90208-04029-00 | Washer, Conical Spring |
| 32 | 4PW-2139U-00-00 | Damper 2 |
| 33 | 4PW-2139U-10-00 | Damper 2 |
| 34 | 4PW-2139U-20-00 | Damper 2 |
| 35 | 4PW-2139X-00-00 | Damper |
| 36 | 4PW-2139X-10-00 | Damper |
| 37 | 4PW-2139X-20-00 | Damper |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 1MY-21510-00-P2 | Front Fender Comp. |
| 01 | 1MY-Y2151-40-5Y | Front Fender Comp. |
| 02 | 4WP-21570-00-00 | Graphic Set, Front Fender |
| 03 | 97027-06012-00 | Bolt |
| 04 | 92907-06100-00 | Washer, Spring |
| 05 | 3EF-21610-00-P0 | Rear Fender Comp. |
| 05 | 3EF-Y2161-80-JW | Rear Fender Comp. |
| 06 | 4WP-21675-00-00 | • . Graphic, Rear Fender |
| 07 | 99236-00080-00 | Emblem, Yamaha |
| 08 | 97027-06012-00 | Bolt |
| 09 | 92907-06100-00 | Washer, Spring |
| 10 | 97027-08012-00 | Bolt |
| 11 | 92907-08100-00 | Washer, Spring |
| 12 | 1RM-2164F-00-00 | Stay 1 |
| 13 | 1RM-2164G-00-00 | Stay 2 |
| 14 | 1RM-2164H-00-00 | Stay 3 |
| 15 | 1RM-2164J-00-00 | Stay 4 |
| 16 | 2AE-2164A-00-00 | Grip 1 |
| 17 | 95817-06016-00 | Bolt, Flange |
| 18 | 95827-06016-00 | Bolt, Flange |
| 19 | 90149-08225-00 | Screw |
| 20 | 90105-10217-00 | Bolt, Washer Based |
| 21 | 42X-21629-00-00 | Guard, Mud |
| 22 | 90159-06128-00 | Screw, With Washer |
| 23 | 26H-21308-00-00 | Helmet Hanger Assy |
| 24 | 90149-06154-00 | Screw |
| 25 | 3EF-21621-00-00 | Flap |
| 26 | 2AE-21641-00-00 | Bracket, Reflector |
| 27 | 90267-40076-00 | Rivet, Blind |
| 28 | 90201-04018-00 | Washer, Plate |
| 29 | 98517-06012-00 | Screw, Pan Head |
| 30 | 92907-06600-00 | Washer, Plate |
| 31 | 90202-05187-00 | Washer, Plate |
| 32 | 95317-06600-00 | Nut |
| 33 | 92907-06200-00 | Washer |
| 34 | 4G0-21639-00-00 | Damper 2 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 42X-21711-00-JW | Cover, Side 1 |
| 01 | 42X-21711-00-P2 | Cover, Side 1 |
| 02 | 42X-21781-00-00 | Emblem 1 |
| 02 | 99237-00080-00 | Emblem, Yamaha |
| 03 | 90480-01401-00 | Grommet |
| 04 | 466-21717-00-00 | Damper |
| 05 | 42X-21721-00-JW | Cover, Side 2 |
| 05 | 42X-21721-00-P2 | Cover, Side 2 |
| 06 | 42X-21782-00-00 | Emblem 2 |
| 06 | 99237-00080-00 | Emblem, Yamaha |
| 07 | 90480-01401-00 | Grommet |
| 08 | 90480-12053-00 | Grommet |
| 09 | 42X-21171-00-00 | Box |
| 10 | 90480-20384-00 | Grommet |
| 11 | 90480-16233-00 | Grommet |
| 12 | 90387-060A7-00 | Collar |
| 13 | 90201-06065-00 | Washer, Plate |
| 14 | 97007-06020-00 | Bolt |
| 15 | 92907-06100-00 | Washer, Spring |
| 16 | 42X-21746-00-00 | Damper |
| 17 | 42X-28185-00-00 | Lid |
| 18 | 42X-2172W-02-00 | Cover |
| 19 | 98507-06010-00 | Screw, Pan Head |
| 20 | 92907-06010-00 | Washer |
| 21 | 42X-2177A-00-00 | Box |
| 22 | 90560-06258-00 | Spacer |
| 23 | 90201-06059-00 | Washer, Plate |
| 24 | 91317-06012-00 | Bolt |
| 25 | 90480-10408-00 | Grommet |
| 26 | 42X-2176E-00-00 | Plate |
| 27 | 90159-06110-00 | Screw, With Washer |
| 28 | 42X-2117F-00-00 | Cover |
| 29 | 90159-06071-00 | Screw, With Washer |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 1RM-22110-00-35 | Rear Arm Comp. |
| 02 | 93332-00010-00 | Bearing |
| 03 | 90387-17543-00 | Collar |
| 04 | 93102-25017-00 | Oil Seal |
| 05 | 42X-22141-00-00 | Shaft, Pivot |
| 06 | 90215-22238-00 | Washer, Lock |
| 07 | 1J7-22141-00-00 | Shaft, Pivot |
| 08 | 1J7-22143-00-00 | Nut |
| 09 | 2H7-2219X-00-00 | Cover |
| 10 | 95024-08035-00 | Bolt, Flange |
| 11 | 4X7-22189-01-00 | Boot, Rubber |
| 12 | 90338-20113-00 | Plug |
| 13 | 42X-22210-12-00 | Shock Absorber Assy, Rear |
| 14 | 42X-22220-12-00 | Shock Absorber Assy, Rear |
| 15 | 57A-22243-01-00 | Washer 1 |
| 16 | 91317-08020-00 | Bolt |
| 17 | 90338-08163-00 | Plug |
| 18 | 90201-105R9-00 | Washer, Plate |
| 19 | 90176-10073-00 | Nut, Crown |
| 20 | 92990-10100-00 | Washer, Spring |
| 21 | 90106-10052-00 | Bolt |


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




1TE130-6230


| Ref No | Part No | Description |
|---|---|---|
| 01 | 5G2-46101-01-00 | Rear Axle Gear Case Assy |
| 02 | 90116-10361-00 | • . Bolt, Stud |
| 03 | 90116-08360-00 | • . Bolt, Stud |
| 04 | 90116-10249-00 | • . Bolt, Stud |
| 05 | 4H7-46153-00-00 | • . Collar, Guide |
| 06 | 93101-30084-00 | • . Oil Seal |
| 07 | 93311-43729-00 | • . Bearing |
| 08 | 93317-41510-00 | Bearing |
| 09 | 2H7-46122-00-00 | • . Race, Inner |
| 10 | 1J7-17537-Y0-30 | • . Shim, Thrust |
| 10 | 1J7-17537-Y0-40 | • . Shim, Thrust |
| 10 | 1J7-17537-Y0-50 | • . Shim, Thrust |
| 11 | 93306-20533-00 | • . Bearing |
| 12 | 4H7-46125-00-00 | • . Retainer, Bearing |
| 13 | 93210-61426-00 | • . O-ring |
| 14 | 93101-38098-00 | • . Oil Seal |
| 15 | 4H7-46123-01-00 | • . Coupling, Gear |
| 16 | 90201-14632-00 | • . Washer, Plate |
| 17 | 90185-14070-00 | • . Nut, Self-locking |
| 18 | 4H7-46152-00-00 | • . Housing, Bearing |
| 19 | 1J7-46117-Y0-30 | • . Shim, Ring Gear |
| 19 | 1J7-46117-Y0-40 | • . Shim, Ring Gear |
| 19 | 1J7-46117-Y0-50 | • . Shim, Ring Gear |
| 20 | 93316-01403-00 | Bearing |
| 21 | 22U-46118-00-12 | • . Washer, Thrust |
| 21 | 22U-46118-00-14 | • . Washer, Thrust |
| 21 | 22U-46118-00-16 | • . Washer, Thrust |
| 21 | 22U-46118-00-18 | • . Washer, Thrust |
| 21 | 22U-46118-00-20 | • . Washer, Thrust |
| 22 | 93211-44348-00 | • . O-ring |
| 23 | 95333-08600-00 | • . Nut |
| 24 | 92901-08700-00 | • . Washer, Wave |
| 25 | 95811-10025-00 | • . Bolt, Flange |
| 26 | 93102-70167-00 | • . Oil Seal |
| 27 | 3VD-13455-00-00 | • . Plug |
| 28 | 214-11198-01-00 | • . Gasket |
| 29 | 2H7-17590-00-00 | • . Breather Comp. |
| 30 | 90340-14118-00 | • . Plug, Straight Screw |
| 31 | 4X7-46172-00-00 | Shaft, Drive |
| 32 | 93108-23007-00 | Oil Seal |
| 33 | 90201-231A2-00 | Washer, Plate |
| 34 | 93410-23056-00 | Circlip |
| 35 | 93410-22039-00 | Circlip |
| 36 | 90501-16491-00 | Spring, Compression |
| 37 | 4X7-46180-00-00 | Cross Joint Comp. |
| 38 | 93399-99926-00 | Bearing |
| 39 | 93440-20088-00 | Circlip |
| 40 | 90176-10075-00 | Nut, Crown |
| 41 | 92990-10100-00 | Washer, Spring |
| 42 | 90387-172A5-00 | Collar |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 93332-00001-00 | Bearing |
| 02 | 93332-00008-00 | Bearing |
| 03 | 1J7-23415-00-00 | Cover, Ball Race 1 |
| 04 | 90179-25033-00 | Nut |
| 05 | 90202-26142-00 | Washer, Plate |
| 06 | 26H-23418-01-00 | Washer, Special |
| 07 | 90176-22050-00 | Nut, Crown |
| 08 | 3AL-W2341-00-38 | Crown, Handle |
| 09 | 95024-08045-00 | Bolt, Flange |
| 10 | 92990-08100-00 | Washer, Spring |
| 11 | 92901-08600-00 | Washer, Plate |
| 12 | 1UF-23317-01-00 | Holder, Cable |
| 13 | 4H7-23441-00-38 | Holder, Handle Upper |
| 14 | 3AL-23442-00-38 | Holder, Handle Lower |
| 15 | 90201-14220-00 | Washer, Plate |
| 16 | 92907-12200-00 | Washer |
| 17 | 92907-12100-00 | Washer |
| 18 | 95317-12700-00 | Nut |
| 19 | 90468-12006-00 | Clip |
| 20 | 91314-08030-00 | Bolt |
| 21 | 90338-08163-00 | Plug |
| 22 | 1RM-23122-00-00 | Cover, Outer 1 |
| 23 | 1RM-2317E-00-00 | Stay |
| 24 | 92014-06012-00 | Bolt, Button Head |
| 25 | 90338-08163-00 | Plug |
| 26 | 42X-2313A-00-00 | Brace, Fork |
| 27 | 95024-08020-00 | Bolt, Flange |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 4FY-23102-30-00 | Front Fork Assy (l.h) |
| 02 | 4FY-23126-30-00 | • . Tube, Outer (left) |
| 03 | 2YK-23125-00-00 | • . Metal, Slide 1 |
| 04 | 4V2-23146-L0-00 | • . Washer, Oil Seal |
| 05 | 3EN-23145-00-00 | • . Oil Seal |
| 06 | 3R4-23153-00-00 | • . Ring, Snap |
| 07 | 3EN-23144-00-00 | • . Seal, Dust |
| 08 | 1RM-23110-00-00 | • . Inner Tube Comp.1 |
| 09 | 33M-23170-00-00 | • . Cylinder Comp., Front Fork |
| 10 | 1W1-23173-L0-00 | • . Spindle, Taper |
| 11 | 509-23158-L0-00 | • . Gasket |
| 12 | 278-23181-50-00 | • . Bolt, Hexagon Socket Head |
| 13 | 42H-23141-00-00 | • . Spring, Front Fork |
| 14 | 4FY-23149-00-00 | • . Washer, Spring Upper |
| 15 | 42X-23118-00-00 | • . Spacer |
| 16 | 31A-23111-31-00 | • . Bolt, Cap |
| 17 | 1W1-23114-L0-00 | • . Gasket |
| 18 | 42H-23168-00-00 | • . Cap, Front Fork |
| 19 | 4FY-23103-30-00 | • . Front Fork Assy (r.h) |
| 20 | 4FY-23136-30-00 | • . Tube, Outer (right) |
| 21 | 2YK-23125-00-00 | Metal, Slide 1 |
| 22 | 4V2-23146-L0-00 | • . Washer, Oil Seal |
| 23 | 3EN-23145-00-00 | • . Oil Seal |
| 24 | 3R4-23153-00-00 | • . Ring, Snap |
| 25 | 3EN-23144-00-00 | • . Seal, Dust |
| 26 | 3RM-23110-00-00 | • . Inner Tube Comp.1 |
| 27 | 33M-23170-00-00 | • . Cylinder Comp., Front Fork |
| 28 | 1W1-23173-L0-00 | • . Spindle, Taper |
| 29 | 509-23158-L0-00 | • . Gasket |
| 30 | 278-23181-50-00 | • . Bolt, Hexagon Socket Head |
| 31 | 42H-23141-00-00 | • . Spring, Front Fork |
| 32 | 4FY-23149-00-00 | • . Washer, Spring Upper |
| 33 | 42X-23118-00-00 | • . Spacer |
| 34 | 31A-23111-31-00 | • . Bolt, Cap |
| 35 | 1W1-23114-L0-00 | • . Gasket |
| 36 | 42H-23168-00-00 | • . Cap, Front Fork |
| 37 | 97313-08045-00 | • . Bolt |
| 38 | 92990-08100-00 | • . Washer, Spring |
| 39 | 95333-08600-00 | • . Nut |
| 40 | 2AE-23340-30-00 | Under Bracket Comp. |
| 41 | 91311-08030-00 | Bolt |
| 42 | 1RM-23132-00-00 | Cover, Outer 2 |
| 43 | 1RM-23132-10-00 | Cover, Outer 2 |
| 44 | 98580-05006-00 | Screw, Pan Head |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 1RM-24110-G0-02 | Fuel Tank Comp. |
| 01 | 1RM-24110-G0-04 | Fuel Tank Comp. |
| 02 | 3JK-24240-50-00 | • . Graphic Set |
| 02 | 4PW-24240-00-00 | • . Graphic Set |
| 03 | 1RM-24161-10-00 | Emblem 1 |
| 03 | 4PW-24161-00-00 | • . Emblem 1 |
| 04 | 1RM-24162-10-00 | Emblem 2 |
| 04 | 4PW-24162-00-00 | • . Emblem 2 |
| 05 | 4H7-24181-00-00 | Damper, Locating 1 |
| 06 | 42X-24182-00-00 | Damper, Locating 2 |
| 07 | 42X-24183-00-00 | Damper, Locating 3 |
| 08 | 97007-08016-00 | Bolt |
| 09 | 42X-24186-00-00 | Washer, Special |
| 10 | 3AL-24500-00-00 | Fuel Cock Assy 1 |
| 11 | 4X8-24512-00-00 | • . Gasket |
| 12 | 1JK-24534-00-00 | • . Seal, Cock |
| 13 | 98503-03008-00 | • . Screw, Pan Head |
| 14 | 3H3-24523-00-00 | • . Valve |
| 15 | 90202-05187-00 | Washer, Plate |
| 16 | 90149-06011-00 | Screw |
| 17 | 3AL-24321-00-00 | Pipe 10 |
| 18 | 90501-08728-00 | Spring, Compression |
| 19 | 90467-10135-00 | Clip |
| 20 | 3AL-2416A-00-00 | Hose |
| 21 | 90501-08410-00 | Spring, Compression |
| 22 | 90467-08092-00 | Clip |
| 23 | 4X7-24602-04-00 | Cap Assy |
| 24 | 4X7-24612-00-00 | • . Gasket, Cap |
| 25 | 91317-05010-00 | Bolt |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3CF-24730-10-00 | Double Seat Assy |
| 02 | 3CF-24731-10-00 | • . Cover, Seat |
| 03 | 509-24724-00-00 | • . Damper, Seat |
| 04 | 1L9-24741-00-00 | • . Pad, Seat |
| 05 | 91317-06016-00 | Bolt |
| 06 | 90110-06077-00 | Bolt, Hexagon Socket Head |
| 07 | 42X-2473R-00-00 | Box 1 |
| 08 | 90480-24186-00 | Grommet |
| 09 | 90201-225A4-00 | Washer, Plate |
| 10 | 5A8-21708-00-00 | Lock Assy 2 |
| 11 | 42X-2473T-00-00 | Lid 1 |
| 12 | 3CF-24723-00-00 | Damper, Seat |
| 13 | 42X-2177K-00-00 | Pin, Hinge |
| 14 | 1RM-2162G-00-00 | Plate 1 |
| 15 | 97017-06041-00 | Bolt |
| 16 | 97017-06016-00 | Bolt |
| 17 | 92907-06100-00 | Washer, Spring |
| 18 | 90201-06057-00 | Washer, Plate |
| 19 | 5H9-21376-00-00 | Band, Tool |
| 20 | 47G-85150-00-00 | Panel, Side |
| 21 | 90183-05003-00 | Nut, Spring |
| 22 | 42X-28100-10-00 | Tool Kit |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LP-25111-00-35 | Hub, Front |
| 02 | 90560-15116-00 | Spacer |
| 03 | 93306-30202-00 | Bearing |
| 04 | 93102-22014-00 | Oil Seal |
| 05 | 56W-2512A-00-00 | Cap, Wheel |
| 06 | 56W-2512A-10-00 | Cap, Wheel |
| 07 | 90110-06091-00 | Bolt, Hexagon Socket Head |
| 08 | 90338-06162-00 | Plug |
| 09 | 94421-19526-00 | Rim |
| 10 | 3LP-25104-00-00 | Spoke Set, Front |
| 11 | 94110-191H4-00 | Tire |
| 11 | 94110-194H3-00 | Tire |
| 12 | 93900-00030-00 | Valve, Rim |
| 13 | 3LP-25398-00-00 | Balancer, Wheel |
| 13 | 3LP-25398-10-00 | Balancer, Wheel |
| 13 | 3LP-25398-20-00 | Balancer, Wheel |
| 14 | 90387-15550-00 | Collar |
| 15 | 42X-25181-00-00 | Axle, Wheel |
| 16 | 42X-25190-00-00 | Gear Unit Assy |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LP-2582T-00-00 | Disc, Brake (left) |
| 02 | 90109-08178-00 | Bolt |
| 03 | 3LP-2582U-00-00 | Disc, Brake (right) |
| 04 | 3LP-2516A-00-00 | Damper |
| 05 | 3LP-2580U-00-00 | Caliper Assy (right) |
| 06 | 3YX-W0057-50-00 | • . Piston Assy, Caliper |
| 07 | 3YX-W0047-50-00 | • . Caliper Seal Kit |
| 08 | 5R2-25937-00-00 | • . Boot 2 |
| 09 | 3YX-25937-00-00 | • . Boot 2 |
| 10 | 3LP-W0045-00-00 | • . Brake Pad Kit |
| 11 | 3YX-25919-00-00 | • . Support, Pad |
| 12 | 3YX-25929-00-00 | • . Spring, Anti Rattle |
| 13 | 51L-W0048-00-00 | • . Bleed Screw Kit |
| 14 | 4DN-25827-00-00 | • . Shim, Caliper |
| 15 | 3LP-2580T-00-00 | • . Caliper Assy (left) |
| 16 | 3YX-W0057-50-00 | • . Piston Assy, Caliper |
| 17 | 3YX-W0047-50-00 | • . Caliper Seal Kit |
| 18 | 5R2-25937-00-00 | • . Boot 2 |
| 19 | 3YX-25937-00-00 | • . Boot 2 |
| 20 | 3YX-W0045-00-00 | • . Brake Pad Kit |
| 21 | 3YX-25919-00-00 | • . Support, Pad |
| 22 | 3YX-25929-00-00 | • . Spring, Anti Rattle |
| 23 | 51L-W0048-00-00 | • . Bleed Screw Kit |
| 24 | 4DN-25827-00-00 | • . Shim, Caliper |
| 25 | 3LP-23317-00-00 | Holder, Cable |
| 26 | 90105-10638-00 | Bolt, Washer Based |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3LP-25311-00-35 | Hub, Rear |
| 02 | 90560-17249-00 | Spacer |
| 03 | 146-25315-00-00 | Flange, Spacer |
| 04 | 93306-30309-00 | Bearing |
| 05 | 93306-20310-00 | Bearing |
| 06 | 93306-20310-00 | Bearing |
| 07 | 16G-25366-01-00 | Clutch, Hub |
| 08 | 42H-25364-00-00 | Damper |
| 09 | 93210-48530-00 | O-ring |
| 10 | 93210-59531-00 | O-ring |
| 11 | 16G-25412-00-00 | Washer |
| 12 | 90170-10219-00 | Nut |
| 13 | 93210-57428-00 | O-ring |
| 14 | 42H-25321-02-00 | Plate, Brake Shoe |
| 15 | 3DR-W2536-00-00 | Brake Shoe Set |
| 16 | 90507-20002-00 | Spring, Tension |
| 17 | 4H7-25351-00-00 | Camshaft |
| 18 | 3CF-25355-00-00 | Lever, Camshaft |
| 19 | 90201-14218-00 | Washer, Plate |
| 20 | 4H7-2533A-02-00 | Plate, Indicator |
| 21 | 90101-06764-00 | Bolt |
| 22 | 94430-15525-00 | Rim |
| 23 | 3LP-25304-00-00 | Spoke Set, Rear |
| 24 | 94114-155U9-00 | Tire |
| 24 | 94114-156U0-00 | Tire |
| 25 | 93900-00016-00 | Valve, Rim |
| 26 | 3LP-25398-10-00 | Balancer, Wheel |
| 26 | 3LP-25398-20-00 | Balancer, Wheel |
| 27 | 42X-25381-00-00 | Axle, Wheel |
| 28 | 90201-146R0-00 | Washer, Plate |
| 29 | 90171-14029-00 | Nut, Castle |
| 30 | 4E7-25188-00-00 | Cap |
| 31 | 91401-30030-00 | Pin, Cotter |
| 32 | 4H7-25377-00-00 | Collar, Wheel |
| 33 | 42X-25371-00-00 | Bar, Tension |
| 34 | 90109-08406-00 | Bolt |
| 35 | 92990-08600-00 | Washer, Plate |
| 36 | 92990-08100-00 | Washer, Spring |
| 37 | 95304-08700-00 | Nut |
| 38 | 91490-20020-00 | Pin, Cotter |
| 39 | 90109-08368-00 | Bolt |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3AL-W2611-10-00 | Handlebar |
| 02 | 3JB-26241-00-00 | Grip |
| 03 | 3JB-26273-00-00 | Rotor |
| 04 | 3JB-26240-00-00 | Grip Assy |
| 05 | 3JB-2628J-00-00 | Cap, Grip |
| 06 | 3CF-26311-00-00 | Cable, Throttle 1 |
| 07 | 3CF-26312-00-00 | Cable, Throttle 2 |
| 08 | 5H0-26393-00-00 | Holder |
| 09 | 98507-05008-00 | Screw, Pan Head |
| 10 | 57A-26335-00-00 | Cable, Clutch |
| 11 | 1E6-26342-00-00 | Boot, Cable |
| 12 | 90179-08148-00 | Nut |
| 13 | 90123-08046-00 | Bolt |
| 14 | 3CF-26331-01-00 | Cable, Starter 1 |
| 15 | 1J7-26290-F0-00 | Rear View Mirror Assy (right) |
| 16 | 1J7-26290-G0-00 | Rear View Mirror Assy (right) |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 22R-25850-02-00 | Master Cylinder Assy |
| 02 | 4K0-25854-00-00 | • . Diaphragm, Reservoir |
| 03 | 3GM-25852-01-00 | • . Cap, Reservoir |
| 04 | 98707-04012-00 | • . Screw, Flat Head |
| 05 | 4K0-W0041-50-00 | • . Cylinder Kit, Master |
| 06 | 4L0-25867-00-00 | Bracket, Master Cylinder |
| 07 | 97007-06025-00 | Bolt |
| 08 | 92907-06100-00 | Washer, Spring |
| 09 | 3LP-25872-11-00 | Hose, Brake 1 |
| 10 | 4L0-25862-00-00 | Boot, Master Cylinder |
| 11 | 90401-10159-00 | Bolt, Union |
| 12 | 90201-10118-00 | Washer, Plate |
| 13 | 42H-25885-01-00 | Joint |
| 14 | 3LP-25873-10-00 | Hose, Brake 2 |
| 15 | 3LP-25874-10-00 | Hose, Brake |
| 16 | 90401-10160-00 | Bolt, Union |
| 17 | 90201-10118-00 | Washer, Plate |
| 18 | 90401-10159-00 | Bolt, Union |
| 19 | 90201-10118-00 | Washer, Plate |
| 20 | 55R-25875-00-00 | Holder, Brake Hose 1 |
| 21 | 95024-06020-00 | Bolt, Flange |
| 22 | 55R-25876-00-00 | Holder, Brake Hose 2 |
| 23 | 95024-06020-00 | Bolt, Flange |
| 24 | 90401-10159-00 | Bolt, Union |
| 25 | 90201-10118-00 | Washer, Plate |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3CF-27211-00-93 | Pedal, Brake |
| 02 | 90109-06468-00 | Bolt |
| 03 | 92995-06100-00 | Washer, Spring |
| 04 | 42X-27212-01-00 | Shaft, Brake Pedal |
| 05 | 90506-20192-00 | Spring, Tension |
| 06 | 90101-06478-00 | Bolt |
| 07 | 90170-06184-00 | Nut |
| 08 | 3CF-27231-01-00 | Rod, Brake |
| 09 | 90240-06057-00 | Pin, Clevis |
| 10 | 90560-06201-00 | Spacer |
| 11 | 92907-06200-00 | Washer |
| 12 | 91490-20020-00 | Pin, Cotter |
| 13 | 3CF-27241-00-00 | Rod, Joint |
| 14 | 90240-06103-00 | Pin, Clevis |
| 15 | 90501-10245-00 | Spring, Compression |
| 16 | 90249-12008-00 | Pin |
| 17 | 90175-06019-00 | Nut, Wing |
| 18 | 42X-27111-00-R4 | Stand, Main |
| 19 | 97007-10016-00 | Bolt |
| 20 | 90201-10752-00 | Washer, Plate |
| 21 | 90506-35149-00 | Spring, Tension |
| 22 | 371-27114-00-00 | Stopper, Main Stand |
| 23 | 42X-27311-00-R4 | Stand, Side |
| 24 | 3Y3-27315-00-00 | Link, Side Stand |
| 25 | 90109-101G3-00 | Bolt |
| 26 | 95304-10700-00 | Nut |
| 27 | 90506-26225-00 | Spring, Tension |
| 28 | 90506-28224-00 | Spring, Tension |
| 29 | 3CF-27410-00-93 | Front Footrest Assy (left) |
| 30 | 1NH-27413-00-00 | • . Cover, Footrest |
| 31 | 95601-06100-00 | • . Nut, U |
| 32 | 90508-18696-00 | • . Spring, Torsion |
| 33 | 91701-08038-00 | • . Pin, Clevis |
| 34 | 91401-25020-00 | • . Pin, Cotter |
| 35 | 90387-087K5-00 | • . Collar |
| 62 | 98517-06012-00 | • . Screw, Pan Head |
| 63 | 1HX-27437-00-00 | • . Washer, Special |
| 64 | 91701-06038-00 | • . Pin, Clevis |
| 65 | 91490-16020-00 | Pin, Cotter |
| 66 | 90501-12743-00 | Spring, Compression |
| 67 | 93501-04011-00 | Ball |
| 68 | 95024-08020-00 | Bolt, Flange |
| 69 | 95024-08045-00 | Bolt, Flange |
| 36 | 1RM-27420-00-93 | Front Footrest Assy (right) |
| 37 | 1NH-27413-00-00 | • . Cover, Footrest |
| 38 | 95607-06100-00 | • . Nut, U |
| 39 | 90508-18696-00 | • . Spring, Torsion |
| 40 | 91701-08038-00 | • . Pin, Clevis |
| 41 | 91401-25020-00 | • . Pin, Cotter |
| 42 | 90387-087K5-00 | • . Collar |
| 43 | 4X7-27414-00-00 | • . Damper, Footrest |
| 44 | 90387-100A1-00 | • . Collar |
| 45 | 90201-100A1-00 | Washer, Plate |
| 46 | 90109-100G0-00 | Bolt |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 47 | 3CF-27471-00-00 | Bar, Footrest 1 |
| 48 | 90338-09012-00 | Plug |
| 49 | 3CF-27472-00-00 | Bar, Footrest 2 |
| 50 | 90105-10050-00 | Bolt, Washer Based |
| 51 | 90176-10075-00 | Nut, Crown |
| 52 | 1RM-27430-00-00 | Rear Footrest Assy 1 |
| 53 | 1NH-27433-00-00 | • . Cover, Rear Footrest |
| 54 | 98517-06012-00 | • . Screw, Pan Head |
| 55 | 1HX-27437-00-00 | • . Washer, Special |
| 56 | 91701-06038-00 | • . Pin, Clevis |
| 57 | 91490-16020-00 | • . Pin, Cotter |
| 58 | 90501-12743-00 | • . Spring, Compression |
| 59 | 1RM-27440-01-00 | • . Rear Footrest Assy 2 |
| 60 | 1RM-27433-00-00 | • . Cover, Rear Footrest |
| 61 | 1NH-27437-00-00 | • . Washer, Special |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 3JL-81450-00-0 | Rotor Assy |
| 02 | 1RM-81410-20- | Stator Assy |
| 03 | 1RM-81661-00- | Spacer |
| 04 | 91317-06050-0 | Bolt |
| 05 | 3JL-81670-00-0 | Pick-up Assy |
| 06 | 91317-06016-0 | Bolt |
| 07 | 90201-06643-0 | Washer, Plate |


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 5A8-81800-10-00 | Starting Motor Assy |
| 02 | 5A8-81826-10-00 | • . Bolt |
| 03 | 11H-81844-00-00 | • . Gasket |
| 04 | 5A8-81830-10-00 | • . Front Bracket Assy |
| 05 | 5A8-81847-10-00 | •• .. O-ring |
| 06 | 5A8-81840-10-00 | • . Brush Holder Assy |
| 07 | 1J7-81847-60-00 | • . O-ring |
| 08 | 98517-06025-00 | Screw, Pan Head |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





42W110-4360


| Ref No | Part No | Description |
|---|---|---|
| 01 | 2EN-83310-00-00 | Front Flasher Light Assy 1 |
| 02 | 1KT-83311-00-00 | Bulb, Flasher |
| 03 | 42X-83312-00-00 | Lens, Flasher |
| 04 | 42X-83313-00-00 | • . Gasket, Flasher Lens |
| 05 | 42X-83363-00-00 | • . Lens, Rim |
| 06 | 98507-03020-00 | • . Screw, Pan Head |
| 07 | 42X-83359-00-00 | • . Washer, Special |
| 08 | 1AA-83318-00-00 | • . Stay, Flasher 1 |
| 09 | 2EN-83330-00-00 | • . Rear Flasher Light Assy 1 |
| 10 | 1KT-83311-00-00 | • . Bulb, Flasher |
| 11 | 2AE-83312-00-00 | • . Lens, Flasher |
| 12 | 42X-83313-00-00 | • . Gasket, Flasher Lens |
| 13 | 42X-83363-00-00 | • . Lens, Rim |
| 14 | 341-83333-70-00 | Screw, Lens Fitting |
| 15 | 42X-83359-00-00 | • . Washer, Special |
| 16 | 1AA-83318-00-00 | Stay, Flasher 1 |
| 17 | 95707-12500-00 | Nut, Flange |
| 18 | 97004-06030-00 | Bolt |
| 19 | 95704-06500-00 | Nut, Flange |
| 20 | 42X-83328-00-00 | Stay, Flasher 2 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 1FL-83570-F0-00 | Speedometer Assy |
| 02 | 1RM-83540-00-00 | Tachometer Assy |
| 03 | 3LP-8353E-00-00 | Case, Meter Upper |
| 04 | 3CF-8353H-00-00 | Case, Under |
| 05 | 1FG-83519-00-00 | Bracket, Meter |
| 06 | 42X-83507-00-00 | Cover, Speedometer |
| 07 | 42X-83508-00-00 | Cover, Tachometer |
| 08 | 1FG-83523-00-00 | Damper |
| 09 | 90201-05013-00 | Washer, Plate |
| 10 | 95307-05600-00 | Nut |
| 11 | 98507-04008-00 | Screw, Pan Head |
| 12 | 97707-40014-00 | Screw, Tapping |
| 13 | 1RM-83509-00-00 | Socket Cord Assy |
| 14 | 42X-83517-00-00 | Bulb |
| 15 | 36Y-82151-00-00 | Fuse |
| 16 | 42X-82151-20-00 | Fuse |
| 17 | 42X-83559-00-00 | Cover, Meter |
| 18 | 1FK-83523-00-00 | Damper |
| 19 | 1FK-83535-00-00 | Tube |
| 20 | 98707-04010-00 | Screw, Flat Head |
| 21 | 55R-83579-00-00 | Cover, Meter 2 |
| 22 | 92907-06200-00 | Washer |
| 23 | 92907-06100-00 | Washer, Spring |
| 24 | 95317-06600-00 | Nut |
| 25 | 584-83541-00-00 | Damper |
| 26 | 90387-06249-00 | Collar |
| 27 | 3LP-83550-00-00 | Speedometer Cable Assy |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 42X-84315-01-00 | Rim, Headlight |
| 02 | 5Y3-84395-00-00 | Ring, Retaining |
| 03 | 2AE-84320-G0-00 | Lens Assy |
| 05 | 2F9-84375-00-00 | Fitting Plate, Bulb |
| 06 | 2F9-84397-01-00 | Cover, Socket |
| 08 | 34L-84346-00-00 | • . Socket, Pilot Light |
| 09 | 90157-04001-00 | • . Screw, Pan Head |
| 10 | 1A0-84332-60-00 | Spring, Screw |
| 11 | 198-84334-60-00 | Nut, Adjusting |
| 12 | 42X-84330-01-00 | Body Assy |
| 13 | 42X-84330-01-00 | Body Assy |
| 14 | 42X-84345-00-00 | • . Damper, Headlight |
| 15 | 42X-84338-00-00 | • . Collar, Body Fitting |
| 16 | 42X-84366-00-00 | • . Damper, Headlight 1 |
| 17 | 90157-05084-00 | Screw, Pan Head |
| 18 | 90201-06073-00 | Washer, Plate |
| 19 | 97017-06016-00 | Bolt |
| 20 | 92907-06100-00 | Washer, Spring |
| 21 | 91317-08055-00 | Bolt |
| 22 | 42X-84318-00-00 | Stay, Headlight 1 |
| 23 | 91317-06025-00 | Bolt |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 2EM-84700-E0-00 | Taillight Assy |
| 02 | 2AE-84721-00-00 | • . Lens, Taillight |
| 03 | 42X-84723-01-00 | • . Gasket, Tail Lens |
| 04 | 1RM-84704-00-00 | • . Gasket, Taillight |
| 05 | 97707-40625-00 | • . Screw, Tapping |
| 06 | 31L-84714-00-00 | • . Bulb |
| 07 | 90119-06097-00 | Bolt, With Washer |
| 08 | 90387-065L5-00 | Collar |
| 09 | 90480-14229-00 | Grommet |
| 10 | 90480-16501-00 | Grommet |
| 11 | 90480-01502-00 | Grommet |
| 12 | 2YL-84751-00-00 | Bracket, License |
| 13 | 95807-06016-00 | Bolt, Flange |
| 14 | 92907-06600-00 | Washer, Plate |
| 15 | 95307-06600-00 | Nut |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.





| Ref No | Part No | Description |
|---|---|---|
| 01 | 10M-82911-00-00 | Holder, Lever 1 |
| 02 | 2GV-83912-00-00 | Lever 1 |
| 03 | 3Y6-82917-00-00 | Switch |
| 04 | 90109-06799-00 | Bolt |
| 05 | 95607-06100-00 | Nut, U |
| 06 | 93210-11368-00 | O-ring |
| 07 | 97007-06025-00 | Bolt |
| 08 | 92907-06100-00 | Washer, Spring |
| 09 | 2W1-83922-00-00 | Lever 2 |
| 10 | 90149-06153-00 | Screw |
| 11 | 90170-06010-00 | Nut |
| 12 | 90501-10312-00 | Spring, Compression |
| 13 | 90109-05577-00 | Bolt |
| 14 | 95607-06100-00 | Nut, U |
| 15 | 1AT-83972-00-00 | Switch, Handle 4 |
| 16 | 98507-06035-00 | • . Screw, Pan Head |
| 17 | 10M-83942-00-00 | • . Cover, Starter |
| 18 | 10M-83941-00-00 | • . Lever, Starter |
| 19 | 90209-10131-00 | • . Washer |
| 20 | 98507-06008-00 | Screw, Pan Head |
| 21 | 92907-06200-00 | Washer |
| 22 | 4FY-83963-00-00 | Switch, Handle 3 (right) |
| 23 | 98507-05040-00 | Screw, Pan Head |
| 24 | 98507-05045-00 | Screw, Pan Head |
| 25 | 437-83936-01-00 | Band, Switch Cord |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 5E3-82110-80-00 | Battery Assy |
| 02 | 1E6-82131-00-00 | Band, Battery |
| 03 | 42H-82115-00-00 | Wire, Plus Lead |
| 04 | 42X-82116-00-00 | Wire, Minus Lead |
| 05 | 90445-081A9-00 | Hose |
| 06 | 4KM-82540-00-00 | Neutral Switch Assy |
| 07 | 90430-10148-00 | Gasket |
| 08 | 42X-82310-70-00 | Ignition Coil Assy |
| 09 | 42X-82320-70-00 | Ignition Coil Assy |
| 10 | 98980-05016-00 | Screw, Bind |
| 11 | 42X-82317-00-00 | Damper, Ignition Coil |
| 12 | 1J7-82370-00-00 | Plug Cap Assy |
| 13 | 57A-82314-00-00 | Cover, Ignition Coil |
| 14 | 98517-06012-00 | Screw, Pan Head |
| 15 | 92907-06600-00 | Washer, Plate |
| 16 | 98507-06025-00 | Screw, Pan Head |
| 17 | 92907-06600-00 | Washer, Plate |
| 18 | 2AE-82510-00-00 | Main Switch Assy |
| 19 | 97017-06016-00 | Bolt |
| 20 | 92907-06600-00 | Washer, Plate |
| 21 | 1A0-83980-30-00 | Front Stop Switch Assy |
| 22 | 42X-82530-02-00 | Stop Switch Assy |
| 23 | 42X-82539-00-00 | Stay, Stop Switch |
| 24 | 4FY-82590-00-00 | Wire Harness Assy |
| 25 | 3H5-82150-00-00 | Fuse Holder Assy |
| 26 | 2H7-82151-00-00 | • . Fuse |
| 27 | 3JL-82305-00-00 | Ignitor Unit Assy |
| 28 | 97707-60520-00 | Screw, Tapping |
| 29 | 90201-063A5-00 | Washer, Plate |
| 30 | 3JK-85750-00-00 | Fuel Meter Assy |
| 31 | 91317-06016-00 | Bolt |
| 32 | 33E-82566-00-00 | Switch, Side Stand |
| 33 | 90152-05021-00 | Screw, Countersunk |
| 34 | 4FY-82571-00-00 | Panel, Switch |
| 35 | 97707-60114-00 | Screw, Tapping |
| 36 | 3BT-82560-00-00 | Thermo Switch Assy |
| 37 | 4FY-82509-00-00 | Wire, Sub Lead |
| 38 | 3JC-82509-00-00 | Wire, Sub Lead |
| 39 | 437-83936-01-00 | Band, Switch Cord |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




| Ref No | Part No | Description |
|---|---|---|
| 01 | 5A8-86110-50-00 | Solenoid |
| 02 | 25G-81950-01-00 | Relay Assy |
| 03 | 3JK-81815-00-00 | Cord, Starter Motor |
| 04 | 95307-06700-00 | Nut |
| 05 | 92907-06100-00 | Washer, Spring |
| 06 | 95307-08700-00 | Nut |
| 07 | 92907-08100-00 | Washer, Spring |
| 08 | 42X-81960-A1-00 | Rectifier & Regulator Assy |
| 09 | 98507-06016-00 | Screw, Pan Head |
| 10 | 92907-06100-00 | Washer, Spring |
| 11 | 92907-06600-00 | Washer, Plate |
| 12 | 90465-10264-00 | Clamp |
| 13 | 4U8-81980-00-00 | Diode Assy |
| 14 | 3BT-83790-00-00 | Heater Assy |
| 15 | 3BT-82103-00-00 | Terminal 1 |
| 16 | 90201-085R5-00 | Washer, Plate |
| 17 | 3UH-14146-00-00 | Plate |
| 18 | 47G-83350-41-00 | Flasher Relay Assy |
| 19 | 1RM-83371-00-00 | Horn |
| 20 | 1RM-83371-10-00 | Horn |
| 21 | 91317-06012-00 | Bolt |
| 22 | 42X-85752-01-00 | Sender Unit Assy, Fuel Meter |
| 23 | 42X-85753-00-00 | Gasket, Sender Unit |
| 24 | 90149-06011-00 | Screw |
| 25 | 90202-05187-00 | Washer, Plate |
| 26 | 449-85131-02-00 | Reflector, Rear 1 |

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.