
YAMAHA

GENUINE

PARTS CATALOGUE

MOTORCYCLE


A1



CYLINDER HEAD

Ref. No.	Part Number	Description	Qty	Remarks
1	3AL-11102-00-00	CYLINDER HEAD ASS''Y	2	
2	93440-14086-00	. CIRCLIP, OUTER	2	
3	4X7-11133-10-00	. GDE, INTK VLV 1 O/S	2	1ST O/S
4	4X7-11127-00-00	ABSORBER 3	8	
5	42H-14873-01-00	PIPE 3	2	
6	91800-06030-00	PIN, DOWEL	4	
7	42Y-11181-00-00	GASKET, CYLINDER HEAD 1 .	2	
8	4X7-11363-01-00	BOLT, CYLINDER HOLDING 3 .	4	
9	90116-12469-00	BOLT, STUD	4	
10	90116-10344-00	BOLT, STUD	2	
11	90179-12326-00	NUT, SPEC''L SHAPE	4	
12	90201-125A3-00	WASHER, PLATE	4	
13	90179-12325-00	NUT	4	
14	90176-10049-00	NUT, CROWN	2	
15	90202-05187-00	WASHER, PLATE	2	
16	91311-08050-00	BOLT, SOCKET HEAD	4	
17	95611-08640-00	BOLT, STUD	4	
18	42X-11185-01-00	COVER, CYLINDER HEAD SIDE 1	1	
19	91311-06016-00	BOLT, SOCKET HEAD	2	
20	42X-11152-00-00	BRACKET, CYLINDER HEAD COVER	1	
21	90202-05187-00	WASHER, PLATE	2	
22	42X-1111H-01-00	COVER, CYLINDER HEAD SIDE 4	1	
23	42X-11165-00-00	PLATE, BREATHER	1	
24	42X-11166-01-00	PIPE, BREATHER 1	1	
25	90467-14015-00	CLIP	2	
26	93210-92448-00	O-RING	2	
27	91311-06025-00	BOLT, SOCKET HEAD	2	


CONTINUED ON NEXT FRAME ➤



CYLINDER HEAD

Ref. No.	Part Number	Description	Qty	Remarks
28	42H-11186-01-00	COVER, CYLINDER HEAD SIDE 2	2	
29	4X7-11187-00-00	COVER, CYLINDER.HEAD 3	2	
30	93210-62446-00	O-RING	4	
31	91311-06016-00	BOLT, SOCKET HEAD	8	
32	4X7-1111F-00-00	PLATE	2	
33	97011-08020-00	BOLT	2	
34	90401-16065-00	BOLT, UNION	2	
35	90430-17168-00	GASKET	2	
36	1RM-1112E-00-00	COVER, CYLINDER HEAD 3	1	
37	90480-23444-00	GROMMET	2	
38	91316-06010-00	BOLT, SOCKET HEAD	1	
39	NGK-BP7ES-00-00	PLUG, SPARK (NGK BP-7ES)	2	UR

CYLINDER




Ref. No.	Part Number	Description	Qty	Remarks
1	1RT-11310-00-00	CYLINDER	2	
2	93210-89447-00	O-RING	2	
3	4X7-11161-00-00	ABSORBER 1	4	
4	90387-087A5-00	COLLAR	4	
5	91311-06040-00	BOLT	6	
6	3JL-11351-00-00	GASKET, CYLINDER	2	
7	4X7-12215-00-00	CAP, TENSIONER CASE	2	
8	4DW-12213-00-00	GASKET, TENSIONER CASE	2	
9	91311-06025-00	BOLT, SOCKET HEAD	4	

FWD


10L110-2020

CRANKSHAFT - PISTON



Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-11411-02-00	CRANKSHAFT	1	
2	93306-30808-00	BEARING (3EF)	1	
3	4X7-13354-00-00	SPROCKET, DRIVE	1	
4	93306-30808-00	BEARING (3EF)	1	
5	42Y-11631-00-A0	PISTON (STD)	2	
	42Y-11636-00-00	PISTON (0.50MM O/S)	2	AP
	42Y-11638-00-00	PISTON (1.00MM O/S)	2	AP
6	42Y-11610-01-00	PISTON RING SET (STD)	2	
	42Y-11610-21-00	PISTON RING SET (0.50MM O/S) (42Y-11610-20-00)	2	AP
	42Y-11610-41-00	PISTON RING SET (1.00MM O/S)	2	AP
7	4X7-11633-00-00	PIN, PISTON	2	
8	93450-22027-00	CIRCLIP	4	
9	4X7-11650-00-00	CONNECTING ROD ASSEMBLY	2	
10	4X7-11654-01-00	. BOLT, CON ROD	2	
11	90179-09379-00	. NUT, SPEC''L SHAPE	2	
12	4X7-11656-00-00	PLANE BRNG, CON ROD	4	UR BLUE
	4X7-11656-10-00	PLANE BRNG, CON ROD	4	UR BLACK
	4X7-11656-20-00	PLANE BRNG, CON ROD	4	UR BROWN
	4X7-11656-30-00	PLANE BRNG, CON ROD	4	UR GREEN
	4X7-11656-40-00	PLANE BRNG, CON ROD	4	UR YELLOW
13	90280-16053-00	KEY, WOODRUFF	1	
14	90201-165H4-00	WASHER, PLATE	1	
15	90179-16448-00	NUT, SPEC''L SHAPE	1	

CAMSHAFT - CHAIN




42W110-4050

Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-11536-00-00	GEAR, DRIVE (35T)	1	
2	4X7-11534-00-00	GEAR, BREAKER DRIVE	1	
3	90501-21133-00	SPRING, COMPRESSION	12	
4	93605-10090-00	PIN, DOWEL	12	
5	4X7-11540-01-00	CM CHN SPRKT ASSEMBLY 1 (20/50T)	1	
6	4X7-11550-00-00	CAM CHAIN SPRKT 2 (20/50T)	1	
7	4X7-12247-01-00	SHAFT, TENSIONER	2	
8	90209-06205-00	WASHER, SPEC''L SHAP	2	
9	90105-06154-00	BOLT, WASHER BASED	2	
10	42X-12171-00-00	CAMSHAFT 1	1	
11	42X-12181-00-00	CAMSHAFT 2	1	
12	42X-11145-00-00	PLATE, BREATHER 2	1	
13	90201-10774-00	WASHER, PLATE	2	
14	90101-10303-00	BOLT	2	
15	90380-25125-00	BUSH, SOLID	2	
16	94590-45098-00	CHAIN, CAM	2	
17	4X7-12176-00-00	SPROCKET, CAM CHAIN	2	
18	93604-10011-00	PIN, DOWEL	2	
19	4X7-12210-01-00	TENSNR ASSEMBLY, CAM CHN	2	
20	90338-06121-00	. PLUG, SPEC''L SHAPE	1	
21	4X7-12231-00-00	GUIDE, STOPPER 1	2	
22	4X7-12241-00-00	GUIDE, STOPPER 2	1	
23	4X7-12221-00-00	GUIDE, STOPPER 3	1	
24	90109-08592-00	BOLT	2	
25	95303-08700-00	NUT	2	
26	92901-06600-00	WASHER	2	
27	91311-06025-00	BOLT, SOCKET HEAD	4	

CONTINUED ON NEXT FRAME ➤


CAMSHAFT - CHAIN



42W110-4050


Ref. No.	Part Number	Description	Qty	Remarks
28	4DW-12213-00-00	GASKET, TENSIONER CASE . .	2	

VALVE




Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-12111-00-00	VALVE, INTAKE	2	
2	4X7-12121-00-00	VALVE, EXHAUST	2	
3	4X7-12116-00-00	SEAT, VALVE SPRING	4	
4	90501-31454-00	SPRING, COMPRESSION	4	
5	90501-44455-00	SPRING, COMPRESSION	4	
6	341-12119-02-00	SEAL, VALVE STEM	4	
7	4X7-12117-00-00	RETAINER, VALVE SPR	4	
8	4X7-12118-00-00	COTTER, VALVE	8	
9	42X-12151-00-00	ARM, VALVE ROCKER (4X7-12151-00)	4	
10	4X7-12156-01-00	SHAFT, ROCKER	4	
11	4X7-12159-00-00	SCREW, VALVE ADJUSTING	4	
12	90170-08173-00	NUT, HEXAGON	4	

OIL PUMP




Ref. No.	Part Number	Description	Qty	Remarks
1	10L-13300-00-00	OIL PUMP ASSEMBLY	1	
2	99510-08016-00	PIN, DOWEL	1	
3	93210-07438-00	O-RING	2	
4	91316-06040-00	BOLT, SOCKET HEAD	3	
5	4X7-13355-00-00	SPROCKET, DRIVEN	1	
6	90105-06154-00	BOLT, WASHER BASED	1	
7	10L-13327-00-00	COVER, PUMP GEAR	1	
8	91316-06010-00	BOLT, SOCKET HEAD	2	
9	94580-25066-00	CHAIN 4 7	1	
10	4X7-13171-00-00	PIPE, DELIVERY 2	1	
11	93210-07438-00	O-RING	2	
12	91316-06010-00	BOLT, SOCKET HEAD	2	
13	4X7-13405-00-00	OIL PIPE CMPLT 1	1	
14	4X7-15485-01-00	CLAMP	1	
15	4X7-15484-00-00	CLAMP 2	1	
16	90468-05113-00	CLIP	1	
17	1RM-13406-00-00	OIL PIPE COMP. 2	1	
18	90401-16067-00	BOLT, UNION	2	
19	90430-17168-00	GASKET	4	
20	90401-10102-00	BOLT, UNION	1	
21	90430-15169-00	GASKET	3	
22	4X7-15485-01-00	CLAMP	1	
23	90468-05113-00	CLIP	1	
24	3VD-13455-00-00	PLUG	1	
25	214-11198-01-00	GASKET	1	



OIL FILTER


Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-13440-90-00	ELMNT ASSEMBLY, OIL CLNR	1	
2	93210-56459-00	O-RING	1	
3	93210-54452-00	O-RING	1	
4	1RM-13447-00-00	COVER, OIL ELEMENT	1	
5	93210-07135-00	O-RING	1	
6	90109-06678-00	BOLT	1	
7	91311-06020-00	BOLT, SOCKET HEAD	1	
8	91311-06050-00	BOLT, SOCKET HEAD	1	
9	11H-13490-00-00	RELIEF VALVE ASSEMBLY	1	
10	93210-10096-00	O-RING	1	
11	90462-10098-00	CLAMP	1	



AIR FILTER

Ref. No.	Part Number	Description	Qty	Remarks
1	24M-13586-01-00	JOINT, CARBURETOR 1	2	
2	16G-13569-00-00	PLUG, BLIND	1	
3	90467-10039-00	CLIP	1	
4	42X-13564-01-00	COVER, MANIFOLD	2	
5	42X-13578-00-00	WASHER	2	
6	42X-13544-00-00	HOSE, VACUUM SENSING 2	1	
7	90467-08092-00	CLIP	2	
8	93210-44545-00	O-RING	2	
9	97016-06020-00	BOLT	4	
10	92906-06600-00	WASHER	4	
11	1TA-13534-00-00	HOSE, VACUUM SENSING 5	1	
12	90467-08092-00	CLIP	2	
13	1RV-13595-00-00	JOINT	1	
14	1TA-13535-00-00	HOSE, VACUUM SENSING 5	1	
15	41R-14489-00-00	NOZZLE	1	
16	3CG-14197-00-00	PIPE	1	
17	3CG-14987-00-00	HOSE	1	
18	90467-14057-00	CLIP	2	
19	3CG-14396-00-00	PIPE	1	
20	90413-07023-00	WAY 3	1	
21	1TA-14349-00-00	PIPE	1	
22	1TA-14348-00-00	PIPE 1	1	
23	90467-10091-00	CLIP, SCISSOR	4	
24	10L-14453-01-00	JOINT, AIR CLEANER 1	2	
25	10L-14407-00-00	COVER, JOINT	1	
26	90460-65195-00	CLAMP, HOSE	4	
27	42X-14401-01-00	AIR CLEANER CASE ASSEMBLY	1	
28	92901-04600-00	WASHER, PLATE	2	


CONTINUED ON NEXT FRAME ➤



AIR FILTER


Ref. No.	Part Number	Description	Qty	Remarks
29	42X-14477-00-00	PLATE	2	
30	97780-40112-00	SCREW, TAPPING	4	
31	42X-14451-00-00	ELEMENT, AIR CLEANER	1	
32	1RM-14422-00-00	CAP, CLEANER CASE 2	1	
33	42X-14452-00-00	SEAL	1	
34	1TA-1441A-00-00	COVER, CLEANER CASE 1	1	
35	97706-50508-00	SCREW, TAPPING	1	
36	98580-05012-00	SCREW, PAN HEAD	1	
37	92901-05600-00	WASHER, PLATE	1	
38	98506-06080-00	SCREW, PAN HEAD	1	
39	98506-06050-00	SCREW, PAN HEAD	1	
40	92906-06600-00	WASHER	1	
41	1TA-1441E-00-00	COVER, CLEANER CASE 2	1	
42	97706-50508-00	SCREW, TAPPING	1	
43	90387-07598-00	COLLAR	1	
44	90110-06138-00	BOLT, HEX SKT HEAD	1	
45	92906-06200-00	WASHER	2	
46	91316-06012-00	BOLT, SOCKET HEAD	1	
47	42X-14485-00-00	PIPE, JOINT	1	
48	90460-65195-00	CLAMP, HOSE	1	
49	42X-14663-02-00	PLATE, AIR CLEANER	1	
50	91311-06090-00	BOLT	1	
51	92906-06200-00	WASHER	1	
52	42X-14484-00-00	PLATE, CLEANER CASE FITTING	1	
53	95811-06025-00	BOLT, FLANGE	1	
54	1RM-14603-00-00	COVER 1	1	
55	90480-14074-00	GROMMET	2	
56	95821-06014-00	BOLT, FLANGE	1	

CONTINUED ON NEXT FRAME ➤



AIR FILTER


Ref. No.	Part Number	Description	Qty	Remarks
57	12R-14484-01-00	PLATE, CLEANER CASE FITTING	1	
58	91316-06035-00	BOLT	1	
59	92906-06200-00	WASHER	1	



CARBURETOR

Ref. No.	Part Number	Description	Qty	Remarks
1	(3CM-14900-00-00	UNAVAILABLE IN PRICE BOOK	1	N/A
	¢3A-L1490-00-10	CARBURETOR ASSEMBLY . . .	1	N/A
2	3CM-14901-01-00	. CARBURETOR ASSEMBLY 1	1	UR
3	3CM-14902-00-00	. CARBURETOR ASS''Y 2 (3AL-14902-01-00)	1	UR
4	3CF-14984-01-00	. . GASKET, FLOAT CHAMBER	1	
5	3CF-14107-15-00	. . NEEDLE VALVE SET	1	
6	3CF-1490J-00-00	. . NEEDLE SET	1	
7	3CF-14940-00-00	. . DIAPHRAGM ASSEMBLY . .	1	
8	¢3C-F1493-30-00	. . SPRING, DIAPHRAGM	1	
9	12R-14105-00-00	. . PILOT SCREW SET	1	
10	537-14186-00-00	. . PIN, FLOAT	1	
11	2VA-14185-00-00	. . FLOAT	1	
12	137-14153-00-00	. . WASHER, MAIN JET	1	
13	3CF-14991-00-00	. . SCREW	1	
14	256-14954-00-00	. . WASHER	1	
15	620-1423A-75-00	. . JET, MAIN (122.5) (620-14231-75-A0)	1	
16	¢3C-F1414-19-40	. . UNAVAILABLE IN PRICE BOOK	1	
17	4G0-14142-40-00	. . JET, PILOT (# 40)	1	
18	3G2-14231-12-00	. . JET, POWER (# 60)	1	
19	98580-05010-00	. . SCREW, PAN HEAD	4	
20	98580-04008-00	. . SCREW, PAN HEAD	2	
21	3CF-1490H-00-00	. . DIAPHRAGM SET 5	1	
22	¢1H-X1423-12-80	. . UNAVAILABLE IN PRICE BOOK (#140)	1	
23	3CF-1410A-00-00	. . STARTER SET	1	
24	98580-05016-00	. . SCREW, PAN HEAD	4	
25	92990-05100-00	. . WASHER, SPRING	4	


CONTINUED ON NEXT FRAME ➤



CARBURETOR

Ref. No.	Part Number	Description	Qty	Remarks
26	12R-14191-00-00	. . PLUG, DRAIN	1	
27	¢2J-U1493-70-00	. . CLIP	1	FOR CALIF.
28	3F9-14118-00-00	. . CAP	1	
29	¢3C-F1425-10-00	. UNAVAILABLE IN PRICE BOOK	1	
30	(3CF-14937-00-00)	CLIP	1	
31	3CG-14197-00-00	. PIPE	1	
32	98580-05012-00	. SCREW, PAN HEAD	4	
33	(3CF-1490K-00-00)	STOP SCREW SET	1	
34	(3CF-14919-00-00)	CLIP	1	
35	3CF-14103-00-00	. THROTTLE SCREW SET	1	
36	98580-05016-00	. SCREW, PAN HEAD	4	
37	(3CF-14197-00-00)	PIPE	1	


EXHAUST




Ref. No.	Part Number	Description	Qty	Remarks
1	42X-14611-00-00	PIPE, EXHAUST 1	1	
2	3EG-14714-00-00	GASKET, MUFFLER	1	
3	1RV-14621-00-00	PIPE, EXHAUST 2	1	
4	1RM-14711-01-00	MUFFLER 1	1	
5	3YF-14755-00-00	GASKET, SILENCER	1	
6	95811-08045-00	BOLT, FLANGE (JN5)	1	
7	95811-08045-00	BOLT, FLANGE (JN5)	1	
8	42X-14748-01-00	PROTECTOR, MUFFLER 4	1	
9	90202-05187-00	WASHER, PLATE	4	
10	98903-06010-00	SCREW, BIND	2	
11	42X-1479H-00-00	COVER, 1	2	
12	92990-06200-00	WASHER	2	
13	42X-14612-00-00	NUT, RING	2	
14	42X-1468A-00-00	RING, SILENCER 1	2	
15	90179-08210-00	NUT, SPEC''L SHAPE	2	
16	90179-08507-00	NUT	2	
17	3EG-14613-00-00	GASKET, EXHAUST PIPE	2	
18	90101-06576-00	BOLT	1	
19	90101-06576-00	BOLT	1	
20	92990-06600-00	WASHER, PLATE	1	
21	92990-06600-00	WASHER, PLATE	1	
22	42H-14882-00-00	HOSE, BEND 2	1	
23	1RV-14840-00-00	AIR CUT VALVE ASS''Y	1	
24	90462-20188-00	CLAMP	1	
25	97701-60114-00	SCREW, TAPPING	1	
26	42H-14883-00-00	HOSE, BEND 3	1	
27	42H-14808-00-00	REED VALVE ASSEMBLY	1	
28	97701-60114-00	SCREW, TAPPING	3	
29	42H-14884-00-00	HOSE, BEND 4	1	

CONTINUED ON NEXT FRAME ➤

EXHAUST




Ref. No.	Part Number	Description	Qty	Remarks
30	42H-14885-00-00	HOSE, BEND 5	1	
31	90501-101J3-00	SPRING, COMPRESSION	1	
32	90501-102A5-00	SPRING, COMPRESSION	1	
33	42H-14871-01-00	PIPE 1	1	
34	42H-14872-02-00	PIPE 2	1	
35	90468-08104-00	CLIP	2	
36	90467-16098-00	CLIP	2	
37	42H-14714-00-00	GASKET, MUFFLER	2	
38	90460-15227-00	CLAMP, HOSE	2	
39	42H-14857-00-00	CASE, AIR CLEANER	1	
40	42H-14858-00-00	CAP, CASE	1	
41	95380-05600-00	NUT	1	
42	92990-05200-00	WASHER, PLAIN	1	
43	90202-05057-00	WASHER, PLATE	1	
44	1TA-14881-00-00	HOSE, BEND 1	1	
45	90467-22080-00	CLIP	1	
46	97701-60114-00	SCREW, TAPPING	1	



CRANKCASE

Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-15100-05-00	CRANKCASE ASSEMBLY	1	
2	99510-12016-00	. PIN, DOWEL	1	
3	95611-10620-00	BOLT, STUD	1	
4	95611-10620-00	BOLT, STUD	1	
5	95611-10670-00	BOLT, STUD	1	
6	93210-07438-00	O-RING	1	
7	93210-07135-00	O-RING	1	
8	90387-064E8-00	COLLAR	1	
9	91311-10100-00	BOLT, SOCKET HEAD	1	
10	91311-10070-00	BOLT, SOCKET HEAD	1	
11	91311-10060-00	BOLT, SOCKET HEAD	1	
12	91311-06080-00	BOLT, SOCKET HEAD	2	
13	91311-06055-00	BOLT, SOCKET HEAD	1	
14	91311-06030-00	BOLT, SOCKET HEAD	13	
15	90430-06014-00	GASKET	1	
16	57A-15363-11-00	PLUG, OIL	1	
17	93210-29198-00	O-RING	1	
18	90465-10168-00	CLAMP	1	
19	4X7-15491-00-00	PROTECTOR	1	
20	4X7-13419-00-00	PLUG	1	
21	90480-20302-00	GROMMET	1	
22	42X-21164-00-00	HOLDER, CABLE	1	
23	90105-10275-00	BOLT, WASHER BASED	1	


CRANKCASE COVER 1




Ref. No.	Part Number	Description	Qty	Remarks
1	1RM-15411-01-00	COVER, CRANKCASE 1	1	
2	4X7-15361-00-00	GAUGE, LEVEL	1	
3	2H7-15361-00-00	GAUGE, LEVEL	1	
4	90465-08309-00	CLAMP	1	
5	98580-06010-00	SCREW, PAN HEAD (92503-06010)	1	
6	3EG-15451-00-00	GASKET, CRCS COVER	1	
7	99530-10014-00	PIN, DOWEL	2	
8	91311-06040-00	BOLT	3	
9	91311-06030-00	BOLT, SOCKET HEAD	6	
10	91311-06020-00	BOLT, SOCKET HEAD	3	
11	1L9-11186-00-00	COVER, CYLINDER HEAD SIDE 2	1	
12	93210-32172-00	O-RING	1	
13	90462-08076-00	CLAMP	1	
14	1RM-15415-00-00	COVER, GENERATOR	1	
15	1RM-15455-00-00	GASKET 1	1	
16	1RM-15425-00-00	COVER, GENERATOR R	1	
17	98780-06016-00	SCREW, FLAT HEAD (92603-06016)	3	
18	98701-06014-00	SCREW, FLAT HEAD	3	
19	42X-15417-01-00	COVER, CAP	1	
20	91311-06055-00	BOLT, SOCKET HEAD	1	
21	91311-06016-00	BOLT, SOCKET HEAD	1	
22	1RM-15419-00-00	COVER, SHIFTER 1	1	
23	3EG-15459-00-00	GASKET, SHIFTER COVER	1	
24	91311-06016-00	BOLT, SOCKET HEAD	2	
25	3CG-15429-00-00	COVER, SHIFTER	1	
26	98580-06030-00	SCREW PAN HEAD	2	
27	91311-06065-00	BOLT	1	

CONTINUED ON NEXT FRAME ➤

CRANKCASE COVER 1




Ref. No.	Part Number	Description	Qty	Remarks
28	42X-15441-00-00	HOLDER, CLUTCH CABLE	1	
29	1RM-W1542-00-00	COVER, CRANKCASE R	1	
30	93101-14102-00	OIL SEAL, S-TYPE	1	
31	4X7-15388-00-00	PLATE, BRNG COVER	1	
32	91316-06016-00	BOLT, SOCKET HEAD	2	
33	3EG-15462-00-00	GASKET, CRCS CVR 3	1	
34	99530-10020-00	PIN, DOWEL	2	
35	91311-06040-00	BOLT	2	
36	91311-06025-00	BOLT, SOCKET HEAD	8	
37	91311-06030-00	BOLT, SOCKET HEAD	1	
38	90462-10143-00	CLAMP	1	
39	90462-10085-00	CLAMP	2	
40	90462-12142-00	CLAMP	1	
41	1RM-13161-00-00	PIPE, DELIVERY 1	1	
42	93210-07438-00	O-RING	3	



GENERATOR


Ref. No.	Part Number	Description	Qty	Remarks
1	3JL-81450-00-00	ROTOR ASSEMBLY	1	
2	1RM-81410-20-00	STATOR ASSEMBLY	1	
3	¢1R-M8166-10-00	SPACER	1	
4	91316-06050-00	BOLT, SOCKET HEAD	3	
5	3JL-81670-00-00	PICK-UP ASSEMBLY	1	
6	91316-06016-00	BOLT, SOCKET HEAD	3	
7	90201-06643-00	WASHER, PLATE	2	




STARTING MOTOR

Ref. No.	Part Number	Description	Qty	Remarks
1	5A8-81800-10-00	STARTING MOTOR ASSEMBLY	1	
2	5A8-81826-10-00	. BOLT	2	
3	11H-81844-00-00	. GASKET	1	
4	5A8-81830-10-00	. FRONT BRACKET ASSEMBLY	1	
5	5A8-81847-10-00	. . O-RING	1	
6	5A8-81840-10-00	. BRUSH HOLDER ASSEMBLY	1	
7	1J7-81847-60-00	. O-RING	1	
8	95811-06025-00	BOLT, FLANGE	2	

STARTER CLUTCH




Ref. No.	Part Number	Description	Qty	Remarks
1	3LP-15570-00-00	STARTER CLUTCH ASSEMBLY	1	
2	99009-13400-00	CIRCLIP (55X)	1	
3	4X7-15521-00-00	SHAFT 1	1	
4	93210-14104-00	O-RING	1	
5	5A8-15524-00-00	WHEEL, STARTER (23T)	1	
6	1TA-15512-00-00	GEAR, IDLER 1	1	
7	5A8-15517-00-00	GEAR, IDLER 2 (27T)	1	
8	90387-172E5-00	COLLAR	2	
9	90501-15636-00	SPRING, COMPRESSION	1	
10	90387-170E5-00	COLLAR	1	
11	5A8-15550-00-00	DRIVE LEVER ASSEMBLY	1	
12	93102-10247-00	OIL SEAL	1	
13	5A8-15542-01-00	COLLAR 2	1	
14	90151-06013-00	SCREW, COUNTERSUNK	1	
15	5A8-15556-00-00	LEVER, DRIVE	1	
16	90508-26494-00	SPRING, TORSION	1	
17	90149-08166-00	SCREW	1	
18	3EG-15568-00-00	GASKET	1	
19	95701-06500-00	NUT, FLANGE	2	



CLUTCH


Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-16111-00-00	GEAR, PRI DRIVE	1	
2	90282-07042-00	KEY, STRAIGHT	1	
3	90214-20022-00	WASHER, CLAW	1	
4	90215-20182-00	WASHER, LOCK	1	
5	90170-20274-00	NUT, HEXAGON	1	
6	2H7-16396-00-00	HOUSING, PUSH SCREW	1	
7	93606-07082-00	PIN, DOWEL	1	
8	2H7-16395-01-00	RETAINER, BALL	1	
9	2H7-16341-00-00	SCREW, PUSH	1	
10	2H7-16343-00-00	SCREW, ADJUSTING	1	
11	93210-48364-00	O-RING	1	
12	4X7-16340-00-00	PUSH LEVER ASSEMBLY	1	
13	92990-08200-00	WASHER, PLAIN	1	
14	95303-08700-00	NUT	1	
15	90506-10069-00	SPRING, TENSION	1	
16	93104-14059-00	OIL SEAL, SO-TYPE	1	
17	4X7-16357-00-00	ROD, PUSH 2	1	
18	4X7-16356-00-00	ROD, PUSH 1	1	
19	93340-21505-00	BEARING	1	
20	90201-154E9-00	WASHER, PLATE	1	
21	4X7-16150-02-00	PRI DRVN GEAR	1	
22	3Y1-16154-00-00	PLATE, THRUST 1	1	
23	4X7-16371-00-00	BOSS, CLUTCH	1	
24	4X7-16384-00-00	PLATE, SEAT	1	
25	4X7-16383-01-00	SPRING, CLUTCH BOSS	1	
26	4X7-16324-00-00	PLATE, CLUTCH 1	1	
27	4X7-16385-00-00	RING, CLUTCH BOSS	1	
28	22U-16321-00-00	PLATE, FRICTION	8	
29	4X7-16325-00-00	PLATE, CLUTCH 2	7	

CONTINUED ON NEXT FRAME ➤



CLUTCH


Ref. No.	Part Number	Description	Qty	Remarks
30	4X7-16351-00-00	PLATE, PRESSURE 1	1	
31	90501-23598-00	SPRING, COMPRESSION	6	
32	90159-06092-00	SCREW, WITH WASHER	6	
33	90215-20231-00	WASHER, LOCK	1	
34	90170-20327-00	NUT	1	



TRANSMISSION


Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-17411-00-00	AXLE, MAIN	1	
2	4X7-17141-00-00	GEAR, 4TH PINION	1	
3	90209-22191-00	WASHER	1	
4	93410-25010-00	CIRCLIP, S-TYPE	1	
5	4X7-17121-00-00	GEAR, 2ND PINION	1	
6	42X-17151-00-00	GEAR, 5TH PINION (34T)	1	
7	90201-20276-00	WASHER, PLATE (1.0T)	1	
8	99009-20400-00	CIRCLIP	1	
9	93306-30525-00	BEARING (B6305)	1	
10	93104-20068-00	OIL SEAL	1	
11	93306-30424-00	BEARING (B6304A3)	1	
12	4X7-17402-00-00	DRIVE AXLE ASSEMBLY	1	
13	4X7-17221-00-00	GEAR, 2ND WHEEL	1	
14	90209-27192-00	WASHER	1	
15	93440-30077-00	CIRCLIP	1	
16	42X-17251-00-00	GEAR , 5TH WHEEL (29T)	1	
17	4X7-17231-00-00	GEAR, 3RD WHEEL	1	
18	90209-27192-00	WASHER	1	
19	93440-30077-00	CIRCLIP	1	
20	4X7-17241-00-00	GEAR, 4TH WHEEL	1	
21	4X7-17211-00-00	GEAR, 1ST WHEEL	1	
22	4X7-17582-01-00	GEAR, MIDDLE DRIVE (45T)	1	
23	93306-20421-00	BEARING	1	
24	93306-20550-00	BEARING (B6205DU8)	1	
25	4X7-17583-01-00	GEAR, MIDDLE DRIVEN	1	
26	93316-01201-00	BEARING, CYLINDER.# 6	1	
27	93306-91201-00	BEARING	1	

MIDDLE DRIVE GEAR




Ref. No.	Part Number	Description	Qty	Remarks
1	1TA-Y1757-00-00	MIDDLE GEAR COMP.	1	
2	93306-20901-00	BEARING (B6209RSH2-C2)	1	
3	90179-44328-00	NUT	1	
4	42X-17526-01-00	CAM, DRIVE	1	
5	31A-17527-00-00	CAM, DRIVEN	1	
6	90501-70762-00	SPRING, COMPRESSION	1	
7	(4X7-17524-00-00)	HOLDER	1	
8	3H5-17529-00-00	WASHER, THRUST	2	
9	4X7-17531-00-15	SHIM, PINION (0.15T)	1	UR
	4X7-17531-00-30	SHIM, PINION (0.30T)	1	UR
	4X7-17531-00-50	SHIM, PINION (0.50T)	1	UR
10	90179-88336-00	NUT, SPEC''L SHAPE	1	
11	93317-22021-00	BEARING, CYLINDER.# 7	1	
12	93311-34050-00	BEARING, CYLINDRICAL	1	
13	90201-255A6-00	WASHER, PLATE	3	
14	1J7-46129-Y1-00	SPACER, EXPANSION	1	
15	11H-17551-00-00	HOUSING, BEARING	1	
16	93210-71360-00	O-RING	1	
17	93306-20548-00	BEARING	1	
18	4X7-17554-00-00	RETAINER, BEARING	1	
19	93210-52449-00	O-RING	1	
20	93101-35099-00	OIL SEAL, S-TYPE	1	
21	(4X7-17558-00-00)	PLATE, BEARING	1	
22	4X7-17556-00-00	YOKE, JOINT	1	
23	93210-14359-00	O-RING	1	
24	90201-14633-00	WASHER, PLATE	1	
25	90179-14317-00	NUT, SPEC''L SHAPE	1	
26	90387-251E1-00	COLLAR	1	
27	95811-08030-00	BOLT, FLANGE	3	

SHIFT CAM - FORK




Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-18540-01-00	SHIFT CAM ASSEMBLY	1	
2	93306-90602-00	. BEARING	1	
3	4G0-18185-01-00	. SEGMENT	1	
4	93604-20156-00	. PIN, DOWEL	1	
5	93604-16092-00	. PIN, DOWEL	3	
6	98701-05035-00	. SCREW, FLAT HEAD	1	
7	136-18542-00-00	. POINT, NEUTRAL	1	
8	90201-30297-00	. WASHER, PLATE	1	
9	4X7-18511-00-00	FORK, SHIFT 1	1	
10	4X7-18512-00-00	FORK, SHIFT 2	1	
11	4X7-18513-00-00	FORK, SHIFT 3	1	
12	4X7-18531-00-00	BAR, SHIF FRK GDE 1	1	
13	(4X7-18536-00-00)	STOPPER, SHIFT BAR	1	
14	98701-06014-00	SCREW, FLAT HEAD	2	



SHIFT SHAFT


Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-18120-01-00	SHIFT LEVER ASSEMBLY	1	
2	90506-08227-00	. SPRING, TENSION	1	
3	4X7-18140-00-00	STOPPER LEVER ASSEMBLY .	1	
4	90508-32535-00	SPRING, TORSION	1	
5	99006-10600-00	CIRCLIP	3	
6	90508-29531-00	SPRING, TORSION	1	
7	90201-12588-00	WASHER, PLATE	1	
8	90387-124F4-00	COLLAR	1	
9	90201-12588-00	WASHER, PLATE	1	
10	90201-12166-00	WASHER, PLATE	1	
11	93102-12321-00	OIL SEAL, SD-TYPE	1	
12	42X-18110-01-00	SHIFT PEDAL ASSEMBLY	1	
13	2H9-18154-00-00	. COVER, DUST	1	
14	132-18113-01-00	. COVER, SHIFT PEDAL	1	
15	90201-124E4-00	WASHER, PLATE	1	
16	99009-12400-00	CIRCLIP	1	
17	42X-18112-01-00	ARM, SHIFT	1	
18	2H9-18154-00-00	. COVER, DUST	1	
19	97011-06020-00	BOLT	1	
20	29L-18115-00-00	ROD, SHIFT	1	
21	90170-06228-00	NUT (COUNTER CLOCKWISE)	1	
22	95380-06700-00	NUT	1	
23	93608-50158-00	PIN, DOWEL	1	

FRAME




Ref. No.	Part Number	Description	Qty	Remarks
1	3CF-21110-00-33	FRAME COMP.	1	YAMAHA
2	42X-21317-00-00	STAY, ENGINE 3	1	
3	(42X-21359-00-00)	BRACKET, COIL	1	
4	98516-06012-00	SCREW, PAN HEAD	1	
5	92906-06100-00	WASHER, SPRING	1	
6	92906-06600-00	WASHER	1	
7	90105-10297-00	BOLT, WASHER BASED	2	
8	90176-10049-00	NUT, CROWN	2	
9	90179-12421-00	NUT, SPEC''L SHAPE	4	
10	90201-125A3-00	WASHER, PLATE	4	
11	42X-21315-00-00	STAY, ENGINE 2	1	
12	42X-21316-00-00	STAY, ENGINE 3	1	
13	90105-10298-00	BOLT, WASHER BASED	2	
14	90201-105H3-00	WASHER, PLATE	2	
15	90387-100E2-00	COLLAR	2	
16	4X7-21485-00-00	DAMPER, RUBBER 1	2	
17	90105-10050-00	BOLT, WASHER BASED	2	
18	90105-10300-00	BOLT, WASHER BASED	1	
19	42X-21458-01-00	BRACKET, SIDE STAND	1	
20	90176-10049-00	NUT, CROWN	2	
21	90105-06069-00	BOLT, WASHER BASED	1	
22	90202-05187-00	WASHER, PLATE	1	
23	90338-07043-00	PLUG, SPEC''L SHAPE	2	
24	90462-08138-00	CLAMP	2	
25	97706-50508-00	SCREW, TAPPING	2	
26	2AE-2139R-00-00	COVER 2 (42X-2139R-00-00)	1	
27	90159-06058-00	SCREW, WITH WASHER	1	

FENDER



Ref. No.	Part Number	Description	Qty	Remarks
1	1MY-21510-00-9B	FENDER, FRONT	1	DARK GRAISH BLUE METALLIC 1
2	97021-06012-00	BOLT	4	
3	92995-06100-00	WASHER, SPRING	4	
4	1RM-21610-01-9B	FENDER, REAR	1	DARK GRAISH BLUE METALLIC 1
5	97021-06012-00	BOLT	2	
6	92995-06100-00	WASHER, SPRING	2	
7	97022-08012-00	BOLT	2	
8	92990-08100-00	WASHER	2	
9	1RM-2164F-00-00	STAY 1	1	
10	1RM-2164G-00-00	STAY 2	1	
11	1RM-2164H-00-00	STAY 3	1	
12	1RM-2164J-00-00	STAY 4	1	
13	55R-2164A-02-00	GRIP 1	1	
14	95811-06016-00	BOLT, FLANGE (95822-06016)	4	
15	95811-06016-00	BOLT, FLANGE (95822-06016)	4	
16	90149-08225-00	SCREW	2	
17	90105-10217-00	BOLT, WASHER BASED	2	
18	42X-21629-00-00	GUARD, MUD	1	
19	90159-06128-00	SCREW, WITH WASHER	2	
20	26H-21308-00-00	HELMET HANGER ASSEMBLY (4R8-21308-00)	1	
21	90149-06154-00	SCREW	1	
22	99236-00020-00	EMBLEM, YAMAHA	1	


SIDE COVER



Ref. No.	Part Number	Description	Qty	Remarks
1	42X-21711-00-9B	COVER, SIDE 1	1	UR DRK GRYISH BLU METALLIC
2	56F-21781-00-00	EMBLEM 1	1	
3	90480-01401-00	GROMMET	1	
4	466-21717-00-00	DAMPER, SIDE COVER	2	
5	42X-21721-00-9B	COVER, SIDE 2	1	UR DRK GRYISH BLU METALLIC
6	56F-21782-00-00	EMBLEM 2	1	
7	3JL-2179R-21-00	PLATE, EPACA 2	1	CALIF.
	3JL-2179V-21-00	PLATE.EPA U 9	1	NON-CA.
8	90480-01401-00	GROMMET	2	
9	90480-12053-00	GROMMET	1	
10	42X-21171-00-00	BOX	1	
11	90480-20384-00	GROMMET	2	
12	90480-16233-00	GROMMET	1	
13	90387-060A7-00	COLLAR	1	
14	90201-06067-00	WASHER, PLATE	1	
15	97011-06020-00	BOLT	1	
16	92995-06100-00	WASHER, SPRING	1	
17	42X-21746-00-00	DAMPER	1	
18	42X-28185-00-00	LID	1	
19	42X-2172W-02-00	COVER	1	
20	98580-06008-00	SCREW, PAN HEAD	2	
21	92995-06100-00	WASHER, SPRING	2	
22	42X-2177A-00-00	BOX	1	
23	90560-06258-00	SPACER	1	
24	90201-06059-00	WASHER, PLATE	3	
25	91316-06012-00	BOLT, SOCKET HEAD	1	
26	90480-10408-00	GROMMET	1	


CONTINUED ON NEXT FRAME ➤

SIDE COVER




Ref. No.	Part Number	Description	Qty	Remarks
27	42X-2176E-00-00	PLATE	1	
28	90159-06110-00	SCREW, WITH WASHER	1	
29	42X-2117F-00-00	COVER	1	
30	90159-06071-00	SCREW, WITH WASHER	2	

SWING ARM - REAR SHOCKS



Ref. No.	Part Number	Description	Qty	Remarks
1	1RM-22110-00-35	REAR ARM COMP.	1	SILVER
2	93332-00010-00	BEARING	2	
3	90387-17543-00	COLLAR	2	
4	93102-25017-00	OIL SEAL	2	
5	42X-22141-00-00	SHAFT, PIVOT	1	
6	90215-22238-00	WASHER, LOCK	1	
7	1J7-22141-00-00	SHAFT, PIVOT	1	
8	1J7-22143-00-00	NUT	1	
9	2H7-2219X-00-00	COVER	2	
10	95023-08035-00	BOLT, FLANGE	1	
11	4X7-22189-01-00	BOOT, RUBBER	1	
12	90338-20113-00	PLUG	1	
13	42X-22210-12-00	SHOCK ABSORBER ASSEMBLY, REAR	1	
14	42X-22220-12-00	SHOCK ABSORBER ASSEMBLY, REAR	1	
15	57A-22243-01-00	WASHER 1	2	
16	91311-08020-00	BOLT, SOCKET HEAD	2	
17	90338-08163-00	PLUG	2	
18	90201-10437-00	WASHER, PLATE	1	
19	90176-10013-00	NUT, CROWN	1	
20	92990-10100-00	WASHER, SPRING	1	
21	90106-10030-00	BOLT, DOME HEAD	1	


DRIVE SHAFT



Ref. No.	Part Number	Description	Qty	Remarks
1	5G2-46101-01-00	REAR AXLE GEAR CASE ASSEMBLY	1	
2	90116-10361-00	. BOLT, STUD	4	
3	90116-08360-00	. BOLT, STUD	6	
4	90116-10249-00	. BOLT, STUD	1	
5	4H7-46153-00-00	. COLLAR, GUIDE	1	
6	93101-30084-00	. OIL SEAL	1	
7	93311-43729-00	. BEARING	1	
8	93317-41510-00	. BEARING	1	
9	2H7-46122-00-00	. RACE, INNER	1	
10	1J7-17537-Y0-30	. SHIM, THRUST (0.30T)	1	UR
	1J7-17537-Y0-40	. SHIM, THRUST (0.40T)	1	UR
	1J7-17537-Y0-50	. SHIM, THRUST (0.50T)	1	UR
11	93306-30533-00	. BEARING (B6305RB1 SPECIAL)	1	
12	4H7-46125-00-00	. RETAINER, BEARING	1	
13	93210-60426-00	. O-RING	1	
14	93101-38098-00	. OIL SEAL	1	
15	4H7-46123-00-00	. COUPLING, GEAR	1	
16	90201-14632-00	. WASHER, PLATE	1	
17	90185-14070-00	. NUT, SELF-LOCKING	1	
18	4H7-46152-00-00	. HOUSING, BEARING	1	
19	1J7-46117-Y0-30	. SHIM, RING GEAR (0.30T)	1	UR
	1J7-46117-Y0-35	. SHIM, RING GEAR	1	UR
	1J7-46117-Y0-40	. SHIM, RING GEAR (0.40T)	1	UR
	1J7-46117-Y0-50	. SHIM, RING GEAR (0.50T)	1	UR
20	93316-01403-00	. BEARING	1	
21	22U-46118-00-12	. SHIM, THRUST (1.2T)	1	UR
	22U-46118-00-14	. SHIM, THRUST (1.4T)	1	UR


CONTINUED ON NEXT FRAME ➤

DRIVE SHAFT



Ref. No.	Part Number	Description	Qty	Remarks
21	22U-46118-00-16	. SHIM, THRUST (1.6T)	1	UR
	22U-46118-00-18	. SHIM, THRUST (1.8T)	1	UR
	22U-46118-00-20	. SHIM, THRUST (2.0T)	1	UR
22	93211-44348-00	. O-RING	1	
23	95333-08600-00	. NUT	6	
24	92901-08700-00	. WASHER, WAVE	6	
25	95811-10025-00	. BOLT, FLANGE	2	
26	93102-70167-00	. OIL SEAL	1	
27	3VD-13455-00-00	. PLUG	1	
28	214-11198-01-00	. GASKET	2	
29	2H7-17590-00-00	. BREATHER COMP.	1	
30	90340-14118-00	. PLUG, STRAIGHT	1	
31	4X7-46172-00-00	SHAFT, DRIVE	1	
32	93108-23007-00	OIL SEAL	1	
33	90201-231A2-00	WASHER, PLATE	1	
34	93410-23056-00	CIRCLIP	1	
35	93410-22039-00	CIRCLIP	1	
36	90501-16491-00	SPRING, COMPRESSION	1	
37	4X7-46180-00-00	CROSS JOINT COMP.	1	
38	93399-99926-00	BEARING	2	
39	93440-20088-00	CIRCLIP	2	
40	90176-10049-00	NUT, CROWN	4	
41	92901-10100-00	WASHER, SPRING	4	
42	90387-172A5-00	COLLAR	1	


FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
1	3JL-23102-00-00	FRONT FORK ASS''Y (L.H) . . .	1	
2	3JL-23126-00-00	. TUBE, OUTER 1	1	
3	3R4-23153-00-00	. RING, SNAP	1	
4	3EN-23145-00-00	. OIL SEAL	1	
5	2YK-23125-00-00	. METAL, SLIDE 1	1	
6	4V2-23146-L0-00	. WASHER, OIL SEAL	1	
7	42X-23144-01-00	. SEAL, DUST	1	
8	1RM-23110-00-00	. INNER TUBE COMP. 1	1	
9	33M-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
10	1W1-23173-L0-00	. SPINDLE, TAPER	1	
11	42H-23141-00-00	. SPRING, FRONT FORK	1	
12	1W1-23142-L0-00	. SEAT, SPRING UPPER	1	
13	1W1-23114-L0-00	. GASKET	1	
14	122-23129-00-00	. GASKET, DRAIN PLUG	1	
15	509-23158-L0-00	. GASKET	1	
16	31A-23111-31-00	. BOLT, CAP	1	
17	42H-23168-00-00	. CAP, FRONT FORK	1	
18	4H7-23119-00-00	. PLUG, DRAIN - (122-23119-01)	1	
19	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
20	¢42-X2311-80-00	. SPACER	1	
21	3JL-23103-00-00	FRONT FORK ASS''Y (R.H) . . .	1	FOR URB
22	3JL-23136-00-00	. TUBE, OUTER 2	1	
23	3R4-23153-00-00	. RING, SNAP	1	
24	3EN-23145-00-00	. OIL SEAL	1	
25	2YK-23125-00-00	. METAL, SLIDE 1	1	
26	4V2-23146-L0-00	. WASHER, OIL SEAL	1	
27	42X-23144-01-00	. SEAL, DUST	1	


CONTINUED ON NEXT FRAME ➤

FRONT FORK




Ref. No.	Part Number	Description	Qty	Remarks
28	1RM-23110-00-00	. INNER TUBE COMP. 1	1	
29	33M-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
30	1W1-23173-L0-00	. SPINDLE, TAPER	1	
31	42H-23141-00-00	. SPRING, FRONT FORK	1	
32	1W1-23142-L0-00	. SEAT, SPRING UPPER	1	
33	1W1-23114-L0-00	. GASKET	1	
34	122-23129-00-00	. GASKET, DRAIN PLUG	1	
35	509-23158-L0-00	. GASKET	1	
36	31A-23111-31-00	. BOLT, CAP	1	
37	42H-23168-00-00	. CAP, FRONT FORK	1	
38	4H7-23119-00-00	. PLUG, DRAIN - (122-23119-01)	1	
39	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
40	90101-08340-00	. BOLT	1	
41	95333-08600-00	. NUT	1	
42	92990-08100-00	. WASHER	1	
43	¢42-X2311-80-00	. SPACER	1	
44	2AE-23340-30-00	UNDER BRACKET COMP.	1	
45	91311-08030-00	BOLT	4	
46	1RM-23132-00-00	COVER (L.H)	1	
47	1RM-23132-10-00	COVER (R.H)	1	
48	98580-05006-00	SCREW, PAN HEAD	2	

STEERING




Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00001-00	BEARING	1	
2	93332-00008-00	BEARING	1	
3	1J7-23415-00-00	COVER, BALL RACE 1	1	
4	90179-25033-00	NUT	2	
5	90202-26142-00	WASHER, PLATE	1	
6	26H-23418-01-00	WASHER, SPECIAL	1	
7	90176-22050-00	NUT, CROWN	1	
8	3AL-W2341-00-38	CROWN, HANDLE	1	CLEAR (W/BUFF)
9	95023-08045-00	BOLT	2	
10	92990-08100-00	WASHER	2	
11	92901-08600-00	WASHER	2	
12	1UF-23317-01-00	HOLDER, CABLE	2	
13	4H7-23441-00-38	HOLDER, HANDLE UPPER	2	CLEAR (W/BUFF)
14	3AL-23442-00-38	HOLDER, HANDLE LOWER	2	CLEAR (W/BUFF)
15	90201-14220-00	WASHER, PLATE	2	
16	92990-12200-00	WASHER, PLAIN	2	
17	92901-12100-00	WASHER, SPRING	2	
18	95301-12700-00	NUT (95302-12700)	2	
19	90468-12006-00	CLIP	2	
20	91311-08030-00	BOLT	4	
21	90338-08163-00	PLUG	4	
22	1RM-23122-00-00	COVER, OUTER 1	1	
23	1RM-2317E-00-00	STAY	1	
24	92016-06012-00	BOLT, BUTTON HEAD	2	
25	90338-08163-00	PLUG	4	
26	42X-2313A-00-00	BRACE, FORK	1	
27	95023-08020-00	BOLT	4	

FUEL TANK (NON-CALIFORNIA MODEL)



Ref. No.	Part Number	Description	Qty	Remarks
1	1RM-24110-00-X4	FUEL TANK	1	UR DRK GRAYISH BLUE METALLIC
2	3JL-24240-20-00	. GRAPHIC SET	1	
3	1RM-24161-00-00	EMBLEM 1	1	
4	1RM-24162-00-00	EMBLEM 2	1	
5	4H7-24181-00-00	DAMPER, LOCATING 1	2	
6	42X-24182-00-00	DAMPER, LOCATING 2	1	
7	42X-24183-00-00	DAMPER, LOCATING 3	1	
8	97313-08016-00	BOLT, HEXAGON	1	
9	42X-24186-00-00	WASHER, SPECIAL	1	
10	3AL-24500-00-00	FUEL COCK ASSEMBLY 1	1	
11	4X8-24512-00-00	. O-RING	1	
12	1JK-24534-00-00	. SEAL, COCK	1	
13	98580-03008-00	. SCREW, PAN HEAD	2	
14	3H3-24523-00-00	. VALVE	1	
15	90202-05187-00	WASHER, PLATE	2	
16	90149-06011-00	SCREW	2	
17	3AL-24321-00-00	PIPE 0	1	
18	90501-08728-00	SPRING, COMPRESSION	1	
19	90467-10091-00	CLIP, SCISSOR	2	
20	3AL-2416A-00-00	HOSE	1	
21	90501-08410-00	SPRING, COMPRESSION	1	
22	90467-08092-00	CLIP	2	
23	4X7-24602-02-00	CAP ASSEMBLY	1	
24	4X7-24612-00-00	. GASKET, CAP	1	
25	98506-05010-00	. SCREW, PAN HEAD	1	


FUEL TANK (CALIFORNIA MODEL ONLY




Ref. No.	Part Number	Description	Qty	Remarks
1	1RV-24110-00-X3	FUEL TANK	1	UR DRK GRAYISH BLU METALLIC
2	3JL-24240-20-00	. GRAPHIC SET	1	
3	1RM-24161-00-00	EMBLEM 1	1	
4	1RM-24162-00-00	EMBLEM 2	1	
5	4H7-24181-00-00	DAMPER, LOCATING 1	2	
6	42X-24182-00-00	DAMPER, LOCATING 2	1	
7	42X-24183-00-00	DAMPER, LOCATING 3	1	
8	97313-08016-00	BOLT, HEXAGON	1	
9	42X-24186-00-00	WASHER, SPECIAL	1	
10	3AL-24500-00-00	FUEL COCK ASSEMBLY 1	1	
11	4X8-24512-00-00	. O-RING	1	
12	1JK-24534-00-00	. SEAL, COCK	1	
13	98580-03008-00	. SCREW, PAN HEAD	2	
14	3H3-24523-00-00	. VALVE	1	
15	90202-05187-00	WASHER, PLATE	2	
16	90149-06011-00	SCREW	2	
17	3AL-24321-00-00	PIPE 0	1	
18	90501-08728-00	SPRING, COMPRESSION	1	
19	90467-10091-00	CLIP, SCISSOR	2	
20	3AL-2416A-00-00	HOSE	1	
21	90501-08410-00	SPRING, COMPRESSION	1	
22	90467-08092-00	CLIP	2	
23	20K-24602-02-00	CAP ASSEMBLY	1	
24	4X7-24612-00-00	. GASKET, CAP	1	
25	98506-05010-00	. SCREW, PAN HEAD	1	
26	25H-24180-00-00	ROLL OVER VALVE ASSEMBLY	1	
27	42X-2419A-00-00	HOLDER	1	

CONTINUED ON NEXT FRAME ➤

FUEL TANK (CALIFORNIA MODEL ONLY




Ref. No.	Part Number	Description	Qty	Remarks
28	97026-06012-00	BOLT	1	
29	92906-06100-00	WASHER, SPRING	1	
30	92906-06600-00	WASHER	1	
31	(42X-24376-00-00)	PIPE, JOINT 1	1	
32	90467-08092-00	CLIP	1	
33	90467-09006-00	CLIP	1	
34	42X-24377-00-00	PIPE, JOINT 3	1	
35	90467-09006-00	CLIP	2	
36	42H-24170-00-00	CANISTER ASSEMBLY	1	
37	90445-105G5-00	HOSE	1	
38	90467-09006-00	CLIP	1	
39	90445-11587-00	HOSE	1	
40	90467-11106-00	CLIP	1	



SEAT


Ref. No.	Part Number	Description	Qty	Remarks
1	3CF-24730-00-00	DOUBLE SEAT ASSEMBLY	1	
2	3CF-24731-00-00	. COVER, DOUBLE SEAT	1	
3	509-24724-00-00	. DAMPER, SEAT	4	
4	1L9-24741-00-00	. PAD, SEAT	1	
5	91316-06016-00	BOLT, SOCKET HEAD	1	
6	90110-06077-00	BOLT, HEXAGON SOCKET HEAD	1	
7	42X-2473R-00-00	BOX 1	1	
8	90480-24186-00	GROMMET	1	
9	90201-225A4-00	WASHER, PLATE (T1.0)	1	
10	5A8-21708-00-00	LOCK ASSEMBLY 2	1	
11	42X-2473T-00-00	LID 1	1	
12	3CF-24723-00-00	DAMPER, SEAT	1	
13	42X-2177K-00-00	PIN, HINGE	1	
14	1RM-2162G-00-00	PLATE 1	1	
15	90176-06041-00	NUT, CROWN	2	
16	97011-06016-00	BOLT	1	
17	92995-06100-00	WASHER, SPRING	1	
18	90201-06057-00	WASHER, PLATE	1	
19	5H9-21376-00-00	BAND, TOOL	1	
20	5A8-W2810-00-00	TOOL KIT	1	

FRONT WHEEL




Ref. No.	Part Number	Description	Qty	Remarks
1	42H-25168-00-P0	CAST WHEEL, FRONT	1	UR
2	90560-15116-00	SPACER	1	
3	146-25115-00-00	FLANGE, SPACER 1	1	
4	93306-30202-00	BEARING	2	
5	93102-22014-00	OIL SEAL	1	
6	94110-194H3-00	TIRE (100/90-19 57H)	1	UR
7	93900-00001-00	VALVE, RIM	1	UR
	93900-00003-00	VALVE, RIM	1	UR
8	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UN
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	UN
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	UN
9	90387-15550-00	COLLAR	1	
10	42X-25181-00-00	AXLE, WHEEL	1	
11	3JK-25190-00-00	GEAR UNIT ASSEMBLY	1	

FRONT BRAKE CALIPER




Ref. No.	Part Number	Description	Qty	Remarks
1	29L-25831-20-00	DISC, BRAKE (RT)	1	UR NEBULA GOLD
	3JK-25831-00-00	DISC, BRAKE (RIGHT)	1	UR SILVER
2	90109-08718-00	BOLT	12	
3	29L-25831-30-00	DISC, BRAKE (LEFT)	1	UR NEBULA GOLD
	3JK-25831-10-00	DISC, BRAKE (LEFT)	1	UR SILVER
4	42H-25810-01-00	CALIPER ASSEMBLY (RIGHT) .	1	
5	26H-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
6	26H-W0047-00-00	. . CALIPER SEAL KIT	1	
7	26H-W0045-11-00	. BRAKE PAD KIT	1	
8	1WG-25919-00-00	. SUPPORT, PAD	1	
9	3HE-25924-00-00	. PIN, PAD	2	
10	3HE-25925-00-00	. CLIP	2	
11	1J3-W0048-00-00	. BLEED SCREW KIT	1	
12	42H-25810-11-00	CALIPER ASSEMBLY (LEFT) . .	1	
13	26H-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
14	26H-W0047-00-00	. . CALIPER SEAL KIT	1	
15	26H-W0045-11-00	. BRAKE PAD KIT	1	
16	1WG-25919-00-00	. SUPPORT, PAD	1	
17	3HE-25924-00-00	. PIN, PAD	2	
18	3HE-25925-00-00	. CLIP	2	
19	1J3-W0048-00-00	. BLEED SCREW KIT	1	
20	90105-10638-00	BOLT, WASHER BASED	4	



REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	42H-25338-01-P1	CAST WHEEL, REAR	1	UR LIGHT YELLOW
2	90560-17249-00	SPACER	1	
3	146-25315-00-00	FLANGE, SPACER	1	
4	93306-30309-00	BEARING	1	
5	93306-20310-00	BEARING	1	
6	93306-20310-00	BEARING	1	
7	16G-25366-01-00	CLUTCH, HUB	1	
8	42H-25364-00-00	DAMPER	6	
9	93210-48530-00	O-RING	1	
10	93210-59531-00	O-RING	1	
11	16G-25412-00-00	WASHER	2	
12	95701-10500-00	NUT, FLANGE (95702-10500)	6	
13	93210-57428-00	O-RING	1	
14	42H-25321-02-00	PLATE, BRAKE SHOE	1	
15	5A8-W2536-00-00	BRAKESHOE SET-2PCS	1	
16	90507-20002-00	SPRING, TENSION	2	
17	4H7-25351-00-00	CAMSHAFT	1	
18	3CF-25355-00-00	LEVER, CAMSHAFT	1	
19	90201-14218-00	WASHER, PLATE	1	
20	4H7-2533A-02-00	PLATE, INDICATOR	1	
21	90101-06291-00	BOLT	1	
22	94114-156U0-00	TIRE (140/90-15 70H)	1	UR BRIDGESTONE
23	93900-00016-00	VALVE, RIM	1	BRIDGESTONE
24	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UN
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	UN
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	UN
25	16G-25327-00-00	COVER, PLATE	1	
26	97021-05020-00	BOLT	4	
27	92990-05100-00	WASHER, SPRING	4	


CONTINUED ON NEXT FRAME ➤




REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
28	92901-05600-00	WASHER, PLATE	4	
29	42X-25381-00-00	AXLE, WHEEL	1	
30	90201-144J5-00	WASHER, PLATE	1	
31	90171-14031-00	NUT, CASTLE	1	
32	91401-30030-00	PIN, COTTER	1	
33	56W-25377-00-00	COLLAR, WHEEL	1	
34	42X-25371-00-00	BAR, TENSION	1	
35	90109-08406-00	BOLT	1	
36	92901-08600-00	WASHER	2	
37	92990-08100-00	WASHER	2	
38	95303-08700-00	NUT	2	
39	91490-20020-00	PIN, COTTER	2	
40	90109-08368-00	BOLT	1	

HANDLEBAR - CABLE




Ref. No.	Part Number	Description	Qty	Remarks
1	3AL-W2611-00-00	HANDLEBAR (3AL-W2611-10-00)	1	
2	3JB-26241-00-00	GRIP (LEFT)	1	
3	3JB-26273-00-00	ROTOR	1	
4	3JB-26240-00-00	GRIP ASSEMBLY	1	
5	3JB-2628J-00-00	CAP, GRIP	2	
6	3CF-26311-00-00	CABLE, THROTTLE 1	1	
7	3CF-26312-00-00	CABLE, THROTTLE 2	1	
8	5H0-26393-00-00	HOLDER	1	
9	98506-05008-00	SCREW, PAN HEAD	1	
10	57A-26335-00-00	CABLE, CLUTCH	1	
11	1E6-26342-00-00	BOOT, CABLE	1	
12	90179-08148-00	NUT	1	
13	90123-08046-00	BOLT	1	
14	3CF-26331-00-00	CABLE, STARTER 1	1	
15	1AA-26280-02-00	REAR VIEW MIRROR ASSEMBLY (LEFT)	1	
16	1AA-26290-02-00	REAR VIEW MIRROR ASSEMBLY (RIGHT)	1	



FRONT MASTER CYLINDER


Ref. No.	Part Number	Description	Qty	Remarks
1	22R-25850-02-00	MASTER CYLINDER ASSEMBLY	1	
2	4K0-25854-00-00	. DIAPHRAGM RESERVOR	1	
3	3GM-25852-01-00	. CAP, RESERVOIR	1	
4	98706-04012-00	. SCREW, FLAT HEAD	2	
5	4K0-W0041-50-00	. CYLINDER KIT, MASTER	1	
6	4L0-25867-00-00	BRACKET, MASTER CYLINDER	1	
7	97016-06025-00	BOLT	2	
8	92906-06100-00	WASHER, SPRING	2	
9	42H-25872-01-00	HOSE, BRAKE 1	1	
10	306-25862-00-00	BOOT, MASTER CYLINDER	1	
11	90401-10034-00	BOLT, UNION	1	
12	90201-10118-00	WASHER, PLATE	2	
13	42H-25885-01-00	JOINT	1	
14	42H-25873-01-00	HOSE, BRAKE 2	2	
15	90401-10044-00	BOLT, UNION	1	
16	90201-10118-00	WASHER, PLATE	3	
17	90401-10034-00	BOLT, UNION	1	
18	90201-10118-00	WASHER, PLATE	2	
19	42X-25875-00-00	HOLDER, BRAKE HOSE 1	1	
20	97011-06010-00	BOLT	1	
21	92995-06100-00	WASHER, SPRING	1	
22	42X-25876-00-00	HOLDER, BRAKE HOSE 2	1	
23	97011-06010-00	BOLT	1	
24	92995-06100-00	WASHER, SPRING	1	
25	90401-10034-00	BOLT, UNION	2	
26	90201-10118-00	WASHER, PLATE	4	



STAND - FOOTREST

Ref. No.	Part Number	Description	Qty	Remarks
1	3CF-27211-00-93	PEDAL, BRAKE	1	CHROME PLATED
2	90109-06468-00	BOLT	1	
3	92995-06100-00	WASHER, SPRING	1	
4	42X-27212-00-00	SHAFT, BRAKE PEDAL	1	
5	90506-20192-00	SPRING, TENSION	1	
6	90101-06478-00	BOLT, HEX.	1	
7	90170-06184-00	NUT, HEXAGON	1	
8	3CF-27231-01-00	ROD, BRAKE	1	
9	90240-06057-00	PIN, CLEVIS	1	
10	90560-06201-00	SPACER	1	
11	92990-06200-00	WASHER	2	
12	91490-20020-00	PIN, COTTER	3	
13	3CF-27241-00-00	ROD, JOINT	1	
14	90240-06103-00	PIN, CLEVIS	2	
15	90501-10245-00	SPRING, COMPRESSION	1	
16	90249-12008-00	PIN	1	
17	90175-06019-00	NUT, WING	1	
18	42X-27111-00-R4	STAND, MAIN	1	BLACK
19	97003-10016-00	BOLT (97002-10016-00)	2	
20	90201-10752-00	WASHER, PLATE	2	
21	90506-35149-00	SPRING, TENSION	1	
22	371-27114-00-00	STOPPER, MAIN STAND	1	
23	42X-27311-00-93	STAND, SIDE	1	CHROME PLATED
24	90109-103A1-00	BOLT	1	
25	95303-10700-00	NUT	1	
26	90507-29009-00	SPRING, TENSION	1	
27	3CF-27410-00-93	FRONT FOOTREST ASSEMBLY (LEFT)	1	CHROME PLATED
28	1NH-27413-00-00	. COVER, FOOTREST	1	


CONTINUED ON NEXT FRAME ➤



STAND - FOOTREST

Ref. No.	Part Number	Description	Qty	Remarks
29	95601-06100-00	. NUT, U	2	
30	90508-18696-00	. SPRING, TORSION	1	
31	91701-08038-00	. PIN, CLEVIS	1	
32	91401-25020-00	. PIN, COTTER	1	
33	90387-087K5-00	. COLLAR	1	
34	1RM-27420-00-93	FRONT FOOTREST ASSEMBLY (RIGHT)	1	CHROME PLATED
35	1NH-27413-00-00	. COVER, FOOTREST	1	
36	90176-06066-00	. NUT, CROWN	2	
37	90508-18696-00	. SPRING, TORSION	1	
38	91701-08038-00	. PIN, CLEVIS	1	
39	91401-25020-00	. PIN, COTTER	1	
40	90387-087K5-00	. COLLAR	1	
41	4X7-27414-00-00	DAMPER, FOOTREST	4	
42	90387-107A7-00	COLLAR	4	
43	90201-100A1-00	WASHER, PLATE	8	
44	90109-101A3-00	BOLT	4	
45	3CF-27471-00-00	BAR, FOOTREST 1	1	
46	90338-09012-00	PLUG	2	
47	3CF-27472-00-00	BAR, FOOTREST 2	1	
48	90105-10050-00	BOLT, WASHER BASED	1	
49	90176-10049-00	NUT, CROWN	3	
50	1RM-27430-01-00	REAR FOOTREST ASSEMBLY 1	1	
51	1NH-27433-00-00	. COVER, REAR FOOTREST	1	
52	92016-06012-00	. BOLT, BUTTON HEAD	2	
53	1HX-27437-00-00	. WASHER, SPECIAL	1	
54	91701-06038-00	. PIN, CLEVIS	1	
55	91490-16020-00	. PIN, COTTER	1	


CONTINUED ON NEXT FRAME ➤



STAND - FOOTREST

Ref. No.	Part Number	Description	Qty	Remarks
56	90501-12743-00	. SPRING, COMPRESSION	1	
57	93501-04011-00	. BALL	1	
58	1RM-27440-00-00	REAR FOOTREST ASS''Y 2 ...	1	
59	1NH-27433-00-00	. COVER, REAR FOOTREST ..	1	
60	92016-06012-00	. BOLT, BUTTON HEAD	2	
61	1HX-27437-00-00	. WASHER, SPECIAL	1	
62	91701-06038-00	. PIN, CLEVIS	1	
63	91490-16020-00	. PIN, COTTER	1	
64	90501-12743-00	. SPRING, COMPRESSION	1	
65	93501-04011-00	. BALL	1	
66	95023-08020-00	BOLT	3	
67	95023-08045-00	BOLT	1	


METER




Ref. No.	Part Number	Description	Qty	Remarks
1	3LP-83570-00-00	SPEEDOMETER ASSEMBLY ..	1	
2	1RM-83540-00-00	TACHOMETER ASSEMBLY ...	1	
3	3CF-8353E-00-00	CASE, METER UPPER	1	
4	3CF-8353H-00-00	CASE, UNDER	1	
5	1FG-83519-00-00	BRACKET, METER	1	
6	3JL-83507-00-00	COVER, SPEEDOMETER 42X-83507-00- 0	1	UR BLACK METALLIC
	42X-83507-00-00	COVER, SPEEDOMETER	1	UR METALLIC CHROME
7	3JL-83508-00-00	COVER, TACHOMETER 42X-83508-00- 0	1	UR BLACK METALLIC
	42X-83508-00-00	COVER, TACHOMETER	1	UR METALLIC CHROME
8	1FG-83523-00-00	DAMPER	4	
9	90201-05031-00	WASHER, PLATE	4	
10	95380-05600-00	NUT	4	
11	98580-04008-00	SCREW, PAN HEAD	2	
12	97701-40014-00	SCREW, TAPPING	6	
13	1RM-83509-00-00	SOCKET CORD ASSEMBLY ..	1	
14	42X-83517-00-00	BULB (12V-3W)	10	
15	36Y-82151-00-00	FUSE (15A-BL)	3	
16	42X-82151-20-00	FUSE (10A)	3	
17	42X-83559-00-00	COVER, METER	1	
18	1FK-83523-00-00	DAMPER	1	
19	1FK-83535-00-00	TUBE	4	
20	98701-04010-00	SCREW, FLAT HEAD	2	
21	55R-83579-00-00	COVER, METER 2	1	
22	92906-06200-00	WASHER	2	
23	92906-06100-00	WASHER, SPRING	2	
24	95316-06600-00	NUT	2	

CONTINUED ON NEXT FRAME ➤

METER




Ref. No.	Part Number	Description	Qty	Remarks
25	584-83541-00-00	DAMPER	4	
26	90387-06249-00	COLLAR	2	
27	57A-83550-00-00	SPEEDOMETER CABLE ASSEMBLY	1	




HEADLIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	42X-84303-A1-00	HEADLIGHT UNIT ASSEMBLY .	1	
2	42X-84315-01-00	. RIM, HEADLIGHT	1	
3	5Y3-84395-00-00	. RING, RETAINING	1	
4	42X-84321-A0-00	. LENS ASSEMBLY	1	
5	2F9-84375-00-00	. SETTING PLATE, BULB	1	
6	2F9-84397-01-00	. COVER, SOCKET	1	
7	90157-04001-00	. SCREW, PAN HEAD	2	
8	1A0-84332-60-00	. SPRING, SCREW	2	
9	198-84334-60-00	. NUT, ADJUSTING	2	
10	42X-84124-60-00	. SPRING, SET	1	
11	5V2-84314-00-XX	BULB, HL 12V60/55W (2F9-84314-00)	1	LM HALOGEN
12	42X-84330-01-00	BODY ASSEMBLY	1	
13	42X-84345-00-00	. DAMPER, HEADLIGHT	2	
14	42X-84366-00-00	. DAMPER, HEADLIGHT 1	1	
15	42X-84338-00-00	. COLLAR, BODY FITTING	2	
16	90157-05084-00	SCREW, PAN HEAD	2	
17	90201-06073-00	WASHER, PLATE	1	
18	97313-06016-00	BOLT, HEXAGON	1	
19	92995-06100-00	WASHER, SPRING	1	
20	91311-08055-00	BOLT, SOCKET HEAD	1	
21	42X-84318-00-00	STAY, HEADLIGHT 1	1	
22	91316-06025-00	BOLT	2	

TAILLIGHT




Ref. No.	Part Number	Description	Qty	Remarks
1	1RM-84700-60-00	TAILLIGHT ASSEMBLY	1	
2	256-84714-61-00	. BULB (12V-27/8W)	2	
3	42X-84721-60-00	. LENS, TAILLIGHT	1	
4	42X-84723-01-00	. GASKET, TAIL LENS	1	
5	1RM-84704-00-00	. GASKET, TAILLIGHT	1	
6	97780-40525-00	. SCREW, TAPPING	2	
7	42X-84717-00-00	. CORD, TAILLIGHT	1	
8	90119-06097-00	BOLT, WITH WASHER	3	
9	90387-065L5-00	COLLAR	3	
10	90480-14229-00	GROMMET	3	
11	90480-16112-00	GROMMET	1	
12	90480-15061-00	GROMMET	1	
13	1RM-84751-00-00	BRACKET, LICENSE	1	
14	97001-06018-00	BOLT	2	
15	92995-06100-00	WASHER, SPRING	2	
16	92901-06600-00	WASHER	2	





TURNSIGNAL


Ref. No.	Part Number	Description	Qty	Remarks
1	42X-83310-K0-00	FRONT FLASHER LIGHT ASSEMBLY 1	2	
2	256-84714-61-00	. BULB (12V-27/8W)	1	
3	42X-83312-00-00	. LENS, FLASHER	1	
4	42X-83313-00-00	. GASKET, FLASHER LENS	1	
5	42X-83363-00-00	. LENS, RIM	1	
6	341-83333-70-00	. SCREW, LENS FITTING	2	
7	42X-83359-00-00	. WASHER, SPECIAL	2	
8	1AA-83318-00-00	STAY, FLASHER 1	2	
9	1AA-83330-K0-00	REAR FLASHER LIGHT ASSEMBLY 1	2	
10	256-83311-70-XX	. BULB, TS 12V27W	1	
11	42X-83312-00-00	. LENS, FLASHER	1	
12	42X-83313-00-00	. GASKET, FLASHER LENS	1	
13	42X-83363-00-00	. LENS, RIM	1	
14	341-83333-70-00	. SCREW, LENS FITTING	2	
15	42X-83359-00-00	. WASHER, SPECIAL	2	
16	1AA-83318-00-00	STAY, FLASHER 1	2	
17	95706-12500-00	NUT, FLANGE	4	
18	97003-06030-00	BOLT	4	
19	95701-06500-00	NUT, FLANGE	4	
20	42X-83328-00-00	STAY, FLASHER 2	1	



ELECTRICAL 1


Ref. No.	Part Number	Description	Qty	Remarks
1	BTY-YB16A-LA-20	BATTERY ASSEMBLY	1	
2	1E6-82131-00-00	BAND, BATTERY	1	
3	42H-82115-00-00	WIRE, PLUS LEAD	1	
4	42X-82116-00-00	WIRE, MINUS LEAD	1	
5	90445-081A9-00	HOSE	1	
6	2H7-82540-00-00	NEUTRAL SWITCH ASSEMBLY	1	
7	90430-10171-00	GASKET	1	
8	42X-82310-70-00	IGNITION COIL ASSEMBLY	1	
9	42X-82320-70-00	IGNITION COIL ASSEMBLY	1	
10	98980-05016-00	SCREW, BIND	2	
11	42X-82317-00-00	DAMPER, IGNITION COIL	2	
12	1J7-82370-00-00	PLUG CAP ASSEMBLY	2	
13	57A-82314-00-00	COVER, IGNITION COIL	1	
14	98516-06012-00	SCREW, PAN HEAD	1	
15	92906-06600-00	WASHER	1	
16	98506-06025-00	SCREW, PAN HEAD	1	
17	92906-06600-00	WASHER	1	
18	42X-82501-50-00	MAIN SWITCH STEERING LOCK	1	
19	97011-06016-00	BOLT	2	
20	92990-06600-00	WASHER, PLATE	2	
21	1A0-83980-30-00	STOP SWITCH ASSEMBLY	1	
22	42X-82530-02-00	STOP SWITCH ASSEMBLY	1	
23	42X-82539-00-00	STAY, STOP SWITCH	1	
24	1RM-82590-00-00	WIRE HARNESS ASS''Y	1	
25	4X7-82150-00-00	FUSE HOLDER ASSEMBLY	1	
26	1A0-82161-00-00	. FUSE (20A) (148-82151-00-00)	2	
27	3JL-82305-00-00	IGNITOR UNIT ASSEMBLY	1	
28	97702-60120-00	SCREW, TAPPING (97702-60520-00)	2	

CONTINUED ON NEXT FRAME ➤



ELECTRICAL 1


Ref. No.	Part Number	Description	Qty	Remarks
29	90201-063A5-00	WASHER, PLATE	2	
30	3JK-85720-00-00	OIL LEVEL GAUGE ASSEMBLY	1	
31	91311-06016-00	BOLT, SOCKET HEAD	2	
32	33E-82566-00-00	SWITCH, SIDE STAND	1	
33	90152-05021-00	SCREW, COUNTERSUNK	2	



ELECTRICAL 2

Ref. No.	Part Number	Description	Qty	Remarks
1	5A8-86110-50-00	SOLENOID	1	
2	25G-81950-01-00	RELAY ASSEMBLY	1	
3	3JK-81815-00-00	CORD, STARTER MOTOR	1	
4	95380-06700-00	NUT	1	
5	92995-06100-00	WASHER, SPRING	1	
6	95303-08700-00	NUT	2	
7	92990-08100-00	WASHER	2	
8	42X-81960-A1-00	RECTIFIER & REGULATOR ASSEMBLY	1	
9	98502-06016-00	SCREW, PAN HEAD (98501-06014-00)	2	
10	92995-06100-00	WASHER, SPRING	2	
11	92990-06600-00	WASHER, PLATE	2	
12	90465-10264-00	CLAMP	1	
13	4U8-81980-M0-00	DIODE ASSEMBLY	1	FOR SIDE STAND
14	41R-83350-71-00	FLASHER RELAY ASSEMBLY	1	
15	1RM-83371-00-00	HORN	1	
16	1RM-83371-10-00	HORN	1	
17	91316-06012-00	BOLT, SOCKET HEAD	2	
18	42X-85110-00-00	REFLECTOR ASSEMBLY	2	
19	95701-05500-00	NUT, FLANGE	2	
20	42X-85752-01-00	SENDER UNIT ASSEMBLY, FUEL METER	1	
21	42X-85753-00-00	GASKET, SENDER UNIT	1	
22	90149-06011-00	SCREW	2	
23	90202-05187-00	WASHER, PLATE	2	
24	2EN-85130-00-00	REAR REFLECTOR ASSEMBLY	1	
25	95701-05500-00	NUT, FLANGE	1	

HANDLE SWITCH - LEVER



Ref. No.	Part Number	Description	Qty	Remarks
1	10M-82911-00-00	HOLDER, LEVER 1	1	
2	57A-83912-01-00	LEVER 1	1	
3	3Y6-82917-00-00	SWITCH	1	
4	90109-067A9-00	BOLT	1	
5	95616-06100-00	NUT, U	1	
6	93210-11368-00	O-RING	1	
7	97006-06022-00	BOLT	1	
8	92906-06100-00	WASHER, SPRING	1	
9	57A-83922-01-00	LEVER 2	1	
10	90149-06153-00	SCREW, SPEC''L SHAPE	1	
11	90170-06010-00	NUT	1	
12	90501-10312-00	SPRING, COMPRESSION	1	
13	90109-06577-00	BOLT	1	
14	95601-06100-00	NUT, U	1	
15	2UJ-83973-00-00	SWITCH, HANDLE 3	1	
16	98506-05035-00	. SCREW, PAN HEAD	2	
17	10M-83942-00-00	. COVER, STARTER	1	
18	10M-83941-00-00	. LEVER, STARTER	1	
19	92995-06200-00	. WASHER (92902-06200)	1	
20	98506-06008-00	. SCREW, PAN HEAD (92506-06008-00)	1	
21	92995-06100-00	. WASHER, SPRING	1	
22	1AA-8397X-00-00	. SPACER	1	
23	3AL-83975-00-00	SWITCH, HANDLE 2	1	
24	98506-05040-00	. SCREW, PAN HEAD	1	
25	98506-05045-00	. SCREW, PAN HEAD	1	
26	437-83936-01-00	BAND, SWITCH CORD	2	

CONTINUED ON NEXT FRAME ➤

SERVICE DATA

MOTORCYCLE	part 11-28-90

XV750B, BC
1991 SERVICE DATA

MODEL / MODEL CODE	XV750 /	3JA
	XV750C /	3JE
INITIAL ENGINE NUMBER / FRAME NUMBER	B: 3AL-049101 / JYA3ALE0[ ]MA049101	
	BC: 3CM-007101 / JYA3CME0[ ]MA007101	
ENGINE	Air-Cooled Four-Stroke, SOHC V-2	
Bore / Stroke / Number Cylinders / Displacement	83mm / 69.2mm / 2 / 749cc	
Piston Skirt Clearance New / Max	0.040 ~ 0.060mm / 0.10mm	
Valve Clearance (Cold): Intake / Exhaust	0.07 ~ 0.12mm / 0.12 ~ 0.17mm	
Oil Type: Above 5°C (40°F)	Yamalube 4* or SAE20W40 SE or SF	
Oil Type: Below 15°C (60°F)	SAE10W30 SE or SF	
Capacity: Oil and Filter Change / Oil Change Only	3100cc (3.8 qt) / 3000cc (3.2 qt)	
Oil Filter Part Number	4X7-13440-90-00	
TRANSMISSION		
Oil Type/Capacity/Drive Chain Free Play	See ENGINE / ø / ø	
MIDDLE GEAR CASE: Oil Type / Capacity	ø	
FINAL GEAR CASE: Oil or Grease Type/Capacity	SAE80 API GL-4 Hypoid Shaft Drive Gear Oil* / 0.2 Lit	
FUEL TANK: Main / Reserve / Fuel Type	14.5 L (3.8 gal)/2.5 L (0.7 gal)/Unleaded Regular	
COOLING SYSTEM: Coolant Type / Mixing Ratio (Liquid)	ø	
CARBURETOR		
Manufacturer / Type / ID Number	Mikuni / BST40 / B: 3AL-01 BC: 3CM-00	
Main Jet / Pilot Jet / Pilot Screw (Turns Out)	#127.5 / #40 / ø	
Needle Jet / Jet Needle / Clip Position	Y-4 / 5DL92 / Fixed	
Slide Cutaway	ø	
Float Height / Fuel Level	24 ±1mm / 2 ±0.5mm (with special tool)	
Idle rpm	1000 ±50	
Max CO# / Max HC# / Set CC's	6.0% / 800 ppm / 4.0 ±0.5% @ 1000 rpm	
SUSPENSION		
Front: Oil Type / Level / Quantity	10 wt. Fork Oil* / 155mm / 396cc	
Gas or Air Pressure: Min ~ Max / Standard	ø	
Rear: Gas or Air Pressure: Min ~ Max / Standard	ø	
TIRE SIZE / Nominal Pressure: Front	100/90-19 57H / 2 kg/cm² (28.4 psi)	
Size / Nominal Pressure: Rear	140/90-15M/C / 2.25 kg/cm² (32 psi)	
CHARGING SYSTEM	AC Magneto Generator	
Battery: Model / Specific Gravity / Charge Rate	YB16AL (12V16A) / 1.280 / 1.6A	
Maximum Output	14V/20A @ 5000 rpm	
Field Coil Color Code / Ω	ø	
Stator Coil Color Code / Ω	W ~ W / 0.5Ω ±10%	
Charge Coil Color Code / Ω	ø	
IGNITION SYSTEM	Transistor Controlled (Digital)	
Ignition Timing	10° @ 1000 rpm Full Adv. 35° @ 3600 rpm	
Spark Plug Type	NGK BPR7ES or ND W22EPR-U	
Spark Plug Gap / Torque / Cap Ω	0.7~0.8mm / 2.0m-kg (14 ft-lb) / 5KΩ	
Ignition Coil Test Gap / Primary Ω / Secondary Ω	6mm / 4.2Ω ±15% / 13.2KΩ ±15%	
Pulser Coil or Pickup Coil Color Code / Ω	Gy~B / 202Ω ±10%	
Source Coil Color Code / Ω	ø	

ø = Does not apply to this model
NA = Information not available

* = Available from YMD
• = For diagnostic use only

LIGHTING SYSTEM	
Headlight / Taillight / Turn Signal	12V 60-55W / 12V 27-8W / 12V 27W
Lighting Coil Color Code / Ω	ø / ø
TORQUE VALUES	
Front Axle Nut	M14: 11.0m-kg (80 ft-lb)
Front Axle Holder Nut	M8: 2.0m-kg (14 ft-lb)
Rear Axle Nut	M14: 11.0m-kg (80 ft-lb)
Rear Axle Pinch Bolt	ø
Clutch Nut	M20: 7.0m-kg (50 ft-lb)
Drain Plug	M14: 4.3m-kg (31 ft-lb)
Flywheel Nut	M16: 17.5m-kg (125 ft-lb)
Cylinder Head Cover	ø
Cylinder Head: Nut	M10: 3.5m-kg (14 ft-lb)
Bolt	M8: 2.0m-kg (14 ft-lb)
Engine Mounting Bolts: Front Bracket Nut	M12: 8.4m-kg (46 ft-lb)
Front & Rear Bolt	M10: 5.5m-kg (40 ft-lb)
Rear Upper & Lower Bolt	M10: 5.5m-kg (40 ft-lb)
Pivot Shaft	M22: 10.0m-kg (72 ft-lb)
Spark Plug	2.0m-kg (14 ft-lb)
SERVICE LITERATURE	
Owner's Manual	LIT-11626-07-73
Service Manual	LIT-11616-XV-11 (Same as XV750U,C,W,WC,A,AC)
Assembly Manual	LIT-11666-04-99 (Same as XV750U,C,W,WC,A,AC)
Consumer Information	LIT-11656-04-56

ø = Does not apply to this model
NA = Information not available

* = Available from YMD
• = For diagnostic use only

TECHNICAL BULLETIN

MOTORCYCLE | DATE 5/10/91 | No. M91-002

1991 EMISSION-CONTROLLED MODELS
HIGH ALTITUDE EMISSION ADJUSTMENTS

INTRODUCTION

This bulletin contains high altitude emissions information required by federal regulation. Yamaha provides high altitude information kits to Yamaha dealers. These kits contain information stickers and instructions for changing to optional main jet(s) on affected models used consistently at altitudes higher than 4,000 feet above sea level.

One high altitude information kit is included with this bulletin. This kit contains a sticker and jetting information sheet for each affected model. Additional kits are available at no charge from Yamaha Parts and Accessories.

DEALER ACTION SUMMARY

Install high altitude carburetor main jets only on units that will always be operated above 4,000 feet. For proper main jet installation, use the instructions provided with the high altitude information kits.

AFFECTED MODEL APPLICATION CHART

(See Page 2 for ADJUSTMENT RECOMMENDATION CHART)

MODEL	DISPLACEMENT	ENGINE FAMILY
TW200B, BC	196 cc	MYA0196A1B2
XT350B, BC	346 cc	MYA0346A1AX
XT600E, EBC	595 cc	MYA0595A1B0
FZR600RB	599 cc	MYA0599A4W4
FZR600RBC	599 cc	MYA0599A4S0
XV750B, BC	749 cc	MYA0749A2S5
FZR1000B, BC	1003 cc	MYA1003A4EX
XV1100B, BC	1063 cc	MYA1063A2S0
FJ1200B, BC	1188 cc	MYA1188A4A6
VMX12B	1198 cc	MYA1198A4W5
VMX12BC	1198 cc	MYA1198A4W6
XVZ13DB, DBC	1294 cc	MYA1294A4W6

PARTS INFORMATION

PART NUMBER	DESCRIPTION	DEALER COST
LIT-10061-14-81	Information Kit	N.C.

NOTE: Main Jets listed in the information kits must be ordered from Yamaha Parts and Accessories.

ADJUSTMENT RECOMMENDATION CHART

CAUTION:

Units on which high altitude main jets have been installed should not be used below 4,000 feet elevation or serious engine damage could occur. Make sure owners of modified machines are aware of this limitation.

MODEL	ORIGINAL MAIN JET	RECOMMENDED MAIN JET	PART NUMBER
TW200B, BC	#114	#110 ~ #114	#110 2B8-14343-55-00 #112 2B8-14343-56-00 #114 2B8-14343-57-00
XT350B, BC	PRIMARY (LEFT SIDE) #125 SECONDARY (RIGHT SIDE) #106	PRIMARY #120 ~ #125 SECONDARY #102 ~ #106	PRIMARY #120 2B8-14343-60-00 #125 2B8-14343-63-00 SECONDARY #102 3DX-14343-51-00 #104 2B8-14343-52-00 #106 3DX-14343-53-00
XT600E, EBC	PRIMARY (LEFT SIDE) #130 SECONDARY (RIGHT SIDE) #104	PRIMARY #120 ~ #130 SECONDARY #100 ~ #104	PRIMARY #120 2B8-14343-60-00 #125 2B8-14343-63-00 #130 2B8-14343-65-00 SECONDARY #100 3DX-14343-50-00 #102 3DX-14343-51-00 #104 2B8-14343-52-00
FZR600RB, RBC	#107.5	#102.5 ~ #107.5	#102.5 3G2-1423A-71-00 #105 3G2-14231-21-00 #107.5 3G2-142[illegible]A-72-00
XV750B, BC	#122.5	#120 ~ #122.5	#120 620-142[illegible]-24-A0 #122.5 620-14[illegible]4-75-00
FZR1000B, BC	#1 & #4 CYL: #125 #2 & 3 CYL: #122.5	#1, 4 CYL: #120 ~ #125 #2, 3 CYL: #117 ~ #122.5	#117.5 3G[illegible]-1423A-74-00 #120 3G2-142[illegible]-24-00 #122.5 3G2-14[illegible]-75-A1 #125 3G2-14231-25-00
XV1100B, BC	#1 CYL: #122.5 #2 CYL: #125	#1 CYL: #120 ~ #122.5 #2 CYL: #122.5 ~ #125	#120 620-14231-24-A0 #122.5 620-1423A-75-00 #125 620-14231-25-A0
FJ1200B, BC	#110	#105 ~ #110	#105 620-14231-21-A0 #110 620-14231-22-A0
VMX12B, BC	#152.5	#147.5 ~ #152.5	#147.5 3G2-1423A-80-A0 #150 3G2-14231-30-A0 #152.5 3G2-1423A-81-00
XVZ13DB, DBC	#125	#120, #125	#120 3G2-14231-24-00 #125 3G2-14231-25-00

WARRANTY INFORMATION

No warranty applies. Installation of parts for high altitude use is done at the customers' option and expense.

CAUTION:

Damage to modified units caused by operation below 4000 feet elevation will not be covered by warranty.

PAGE 1 OF 2 | PAGE 2 OF 2 | ROUTE TO: ✓ SERVICE | ✓ PARTS | WARRANTY | SALES

TECHNICAL BULLETIN

MOTORCYCLE | DATE 5/27/92 | No. M92-005

XV750/1100A,B,D, & VMX12A,B,D
ADDITIONAL ASSEMBLY INSTRUCTIONS

INTRODUCTION

The following information is not included in the Assembly Manuals for the XV750/1100A,B,D. Installing the handlebar switches outside the locating tab or projection may result in the loss of the handlebar end caps because the caps will not fit far enough into the handlebar. Please use the instructions below when assembling the handlebars on these units.

DEALER ACTION SUMMARY

Copies of this bulletin should be attached to the assembly manuals of all affected units.

UNSOLD UNITS: Make sure all new units are assembled according to this bulletin information. Inspect all assembled units, both sold and unsold, to verify proper assembly. Rectify any incorrect switch installation.

CUSTOMER UNITS: Have any customer who reports losing handlebar end caps bring their unit in for inspection to make sure the handlebar switches are installed according to the information in this bulletin.

PARTS REQUIRED: No

WARRANTY: No warranty applies

AFFECTED UNITS


XV750A, AC	All	XV1100D, DC	All
XV750B, BC	All	VMX12A, AC	All
XV750D, DC	All	VMX12B, BC	All
XV1100A, AC	All	VMX12D, DC	All
XV1100B, BC	All		


SERVICE PROCEDURES

Observe the following when installing the handlebar switches on the above units during assembly. Failure to properly position the throttle/switch assembly during installation may result in the loss of the chrome handlebar end cap.

1. Right side handle bar switch: The stepped tab on the handlebar should touch the inner surface of the handlebar switch. The switch should completely cover the tab when installed properly. Refer to the illustration for the right side switch.

2. Left side handlebar switch: Align the notch on the inner side of the switch housing with the projection on the clutch lever holder. The switch should cover the projection when installed properly. Refer to the illustration of the left side switch.





WARRANTY INFORMATION

This bulletin is for assembly information only. There is no warranty allowance for assembly and preparation.

PAGE 1 OF 2 | PAGE 2 OF 2 | ROUTE TO: ✓ SERVICE | PARTS | WARRANTY | SALES