YAMAHA


GENUINE

PARTS CATALOGUE

MOTORCYCLE

A1


CYLINDER HEAD



Ref. No.	Part Number	Description	Qty	Remarks
1	3AL-11102-00-00	CYLINDER HEAD ASS''Y	2	
2	93440-14086-00	. CIRCLIP, OUTER	2	
3	4X7-11133-10-00	. GDE, INTK VLV 1 O/S	2	
4	4X7-11127-00-00	ABSORBER 3	8	
5	42H-14873-01-00	PIPE 3	2	
6	91800-06030-00	PIN, DOWEL	4	
7	42Y-11181-00-00	GASKET, CYLINDER HEAD 1	2	
8	4X7-11363-01-00	BOLT, CYLINDER HOLDING 3	4	
9	90116-12469-00	BOLT, STUD	4	
10	90116-10344-00	BOLT, STUD	2	
11	90179-12326-00	NUT, SPEC''L SHAPE	4	
12	90201-125A3-00	WASHER, PLATE	4	
13	90179-12325-00	NUT	4	
14	90176-10049-00	NUT, CROWN	2	
15	90201-102G9-00	WASHER, PLATE	2	
16	91311-08050-00	BOLT, SOCKET HEAD	4	
17	95611-08640-00	BOLT, STUD	4	
18	42X-11185-01-00	COVER, CYLINDER HEAD SIDE 1	1	
19	91311-06016-00	BOLT, SOCKET HEAD	2	
20	42X-11152-00-00	BRACKET, CYLINDER HEAD COVER	1	
21	90202-05187-00	WASHER, PLATE	2	
22	42X-1111H-01-00	COVER, CYLINDER HEAD SIDE 4	1	
23	42X-11165-00-00	PLATE, BREATHER	1	
24	42X-11166-01-00	PIPE, BREATHER 1	1	
25	90467-14015-00	CLIP	2	
26	93210-92448-00	O-RING	2	
27	91311-06025-00	BOLT, SOCKET HEAD	2	


CONTINUED ON NEXT FRAME ➤


CYLINDER HEAD



Ref. No.	Part Number	Description	Qty	Remarks
28	42H-11186-01-00	COVER, CYLINDER HEAD SIDE 2	2	
29	4X7-11187-00-00	COVER, CYLINDER.HEAD 3	2	
30	93210-62446-00	O-RING	4	
31	91311-06016-00	BOLT, SOCKET HEAD	8	
32	4X7-1111F-00-00	PLATE	2	
33	97011-08020-00	BOLT	2	
34	90401-16065-00	BOLT, UNION	2	
35	90430-17168-00	GASKET	2	
36	1RM-1112E-00-00	COVER, CYLINDER HEAD 3	1	
37	90480-23444-00	GROMMET	2	
38	91316-06010-00	BOLT, SOCKET HEAD	1	
39	NGK-BP7ES-00-00	PLUG, SPARK (NGK BP-7ES)	2	

CYLINDER






FWD

10L110-2020

Ref. No.	Part Number	Description	Qty	Remarks
1	1RT-11310-00-00	CYLINDER	2	
2	93210-89447-00	O-RING	2	
3	4X7-11161-00-00	ABSORBER 1	4	
4	90387-087A5-00	COLLAR	4	
5	91311-06040-00	BOLT	6	
6	3JL-11351-00-00	GASKET, CYLINDER	2	
7	4X7-12215-00-00	CAP, TENSIONER CASE	2	
8	4DW-12213-00-00	GASKET, TENSIONER CASE	2	
9	91311-06025-00	BOLT, SOCKET HEAD	4	

CRANKSHAFT - PISTON



Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-11411-02-00	CRANKSHAFT	1	
2	93306-30808-00	BEARING (3EF)	1	
3	4X7-13354-00-00	SPROCKET, DRIVE	1	
4	93306-30808-00	BEARING (3EF)	1	
5	42Y-11631-00-A0	PISTON (STD)	2	
	42Y-11636-00-00	PISTON (0.50MM O/S)	2	
	42Y-11638-00-00	PISTON (1.00MM O/S)	2	
6	42Y-11610-01-00	PISTON RING SET (STD)	2	
	42Y-11610-21-00	PISTON RING SET (0.50MM O/S) (42Y-11610-20-00)	2	
	42Y-11610-41-00	PISTON RING SET (1.00MM O/S)	2	
7	4X7-11633-00-00	PIN, PISTON	2	
8	93450-22027-00	CIRCLIP	4	
9	4X7-11650-00-00	CONNECTING ROD ASSEMBLY	2	
10	4X7-11654-01-00	. BOLT, CON ROD	2	
11	90179-09379-00	. NUT, SPEC"L SHAPE	2	
12	4X7-11656-00-00	PLANE BRNG, CON ROD	4	UR BLUE
	4X7-11656-10-00	PLANE BRNG, CON ROD	4	UR BLACK
	4X7-11656-20-00	PLANE BRNG, CON ROD	4	UR BROWN
	4X7-11656-30-00	PLANE BRNG, CON ROD	4	UR GREEN
	4X7-11656-40-00	PLANE BRNG, CON ROD	4	UR YELLOW
13	90280-16053-00	KEY, WOODRUFF	1	
14	90201-165H4-00	WASHER, PLATE	1	
15	90179-16448-00	NUT, SPEC"L SHAPE	1	

CONNECTING ROD BEARING SELECTION


Housing No. - Shaft No. = Bearing No.

BEARING No.	PART No.	COLOUR
BEARING 1	4X7-11656-00	BLUE
BEARING 2	4X7-11656-10	BLACK
BEARING 3	4X7-11656-20	BROWN
BEARING 4	4X7-11656-30	GREEN
BEARING 5	4X7-11656-40	YELLOW

FWD

42W110-4030


CAMSHAFT - CHAIN



Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-11536-00-00	GEAR, DRIVE (35T)	1	
2	4X7-11534-00-00	GEAR, BREAKER DRIVE	1	
3	90501-21133-00	SPRING, COMPRESSION	12	
4	93605-10090-00	PIN, DOWEL	12	
5	4X7-11540-01-00	CM CHN SPRKT ASSEMBLY 1 (20/50T)	1	
6	4X7-11550-00-00	CAM CHAIN SPRKT 2 (20/50T)	1	
7	4X7-12247-01-00	SHAFT, TENSIONER	2	
8	90209-06205-00	WASHER, SPEC''L SHAP	2	
9	90105-06154-00	BOLT, WASHER BASED	2	
10	42X-12171-00-00	CAMSHAFT 1	1	
11	42X-12181-00-00	CAMSHAFT 2	1	
12	42X-11145-00-00	PLATE, BREATHER 2	1	
13	90201-10774-00	WASHER, PLATE	2	
14	90101-10303-00	BOLT	2	
15	90380-25125-00	BUSH, SOLID	2	
16	94590-45098-00	CHAIN, CAM	2	
17	4X7-12176-00-00	SPROCKET, CAM CHAIN	2	
18	93604-10011-00	PIN, DOWEL	2	
19	4X7-12210-01-00	TENSNR ASSEMBLY, CAM CHN	2	
20	90338-06121-00	. PLUG, SPEC''L SHAPE	1	
21	4X7-12231-00-00	GUIDE, STOPPER 1	2	
22	4X7-12241-00-00	GUIDE, STOPPER 2	1	
23	4X7-12221-00-00	GUIDE, STOPPER 3	1	
24	90109-08592-00	BOLT	2	
25	95303-08700-00	NUT	2	
26	92901-06600-00	WASHER	2	
27	91311-06025-00	BOLT, SOCKET HEAD	4	

CONTINUED ON NEXT FRAME ➤


CAMSHAFT - CHAIN



42W110-4050

Ref. No.	Part Number	Description	Qty	Remarks
28	4DW-12213-00-00	GASKET, TENSIONER CASE . .	2	


VALVE



5E3171-1050

Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-12111-00-00	VALVE, INTAKE	2	
2	4X7-12121-00-00	VALVE, EXHAUST	2	
3	4X7-12116-00-00	SEAT, VALVE SPRING	4	
4	90501-31454-00	SPRING, COMPRESSION	4	
5	90501-44455-00	SPRING, COMPRESSION	4	
6	341-12119-02-00	SEAL, VALVE STEM	4	
7	4X7-12117-00-00	RETAINER, VALVE SPR	4	
8	4X7-12118-00-00	COTTER, VALVE	8	
9	42X-12151-00-00	ARM, VALVE ROCKER (4X7-12151-00)	4	
10	4X7-12156-01-00	SHAFT, ROCKER	4	
11	4X7-12159-00-00	SCREW, VALVE ADJUSTING	4	
12	90170-08173-00	NUT, HEXAGON	4	


OIL PUMP



1RR110-6060

Ref. No.	Part Number	Description	Qty	Remarks
1	10L-13300-00-00	OIL PUMP ASSEMBLY	1	
2	99510-08016-00	PIN, DOWEL	1	
3	93210-07438-00	O-RING	2	
4	91316-06040-00	BOLT, SOCKET HEAD	3	
5	4X7-13355-00-00	SPROCKET, DRIVEN	1	
6	90105-06154-00	BOLT, WASHER BASED	1	
7	10L-13327-00-00	COVER, PUMP GEAR	1	
8	91316-06010-00	BOLT, SOCKET HEAD	2	
9	94580-25066-00	CHAIN 4 7	1	
10	4X7-13171-00-00	PIPE, DELIVERY 2	1	
11	93210-07438-00	O-RING	2	
12	91316-06010-00	BOLT, SOCKET HEAD	2	
13	4X7-13405-00-00	OIL PIPE CMPLT 1	1	
14	4X7-15485-01-00	CLAMP	1	
15	4X7-15484-00-00	CLAMP 2	1	
16	90468-05113-00	CLIP	1	
17	1RM-13406-00-00	OIL PIPE COMP. 2	1	
18	90401-16067-00	BOLT, UNION	2	
19	90430-17168-00	GASKET	4	
20	90401-10102-00	BOLT, UNION	1	
21	90430-15169-00	GASKET	3	
22	4X7-15485-01-00	CLAMP	1	
23	90468-05113-00	CLIP	1	
24	3JL-13455-00-00	PLUG	1	
25	214-11198-01-00	GASKET	1	

OIL CLEANER




Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-13440-90-00	ELMNT ASSEMBLY, OIL CLNR	1	
2	93210-56459-00	O-RING	1	
3	93210-54452-00	O-RING	1	
4	1RM-13447-00-00	COVER, OIL ELEMENT	1	
5	93210-07135-00	O-RING	1	
6	90109-06678-00	BOLT	1	
7	91311-06020-00	BOLT, SOCKET HEAD	1	
8	91311-06050-00	BOLT, SOCKET HEAD	1	
9	11H-13490-00-00	RELIEF VALVE ASSEMBLY	1	
10	93210-10096-00	O-RING	1	
11	90462-10098-00	CLAMP	1	

FWD

5E3171-1070


INTAKE



Ref. No.	Part Number	Description	Qty	Remarks
1	24M-13586-01-00	JOINT, CARBURETOR 1	2	
2	16G-13569-00-00	PLUG, BLIND	1	
3	90467-10039-00	CLIP	1	
4	42X-13564-01-00	COVER, MANIFOLD	2	
5	42X-13578-00-00	WASHER	2	
6	42X-13544-00-00	HOSE, VACUUM SENSING 2	1	
7	90467-08092-00	CLIP	2	
8	93210-44545-00	O-RING	2	
9	97016-06020-00	BOLT	4	
10	92906-06600-00	WASHER	4	
11	1TA-13534-00-00	HOSE, VACUUM SENSING 5	1	
12	90467-08092-00	CLIP	2	
13	1RV-13595-00-00	JOINT	1	
14	1TA-13535-00-00	HOSE, VACUUM SENSING 5	1	
15	41R-14489-00-00	NOZZLE	1	
16	3CG-14197-00-00	PIPE	1	
17	3CG-14987-00-00	HOSE	1	
18	90467-14057-00	CLIP	2	
19	3CG-14396-00-00	PIPE	1	
20	¢90-41307-02-30	WAY 3	1	
21	1TA-14349-00-00	PIPE	1	
22	1TA-14348-00-00	PIPE 1	1	
23	90467-10091-00	CLIP, SCISSOR	4	
24	10L-14453-01-00	JOINT, AIR CLEANER 1	2	
25	10L-14407-00-00	COVER, JOINT	1	
26	90460-65195-00	CLAMP, HOSE	4	
27	42X-14401-01-00	AIR CLEANER CASE ASSEMBLY	1	
28	92901-04600-00	WASHER, PLATE	2	

CONTINUED ON NEXT FRAME ➤


INTAKE



Ref. No.	Part Number	Description	Qty	Remarks
29	42X-14477-00-00	PLATE	2	
30	97780-40112-00	SCREW, TAPPING	4	
31	42X-14451-00-00	ELEMENT, AIR CLEANER	1	
32	1RM-14422-00-00	CAP, CLEANER CASE 2	1	
33	42X-14452-00-00	SEAL	1	
34	1TA-1441A-00-00	COVER, CLEANER CASE 1	1	
35	97706-50508-00	SCREW, TAPPING	1	
36	98580-05012-00	SCREW, PAN HEAD	1	
37	92901-05600-00	WASHER, PLATE	1	
38	98506-06080-00	SCREW, PAN HEAD	1	
39	98506-06050-00	SCREW, PAN HEAD	1	
40	92906-06600-00	WASHER	1	
41	1TA-1441E-00-00	COVER, CLEANER CASE 2	1	
42	97706-50508-00	SCREW, TAPPING	1	
43	90387-07598-00	COLLAR	1	
44	90110-06138-00	BOLT, HEX SKT HEAD	1	
45	92906-06200-00	WASHER	2	
46	91316-06012-00	BOLT, SOCKET HEAD	1	
47	42X-14485-00-00	PIPE, JOINT	1	
48	90460-65195-00	CLAMP, HOSE	1	
49	42X-14663-02-00	PLATE, AIR CLEANER	1	
50	91311-06090-00	BOLT	1	
51	92906-06200-00	WASHER	1	
52	42X-14484-00-00	PLATE, CLEANER CASE FITTING	1	
53	95811-06025-00	BOLT, FLANGE	1	
54	1RM-14603-00-00	COVER 1	1	
55	90480-14074-00	GROMMET	2	
56	95821-06014-00	BOLT, FLANGE	1	


CONTINUED ON NEXT FRAME ➤

INTAKE




Ref. No.	Part Number	Description	Qty	Remarks
57	12R-14484-01-00	PLATE, CLEANER CASE FITTING	1	
58	91316-06035-00	BOLT	1	
59	92906-06200-00	WASHER	1	

CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
1	¢3A-L1490-00-10	CARBURETOR ASSEMBLY . . .	1	N/A
	¢3C-M1490-00-00	CARBURETOR ASSEMBLY . . .	1	N/A
2	3CM-14901-01-00	. CARBURETOR ASSEMBLY 1	1	UR CA
	3CM-14901-01-00	. CARBURETOR ASSEMBLY 1	1	UR NON-CA
3	3CM-14902-00-00	. CARBURETOR ASS''Y 2 (3AL-14902-01-00)	1	UR CA
	3CM-14902-00-00	. CARBURETOR ASS''Y 2 (3AL-14902-01-00)	1	UR NON-CA
4	3CF-14984-01-00	. . GASKET, FLOAT CHAMBER	1	
5	3CF-14107-15-00	. . NEEDLE VALVE SET	1	
6	3CF-1490J-00-00	. . NEEDLE SET	1	
7	3CF-14940-00-00	. . DIAPHRAGM ASSEMBLY . .	1	
8	¢3C-F1493-30-00	. . SPRING, DIAPHRAGM	1	
9	12R-14105-00-00	. . PILOT SCREW SET	1	
10	537-14186-00-00	. . PIN, FLOAT	1	
11	2VA-14185-00-00	. . FLOAT	1	
12	137-14153-00-00	. . WASHER, MAIN JET	1	
13	3CF-14991-00-00	. . SCREW	1	
14	256-14954-00-00	. . WASHER	1	
15	620-1423A-75-00	. . JET, MAIN (122.5) (620-14231-75-A0)	1	
16	3CF-14141-94-00	. . NOZZLE, MAIN	1	
17	4G0-14142-40-00	. . JET, PILOT (# 40)	1	
18	3G2-14231-12-00	. . JET, POWER (# 60)	1	
19	98580-05010-00	. . SCREW, PAN HEAD	4	
20	98580-04008-00	. . SCREW, PAN HEAD	2	
21	3CF-1490H-00-00	. . DIAPHRAGM SET 5	1	
22	1HX-14231-28-00	. . JET, MAIN (#140)	1	
23	3CF-1410A-00-00	. . STARTER SET	1	
24	98580-05016-00	. . SCREW, PAN HEAD	4	


CONTINUED ON NEXT FRAME ➤



CARBURETOR

Ref. No.	Part Number	Description	Qty	Remarks
25	92990-05100-00	. . WASHER, SPRING	4	
26	12R-14191-00-00	. . PLUG, DRAIN	1	
27	2JU-14937-00-00	. . CLIP	1	FOR CA
28	3F9-14118-00-00	. . CAP	1	
29	3CF-14251-00-00	. NIPPLE	1	
30	3CF-14937-00-00	. CLIP	1	
31	3CG-14197-00-00	. PIPE	1	
32	98580-05012-00	. SCREW, PAN HEAD	4	
34	3CF-14919-00-00	. CLIP	1	
35	3CF-14103-00-00	. THROTTLE SCREW SET	1	
36	98580-05016-00	. SCREW, PAN HEAD	4	
37	3CF-14197-00-00	. PIPE	1	


EXHAUST



Ref. No.	Part Number	Description	Qty	Remarks
1	42X-14611-00-00	PIPE, EXHAUST 1	1	
2	3EG-14714-00-00	GASKET, MUFFLER	1	
3	1RV-14621-00-00	PIPE, EXHAUST 2	1	
4	1RM-14711-01-00	MUFFLER 1	1	
5	3YF-14755-00-00	GASKET, SILENCER	1	
6	95811-08045-00	BOLT, FLANGE (JN5)	1	
7	95811-08045-00	BOLT, FLANGE (JN5)	1	
8	42X-14748-01-00	PROTECTOR, MUFFLER 4	1	
9	90202-05187-00	WASHER, PLATE	4	
10	98903-06010-00	SCREW, BIND	2	
11	42X-1479H-00-00	COVER, 1	2	
12	92990-06200-00	WASHER	2	
13	42X-14612-00-00	NUT, RING	2	
14	42X-1468A-00-00	RING, SILENCER 1	2	
15	90179-08210-00	NUT, SPEC''L SHAPE	2	
16	90179-08507-00	NUT	2	
17	3EG-14613-00-00	GASKET, EXHAUST PIPE	2	
18	90101-06576-00	BOLT	1	
19	90101-06576-00	BOLT	1	
20	92990-06600-00	WASHER, PLATE	1	
21	92990-06600-00	WASHER, PLATE	1	
22	42H-14882-00-00	HOSE, BEND 2	1	
23	1RV-14840-00-00	AIR CUT VALVE ASS''Y	1	
24	90462-20188-00	CLAMP	1	
25	97701-60114-00	SCREW, TAPPING	1	
26	42H-14883-00-00	HOSE, BEND 3	1	
27	42H-14808-00-00	REED VALVE ASSEMBLY	1	
28	97701-60114-00	SCREW, TAPPING	3	
29	42H-14884-00-00	HOSE, BEND 4	1	


CONTINUED ON NEXT FRAME ➤

EXHAUST



Ref. No.	Part Number	Description	Qty	Remarks
30	42H-14885-00-00	HOSE, BEND 5	1	
31	90501-102A3-00	SPRING, COMPRESSION	1	
32	90501-102A5-00	SPRING, COMPRESSION	1	
33	42H-14871-01-00	PIPE 1	1	
34	42H-14872-02-00	PIPE 2	1	
35	90468-08104-00	CLIP	2	
36	90467-16098-00	CLIP	2	
37	42H-14714-00-00	GASKET, MUFFLER	2	
38	90460-15227-00	CLAMP, HOSE	2	
39	42H-14857-00-00	CASE, AIR CLEANER	1	
40	42H-14858-00-00	CAP, CASE	1	
41	95380-05600-00	NUT	1	
42	92990-05200-00	WASHER, PLAIN	1	
43	90202-05057-00	WASHER, PLATE	1	
44	1TA-14881-00-00	HOSE, BEND 1	1	
45	90467-22080-00	CLIP	1	
46	97701-60114-00	SCREW, TAPPING	1	


CRANKCASE



42W110-4110

Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-15100-05-00	CRANKCASE ASSEMBLY	1	
2	99510-12016-00	. PIN, DOWEL	1	
3	95611-10620-00	BOLT, STUD	1	
4	95611-10620-00	BOLT, STUD	1	
5	95611-10670-00	BOLT, STUD	1	
6	93210-07438-00	O-RING	1	
7	93210-07135-00	O-RING	1	
8	90387-064E8-00	COLLAR	1	
9	91311-10100-00	BOLT, SOCKET HEAD	1	
10	91311-10070-00	BOLT, SOCKET HEAD	1	
11	91311-10060-00	BOLT, SOCKET HEAD	1	
12	91311-06080-00	BOLT, SOCKET HEAD	2	
13	91311-06055-00	BOLT, SOCKET HEAD	1	
14	91311-06030-00	BOLT, SOCKET HEAD	13	
15	90430-06014-00	GASKET	1	
16	57A-15363-11-00	PLUG, OIL	1	
17	93210-29198-00	O-RING	1	
18	90465-10168-00	CLAMP	1	
19	4X7-15491-00-00	PROTECTOR	1	
20	4X7-13419-00-00	PLUG	1	
21	90480-20302-00	GROMMET	1	
22	42X-21164-00-00	HOLDER, CABLE	1	
23	90105-10275-00	BOLT, WASHER BASED	1	


CRANKCASE COVER 1



Ref. No.	Part Number	Description	Qty	Remarks
1	1RM-15411-01-00	COVER, CRANKCASE 1	1	
2	4X7-15361-00-00	GAUGE, LEVEL	1	
3	2H7-15361-00-00	GAUGE, LEVEL	1	
4	90465-08309-00	CLAMP	1	
5	98580-06010-00	SCREW, PAN HEAD (92503-06010)	1	
6	3EG-15451-00-00	GASKET, CRCS COVER	1	
7	99530-10014-00	PIN, DOWEL	2	
8	91311-06040-00	BOLT	3	
9	91311-06030-00	BOLT, SOCKET HEAD	6	
10	91311-06020-00	BOLT, SOCKET HEAD	3	
11	1L9-11186-00-00	COVER, CYLINDER HEAD SIDE 2	1	
12	93210-32172-00	O-RING	1	
13	90462-08076-00	CLAMP	1	
14	1RM-15415-00-00	COVER, GENERATOR	1	
15	1RM-15455-00-00	GASKET 1	1	
16	3JK-15425-00-00	COVER, GENERATOR 2	1	
17	98780-06016-00	SCREW, FLAT HEAD (92603-06016)	3	
18	98701-06014-00	SCREW, FLAT HEAD	3	
19	42X-15417-01-00	COVER, CAP	1	
20	91311-06055-00	BOLT, SOCKET HEAD	1	
21	91311-06016-00	BOLT, SOCKET HEAD	1	
22	1RM-15419-00-00	COVER, SHIFTER 1	1	
23	3EG-15459-00-00	GASKET, SHIFTER COVER	1	
24	91311-06016-00	BOLT, SOCKET HEAD	2	
25	3CG-15429-00-00	COVER, SHIFTER	1	
26	98580-06030-00	SCREW PAN HEAD	2	
27	91311-06065-00	BOLT	1	


CONTINUED ON NEXT FRAME ➤

CRANKCASE COVER 1



Ref. No.	Part Number	Description	Qty	Remarks
28	42X-15441-00-00	HOLDER, CLUTCH CABLE	1	
29	3JK-W1542-00-00	COVER, CRANKCASE 3	1	
30	93101-14102-00	OIL SEAL, S-TYPE	1	
31	4X7-15388-00-00	PLATE, BRNG COVER	1	
32	91316-06016-00	BOLT, SOCKET HEAD	2	
33	3EG-15462-00-00	GASKET, CRCS CVR 3	1	
34	99530-10020-00	PIN, DOWEL	2	
35	91311-06040-00	BOLT	2	
36	91311-06025-00	BOLT, SOCKET HEAD	8	
37	91311-06030-00	BOLT, SOCKET HEAD	1	
38	90462-10143-00	CLAMP	1	
39	90462-10085-00	CLAMP	2	
40	90462-12142-00	CLAMP	1	
41	1RM-13161-00-00	PIPE, DELIVERY 1	1	
42	93210-07438-00	O-RING	3	


GENERATOR



3JL7110-1340

Ref. No.	Part Number	Description	Qty	Remarks
1	3JL-81450-00-00	ROTOR ASSEMBLY	1	
2	1RM-81410-20-00	STATOR ASSEMBLY	1	
3	¢1R-M8166-10-00	SPACER	1	
4	91316-06050-00	BOLT, SOCKET HEAD	3	
5	3JL-81670-00-00	PICK-UP ASSEMBLY	1	
6	91316-06016-00	BOLT, SOCKET HEAD	3	
7	90201-06643-00	WASHER, PLATE	2	


STARTING MOTOR



3JK4110-0350


Ref. No.	Part Number	Description	Qty	Remarks
1	5A8-81800-10-00	STARTING MOTOR ASSEMBLY	1	
2	5A8-81826-10-00	. BOLT	2	
3	11H-81844-00-00	. GASKET	1	
4	5A8-81830-10-00	. FRONT BRACKET ASSEMBLY	1	
5	5A8-81847-10-00	. . O-RING	1	
6	5A8-81840-10-00	. BRUSH HOLDER ASSEMBLY	1	
7	1J7-81847-60-00	. O-RING	1	
8	95811-06025-00	BOLT, FLANGE	2	

STARTER CLUTCH



Ref. No.	Part Number	Description	Qty	Remarks
1	3LP-15570-00-00	STARTER CLUTCH ASSEMBLY	1	
2	99009-13400-00	CIRCLIP (55X)	1	
3	4X7-15521-00-00	SHAFT 1	1	
4	93210-14104-00	O-RING	1	
5	5A8-15524-00-00	WHEEL, STARTER (23T)	1	
6	1TA-15512-00-00	GEAR, IDLER 1	1	
7	5A8-15517-00-00	GEAR, IDLER 2 (27T)	1	
8	90387-172E5-00	COLLAR	2	
9	90501-15636-00	SPRING, COMPRESSION	1	
10	90387-170E5-00	COLLAR	1	
11	5A8-15550-00-00	DRIVE LEVER ASSEMBLY	1	
12	93102-10247-00	OIL SEAL	1	
13	5A8-15542-01-00	COLLAR 2	1	
14	90151-06013-00	SCREW, COUNTERSUNK	1	
15	5A8-15556-00-00	LEVER, DRIVE	1	
16	90508-26494-00	SPRING, TORSION	1	
17	90149-08166-00	SCREW	1	
18	3EG-15568-00-00	GASKET	1	
19	95701-06500-00	NUT, FLANGE	2	


CLUTCH



Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-16111-00-00	GEAR, PRI DRIVE	1	
2	90282-07042-00	KEY, STRAIGHT	1	
3	90214-20022-00	WASHER, CLAW	1	
4	90215-20182-00	WASHER, LOCK	1	
5	90170-20274-00	NUT, HEXAGON	1	
6	2H7-16396-00-00	HOUSING, PUSH SCREW	1	
7	93606-07082-00	PIN, DOWEL	1	
8	2H7-16395-01-00	RETAINER, BALL	1	
9	2H7-16341-00-00	SCREW, PUSH	1	
10	2H7-16343-00-00	SCREW, ADJUSTING	1	
11	93210-48364-00	O-RING	1	
12	4X7-16340-00-00	PUSH LEVER ASSEMBLY	1	
13	92990-08200-00	WASHER, PLAIN	1	
14	95303-08700-00	NUT	1	
15	90506-10069-00	SPRING, TENSION	1	
16	93104-14059-00	OIL SEAL, SO-TYPE	1	
17	4X7-16357-00-00	ROD, PUSH 2	1	
18	4X7-16356-00-00	ROD, PUSH 1	1	
19	93340-21505-00	BEARING	1	
20	90201-154E9-00	WASHER, PLATE	1	
21	4X7-16150-02-00	PRI DRVN GEAR	1	
22	3Y1-16154-00-00	PLATE, THRUST 1	1	
23	4X7-16371-00-00	BOSS, CLUTCH	1	
24	4X7-16384-00-00	PLATE, SEAT	1	
25	4X7-16383-01-00	SPRING, CLUTCH BOSS	1	
26	4X7-16324-00-00	PLATE, CLUTCH 1	1	
27	4X7-16385-00-00	RING, CLUTCH BOSS	1	
28	22U-16321-00-00	PLATE, FRICTION	8	
29	4X7-16325-00-00	PLATE, CLUTCH 2	7	


CONTINUED ON NEXT FRAME ➤

CLUTCH




Ref. No.	Part Number	Description	Qty	Remarks
30	4X7-16351-00-00	PLATE, PRESSURE 1	1	
31	90501-23598-00	SPRING, COMPRESSION	6	
32	90159-06092-00	SCREW, WITH WASHER	6	
33	90215-20231-00	WASHER, LOCK	1	
34	90170-20327-00	NUT	1	

TRANSMISSION




Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-17411-00-00	AXLE, MAIN	1	
2	4X7-17141-00-00	GEAR, 4TH PINION	1	
3	90209-22191-00	WASHER	1	
4	93410-25010-00	CIRCLIP, S-TYPE	1	
5	4X7-17121-00-00	GEAR, 2ND PINION	1	
6	42X-17151-00-00	GEAR, 5TH PINION (34T)	1	
7	90201-20276-00	WASHER, PLATE (1.0T)	1	
8	99009-20400-00	CIRCLIP	1	
9	93306-30525-00	BEARING (B6305)	1	
10	93104-20068-00	OIL SEAL	1	
11	93306-30424-00	BEARING (B6304A3)	1	
12	4X7-17402-00-00	DRIVE AXLE ASSEMBLY	1	
13	4X7-17221-00-00	GEAR, 2ND WHEEL	1	
14	90209-27192-00	WASHER	1	
15	93440-30077-00	CIRCLIP	1	
16	42X-17251-00-00	GEAR , 5TH WHEEL (29T)	1	
17	4X7-17231-00-00	GEAR, 3RD WHEEL	1	
18	90209-27192-00	WASHER	1	
19	93440-30077-00	CIRCLIP	1	
20	4X7-17241-00-00	GEAR, 4TH WHEEL	1	
21	4X7-17211-00-00	GEAR, 1ST WHEEL	1	
22	4X7-17582-01-00	GEAR, MIDDLE DRIVE (45T)	1	
23	93306-20421-00	BEARING	1	
24	93306-20550-00	BEARING (B6205DU8)	1	
25	4X7-17583-01-00	GEAR, MIDDLE DRIVEN	1	
26	93316-01201-00	BEARING, CYLINDER.# 6	1	
27	93306-91201-00	BEARING	1	

MIDDLE DRIVE GEAR



Ref. No.	Part Number	Description	Qty	Remarks
1	1TA-Y1757-00-00	MIDDLE GEAR COMP.	1	
2	93306-20901-00	BEARING (B6209RSH2-C2)	1	
3	90179-44328-00	NUT	1	
4	42X-17526-01-00	CAM, DRIVE	1	
5	31A-17527-00-00	CAM, DRIVEN	1	
6	90501-70762-00	SPRING, COMPRESSION	1	
7	4X7-17524-00-00	HOLDER	1	
8	3H5-17529-00-00	WASHER, THRUST	2	
9	4X7-17531-00-15	SHIM, PINION (0.15T)	1	UR
	4X7-17531-00-30	SHIM, PINION (0.30T)	1	UR
	4X7-17531-00-50	SHIM, PINION (0.50T)	1	UR
10	90179-88336-00	NUT, SPEC''L SHAPE	1	
11	93317-22021-00	BEARING, CYLINDER.# 7	1	
12	93311-34050-00	BEARING, CYLINDRICAL	1	
13	90201-255A6-00	WASHER, PLATE	3	
14	1J7-46129-Y1-00	SPACER, EXPANSION	1	
15	11H-17551-00-00	HOUSING, BEARING	1	
16	93210-71360-00	O-RING	1	
17	93306-20548-00	BEARING	1	
18	4X7-17554-00-00	RETAINER, BEARING	1	
19	93210-52449-00	O-RING	1	
20	93101-35099-00	OIL SEAL, S-TYPE	1	
21	4X7-17558-00-00	PLATE, BEARING	1	
22	4X7-17556-00-00	YOKE, JOINT	1	
23	93210-14359-00	O-RING	1	
24	90201-14633-00	WASHER, PLATE	1	
25	90179-14317-00	NUT, SPEC''L SHAPE	1	
26	90387-251E1-00	COLLAR	1	
27	95811-08030-00	BOLT, FLANGE	3	


SHIFT CAM - SHIFT FORK



5E3171-1190

Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-18540-01-00	SHIFT CAM ASSEMBLY	1	
2	93306-90602-00	. BEARING	1	
3	4G0-18185-01-00	. SEGMENT	1	
4	93604-20156-00	. PIN, DOWEL	1	
5	93604-16092-00	. PIN, DOWEL	3	
6	98701-05035-00	. SCREW, FLAT HEAD	1	
7	136-18542-00-00	. POINT, NEUTRAL	1	
8	90201-30297-00	. WASHER, PLATE	1	
9	4X7-18511-00-00	FORK, SHIFT 1	1	
10	4X7-18512-00-00	FORK, SHIFT 2	1	
11	4X7-18513-00-00	FORK, SHIFT 3	1	
12	4X7-18531-00-00	BAR, SHIF FRK GDE 1	1	
13	4X7-18536-00-00	STOPPER, SHIFT BAR	1	
14	98701-06014-00	SCREW, FLAT HEAD	2	


SHIFT SHAFT



42W110-4180

Ref. No.	Part Number	Description	Qty	Remarks
1	4X7-18120-01-00	SHIFT LEVER ASSEMBLY	1	
2	90506-08227-00	. SPRING, TENSION	1	
3	4X7-18140-00-00	STOPPER LEVER ASSEMBLY .	1	
4	90508-32535-00	SPRING, TORSION	1	
5	99006-10600-00	CIRCLIP	3	
6	90508-29531-00	SPRING, TORSION	1	
7	90201-12588-00	WASHER, PLATE	1	
8	90387-124F4-00	COLLAR	1	
9	90201-12588-00	WASHER, PLATE	1	
10	90201-12166-00	WASHER, PLATE	1	
11	93102-12321-00	OIL SEAL, SD-TYPE	1	
12	42X-18110-01-00	SHIFT PEDAL ASSEMBLY	1	
13	2H9-18154-00-00	. COVER, DUST	1	
14	132-18113-01-00	. COVER, SHIFT PEDAL	1	
15	90201-124E4-00	WASHER, PLATE	1	
16	99009-12400-00	CIRCLIP	1	
17	42X-18112-01-00	ARM, SHIFT	1	
18	2H9-18154-00-00	. COVER, DUST	1	
19	97011-06020-00	BOLT	1	
20	29L-18115-00-00	ROD, SHIFT	1	
21	90170-06228-00	NUT (COUNTER CLOCKWISE)	1	
22	95380-06700-00	NUT	1	
23	93608-50158-00	PIN, DOWEL	1	

FRAME




FWD

3AL110-8190


Ref. No.	Part Number	Description	Qty	Remarks
1	3CF-21110-00-33	FRAME COMP.	1	
2	42X-21317-00-00	STAY, ENGINE 3	1	
3	42X-21359-00-00	BRACKET, COIL	1	
4	98516-06012-00	SCREW, PAN HEAD	1	
5	92906-06100-00	WASHER, SPRING	1	
6	92906-06600-00	WASHER	1	
7	90105-10297-00	BOLT, WASHER BASED	2	
8	90176-10049-00	NUT, CROWN	2	
9	90179-12421-00	NUT, SPEC''L SHAPE	4	
10	90201-125A3-00	WASHER, PLATE	4	
11	42X-21315-00-00	STAY, ENGINE 2	1	
12	42X-21316-00-00	STAY, ENGINE 3	1	
13	90105-10298-00	BOLT, WASHER BASED	2	
14	90201-105H3-00	WASHER, PLATE	2	
15	90387-100E2-00	COLLAR	2	
16	4X7-21485-00-00	DAMPER, RUBBER 1	2	
17	90105-10050-00	BOLT, WASHER BASED	2	
18	90105-10300-00	BOLT, WASHER BASED	1	
19	42X-21458-01-00	BRACKET, SIDE STAND	1	
20	90176-10049-00	NUT, CROWN	2	
21	90105-06069-00	BOLT, WASHER BASED	1	
22	90202-05187-00	WASHER, PLATE	1	
23	90338-07043-00	PLUG, SPEC''L SHAPE	2	
24	90462-08138-00	CLAMP	2	
25	97706-50508-00	SCREW, TAPPING	2	
26	42X-2139R-00-00	COVER 2	1	
27	90159-06058-00	SCREW, WITH WASHER	1	

FENDER



Ref. No.	Part Number	Description	Qty	Remarks
1	1MY-21510-00-R0	FRONT FENDER COMP	1	
2	97021-06012-00	BOLT	4	
3	92990-06100-00	WASHER, SPRING	4	
4	1RM-21610-01-R0	REAR FENDER COMP	1	UR GRACEFUL MAROON
5	97021-06012-00	BOLT	2	
6	92990-06100-00	WASHER, SPRING	2	
7	97022-08012-00	BOLT	2	
8	92990-08100-00	WASHER	2	
9	1RM-2164F-00-00	STAY 1	1	
10	1RM-2164G-00-00	STAY 2	1	
11	1RM-2164H-00-00	STAY 3	1	
12	1RM-2164J-00-00	STAY 4	1	
13	55R-2164A-02-00	GRIP 1	1	
14	95811-06016-00	BOLT, FLANGE (95822-06016)	4	
15	95811-06016-00	BOLT, FLANGE (95822-06016)	4	
16	90149-08225-00	SCREW	2	
17	90105-10217-00	BOLT, WASHER BASED	2	
18	42X-21629-00-00	GUARD, MUD	1	
19	90159-06128-00	SCREW, WITH WASHER	2	
20	26H-21308-00-00	HELMET HANGER ASSEMBLY (4R8-21308-00)	1	
21	90149-06154-00	SCREW	1	
22	99236-00020-00	EMBLEM, YAMAHA	1	

SIDE COVER




Ref. No.	Part Number	Description	Qty	Remarks
1	42X-21711-00-R0	COVER COVER, SIDE 1	1	GRACEFUL MAROON
2	56F-21781-00-00	EMBLEM 1	1	
3	90480-01401-00	GROMMET	1	
4	466-21717-00-00	DAMPER, SIDE COVER	2	
5	42X-21721-00-R0	COVER, SIDE 2	1	GRACEFUL MAROON
6	56F-21782-00-00	EMBLEM 2	1	
7	3JL-2179R-30-00	PLATE, EPA 1	1	CA
	3JL-2179V-30-00	PLATE, EPA 1	1	NON-CA
8	90480-01401-00	GROMMET	2	
9	90480-12053-00	GROMMET	1	
10	42X-21171-00-00	BOX	1	
11	90480-20384-00	GROMMET	2	
12	90480-16233-00	GROMMET	1	
13	90387-060A7-00	COLLAR	1	
14	90201-06067-00	WASHER, PLATE	1	
15	97011-06020-00	BOLT	1	
16	92990-06100-00	WASHER, SPRING	1	
17	42X-21746-00-00	DAMPER	1	
18	42X-28185-00-00	LID	1	
19	42X-2172W-02-00	COVER	1	
20	98580-06008-00	SCREW, PAN HEAD	2	
21	92990-06100-00	WASHER, SPRING	2	
22	42X-2177A-00-00	BOX	1	
23	90560-06258-00	SPACER	1	
24	90201-06059-00	WASHER, PLATE	3	
25	91316-06012-00	BOLT, SOCKET HEAD	1	
26	90480-10408-00	GROMMET	1	
27	42X-2176E-00-00	PLATE	1	
28	90159-06110-00	SCREW, WITH WASHER	1	


CONTINUED ON NEXT FRAME ➤

SIDE COVER

Ref. No.	Part Number	Description	Qty	Remarks
29	42X-2117F-00-00	COVER	1	
30	90159-06071-00	SCREW, WITH WASHER	2	




REAR ARM - SUSPENSION



3CF110-8220

Ref. No.	Part Number	Description	Qty	Remarks
1	1RM-22110-00-35	REAR ARM COMP.	1	
2	93332-00010-00	BEARING	2	
3	90387-17543-00	COLLAR	2	
4	93102-25017-00	OIL SEAL	2	
5	42X-22141-00-00	SHAFT, PIVOT	1	
6	90215-22238-00	WASHER, LOCK	1	
7	1J7-22141-00-00	SHAFT, PIVOT	1	
8	1J7-22143-00-00	NUT	1	
9	2H7-2219X-00-00	COVER	2	
10	95023-08035-00	BOLT, FLANGE	1	
11	4X7-22189-01-00	BOOT, RUBBER	1	
12	90338-20113-00	PLUG	1	
13	42X-22210-12-00	SHOCK ABSORBER ASSEMBLY, REAR	1	
14	42X-22220-12-00	SHOCK ABSORBER ASSEMBLY, REAR	1	
15	57A-22243-01-00	WASHER 1	2	
16	91311-08020-00	BOLT, SOCKET HEAD	2	
17	90338-08163-00	PLUG	2	
18	90201-10437-00	WASHER, PLATE	1	
19	90176-10013-00	NUT, CROWN	1	
20	92990-10100-00	WASHER, SPRING	1	
21	90106-10030-00	BOLT, DOME HEAD	1	

DRIVE SHAFT




1TE110-6230

Ref. No.	Part Number	Description	Qty	Remarks
1	5G2-46101-01-00	REAR AXLE GEAR CASE ASSEMBLY	1	
2	90116-10361-00	. BOLT, STUD	4	
3	90116-08360-00	. BOLT, STUD	6	
4	90116-10249-00	. BOLT, STUD	1	
5	4H7-46153-00-00	. COLLAR, GUIDE	1	
6	93101-30084-00	. OIL SEAL	1	
7	93311-43729-00	. BEARING	1	
8	93317-41510-00	. BEARING	1	
9	2H7-46122-00-00	. RACE, INNER	1	
10	1J7-17537-Y0-30	. SHIM, THRUST (0.30T)	1	UR
	1J7-17537-Y0-40	. SHIM, THRUST (0.40T)	1	UR
	1J7-17537-Y0-50	. SHIM, THRUST (0.50T)	1	UR
11	93306-30533-00	. BEARING (B6305RB1 SPECIAL)	1	
12	4H7-46125-00-00	. RETAINER, BEARING	1	
13	93210-60426-00	. O-RING	1	
14	93101-38098-00	. OIL SEAL	1	
15	4H7-46123-00-00	. COUPLING, GEAR	1	
16	90201-14632-00	. WASHER, PLATE	1	
17	90185-14070-00	. NUT, SELF-LOCKING	1	
18	4H7-46152-00-00	. HOUSING, BEARING	1	
19	1J7-46117-Y0-30	. SHIM, RING GEAR (0.30T)	1	UR
	1J7-46117-Y0-35	. SHIM, RING GEAR	1	UR
	1J7-46117-Y0-40	. SHIM, RING GEAR (0.40T)	1	UR
	1J7-46117-Y0-45	. SHIM, ring gear (0.45T)	1	UR
	1J7-46117-Y0-50	. SHIM, RING GEAR (0.50T)	1	UR
20	93316-01403-00	. BEARING	1	
21	22U-46118-00-12	. SHIM, THRUST (1.2T)	1	UR

CONTINUED ON NEXT FRAME ➤


DRIVE SHAFT



1TE110-6230

Ref. No.	Part Number	Description	Qty	Remarks
21	22U-46118-00-14	. SHIM, THRUST (1.4T)	1	UR
	22U-46118-00-16	. SHIM, THRUST (1.6T)	1	UR
	22U-46118-00-18	. SHIM, THRUST (1.8T)	1	UR
	22U-46118-00-20	. SHIM, THRUST (2.0T)	1	UR
22	93211-44348-00	. O-RING	1	
23	95333-08600-00	. NUT	6	
24	92901-08700-00	. WASHER, WAVE	6	
25	95811-10025-00	. BOLT, FLANGE	2	
26	93102-70167-00	. OIL SEAL	1	
27	3VD-13455-00-00	. PLUG	1	
28	214-11198-01-00	. GASKET	2	
29	2H7-17590-00-00	. BREATHER COMP.	1	
30	90340-14118-00	. PLUG, STRAIGHT	1	
31	4X7-46172-00-00	SHAFT, DRIVE	1	
32	93108-23007-00	OIL SEAL	1	
33	90201-231A2-00	WASHER, PLATE	1	
34	93410-23056-00	CIRCLIP	1	
35	93410-22039-00	CIRCLIP	1	
36	90501-16491-00	SPRING, COMPRESSION	1	
37	4X7-46180-00-00	CROSS JOINT COMP.	1	
38	93399-99926-00	BEARING	2	
39	93440-20088-00	CIRCLIP	2	
40	90176-10049-00	NUT, CROWN	4	
41	92901-10100-00	WASHER, SPRING	4	
42	90387-172A5-00	COLLAR	1	


FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
1	3JL-23102-00-00	FRONT FORK ASS''Y (L.H) . . .	1	
2	3JL-23126-00-00	. TUBE, OUTER 1	1	
3	3R4-23153-00-00	. RING, SNAP	1	
4	3EN-23145-00-00	. OIL SEAL	1	
5	2YK-23125-00-00	. METAL, SLIDE 1	1	
6	4V2-23146-L0-00	. WASHER, OIL SEAL	1	
7	42X-23144-01-00	. SEAL, DUST	1	
8	1RM-23110-00-00	. INNER TUBE COMP. 1	1	
9	33M-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
10	5A8-23173-00-00	. SPINDLE, TAPER	1	
11	42H-23141-00-00	. SPRING, FRONT FORK	1	
12	1W1-23142-L0-00	. SEAT, SPRING UPPER	1	
13	1W1-23114-L0-00	. GASKET	1	
14	122-23129-00-00	. GASKET, DRAIN PLUG	1	
15	509-23158-L0-00	. GASKET	1	
16	31A-23111-31-00	. BOLT, CAP	1	
17	42H-23168-00-00	. CAP, FRONT FORK	1	
18	4H7-23119-00-00	. PLUG, DRAIN - (122-23119-01)	1	
19	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
20	¢42-X2311-80-00	. SPACER	1	
21	3JL-23103-00-00	FRONT FORK ASS''Y (R.H) . . .	1	FOR URB
22	3JL-23136-00-00	. TUBE, OUTER 2	1	
23	3R4-23153-00-00	. RING, SNAP	1	
24	3EN-23145-00-00	. OIL SEAL	1	
25	2YK-23125-00-00	. METAL, SLIDE 1	1	
26	4V2-23146-L0-00	. WASHER, OIL SEAL	1	
27	42X-23144-01-00	. SEAL, DUST	1	


CONTINUED ON NEXT FRAME ➤

FRONT FORK




Ref. No.	Part Number	Description	Qty	Remarks
28	1RM-23110-00-00	. INNER TUBE COMP. 1	1	
29	33M-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
30	5A8-23173-00-00	. SPINDLE, TAPER	1	
31	42H-23141-00-00	. SPRING, FRONT FORK	1	
32	1W1-23142-L0-00	. SEAT, SPRING UPPER	1	
33	1W1-23114-L0-00	. GASKET	1	
34	122-23129-00-00	. GASKET, DRAIN PLUG	1	
35	509-23158-L0-00	. GASKET	1	
36	31A-23111-31-00	. BOLT, CAP	1	
37	42H-23168-00-00	. CAP, FRONT FORK	1	
38	4H7-23119-00-00	. PLUG, DRAIN - (122-23119-01)	1	
39	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
40	90101-08340-00	. BOLT	1	
41	95333-08600-00	. NUT	1	
42	92990-08100-00	. WASHER	1	
43	¢42-X2311-80-00	. SPACER	1	
44	2AE-23340-30-00	UNDER BRACKET COMP.	1	
45	91311-08030-00	BOLT	4	
46	1RM-23132-00-00	COVER (L.H)	1	
47	1RM-23132-10-00	COVER (R.H)	1	
48	98580-05006-00	SCREW, PAN HEAD	2	

STEERING




Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00001-00	BEARING	1	
2	93332-00008-00	BEARING	1	
3	1J7-23415-00-00	COVER, BALL RACE 1	1	
4	90179-25033-00	NUT	2	
5	90202-26142-00	WASHER, PLATE	1	
6	26H-23418-01-00	WASHER, SPECIAL	1	
7	90176-22050-00	NUT, CROWN	1	
8	3AL-W2341-00-38	CROWN, HANDLE	1	CLEAR W/BUFF)
9	95023-08045-00	BOLT	2	
10	92990-08100-00	WASHER	2	
11	92901-08600-00	WASHER	2	
12	1UF-23317-01-00	HOLDER, CABLE	2	
13	4H7-23441-00-38	HOLDER, HANDLE UPPER	2	CLEAR W/BUFF)
14	3AL-23442-00-38	HOLDER, HANDLE LOWER	2	CLEAR W/BUFF)
15	90201-14220-00	WASHER, PLATE	2	
16	92990-12200-00	WASHER, PLAIN	2	
17	92901-12100-00	WASHER, SPRING	2	
18	95301-12700-00	NUT (95302-12700)	2	
19	90468-12006-00	CLIP	2	
20	91311-08030-00	BOLT	4	
21	90338-08163-00	PLUG	4	
22	1RM-23122-00-00	COVER, OUTER 1	1	
23	1RM-2317E-00-00	STAY	1	
24	92011-06012-00	SCREW (92016-06012-00)	2	
25	90338-08163-00	PLUG	4	
26	42X-2313A-00-00	BRACE, FORK	1	
27	95023-08020-00	BOLT	4	

FUEL TANK (NON-CALIFORNIA MODEL)



Ref. No.	Part Number	Description	Qty	Remarks
1	1RM-24110-00-X5	FUEL TANK COMP	1	UR GRACEFUL MAROON
2	3JL-24240-30-00	. GRAPHIC SET	1	
3	1RM-24161-00-00	EMBLEM 1	1	
4	1RM-24162-00-00	EMBLEM 2	1	
5	4H7-24181-00-00	DAMPER, LOCATING 1	2	
6	42X-24182-00-00	DAMPER, LOCATING 2	1	
7	42X-24183-00-00	DAMPER, LOCATING 3	1	
8	97313-08016-00	BOLT, HEXAGON	1	
9	42X-24186-00-00	WASHER, SPECIAL	1	
10	3AL-24500-00-00	FUEL COCK ASSEMBLY 1 ...	1	
11	4X8-24512-00-00	. O-RING	1	
12	1JK-24534-00-00	. SEAL, COCK	1	
13	98580-03008-00	. SCREW, PAN HEAD	2	
14	3H3-24523-00-00	. VALVE	1	
15	90202-05187-00	WASHER, PLATE	2	
16	90149-06011-00	SCREW	2	
17	3AL-24321-00-00	PIPE 0	1	
18	90501-08728-00	SPRING, COMPRESSION	1	
19	90467-10091-00	CLIP, SCISSOR	2	
20	3AL-2416A-00-00	HOSE	1	
21	90501-08410-00	SPRING, COMPRESSION	1	
22	90467-08092-00	CLIP	2	
23	4X7-24602-02-00	CAP ASSEMBLY	1	
24	4X7-24612-00-00	. GASKET, CAP	1	
25	98506-05010-00	. SCREW, PAN HEAD	1	

FUEL TANK (CALIFORNIA MODEL ONLY




3JL110-9260

Ref. No.	Part Number	Description	Qty	Remarks
1	1RV-24110-00-X4	FUEL TANK COMP	1	UR GRACEFUL MAROON
2	3JL-24240-20-00	. GRAPHIC SET	1	
3	1RM-24161-00-00	EMBLEM 1	1	
4	1RM-24162-00-00	EMBLEM 2	1	
5	4H7-24181-00-00	DAMPER, LOCATING 1	2	
6	42X-24182-00-00	DAMPER, LOCATING 2	1	
7	42X-24183-00-00	DAMPER, LOCATING 3	1	
8	97313-08016-00	BOLT, HEXAGON	1	
9	42X-24186-00-00	WASHER, SPECIAL	1	
10	3AL-24500-00-00	FUEL COCK ASSEMBLY 1	1	
11	4X8-24512-00-00	. O-RING	1	
12	1JK-24534-00-00	. SEAL, COCK	1	
13	98580-03008-00	. SCREW, PAN HEAD	2	
14	3H3-24523-00-00	. VALVE	1	
15	90202-05187-00	WASHER, PLATE	2	
16	90149-06011-00	SCREW	2	
17	3AL-24321-00-00	PIPE 0	1	
18	90501-08728-00	SPRING, COMPRESSION	1	
19	90467-10091-00	CLIP, SCISSOR	2	
20	3AL-2416A-00-00	HOSE	1	
21	90501-08410-00	SPRING, COMPRESSION	1	
22	90467-08092-00	CLIP	2	
23	20K-24602-00-00	CAP ASSEMBLY	1	
24	4X7-24612-00-00	. GASKET, CAP	1	
25	98506-05010-00	. SCREW, PAN HEAD	1	
26	25H-24180-00-00	ROLL OVER VALVE ASSEMBLY	1	
27	42X-2419A-00-00	HOLDER	1	


CONTINUED ON NEXT FRAME ➤

FUEL TANK (CALIFORNIA MODEL ONLY



3JL110-9260


Ref. No.	Part Number	Description	Qty	Remarks
28	97026-06012-00	BOLT	1	
29	92906-06100-00	WASHER, SPRING	1	
30	92906-06600-00	WASHER	1	
31	42X-24376-00-00	PIPE, JOINT 1	1	
32	90467-08092-00	CLIP	1	
33	90467-09006-00	CLIP	1	
34	42X-24377-00-00	PIPE, JOINT 3	1	
35	90467-09006-00	CLIP	2	
36	42H-24170-00-00	CANISTER ASSEMBLY	1	
37	90445-105G5-00	HOSE	1	
38	90467-09006-00	CLIP	1	
39	90445-11587-00	HOSE	1	
40	90467-11106-00	CLIP	1	



3CF110-8270

SEAT


Ref. No.	Part Number	Description	Qty	Remarks
1	3CF-24730-10-00	DOUBLE SEAT ASSEMBLY . . .	1	YAMAHA BLK
2	3CF-24731-10-00	. COVER, SEAT	1	YAMAHA BLK
3	509-24724-00-00	. DAMPER, SEAT	4	
4	1L9-24741-00-00	. PAD, SEAT	1	
5	91316-06016-00	BOLT, SOCKET HEAD	1	
6	90110-06077-00	BOLT, HEXAGON SOCKET HEAD	1	
7	42X-2473R-00-00	BOX 1	1	
8	90480-24186-00	GROMMET	1	
9	90201-225A4-00	WASHER, PLATE (T1.0)	1	
10	5A8-21708-00-00	LOCK ASSEMBLY 2	1	
11	42X-2473T-00-00	LID 1	1	
12	3CF-24723-00-00	DAMPER, SEAT	1	
13	42X-2177K-00-00	PIN, HINGE	1	
14	1RM-2162G-00-00	PLATE 1	1	
15	90176-06041-00	NUT, CROWN	2	
16	97011-06016-00	BOLT	1	
17	92990-06100-00	WASHER, SPRING	1	
18	90201-06057-00	WASHER, PLATE	1	
19	5H9-21376-00-00	BAND, TOOL	1	
20	5A8-W2810-00-00	TOOL KIT	1	



42G110-4280

FRONT WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
1	42H-25168-00-P0	CAST WHEEL, FRONT	1	UR LIGHT YELLOW
2	90560-15116-00	SPACER	1	
3	146-25115-00-00	FLANGE, SPACER 1	1	
4	93306-30202-00	BEARING	2	
5	93102-22014-00	OIL SEAL	1	
6	¢94-11019-4H-30	TIRE (100/90-19 57H)	1	UR BRIDGESTONE
	¢94-11019-4H-40	TIRE (100/90-19 57H)	1	UR DUNLOP
7	93900-00001-00	VALVE, RIM	1	UR BRIDGESTONE
	93900-00003-00	VALVE, RIM	1	UR DUNLOP
8	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UN
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	UN
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	UN
9	90387-15550-00	COLLAR	1	
10	42X-25181-00-00	AXLE, WHEEL	1	
11	42X-25190-00-00	GEAR UNIT ASSEMBLY	1	



FRONT BRAKE CALIPER

Ref. No.	Part Number	Description	Qty	Remarks
1	29L-25831-20-00	DISC, BRAKE (RT)	1	UR NEBULA GOLD
	3JK-25831-00-00	DISC, BRAKE (RIGHT)	1	UR SILVER
2	90109-08718-00	BOLT	12	
3	29L-25831-30-00	DISC, BRAKE (LEFT)	1	UR NEBULA GOLD
	3JK-25831-10-00	DISC, BRAKE (LEFT)	1	UR SILVER
4	42H-25810-01-00	CALIPER ASSEMBLY (RIGHT)	1	
5	26H-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
6	26H-W0047-00-00	. . CALIPER SEAL KIT	1	
7	26H-W0045-11-00	. BRAKE PAD KIT	1	
8	1WG-25919-00-00	. SUPPORT, PAD	1	
9	3HE-25924-00-00	. PIN, PAD	2	
10	3HE-25925-00-00	. CLIP	2	
11	1J3-W0048-00-00	. BLEED SCREW KIT	1	
12	42H-25810-11-00	CALIPER ASSEMBLY (LEFT)	1	
13	26H-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
14	26H-W0047-00-00	. . CALIPER SEAL KIT	1	
15	26H-W0045-11-00	. BRAKE PAD KIT	1	
16	1WG-25919-00-00	. SUPPORT, PAD	1	
17	3HE-25924-00-00	. PIN, PAD	2	
18	3HE-25925-00-00	. CLIP	2	
19	1J3-W0048-00-00	. BLEED SCREW KIT	1	
20	90105-10638-00	BOLT, WASHER BASED	4	

REAR WHEEL




42G110-4300

Ref. No.	Part Number	Description	Qty	Remarks
1	42H-25338-01-P1	CAST WHEEL, REAR	1	UR LIGHT YELLOW
2	90560-17249-00	SPACER	1	
3	146-25315-00-00	FLANGE, SPACER	1	
4	93306-30309-00	BEARING	1	
5	93306-20310-00	BEARING	1	
6	93306-20310-00	BEARING	1	
7	16G-25366-01-00	CLUTCH, HUB	1	
8	42H-25364-00-00	DAMPER	6	
9	93210-48530-00	O-RING	1	
10	93210-59531-00	O-RING	1	
11	16G-25412-00-00	WASHER	2	
12	95701-10500-00	NUT, FLANGE (95702-10500)	6	
13	93210-57428-00	O-RING	1	
14	42H-25321-02-00	PLATE, BRAKE SHOE	1	
15	3DR-W2536-00-00	BRAKE SHOE SET	1	
16	90507-20002-00	SPRING, TENSION	2	
17	4H7-25351-00-00	CAMSHAFT	1	
18	3CF-25355-00-00	LEVER, CAMSHAFT	1	
19	90201-14218-00	WASHER, PLATE	1	
20	4H7-2533A-02-00	PLATE, INDICATOR	1	
21	90101-06291-00	BOLT	1	
22	94114-156U0-00	TIRE (140/90-15 70H)	1	UR BRIDGESTONE
23	93900-00016-00	VALVE, RIM	1	BRIDGESTONE
24	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UN
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	UN
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	UN
25	16G-25327-00-00	COVER, PLATE	1	
26	97021-05020-00	BOLT	4	
27	92990-05100-00	WASHER, SPRING	4	

CONTINUED ON NEXT FRAME ➤


REAR WHEEL



42G110-4300

Ref. No.	Part Number	Description	Qty	Remarks
28	92901-05600-00	WASHER, PLATE	4	
29	42X-25381-00-00	AXLE, WHEEL	1	
30	90201-144J5-00	WASHER, PLATE	1	
31	90171-14031-00	NUT, CASTLE	1	
32	91401-30030-00	PIN, COTTER	1	
33	56W-25377-00-00	COLLAR, WHEEL	1	
34	42X-25371-00-00	BAR, TENSION	1	
35	90109-08406-00	BOLT	1	
36	92901-08600-00	WASHER	2	
37	92990-08100-00	WASHER	2	
38	95303-08700-00	NUT	2	
39	91490-20020-00	PIN, COTTER	2	
40	90109-08368-00	BOLT	1	


STEERING HANDLE - CABLE



3JK4110-0310

Ref. No.	Part Number	Description	Qty	Remarks
1	3AL-W2611-00-00	HANDLEBAR (3AL-W2611-10-00)	1	
2	3JB-26241-00-00	GRIP (LEFT)	1	
3	3JB-26273-00-00	ROTOR	1	
4	3JB-26240-00-00	GRIP ASSEMBLY	1	
5	3JB-2628J-00-00	CAP, GRIP	2	
6	3CF-26311-00-00	CABLE, THROTTLE 1	1	
7	3CF-26312-00-00	CABLE, THROTTLE 2	1	
8	5H0-26393-00-00	HOLDER	1	
9	98506-05008-00	SCREW, PAN HEAD	1	
10	57A-26335-00-00	CABLE, CLUTCH	1	
11	1E6-26342-00-00	BOOT, CABLE	1	
12	90179-08148-00	NUT	1	
13	90123-08046-00	BOLT	1	
14	3CF-26331-00-00	CABLE, STARTER 1	1	
15	1AA-26280-02-00	REAR VIEW MIRROR ASSEMBLY (LEFT)	1	
16	1AA-26290-02-00	REAR VIEW MIRROR ASSEMBLY (RIGHT)	1	


FRONT MASTER CYLINDER



42W110-4320

Ref. No.	Part Number	Description	Qty	Remarks
1	22R-25850-02-00	MASTER CYLINDER ASSEMBLY	1	
2	4K0-25854-00-00	. DIAPHRAGM RESERVOR	1	
3	3GM-25852-01-00	. CAP, RESERVOIR	1	
4	98706-04012-00	. SCREW, FLAT HEAD	2	
5	4K0-W0041-50-00	. CYLINDER KIT, MASTER	1	
6	4L0-25867-00-00	BRACKET, MASTER CYLINDER	1	
7	97016-06025-00	BOLT	2	
8	92906-06100-00	WASHER, SPRING	2	
9	42H-25872-01-00	HOSE, BRAKE 1	1	
10	306-25862-00-00	BOOT, MASTER CYLINDER	1	
11	90401-10034-00	BOLT, UNION	1	
12	90201-10118-00	WASHER, PLATE	2	
13	42H-25885-01-00	JOINT	1	
14	42H-25873-01-00	HOSE, BRAKE 2	2	
15	90401-10044-00	BOLT, UNION	1	
16	90201-10118-00	WASHER, PLATE	3	
17	90401-10034-00	BOLT, UNION	1	
18	90201-10118-00	WASHER, PLATE	2	
19	42X-25875-00-00	HOLDER, BRAKE HOSE 1	1	
20	97011-06010-00	BOLT	1	
21	92990-06100-00	WASHER, SPRING	1	
22	42X-25876-00-00	HOLDER, BRAKE HOSE 2	1	
23	97011-06010-00	BOLT	1	
24	92995-06100-00	WASHER, SPRING	1	
25	90401-10034-00	BOLT, UNION	2	
26	90201-10118-00	WASHER, PLATE	4	

STAND - FOOTREST




3CF110-8330

Ref. No.	Part Number	Description	Qty	Remarks
1	3CF-27211-00-93	PEDAL, BRAKE	1	CHROME PLATED
2	90109-06468-00	BOLT	1	
3	92990-06100-00	WASHER, SPRING	1	
4	42X-27212-00-00	SHAFT, BRAKE PEDAL	1	
5	90506-20192-00	SPRING, TENSION	1	
6	90101-06478-00	BOLT, HEX.	1	
7	90170-06184-00	NUT, HEXAGON	1	
8	3CF-27231-01-00	ROD, BRAKE	1	
9	90240-06057-00	PIN, CLEVIS	1	
10	90560-06201-00	SPACER	1	
11	92990-06200-00	WASHER	2	
12	91490-20020-00	PIN, COTTER	3	
13	3CF-27241-00-00	ROD, JOINT	1	
14	90240-06103-00	PIN, CLEVIS	2	
15	90501-10245-00	SPRING, COMPRESSION	1	
16	90249-12008-00	PIN	1	
17	90175-06019-00	NUT, WING	1	
18	42X-27111-00-R4	STAND, MAIN	1	BLACK
19	97003-10016-00	BOLT (97002-10016-00)	2	
20	90201-10752-00	WASHER, PLATE	2	
21	90506-35149-00	SPRING, TENSION	1	
22	371-27114-00-00	STOPPER, MAIN STAND	1	
23	42X-27311-00-93	STAND, SIDE	1	CHROME PLATED
24	90109-103A1-00	BOLT	1	
25	95303-10700-00	NUT	1	
26	90507-29009-00	SPRING, TENSION	1	
27	3CF-27410-00-93	FRONT FOOTREST ASSEMBLY (LEFT)	1	CHROME PLATED
28	1NH-27413-00-00	. COVER, FOOTREST	1	

CONTINUED ON NEXT FRAME ➤

STAND - FOOTREST




3CF110-8330

Ref. No.	Part Number	Description	Qty	Remarks
29	95601-06100-00	. NUT, U	2	
30	90508-18696-00	. SPRING, TORSION	1	
31	91701-08038-00	. PIN, CLEVIS	1	
32	91401-25020-00	. PIN, COTTER	1	
33	90387-087K5-00	. COLLAR	1	
34	1RM-27420-00-93	FRONT FOOTREST ASSEMBLY (RIGHT)	1	CHROME PLATED
35	1NH-27413-00-00	. COVER, FOOTREST	1	
36	90176-06058-00	. NUT, CROWN	2	
37	90508-18696-00	. SPRING, TORSION	1	
38	91701-08038-00	. PIN, CLEVIS	1	
39	91401-25020-00	. PIN, COTTER	1	
40	90387-087K5-00	. COLLAR	1	
41	4X7-27414-00-00	DAMPER, FOOTREST	4	
42	90387-107A7-00	COLLAR	4	
43	90201-100A1-00	WASHER, PLATE	8	
44	90109-101A3-00	BOLT	4	
45	3CF-27471-00-00	BAR, FOOTREST 1	1	
46	90338-09012-00	PLUG	2	
47	3CF-27472-00-00	BAR, FOOTREST 2	1	
48	90105-10050-00	BOLT, WASHER BASED	1	
49	90176-10049-00	NUT, CROWN	3	
50	1RM-27430-01-00	REAR FOOTREST ASSEMBLY 1	1	
51	1NH-27433-00-00	. COVER, REAR FOOTREST	1	
52	92011-06012-00	. SCREW (92016-06012-00)	2	
53	1HX-27437-00-00	. WASHER, SPECIAL	1	
54	91701-06038-00	. PIN, CLEVIS	1	
55	91401-16015-00	. PIN, COTTER	1	

CONTINUED ON NEXT FRAME ➤


STAND - FOOTREST



3CF110-8330

Ref. No.	Part Number	Description	Qty	Remarks
56	90501-12743-00	. SPRING, COMPRESSION	1	
57	93501-04011-00	. BALL	1	
58	1RM-27440-00-00	REAR FOOTREST ASS''Y 2 ...	1	
59	1NH-27433-00-00	. COVER, REAR FOOTREST ..	1	
60	92011-06012-00	. SCREW (92016-06012-00) ...	2	
61	1HX-27437-00-00	. WASHER, SPECIAL	1	
62	91701-06038-00	. PIN, CLEVIS	1	
63	91401-16015-00	. PIN, COTTER	1	
64	90501-12743-00	. SPRING, COMPRESSION	1	
65	93501-04011-00	. BALL	1	
66	95023-08020-00	BOLT	3	
67	95023-08045-00	BOLT	1	


METER



Ref. No.	Part Number	Description	Qty	Remarks
1	3LP-83570-00-00	SPEEDOMETER ASSEMBLY ..	1	
2	1RM-83540-00-00	TACHOMETER ASSEMBLY ...	1	
3	3CF-8353E-00-00	CASE, METER UPPER	1	
4	3CF-8353H-00-00	CASE, UNDER	1	
5	1FG-83519-00-00	BRACKET, METER	1	
6	3JL-83507-00-00	COVER, SPEEDOMETER		
	42X-83507-00- 0	.....	1	UR BLACK METALLIC
	42X-83507-00-00	COVER, SPEEDOMETER	1	UR METALLIC CHOME
7	3JL-83508-00-00	COVER, TACHOMETER		
	42X-83508-00- 0	.....	1	UR BLACK METALLIC
	42X-83508-00-00	COVER, TACHOMETER	1	UR METALLIC CHOME
8	1FG-83523-00-00	DAMPER	4	
9	90201-05031-00	WASHER, PLATE	4	
10	95380-05600-00	NUT	4	
11	98580-04008-00	SCREW, PAN HEAD	2	
12	97701-40014-00	SCREW, TAPPING	6	
13	1RM-83509-00-00	SOCKET CORD ASSEMBLY ..	1	
14	42X-83517-00-00	BULB (12V-3W)	10	
15	36Y-82151-00-00	FUSE (15A-BL)	3	
16	42X-82151-20-00	FUSE (10A)	3	
17	42X-83559-00-00	COVER, METER	1	
18	1FK-83523-00-00	DAMPER	1	
19	1FK-83535-00-00	TUBE	4	
20	98701-04010-00	SCREW, FLAT HEAD	2	
21	55R-83579-00-00	COVER, METER 2	1	
22	92906-06200-00	WASHER	2	
23	92906-06100-00	WASHER, SPRING	2	
24	95316-06600-00	NUT	2	
25	584-83541-00-00	DAMPER	4	


CONTINUED ON NEXT FRAME ➤

METER



Ref. No.	Part Number	Description	Qty	Remarks
26	90387-06249-00	COLLAR	2	
27	57A-83550-00-00	SPEEDOMETER CABLE ASSEMBLY	1	


HEADLIGHT



3JL7110-1380

Ref. No.	Part Number	Description	Qty	Remarks
1	42X-84303-A1-00	HEADLIGHT UNIT ASSEMBLY .	1	
2	42X-84315-01-00	. RIM, HEADLIGHT	1	
3	5Y3-84395-00-00	. RING, RETAINING	1	
4	42X-84321-A0-00	. LENS ASSEMBLY	1	
5	2F9-84375-00-00	. SETTING PLATE, BULB	1	
6	2F9-84397-01-00	. COVER, SOCKET	1	
7	90157-04001-00	. SCREW, PAN HEAD	2	
8	1A0-84332-60-00	. SPRING, SCREW	2	
9	198-84334-60-00	. NUT, ADJUSTING	2	
10	42X-84124-60-00	. SPRING, SET	1	
11	5V2-84314-00-XX	BULB, HL 12V60/55W (2F9-84314-00)	1	
12	42X-84330-01-00	BODY ASSEMBLY	1	
13	42X-84345-00-00	. DAMPER, HEADLIGHT	2	
14	42X-84366-00-00	. DAMPER, HEADLIGHT 1	1	
15	42X-84338-00-00	. COLLAR, BODY FITTING	2	
16	90157-05084-00	SCREW, PAN HEAD	2	
17	90201-06073-00	WASHER, PLATE	1	
18	97095-06016-00	BOLT	1	
19	92990-06100-00	WASHER, SPRING	1	
20	91311-08055-00	BOLT, SOCKET HEAD	1	
21	42X-84318-00-00	STAY, HEADLIGHT 1	1	
22	91316-06025-00	BOLT	2	


TAILLIGHT



1RR110-6390

Ref. No.	Part Number	Description	Qty	Remarks
1	1RM-84700-60-00	TAILLIGHT ASSEMBLY	1	
2	256-84714-61-00	. BULB (12V-27/8W)	2	
3	42X-84721-60-00	. LENS, TAILLIGHT	1	
4	42X-84723-01-00	. GASKET, TAIL LENS	1	
5	1RM-84704-00-00	. GASKET, TAILLIGHT	1	
6	97780-40525-00	. SCREW, TAPPING	2	
7	42X-84717-00-00	. CORD, TAILLIGHT	1	
8	90119-06097-00	BOLT, WITH WASHER	3	
9	90387-065L5-00	COLLAR	3	
10	90480-14229-00	GROMMET	3	
11	90480-16112-00	GROMMET	1	
12	90480-15061-00	GROMMET	1	
13	1RM-84751-00-00	BRACKET, LICENSE	1	
14	97001-06018-00	BOLT	2	
15	92990-06100-00	WASHER, SPRING	2	
16	92901-06600-00	WASHER	2	

FLASHER LIGHT - TURNSIGNAL




FWD

42W110-4360


Ref. No.	Part Number	Description	Qty	Remarks
1	42X-83310-K0-00	FRONT FLASHER LIGHT ASSEMBLY 1	2	
2	256-84714-61-00	. BULB (12V-27/8W)	1	
3	42X-83312-00-00	. LENS, FLASHER	1	
4	42X-83313-00-00	. GASKET, FLASHER LENS	1	
5	42X-83363-00-00	. LENS, RIM	1	
6	341-83333-70-00	. SCREW, LENS FITTING	2	
7	42X-83359-00-00	. WASHER, SPECIAL	2	
8	1AA-83318-00-00	STAY, FLASHER 1	2	
9	1AA-83330-K0-00	REAR FLASHER LIGHT ASSEMBLY 1	2	
10	256-83311-70-XX	. BULB, TS 12V27W	1	
11	42X-83312-00-00	. LENS, FLASHER	1	
12	42X-83313-00-00	. GASKET, FLASHER LENS	1	
13	42X-83363-00-00	. LENS, RIM	1	
14	341-83333-70-00	. SCREW, LENS FITTING	2	
15	42X-83359-00-00	. WASHER, SPECIAL	2	
16	1AA-83318-00-00	STAY, FLASHER 1	2	
17	95706-12500-00	NUT, FLANGE	4	
18	97003-06030-00	BOLT	4	
19	95701-06500-00	NUT, FLANGE	4	
20	42X-83328-00-00	STAY, FLASHER 2	1	

ELECTRICAL 1



Ref. No.	Part Number	Description	Qty	Remarks
1	BTY-YB16A-LA-20	BATTERY ASSEMBLY	1	
2	1E6-82131-00-00	BAND, BATTERY	1	
3	42H-82115-00-00	WIRE, PLUS LEAD	1	
4	42X-82116-00-00	WIRE, MINUS LEAD	1	
5	90445-081A9-00	HOSE	1	
6	2H7-82540-00-00	NEUTRAL SWITCH ASSEMBLY	1	
7	90430-10171-00	GASKET	1	
8	42X-82310-70-00	IGNITION COIL ASSEMBLY	1	
9	42X-82320-70-00	IGNITION COIL ASSEMBLY	1	
10	98980-05016-00	SCREW, BIND	2	
11	42X-82317-00-00	DAMPER, IGNITION COIL	2	
12	1J7-82370-00-00	PLUG CAP ASSEMBLY	2	
13	57A-82314-00-00	COVER, IGNITION COIL	1	
14	98516-06012-00	SCREW, PAN HEAD	1	
15	92906-06600-00	WASHER	1	
16	98506-06025-00	SCREW, PAN HEAD	1	
17	92906-06600-00	WASHER	1	
18	42X-82501-50-00	MAIN SWITCH STEERING LOCK	1	
19	97011-06016-00	BOLT	2	
20	92990-06600-00	WASHER, PLATE	2	
21	1A0-83980-30-00	STOP SWITCH ASSEMBLY	1	
22	42X-82530-02-00	STOP SWITCH ASSEMBLY	1	
23	42X-82539-00-00	STAY, STOP SWITCH	1	
24	1RM-82590-00-00	WIRE HARNESS ASS''Y	1	
25	4X7-82150-00-00	FUSE HOLDER ASSEMBLY	1	
26	1A0-82161-00-00	. FUSE (20A) (148-82151-00-00)	2	
27	3JL-82305-00-00	IGNITOR UNIT ASSEMBLY	1	
28	97780-60520-00	SCREW, TAPPING	2	


CONTINUED ON NEXT FRAME ➤



ELECTRICAL 1


Ref. No.	Part Number	Description	Qty	Remarks
29	90201-063A5-00	WASHER, PLATE	2	
30	3JK-85720-00-00	OIL LEVEL GAUGE ASSEMBLY	1	
31	91311-06016-00	BOLT, SOCKET HEAD	2	
32	33E-82566-00-00	SWITCH, SIDE STAND	1	
33	90152-05021-00	SCREW, COUNTERSUNK	2	

ELECTRICAL 2



Ref. No.	Part Number	Description	Qty	Remarks
1	5A8-86110-50-00	SOLENOID	1	
2	25G-81950-01-00	RELAY ASSEMBLY	1	
3	3JK-81815-00-00	CORD, STARTER MOTOR	1	
4	95380-06700-00	NUT	1	
5	92990-06100-00	WASHER, SPRING	1	
6	95303-08700-00	NUT	2	
7	92990-08100-00	WASHER	2	
8	42X-81960-A1-00	RECTIFIER & REGULATOR ASSEMBLY	1	
9	98502-06016-00	SCREW, PAN HEAD (98501-06014-00)	2	
10	92990-06100-00	WASHER, SPRING	2	
11	92990-06600-00	WASHER, PLATE	2	
12	90465-10264-00	CLAMP	1	
13	4U8-81980-M0-00	DIODE ASSEMBLY	1	
14	41R-83350-71-00	FLASHER RELAY ASSEMBLY	1	
15	1RM-83371-00-00	HORN	1	
16	1RM-83371-10-00	HORN	1	
17	91316-06012-00	BOLT, SOCKET HEAD	2	
18	42X-85110-00-00	REFLECTOR ASSEMBLY	2	
19	95701-05500-00	NUT, FLANGE	2	
20	42X-85752-01-00	SENDER UNIT ASSEMBLY, FUEL METER	1	
21	42X-85753-00-00	GASKET, SENDER UNIT	1	
22	90149-06011-00	SCREW	2	
23	90202-05187-00	WASHER, PLATE	2	
24	2EN-85130-00-00	REAR REFLECTOR ASSEMBLY	1	
25	95701-05500-00	NUT, FLANGE	1	

HANDLE SWITCH - LEVER



Ref. No.	Part Number	Description	Qty	Remarks
1	10M-82911-00-00	HOLDER, LEVER 1	1	
2	57A-83912-01-00	LEVER 1	1	
3	3Y6-82917-00-00	SWITCH	1	
4	90109-067A9-00	BOLT	1	
5	95616-06100-00	NUT, U	1	
6	93210-11368-00	O-RING	1	
7	97006-06022-00	BOLT	1	
8	92906-06100-00	WASHER, SPRING	1	
9	57A-83922-01-00	LEVER 2	1	
10	90149-06153-00	SCREW, SPEC''L SHAPE	1	
11	90170-06010-00	NUT	1	
12	90501-10312-00	SPRING, COMPRESSION	1	
13	90109-06577-00	BOLT	1	
14	95601-06100-00	NUT, U	1	
15	2UJ-83973-00-00	SWITCH, HANDLE 3	1	
16	98506-05035-00	. SCREW, PAN HEAD	2	
17	10M-83942-00-00	. COVER, STARTER	1	
18	10M-83941-00-00	. LEVER, STARTER	1	
19	92990-06200-00	. WASHER	1	
20	98506-06008-00	. SCREW, PAN HEAD (92506-06008-00)	1	
21	92990-06100-00	. WASHER, SPRING	1	
22	1AA-8397X-00-00	. SPACER	1	
23	3AL-83975-00-00	SWITCH, HANDLE 2	1	
24	98506-05040-00	. SCREW, PAN HEAD	1	
25	98506-05045-00	. SCREW, PAN HEAD	1	
26	437-83936-01-00	BAND, SWITCH CORD	2	

CONTINUED ON NEXT FRAME ➤

MOTORCYCLE	DATE 3/18/92	BUL M92-002

1992 EMISSION-CONTROLLED MODELS
HIGH ALTITUDE EMISSION ADJUSTMENTS

INTRODUCTION

This bulletin contains high altitude emissions information required by federal regulation. Yamaha provides high altitude information kits to Yamaha dealers. These kits contain information stickers and instructions for changing to optional main jet(s) on affected models used consistently at altitudes higher than 4,000 feet above sea level.

One high altitude information kit is included with this bulletin. This kit contains a sticker and jetting information sheet for each affected model. Additional kits are available at no charge from Yamaha Parts and Accessories.

DEALER ACTION SUMMARY

Install high altitude carburetor main jets only on units that will always be operated above 4,000 feet. For proper main jet installation, use the instructions provided with the high altitude information kits.

AFFECTED MODEL APPLICATION CHART
(See Page 2 for ADJUSTMENT RECOMMENDATION CHART)

MODEL	DISPLACEMENT	ENGINE FAMILY
TW200D, DC	196 cc	NYA019641B1
XT225D, DC	223 cc	NYA022341A3
XT350D, DC	346 cc	NYA034641A9
XT600ED, EDC	595 cc	NYA059541BX
FZR600RD	599 cc	NYA059944WX
FZR600RDC	599 cc	NYA059944SX
XJ600SD, SDC	599 cc	NYA059944D1
XV750D, DC	749 cc	NYA074942S4
TDM850D, DC	849 cc	NYA084942W3
FZR1000D, DC	1003 cc	NYA100944E9
XV1100D, DC	1063 cc	NYA106342SX
FJ1200BD, DC	1188 cc	NYA118844A5
FJ1200AD, FJ1200ADC	1188 cc	NYA118844B6
VMX12D	1198 cc	NYA119844AX
VMX12DC	1198 cc	NYA119844W4
XVZ13DD, DDC	1294 cc	NYA129444W5

PARTS INFORMATION

PART NUMBER	DESCRIPTION	DEALER COST
LIT-10061-16-81	Information Kit	N/C

NOTE: Main jets listed in the information kits must be ordered from Yamaha Parts and Accessories.

ADJUSTMENT RECOMMENDATION CHART

CAUTION
Units on which high altitude main jets have been installed should not be used below 4,000 feet elevation or serious engine damage could occur. Make sure owners of modified machines are aware of this limitation.

MODEL	ORIGINAL MAIN JET	RECOMMENDED MAIN JET	PART NUMBER
TW200D, DC	#114	#110 ~ #114	#110: 288-14343-55-00 #112: 288-14343-56-00 #114: 288-14343-57-00
XT225D, DC	#130	#127.5 ~ #130	#127.5: 620-1423A-76-A0 #130: 620-14231-26-A0
XT350D, DC	PRIMARY (LEFT SIDE) #125 SECONDARY (RIGHT SIDE) #106	PRIMARY #120, #125 SECONDARY #102 ~ #106	PRIMARY #120: 288-14343-60-00 #125: 288-14343-63-00 SECONDARY #102: 30X-14343-51-00 #104: 288-14343-52-00 #106: 30X-14343-53-00
XT600ED, EDC	PRIMARY (LEFT SIDE) #130 SECONDARY (RIGHT SIDE) #104	PRIMARY #120 ~ #130 SECONDARY #100 ~ #104	PRIMARY #120: 288-14343-60-00 #125: 288-14343-63-00 #130: 288-14343-65-00 SECONDARY #100: 30X-14343-50-00 #102: 30X-14343-51-00 #104: 288-14343-52-00
FZR600RD, RDC	#107.5	#102.5 ~ #107.5	#102.5: 3G2-1423A-71-00 #105: 3G2-14231-21-00 #107.5 3G2-1423A-72-00
XJ600SD, SDC	#102.5	#100 ~ #102.5	#100: 620-14231-20-00 #102.5: 620-1423A-71-A0
XV750D, DC	#122.5	#120 ~ #122.5	#120: 620-14231-24-A0 #122.5: 620-1423A-75-00
TDM850D, DC	#140	#135 ~ #140	#135: 3LD-14231-27-00 #137.5: 3LD-14231-78-00 #140: 3LD-14231-28-00
FZR1000D, DC	#1 & #4 CYL: #125 #2 & 3 CYL: #122.5	#1, 4 CYL: #120 ~ #125 #2, 3 CYL: #117 ~ 122.5	#117.5: 3G2-1423A-74-00 #120: 3G2-14231-24-00 #122.5: 3G2-1423A-75-A1 #125: 3G2-14231-25-00
XV1100D, DC	#1 CYL: #122.5 #2 CYL: #125	#1 CYL: #120 ~ #122.5 #2 CYL: #122.5 ~ #125	#120: 620-14231-24-A0 #122.5: 620-1423A-75-00 #125: 620-14231-25-A0
FJ1200AD, ADC, D, DC	#110	#105 ~ #110	#105: 620-14231-21-A0 #110: 620-14231-22-A0
VMX12D, DC	#152.5	#147.5 ~ #152.5	#147.5: 3G2-1423A-80-A0 #150: 3G2-14231-30-A0 #152.5: 3G2-1423A-81-00
XVZ13DD, DDC	#125	#120, #125	#120: 3G2-14231-24-00 #125: 3G2-14231-25-00

WARRANTY INFORMATION

No warranty applies. Installation of parts for high altitude use is done at the customers' option and expense.

CAUTION
Damage to modified units caused by operation below 4,000 feet elevation will not be covered by warranty.

MOTORCYCLE	DATE 5/27/92	SUL M92-005

XV750/1100A,B,D, & VMX12A,B,D
ADDITIONAL ASSEMBLY INSTRUCTIONS

INTRODUCTION

The following information is not included in the Assembly Manuals for the XV750/1100A,B,D. Installing the handlebar switches outside the locating tab or projection may result in the loss of the handlebar end caps because the caps will not fit far enough into the handlebar. Please use the instructions below when assembling the handlebars on these units.

DEALER ACTION SUMMARY

Copies of this bulletin should be attached to the assembly manuals of all affected units.

UNSOLD UNITS: Make sure all new units are assembled according to this bulletin information. Inspect all assembled units, both sold and unsold, to verify proper assembly. Rectify any incorrect switch installation.

CUSTOMER UNITS: Have any customer who reports losing handlebar end caps bring their unit in for inspection to make sure the handlebar switches are installed according to the information in this bulletin.

PARTS REQUIRED: No

WARRANTY: No warranty applies

AFFECTED UNITS


XV750A, AC	All	XV1100D, DC	All
XV750B, BC	All	VMX12A, AC	All
XV750D, DC	All	VMX12B,BC	All
XV1100A, AC	All	VMX12D, DC	All
XV1100B, BC	All		


SERVICE PROCEDURES

Observe the following when installing the handlebar switches on the above units during assembly. Failure to properly position the throttle/switch assembly during installation may result in the loss of the chrome handlebar end cap.

1. Right side handle bar switch: The stopper tab on the handlebar should touch the inner surface of the handlebar switch. The switch should completely cover the tab when installed properly. Refer to the illustration for the right side switch.

2. Left side handlebar switch: Align the notch on the inner side of the switch housing with the projection on the clutch lever holder. The switch should cover the projection when installed properly. Refer to the illustration of the left side switch.





WARRANTY INFORMATION

This bulletin is for assembly information only. There is no warranty allowance for assembly and preparation.