



Ref No	Part No	Description
01	4FM-11102-00-00	Cylinder Head Assy
02	3GM-11133-10-00	• . Guide, Intake Valve
03	3GM-11134-10-00	• . Guide, Exhaust Valve
04	93440-10153-00	• . Circlip
05	90340-18101-00	• . Plug, Straight Screw
06	95617-08625-00	Bolt, Stud
07	94701-00318-00	Plug, Spark (ngk R Cr9e)
07	94701-00319-00	Plug, Spark (nd U27esr-n)
08	90201-103M4-00	Washer, Plate
09	90176-10075-00	Nut, Crown
10	90179-10584-00	Nut
11	91810-25008-00	Pin, Dowel
12	3FV-11182-00-00	Gasket, Cylinder Head 2
13	4FM-1115A-00-00	Cam Case Assy
14	99510-08016-00	• . Pin, Dowel
15	90105-06153-00	• . Bolt, Washer Based
16	95027-06012-00	Bolt, Flange
17	90430-06014-00	Gasket
18	90105-06541-00	Bolt, Washer Based
19	90105-06693-00	Bolt, Washer Based
20	95027-06025-00	Bolt, Flange
21	3GM-11191-00-00	Cover, Cylinder Head 1
22	3GM-11193-00-00	Gasket, Head Cover 1
23	90109-064F0-00	Bolt
24	90209-11262-00	Washer
25	2GH-1111G-00-00	Rubber, Mount 1


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4HD300-3020


Ref No	Part No	Description
01	3FV-11351-00-00	Gasket, Cylinder
02	4FM-11310-00-00	Cylinder
03	93210-76211-00	O-ring
04	95027-06012-00	Bolt, Flange
05	90430-06014-00	Gasket
06	99510-14016-00	Pin, Dowel
07	3FV-11181-00-00	Gasket, Cylinder Head 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-11411-00-00	Crankshaft
02	3GM-11416-00-00	Plane Bearing, Crankshaft 1
02	3GM-11416-10-00	Plane Bearing, Crankshaft 1
02	3GM-11416-20-00	Plane Bearing, Crankshaft 1
02	3GM-11416-30-00	Plane Bearing, Crankshaft 1
02	3GM-11416-40-00	Plane Bearing, Crankshaft 1
03	4FM-11631-00-A0	Piston (std)
03	4FM-11636-00-00	Piston (0.50mm O/s)
04	4FM-11603-00-00	Piston Ring Set (std)
04	4FM-11605-00-00	Piston Ring Set (0.50mm O/s)
05	3GM-11633-00-00	Pin, Piston
06	93450-19095-00	Circlip
07	4FM-11650-01-00	Connecting Rod Assy
08	36Y-11654-00-00	• . Bolt, Connecting Rod
09	90179-08327-00	• . Nut
10	3GM-11656-00-00	Plane Bearing, Connecting Rod
10	3GM-11656-10-00	Plane Bearing, Connecting Rod
10	3GM-11656-20-00	Plane Bearing, Connecting Rod
10	3GM-11656-30-00	Plane Bearing, Connecting Rod

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4FM-12111-00-00	Valve, Intake
02	4FM-12112-00-00	Valve, Intake 2
03	4FM-12121-00-00	Valve, Exhaust
04	4FM-12116-00-00	Seat, Valve Spring
05	3GM-12126-00-00	Seat, Valve Spring 2
06	3FV-12113-00-00	Spring, Valve Inner
07	3FV-12114-00-00	Spring, Valve Outer
08	3GM-12117-00-00	Retainer, Valve Spring
09	1WG-12117-00-00	Retainer, Valve Spring
10	1WG-12118-00-00	Cotter, Valve
11	1WG-12119-00-00	Seal, Valve Stem
12	1HX-12168-00-00	Pad, Adjusting (1.20)
12	1HX-12168-M1-00	Pad, Adjusting (1.65)
12	1HX-12168-R1-00	Pad, Adjusting (1.70)
12	1HX-12168-U1-00	Pad, Adjusting (1.75)
12	1HX-12168-W1-00	Pad, Adjusting (1.80)
12	1HX-12168-Y1-00	Pad, Adjusting (1.85)
12	1HX-12169-11-00	Pad, Adjusting (1.90)
12	1HX-12169-31-00	Pad, Adjusting (1.95)
12	1HX-12169-50-00	Pad, Adjusting (2.00)
12	1HX-12168-70-00	Pad, Adjusting (2.05)
12	1HX-12168-90-00	Pad, Adjusting (2.10)
12	1HX-12168-20-00	Pad, Adjusting (1.25)
12	1HX-12168-E0-00	Pad, Adjusting (2.15)
12	1HX-12168-G0-00	Pad, Adjusting (2.20)
12	1HX-12168-J0-00	Pad, Adjusting (2.25)
12	1HX-12168-L0-00	Pad, Adjusting (2.30)
12	1HX-12168-N0-00	Pad, Adjusting (2.35)
12	1HX-12168-T0-00	Pad, Adjusting (2.40)
12	1HX-12168-40-00	Pad, Adjusting (1.30)
12	1HX-12168-60-00	Pad, Adjusting (1.35)
12	1HX-12168-80-00	Pad, Adjusting (1.40)
12	1HX-12168-A0-00	Pad, Adjusting (1.45)
12	1HX-12168-F0-00	Pad, Adjusting (1.50)
12	1HX-12168-H1-00	Pad, Adjusting (1.55)
12	1HX-12168-K1-00	Pad, Adjusting (1.60)
13	3LN-12153-20-00	Lifter, Valve
13	3LN-12153-30-00	Lifter, Valve
13	3LN-12153-09-00	Lifter, Valve (ug)
14	3FV-12153-10-00	Lifter, Valve
14	3FV-12153-09-00	Lifter, Valve (ug)


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4HD300-3050

Ref No	Part No	Description
01	4HD-12171-00-00	Camshaft 1
02	4HD-12181-00-00	Camshaft 2
03	3GM-12176-00-00	Sprocket, Cam Chain
04	90105-07342-00	Bolt, Washer Based
05	94580-81104-00	Chain (did219-fts-104l)
06	94680-81021-00	• . Joint, Chain
07	2GH-12241-00-00	Guide, Stopper 2
08	4FM-12210-00-00	Tensioner Assy, Cam Chain
09	90109-112F1-00	Bolt
10	4FM-12213-00-00	Gasket, Tensioner Case
11	91317-06025-00	Bolt
12	3FV-12251-00-00	Damper, Chain 1
13	4FM-12252-00-00	Damper, Chain 2
14	90109-065A8-00	Bolt


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4HD300-5060


Ref No	Part No	Description
01	1UF-12421-09-00	Housing, Water Pump
02	93306-00106-00	Bearing
03	93101-12060-00	Oil Seal
04	11H-12438-00-00	Seal, Mechanical
05	1UF-12450-00-00	Impeller Shaft Assy
06	99009-12400-00	Circlip
07	1AE-12439-00-00	O-ring
08	93604-10011-00	Pin, Dowel
09	3GM-12442-00-00	Pulley 2
10	95027-06025-00	Bolt, Flange
11	90430-06014-00	Gasket
12	93210-33133-00	O-ring
13	95027-06050-00	Bolt, Flange
14	1AE-12481-01-00	Pipe 1
15	93210-23787-00	O-ring
16	95027-06012-00	Bolt, Flange
17	3FV-12469-00-00	Joint 1
18	93210-30694-00	O-ring
19	95027-06020-00	Bolt, Flange
20	95027-06030-00	Bolt, Flange
21	95027-06040-00	Bolt, Flange
22	4FN-12482-00-00	Pipe 2
23	93210-18417-00	O-ring
24	93210-23787-00	O-ring
25	95027-06010-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-12417-00-00	Housing, Thermostat
02	4FM-12410-00-00	Thermostat Assy
03	3GM-12413-00-00	Cover, Thermostat
04	95027-06025-00	Bolt, Flange
05	4FM-1243A-10-00	Hose 1
06	90467-11090-00	Clip
07	4FM-12576-10-00	Hose 1
08	90450-38040-00	Hose Clamp Assy
09	90464-44109-00	Clamp
10	4FM-1240A-10-00	Radiator Assy
11	4FM-12461-10-00	• . Radiator Assy
12	4FM-12405-10-00	• . Blower Assy
13	22W-12462-00-00	Cap, Radiator
14	4HD-12535-00-00	Plate
15	97007-06025-00	Bolt
16	90201-06049-00	Washer, Plate
17	90387-064T3-00	Collar
18	2TV-21638-00-00	Damper 1
19	90480-15363-00	Grommet
20	90387-07391-00	Collar
21	90480-10542-00	Grommet
22	90201-063J2-00	Washer, Plate
23	95827-06025-00	Bolt, Flange
24	95707-06500-00	Nut, Flange
25	4FM-12579-10-00	Hose 4
26	90450-38040-00	Hose Clamp Assy
27	2GH-12484-00-00	Pipe 4
28	93210-23787-00	O-ring
29	90110-06142-00	Bolt, Hexagon Socket Head
30	4FM-12588-01-00	Hose 5
31	4FM-12589-10-00	Hose 6
32	90450-22052-00	Hose Clamp Assy
33	90445-09635-00	Hose
34	90467-08003-00	Clip
35	90465-13355-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1AE-13300-00-00	Oil Pump Assy
02	99510-08012-00	Pin, Dowel
03	2GH-13329-00-00	Gasket, Pump Cover
04	91317-06050-00	Bolt
05	3GM-13412-50-00	Housing, Strainer
06	4FM-13411-00-00	Strainer, Oil
07	91317-06030-00	Bolt
08	4BH-1316F-01-00	Hose, Oil 1
09	4BH-1316G-01-00	Hose, Oil 2
10	90430-10171-00	Gasket
11	90401-10159-00	Bolt, Union
12	90401-10044-00	Bolt, Union
13	3GM-13181-00-00	Pipe, Delivery 3
14	95027-06012-00	Bolt, Flange
15	93210-06632-00	O-ring
16	3GM-13191-00-00	Pipe, Delivery 4
17	95027-06012-00	Bolt, Flange
18	93210-06632-00	O-ring
19	1AE-1316E-00-00	Pipe, Delevery 5
20	93210-07135-00	O-ring
21	95027-06012-00	Bolt, Flange
22	2GH-15123-00-00	Plate, Buffle 1
23	95027-06012-00	Bolt, Flange
24	1AE-15124-00-00	Plate, Buffle 2
25	95027-06012-00	Bolt, Flange
26	2GH-15133-00-00	Plate, Buffle 3
27	95027-06012-00	Bolt, Flange
28	90201-061M7-00	Washer, Plate
29	4FM-13475-00-00	Gasket
30	95827-06016-00	Bolt, Flange
31	3GM-13454-00-00	Nozzle

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-13470-10-00	Oil Cooler Assy
02	90401-20161-00	Bolt, Union
03	93210-87723-00	O-ring
04	3FV-13440-00-00	Element Assy, Oil Cleaner
05	3KS-13490-00-00	Relief Valve Assy
06	93210-15566-00	O-ring
07	4FM-13417-00-00	Cover, Strainer
08	3FV-13416-01-00	Pipe, Oil 1
09	93210-14579-00	O-ring
10	3GM-13337-00-00	Plate, Baffle Lower
11	95027-06010-00	Bolt, Flange
12	99510-08016-00	Pin, Dowel
13	4FM-13414-00-00	Gasket, Strainer Cover
14	95027-06030-00	Bolt, Flange
15	3VD-13455-00-00	Plug
16	214-11198-01-00	Gasket
17	3GM-13161-01-00	Pipe, Delivery 1
18	93210-06714-00	O-ring
19	95027-06012-00	Bolt, Flange
20	3GM-15373-00-00	Pipe, Breather
21	3GM-13174-00-00	Holder, Oil Pipe
22	99009-10400-00	Circlip
23	90465-08076-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FN-13586-00-00	Joint, Carburetor 1
02	90430-06014-00	• . Gasket
03	91317-06012-00	• . Bolt
04	4FM-13586-10-00	Joint, Carburetor 1
05	3FV-2416A-00-00	Hose
06	90467-08092-00	Clip
07	4FM-13596-10-00	Joint, Carburetor 2
08	4HD-13596-10-00	Joint, Carburetor 2
09	3GM-13597-00-00	Joint, Carburetor 3
10	3GM-13598-00-00	Joint, Carburetor 4
11	4FM-13556-01-00	Gasket, Manifold
12	91317-06020-00	Bolt
13	90450-57034-00	Hose Clamp Assy
14	90464-17184-00	Clamp
15	4FM-14401-10-00	Air Cleaner Case Assy
16	4FM-14452-00-00	• . Seal
17	97707-50525-00	• . Screw, Tapping
18	4FM-14451-00-00	Element, Air Cleaner
19	4FM-14437-00-00	Duct
20	4FM-14453-00-00	Joint, Air Cleaner 1
21	90450-67066-00	Hose Clamp Assy
22	1HX-1443E-00-00	Pipe, Drain
23	4X7-2149Y-00-00	Filter Assy
24	90467-11106-00	Clip
25	90445-116H6-00	Hose
26	4FM-14462-00-00	Seal
27	4FM-14467-00-00	Seal
28	90480-12314-00	Grommet
29	90387-065J6-00	Collar
30	95817-06020-00	Bolt, Flange
31	90445-090E5-00	Hose
32	90338-05240-00	Plug
33	90467-08017-00	Clip
34	90468-15139-00	Clip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4HN-14900-10-00	Carburetor Assy
02	4HN-14901-10-00	• . Carburetor Assy 1
03	4HN-14902-10-00	• . Carburetor Assy 2
04	4HN-14903-10-00	• . Carburetor Assy 3
05	4HN-14904-10-00	• . Carburetor Assy 4
06	3FV-14191-00-00	•• .. Plug, Drain
07	98502-05012-00	•• .. Screw, Pan Head
08	98580-04008-00	•• .. Screw, Pan Head
09	98580-04008-00	•• .. Screw, Pan Head
10	98586-05016-00	•• .. Screw, Pan Head
11	92906-05100-00	•• .. Washer, Spring
12	92906-05600-00	•• .. Washer, Plate
13	3EN-14147-00-00	•• .. O-ring
14	53L-14186-00-00	•• .. Pin, Float
15	3GM-14985-00-00	•• .. Float
16	3EN-1410A-01-00	•• .. Starter Set
17	12R-14105-00-00	•• .. Pilot Screw Set
18	3FV-14147-00-00	•• .. O-ring
19	3GM-14940-00-00	•• .. Diaphragm Assy
20	3GM-1411E-00-00	•• .. Block, Jet
21	4HD-14933-00-00	•• .. Spring, Diaphragm
22	4HD-1490J-20-00	•• .. Needle Set
22	4HN-1490J-30-00	•• .. Needle Set
23	4HD-1411A-10-00	•• .. Block Jet Assy
24	3GM-14153-00-00	•• .. Washer, Main Jet
25	4HD-14565-00-00	•• .. Screw
26	3LF-14147-00-00	•• .. O-ring
27	1AE-14147-00-00	•• .. O-ring
28	3GM-14997-00-00	•• .. Seal
29	3GM-14107-10-00	•• .. Needle Valve Set
30	3LK-14987-00-00	•• .. Hose
31	3G2-14231-24-00	•• .. Jet, Main (120)
32	4HD-1414M-92-00	•• .. Nozzle, Main
33	830-14231-29-00	•• .. Jet, Main (145)
34	4G0-14142-45-00	•• .. Jet, Pilot (45)
35	3G2-1423A-62-00	•• .. Jet, Main (57.5)
36	4HD-14291-00-00	•• .. Bracket 1
37	98502-04008-00	•• .. Screw, Pan Head
38	92901-05600-00	• . Washer, Plate
39	95380-05600-00	• . Nut
40	3EN-1490K-00-00	• . Stop Screw Set
41	3EN-14261-00-00	• . Holder
42	3GM-14918-00-00	• . Ring
43	17A-14251-00-00	• . Nipple
44	3GM-14197-00-00	• . Pipe
45	4HD-14988-00-00	• . Pipe, Starter Connecting
46	3EN-14997-00-00	• . Seal
47	1KT-14994-00-00	• . Net, Filter
48	822-14147-00-00	• . O-ring
49	3GM-14103-00-00	• . Throttle Screw Set
50	92990-06600-00	• . Washer, Plate
51	95380-06600-00	• . Nut, Hexagon
52	3EN-14988-00-00	• . Pipe, Starter Connecting
53	98580-05008-00	• . Screw, Pan Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
54	3GM-14251-00-00	• . Nipple
55	3LK-14147-00-00	• . O-ring
56	3GM-14992-00-00	• . Rod
57	2LE-14197-00-00	• . Pipe
58	4HM-14216-00-00	• . Screw
59	4HD-85885-00-00	• . Throttle Sensor Assy
60	4HD-14188-00-00	• . Connector
61	4HM-14239-00-00	• . Seal
62	4KG-14285-00-00	• . Washer
63	3GM-14197-00-00	Pipe
64	90464-10075-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-14610-10-00	Exhaust Pipe Assy 1
02	90101-06576-00	• . Bolt
03	3GM-14821-00-00	• . Arm, Shaft (valve)
04	3GM-14811-00-00	• . Housing
05	2TK-14845-00-00	• . Dust Seal Assy
06	2TK-14867-01-00	• . Bracket
07	90119-06115-00	• . Bolt, With Washer
08	90201-106M5-00	• . Washer, Plate
09	90380-10195-00	• . Bush, Solid
10	2TK-14865-01-00	• . Pulley
11	92990-05200-00	• . Washer, Plain
12	97080-05012-00	• . Bolt
13	90387-106U7-00	• . Collar
14	3GM-14683-00-00	• . Spring, Hook
15	4FM-24181-00-00	• . Damper, Locating 1
16	4HD-14826-00-00	Protector, Exhaust
17	90119-06187-00	Bolt, With Washer
18	4FM-14613-00-00	Gasket, Exhaust Pipe
19	90179-08410-00	Nut
20	95817-08035-00	Bolt, Flange
21	4HN-14710-01-00	Muffler Assy 1
22	3HE-14755-00-00	• . Gasket, Silencer
23	95817-08025-00	• . Bolt, Flange
24	4FM-1133E-00-00	Cable, Pulley 1
25	4FM-1133F-00-00	Cable, Pulley 2

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-15100-52-00	Crankcase Assy
02	99530-10014-00	Pin, Dowel
03	90116-10529-00	Bolt, Stud
04	90116-10528-00	Bolt, Stud
05	90116-10569-00	Bolt, Stud
06	90387-05383-00	Collar
07	93210-07135-00	O-ring
08	90105-09373-00	Bolt, Washer Based
09	90105-09580-00	Bolt, Washer Based
10	90201-096J9-00	Washer, Plate
11	95817-06035-00	Bolt, Flange
12	95817-08045-00	Bolt, Flange
13	95817-06060-00	Bolt, Flange
14	95817-06080-00	Bolt, Flange
15	95817-06140-00	Bolt, Flange
16	95817-08045-00	Bolt, Flange
17	95817-08055-00	Bolt, Flange
18	95817-08065-00	Bolt, Flange
19	95817-08090-00	Bolt, Flange
20	95817-08060-00	Bolt, Flange
21	90105-09555-00	Bolt, Washer Based
22	90201-08087-00	Washer, Plate
23	3FV-11166-00-00	Pipe, Breather 1
24	90467-15054-00	Clip
25	90467-14015-00	Clip
26	90338-30096-00	Plug
27	3FV-15363-00-00	Plug, Oil
28	93210-27778-00	O-ring
29	4H7-15189-00-00	Plug
30	93210-20573-00	O-ring
31	90340-14068-00	Plug, Straight Screw
32	93210-14369-00	O-ring
33	1AE-15383-00-00	Plate, Bearing Cover
34	90151-06014-00	Screw, Countersunk
35	90462-08184-00	Clamp
36	95027-06012-00	Bolt, Flange
37	90462-08158-00	Clamp
38	99510-12016-00	Pin, Dowel
39	3FV-15105-00-00	Nozzle Assy
40	93210-06632-00	O-ring
41	90116-10568-00	Bolt, Stud

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-15416-00-00	Cover, Oil Pump
02	1AE-15456-00-00	Gasket, Oil Pump Cover 1
03	90152-06014-00	Screw, Countersunk
04	4FM-15410-01-00	Crankcase Cover Assy 1
05	1TV-15435-00-00	• . Emblem
06	3GM-15427-00-00	Cover, Cap 2
07	1AE-15316-00-00	Damper, Engine Mount 1
08	92017-06010-00	Bolt, Button Head
09	4FM-15451-00-00	Gasket, Crankcase Cover 1
10	4FM-15467-00-00	Gasket
11	99510-08012-00	Pin, Dowel
12	95027-06040-00	Bolt, Flange
13	95027-06050-00	Bolt, Flange
14	4FM-15421-00-00	Cover, Crankcase 2
15	3Y1-15361-00-00	Gauge, Level
16	4FM-15362-00-00	Plug, Oil Level
17	93210-27778-00	O-ring
18	3GM-15417-00-00	Cover, Cap
19	3GM-15449-00-00	Ring, Rubber
20	4H7-15486-00-00	Grommet
21	90209-06096-00	Washer
22	98507-06010-00	Screw, Pan Head
23	3GM-15346-00-00	Breather 1
24	4FM-15463-00-00	Gasket, Carburetor Cover 2
25	98517-06020-00	Screw, Pan Head
26	90157-06104-00	Screw, Pan Head
27	90152-06024-00	Screw, Countersunk
28	4FM-15461-00-00	Gasket, Crankcase Cover 2
29	99510-08012-00	Pin, Dowel
30	95027-06030-00	Bolt, Flange
31	95027-06020-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-15512-00-00	Gear, Idler 1
02	51Y-15521-00-00	Shaft 1
03	4BH-15517-00-00	Gear, Idler 2
04	3GM-15580-00-00	Starter Clutch Outer Assy
05	93615-12088-00	• . Pin, Dowel
06	1J7-15583-01-00	• . Cap, Starter Clutch Spring
07	90501-04623-00	• . Spring, Compression
08	3GM-15524-00-00	Wheel, Starter
09	90110-08177-00	Bolt, Hexagon Socket Head
10	4H7-16155-01-00	Absorber 1
11	3GM-15689-00-00	Retainer
12	3GM-15519-00-00	Sprocket, Starter 2
13	3GM-15522-00-00	Shaft 2
14	93306-20335-00	Bearing
15	93306-20541-00	Bearing (b6205)
16	1AE-15381-00-00	Plate, Bearing Cover
17	95027-06016-00	Bolt, Flange
18	3GM-11474-00-00	Guide, Upper
19	95817-06014-00	Bolt, Flange
20	4FM-11456-00-00	Chain, Primary

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-16150-00-00	Primary Driven Gear Comp.
02	1AE-16154-00-00	Plate, Thrust 1
03	2GH-16371-00-00	Boss, Clutch
04	3J2-16324-00-00	Plate, Clutch 1
05	4FN-16321-00-00	Plate, Friction
06	58L-16351-00-00	Plate, Pressure 1
07	90501-225A9-00	Spring, Compression
08	90159-06123-00	Screw, With Washer
09	90560-25270-00	Spacer
10	93310-340N8-00	Bearing
11	1AE-16164-00-00	Plate, Thrust 2
12	90215-20231-00	Washer, Lock
13	90170-20327-00	Nut
14	1LJ-16356-00-00	Rod, Push 1
15	93210-06632-00	O-ring
16	93511-32027-00	Ball
17	1AE-16357-00-00	Rod, Push 2
18	93109-08061-00	Oil Seal
19	1TV-16381-10-00	Push Lever Comp.
20	36Y-W0048-00-00	• . Bleed Screw Kit
21	26H-W0098-00-00	• . Push Lever Seal Kit
22	99510-08012-00	Pin, Dowel
23	95027-06030-00	Bolt, Flange
24	95027-06090-00	Bolt, Flange
25	93340-21505-00	Bearing
26	90201-150H2-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-W1741-00-00	Main Axle Assy
02	90387-253M6-00	• . Collar
03	4FM-17151-00-00	Gear, 5th Pinion
04	90209-22191-00	Washer
05	93440-25084-00	Circlip
06	4FM-17131-00-00	Gear, 3rd Pinion
07	90201-200K3-00	Washer, Plate
08	4FM-17161-00-00	Gear, 6th Pinion
09	3FV-17121-00-00	Gear, 2nd Pinion (17z)
10	93306-30560-00	Bearing
11	90387-203M7-00	Collar
12	93306-20455-00	Bearing
13	3FV-W1742-00-00	Drive Axle Assy
14	90387-284M8-00	• . Collar
15	90387-184M0-00	• . Collar
16	90387-204M1-00	• . Collar
17	4FM-17221-00-00	Gear, 2nd Wheel
18	93305-30501-00	Bearing
19	90387-255V9-00	Collar
20	4FM-17261-00-00	Gear, 6th Wheel
21	4FM-17231-00-00	Gear, 3rd Wheel
22	4FM-17241-00-00	Gear, 4th Wheel
23	90209-25196-00	Washer
24	93440-28062-00	Circlip
25	4FM-17251-00-00	Gear, 5th Wheel
26	4FM-17211-00-00	Gear, 1st Wheel
27	93102-35423-00	Oil Seal
28	2GH-17460-00-00	Sprocket, Drive (2gh1746160)
29	90215-21022-00	Washer, Lock
30	90179-18020-00	Nut
31	278-17424-01-00	Circlip 1
32	93306-20455-00	Bearing
33	93440-45144-00	Circlip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-18540-00-00	Shift Cam Assy
02	90501-06022-00	• . Spring, Compression
03	278-18542-00-00	• . Point, Neutral
04	98707-05012-00	• . Screw, Flat Head
05	278-18566-00-00	• . Plate, Side 2
06	90201-06643-00	Washer, Plate
07	95827-06016-00	Bolt, Flange
08	4FM-18511-00-00	Fork, Shift 1
09	4FM-18512-00-00	Fork, Shift 2
10	4FM-18513-00-00	Fork, Shift 3
11	4BH-18531-00-00	Bar, Shift Fork Guide 1
12	1AE-18536-00-00	Stopper, Shift Bar
13	90508-26681-00	Spring, Torsion
14	36Y-18140-00-00	Stopper Lever Assy
15	90109-063F8-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4G0-18127-00-00	Stopper, Screw
02	93102-12106-00	Oil Seal
03	1AE-18101-01-00	Shift Shaft Assy
04	90508-32682-00	• . Spring, Torsion
05	90387-114K8-00	• . Collar
06	90201-12575-00	Washer, Plate
07	99006-10600-00	Circlip
08	90560-12191-00	Spacer
09	93109-12053-00	Oil Seal
10	2GH-18112-01-00	Arm, Shift
11	2H9-18154-00-00	Cover, Dust
12	95817-06020-00	Bolt, Flange
13	1WG-18115-00-00	Rod, Shift
14	90170-06228-00	Nut (verkehtheit Schreube)
15	95304-06700-00	Nut
16	4FM-18110-00-00	Shift Pedal Assy
17	2H9-18154-00-00	• . Cover, Dust
18	132-18113-01-00	• . Cover, Shift Pedal

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-21110-10-00	Frame Comp.
02	4FM-21645-01-00	Stay, Rear
03	90338-16148-00	Plug
04	95817-08035-00	Bolt, Flange
05	95817-08016-00	Bolt, Flange
06	91317-10040-00	Bolt
07	92907-10600-00	Washer, Plate
08	91317-10045-00	Bolt
09	91317-08030-00	Bolt
10	90387-115V8-00	Collar
11	90387-105V7-00	Collar
12	90179-10590-00	Nut
13	90110-10169-00	Bolt, Hexagon Socket Head
14	95817-08030-00	Bolt, Flange
15	90105-10716-00	Bolt, Washer Based
17	4FM-2142K-01-00	Bracket, Radiator
18	97007-06012-00	Bolt
19	92907-06600-00	Washer, Plate
20	90338-15202-00	Plug
21	4FM-2117M-01-00	Cover 2
22	4FM-2117N-00-00	Cover 3
23	90201-04018-00	Washer, Plate
24	90267-40076-00	Rivet, Blind
25	90201-101J1-00	Washer, Plate
26	95707-10500-00	Nut, Flange
27	4FM-21446-00-00	Stay, Muffler 2
28	4FM-21359-10-00	Bracket, Coil
29	4BH-82317-01-00	Damper, Ignition Coil
30	90119-06018-00	Bolt, With Washer
31	4FM-21161-01-00	Holder, Cable
32	4FM-21162-00-00	Holder, Clutch Cable
33	90101-06664-00	Bolt
34	4FM-2116J-00-00	Bracket 7
35	95807-06016-00	Bolt, Flange
36	4FM-21871-00-00	Tank, Recovery
37	90159-06033-00	Screw, With Washer
38	4L0-21875-00-00	Cap
39	1AA-21874-00-00	Gasket
40	90445-084G9-00	Hose
41	90467-08003-00	Clip
42	4FM-12683-00-00	Protector, Heat

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-Y2151-33-P0	Front Fender Comp.
01	4FM-Y2151-33-P2	Front Fender Comp.
02	4FM-21569-40-00	• . Graphic 1
03	90154-06061-00	Screw, Binding
04	95807-06016-00	Bolt, Flange
05	90387-0608A-00	Collar
06	4FM-21611-03-00	Fender, Rear
07	90119-06118-00	Bolt, With Washer
08	90119-06205-00	Bolt, With Washer
09	3VD-21366-00-00	Hook, Tool Band
10	1M1-21366-00-00	Hook, Tool Band
11	4JH-2161A-00-00	Bracket 3
12	90267-40076-00	Rivet, Blind
13	90201-04018-00	Washer, Plate
14	36X-2811G-00-00	Band
15	4J2-82131-01-00	Band, Battery
16	35T-24724-00-00	Damper, Seat
17	1LJ-2414J-00-00	Damper, Plate 2
18	90338-07043-00	Plug
19	3XV-21778-00-00	Damper, Locating 1
20	90464-09130-00	Clamp
21	3GM-21621-00-00	Flap
22	90149-04278-00	Screw
23	90201-04018-00	Washer, Plate
24	95607-04100-00	Nut, U
25	3GM-21649-00-00	Damper
26	3GM-21649-10-00	Damper
27	90480-10258-00	Grommet
28	4JH-2163A-00-00	Cover, Rear Fender 1
29	97707-60016-00	Screw, Tapping
30	4JH-21366-00-00	Hook, Tool Band
31	95807-06016-00	Bolt, Flange
32	4FM-28100-10-00	Tool Kit
33	3G1-85130-01-00	Rear Reflector Assy
34	95707-05500-00	Nut, Flange
35	90387-087L0-00	Collar
36	4FM-28372-00-00	Damper
37	90480-12596-00	Grommet
38	90338-10132-00	Plug
39	90209-18340-00	Washer

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4FM-Y2171-F1-P0	Cover, Side 1
01	4FM-Y2171-G1-P4	Cover, Side 1
02	3GM-21575-00-00	• . Seal 1
03	4FM-2173T-00-00	• . Tape 1
04	1WG-2143A-00-00	• . Cap
05	90480-13398-00	• . Grommet
06	4FM-2173L-40-00	• . Graphic Set 1
06	4FM-2173L-50-00	• . Graphic Set 1
07	90150-06036-00	Screw, Round Head
08	90159-06093-00	Screw, With Washer
09	4FM-Y2172-A1-P0	Cover, Side 2
09	4FM-Y2172-B1-P4	Cover, Side 2
10	3GM-21576-00-00	• . Seal 2
11	4FM-2173T-00-00	• . Tape 1
12	90480-13398-00	• . Grommet
13	4FM-2174L-40-00	• . Graphic Set 2
13	4FM-2174L-50-00	• . Graphic Set 2
14	90150-06036-00	Screw, Round Head
15	90159-06093-00	Screw, With Washer
16	90183-04064-00	Nut, Spring
17	97706-40010-00	Screw, Tapping
18	90480-04166-00	Grommet


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4HD300-5230


Ref No	Part No	Description
01	4FM-22110-10-00	Rear Arm Comp.
02	3FV-22184-00-00	Bush
03	93315-42523-00	Bearing
04	3XV-22127-00-00	Shim
05	3FV-22128-00-00	Cover, Thrust 1
06	3GM-22141-00-00	Shaft, Pivot
07	90185-18104-00	Nut, Self-locking
08	90201-18264-00	Washer, Plate
09	4FM-2217A-00-00	Arm, Relay
10	4BH-2217M-00-00	Arm 1
11	90101-10658-00	Bolt
12	90387-122R5-00	Collar
13	90201-101J1-00	Washer, Plate
14	95617-10100-00	Nut, U
15	93317-10376-00	Bearing
16	90105-10376-00	Bolt, Washer Based
17	90387-102R4-00	Collar
18	95617-10200-00	Nut, Self-locking
20	90101-10659-00	Bolt
21	90387-127W0-00	Collar
22	90201-10659-00	Washer, Plate
23	95617-10100-00	Nut, U
24	93109-17048-00	Oil Seal
25	4FM-22311-00-00	Case, Chain
26	4FM-2213J-00-00	Stay, Chain Case
27	95027-06016-00	Bolt, Flange
28	90119-06060-00	Bolt, With Washer
29	90119-06163-00	Bolt, With Washer
30	4FM-22151-01-00	Seal, Guard
31	90387-06704-00	Collar
32	90387-06681-00	Collar
33	4HD-2218A-00-00	Emblem, Rear Arm

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4HD-22210-00-00	Shock Absorber Assy, Rear
02	4AA-22259-40-00	Label, Warning
03	90105-10402-00	Bolt, Washer Based
04	90201-101J1-00	Washer, Plate
05	95617-10100-00	Nut, U
06	4FM-22219-00-00	Bracket, Upper
07	90185-16127-00	Nut, Self-locking
08	90201-164H4-00	Washer, Plate
09	478-25335-00-00	Cap
10	4FM-22262-10-00	Holder, Sub Tank
11	95807-06016-00	Bolt, Flange
12	90450-32008-00	Hose Clamp Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	93399-99932-00	Bearing
02	3FV-23462-00-00	Seal, Steering
03	93399-99931-00	Bearing
04	90202-24190-00	Washer, Plate
05	3GM-23415-00-00	Cover, Ball Race 1
06	90179-25615-00	Nut
07	3YF-23418-00-00	Washer, Special
08	90202-26142-00	Washer, Plate
09	90176-22050-00	Nut, Crown
10	4FM-23435-20-00	Crown, Handle
11	91317-08030-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-23102-40-00	Front Fork Assy (l.h)
02	4FM-23136-40-00	• . Tube, Outer (right)
03	4FM-23125-40-00	• . Metal, Slide 1
04	36Y-23146-10-00	• . Washer, Oil Seal
05	4FM-23145-40-00	• . Oil Seal
06	26H-23156-00-00	• . Clip, Oil Seal
07	3XV-23144-50-00	• . Seal, Dust
08	4FM-23110-20-00	• . Inner Tube Comp.1
09	4FM-23171-40-00	• . Piston, Front Fork
10	4FM-23170-40-00	• . Cylinder Comp., Front Fork
11	2KB-23158-L0-00	• . Gasket
12	3LC-23181-00-00	• . Bolt, Hexagon Socket Head
13	4FM-23141-00-00	• . Spring, Front Fork
14	4FM-23118-40-00	• . Spacer
15	3LC-23357-00-00	• . Nut
16	4FM-23111-10-00	• . Bolt, Cap
17	91317-08040-00	• . Bolt
18	4FM-23103-40-00	Front Fork Assy (r.h)
19	4FM-23136-40-00	• . Tube, Outer (right)
20	4FM-23125-40-00	• . Metal, Slide 1
21	36Y-23146-10-00	• . Washer, Oil Seal
22	4FM-23145-40-00	• . Oil Seal
23	26H-23156-00-00	• . Clip, Oil Seal
24	3XV-23144-50-00	• . Seal, Dust
25	4FM-23120-20-00	• . Inner Tube Comp.2
26	4FM-23171-40-00	• . Piston, Front Fork
27	4FM-23170-40-00	• . Cylinder Comp., Front Fork
28	2K8-23158-L0-00	• . Gasket
29	3LC-23181-00-00	• . Bolt, Hexagon Socket Head
30	4FM-23141-00-00	• . Spring, Front Fork
31	4FM-23118-40-00	• . Spacer
32	3LC-23357-00-00	• . Nut
33	4FM-23111-10-00	• . Bolt, Cap
34	91317-08040-00	• . Bolt
35	4FM-23340-00-00	Under Bracket Comp.
36	91317-08030-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-24110-50-X2	Fuel Tank Comp.
01	4FM-24110-50-X3	Fuel Tank Comp.
02	99226-00160-00	• . Emblem, Yamaha
02	99227-00160-00	• . Emblem, Yamaha
03	4FM-24240-20-00	• . Graphic Set
03	4FM-24240-30-00	• . Graphic Set
04	4FM-24191-00-00	Bracket, Fuel Tank 1
05	90176-06055-00	Nut, Crown
06	2GH-24181-00-00	Damper, Locating 1
07	2GH-24183-00-00	Damper, Locating 3
08	2GH-24186-00-00	Washer, Special
09	90387-06299-00	Collar
10	97007-06025-00	Bolt
11	92907-06600-00	Washer, Plate
12	95817-06075-00	Bolt, Flange
13	2GH-24184-00-00	Damper, Locating 4
14	3Y6-24183-00-00	Damper, Locating 3
15	4FM-24187-00-00	Washer, Special
16	95817-08016-00	Bolt, Flange
17	4JH-24183-00-00	Damper, Locating 3
18	3FV-24500-01-00	Fuel Cock Assy 1
19	4X8-24512-00-00	• . Gasket
20	90149-06008-00	Screw
21	90202-05187-00	Washer, Plate
22	4FM-13910-00-00	Fuel Pump Assy
23	4FM-2414G-00-00	Seal
24	98507-05016-00	Screw, Pan Head
25	92907-05100-00	Washer, Spring
26	92907-05600-00	Washer, Plate
27	4HN-24602-00-00	Cap Assy
28	90110-05112-00	Bolt, Hexagon Socket Head
29	91317-05010-00	Bolt
30	90445-102G7-00	Hose
31	90467-102G7-00	Clip
32	90464-25160-00	Clamp
33	90445-105G5-00	Hose
34	3FV-14294-02-00	Hose
35	90467-13123-00	Clip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-24710-01-00	Single Seat Assy
02	4FM-24711-00-00	• . Cover, Single Seat
03	4FM-24724-00-00	• . Damper, Seat
04	4FM-24780-00-00	Seat Lock Assy
05	95817-06016-00	Bolt, Flange
06	4FM-24750-10-00	Tandem Seat Assy
07	4FM-24751-00-00	• . Cover, Tandem Seat
08	509-24724-00-00	• . Damper, Seat
09	4BP-24780-00-00	Seat Lock Assy
10	4BP-24792-00-00	Plate
11	95707-06500-00	Nut, Flange
12	4FM-2478E-01-00	Cable, Seat Lock
13	3CK-W2470-00-00	Seat Lock Assy
14	4FM-2117K-00-00	Stay, Lock
15	90149-06308-00	Screw
16	4FM-24791-00-P0	Cover, Seat Back
16	4FM-24791-00-P5	Cover, Seat Back
17	4FM-2475H-01-00	Bracket, Seat Lever 1
18	4FM-2475J-01-00	Bracket, Seat Lever 2

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-25168-00-7B	Cast Wheel, Front
02	90387-2200S-00	Collar
03	93306-00420-00	Bearing
04	93102-28021-00	Oil Seal
05	4FM-25149-00-00	Clutch, Meter
06	341-25846-00-00	Retainer, Clutch
07	93105-45017-00	Oil Seal
08	94112-1700M-00	Tire (120/70 Zr17 Bt50f)
09	93900-00030-00	Valve, Rim
10	29L-25398-00-00	Balancer, Wheel (10g)
10	29L-25398-10-00	Balancer, Wheel (20g)
10	29L-25398-20-00	Balancer, Wheel (30g)
11	4FM-25190-00-00	Gear Unit Assy
12	4FM-25181-01-00	Axle, Wheel
13	90387-2200T-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-2581T-01-00	Disc Brake Assy
02	90109-082G4-00	Bolt
03	4FM-2580T-30-00	Caliper Assy (left)
04	4FM-W0057-10-00	• . Piston Assy, Caliper
05	3MA-W0047-10-00	•• .. Caliper Seal Kit
06	4FM-W0057-00-00	• . Piston Assy, Caliper
07	4FM-W0047-00-00	•• .. Caliper Seal Kit
08	4FM-W0045-30-00	• . Brake Pad Kit
09	4FM-25919-00-00	• . Support, Pad
10	4FM-25924-00-00	• . Pin, Pad
11	4FM-25925-00-00	• . Clip
12	1J3-W0048-00-00	• . Bleed Screw Kit
13	4FM-25827-00-00	• . Shim, Caliper
14	4FM-2580U-30-00	Caliper Assy (right)
15	4FM-W0057-10-00	• . Piston Assy, Caliper
16	3MA-W0047-10-00	•• .. Caliper Seal Kit
17	4FM-W0057-00-00	• . Piston Assy, Caliper
18	4FM-W0047-00-00	•• .. Caliper Seal Kit
19	4FM-W0045-30-00	• . Brake Pad Kit
20	4FM-25919-00-00	• . Support, Pad
21	4FM-25924-00-00	• . Pin, Pad
22	4FM-25925-00-00	• . Clip
23	1J3-W0048-00-00	• . Bleed Screw Kit
24	4FM-25827-00-00	• . Shim, Caliper
25	90105-10725-00	Bolt, Washer Based
26	4FM-21596-00-00	Holder

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4FM-25338-00-7B	Cast Wheel, Rear
02	93306-20567-00	Bearing
03	93102-35412-00	Oil Seal
04	90560-28389-00	Spacer
05	4FM-25364-00-00	Damper
06	94118-1700R-00	Tire (180/55 Zr17 Bt50f)
07	93900-00030-00	Valve, Rim
08	29L-25398-00-00	Balancer, Wheel (10g)
08	29L-25398-10-00	Balancer, Wheel (20g)
08	29L-25398-20-00	Balancer, Wheel (30g)
09	4FM-25366-00-00	Clutch, Hub
10	93306-20644-00	Bearing
11	93102-40211-00	Oil Seal
12	4FM-25377-00-00	Collar, Wheel
13	3FV-25443-01-00	Sprocket, Driven (43z)
14	90116-10575-00	Bolt, Stud
15	95617-10200-00	Nut, Self-locking
16	94581-55106-00	Chain (did532zlvka1-l108)
17	94681-55031-00	• . Joint, Chain
18	4FM-25388-01-00	Puller, Chain 1
19	4FM-25389-00-00	Puller, Chain 2
20	90101-08766-00	Bolt
21	95307-08600-00	Nut
22	4FM-25371-00-00	Bar, Tension
23	90105-08321-00	Bolt, Washer Based
24	95707-08500-00	Nut, Flange
25	91490-20020-00	Pin, Cotter
26	90468-16099-00	Clip
27	4FM-25381-10-00	Axle, Wheel
28	90185-24165-00	Nut, Self-locking
29	90201-257R5-00	Washer, Plate
30	90387-2805W-00	Collar
31	90387-2805X-00	Collar
32	4FM-25887-00-00	Holder, Brake Hose
33	2AL-84553-00-00	Damper


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4FM-2582W-00-00	Disc, Rear Brake 2
02	90109-082G4-00	Bolt
03	4FM-2580W-10-00	Caliper Assy, Rear 2
04	31A-W0057-00-00	• . Piston Assy, Caliper
05	31A-W0047-00-00	•• .. Caliper Seal Kit
06	4FM-W0046-00-00	• . Brake Pad Kit 2
07	29L-25919-A0-00	Support, Pad
08	3GM-25925-00-00	• . Clip
09	1J3-W0048-00-00	• . Bleed Screw Kit
10	42H-25836-00-00	• . Cover, Dust
11	1FK-25827-00-00	• . Shim, Caliper
12	1FK-25828-00-00	• . Shim, Caliper
13	4FM-25819-01-00	Bracket, Caliper
14	90105-10725-00	Bolt, Washer Based


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.

STEERING HANDLE. CABLE




Ref No	Part No	Description
01	4FM-26121-01-00	Handlebar (left)
02	4FM-26122-00-00	Handlebar (right)
03	36Y-26246-00-00	End, Grip
04	91317-06020-00	Bolt
05	91317-06025-00	Bolt
06	10L-23469-00-00	Cap, Bolt
07	4FM-26241-00-00	Grip (left)
08	4FM-26240-00-00	Grip Assy
09	3LN-26270-01-00	Cable Connector Cap Assy
10	4FM-26302-20-00	Throttle Cable Assy
11	4FM-83940-00-00	Starter Assy
12	1WG-83941-00-00	• . Lever, Starter
13	90209-10131-00	• . Washer
14	98907-06008-00	• . Screw, Bind
15	95817-06010-00	Bolt, Flange
16	3FV-26331-00-00	Cable, Starter 1
17	3GM-83969-01-00	Switch, Handle 5
18	98506-05030-00	• . Screw, Pan Head
19	98506-05040-00	• . Screw, Pan Head
20	4FM-83975-00-00	Switch, Handle 2
21	98506-05018-00	• . Screw, Pan Head
22	25G-83936-01-00	Band, Switch Cord

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-W2587-50-00	Master Cylinder Sub Assy
02	3GM-W0041-50-00	• . Cylinder Kit, Master
03	93210-15620-00	• . O-ring
04	2VN-25866-00-00	• . Circlip
05	3FV-2589A-00-00	• . Cover, Dust
06	56A-25867-00-00	Bracket, Master Cylinder
07	95027-06025-00	Bolt, Flange
08	3GM-83922-51-00	Lever 2
09	3FV-2589F-00-00	Bolt, Lever
10	95607-06100-00	Nut, U
11	3FV-25894-00-00	Tank, Reservoir
12	3GM-25852-50-00	Cap, Reservoir
13	3FV-25854-00-00	Diaphragm, Reservoir
14	2J2-25855-50-00	Bush,diaphragm
15	3FV-83980-00-00	Front Stop Switch Assy
16	98517-04012-00	Screw, Pan Head
17	92990-04100-00	Washer, Spring
18	92901-04600-00	Washer, Plate
19	3GM-2585F-00-00	O-ring
20	3PA-24356-00-00	Clip, Pipe 1
21	4FM-26292-00-00	Stay
22	91317-06012-00	Bolt
23	3FV-2589G-00-00	Holder
24	3GM-2589H-00-00	Screw
25	4FM-25872-02-00	Hose, Brake 1
26	4FM-25873-02-00	Hose, Brake 2
27	4FM-23377-00-00	Bracket, Horn
28	4FM-23378-00-00	Bracket, Horn
29	91317-06010-00	Bolt
30	91317-06012-00	Bolt
31	90401-10160-00	Bolt, Union
32	90401-10159-00	Bolt, Union
33	90201-10118-00	Washer, Plate
34	3MA-25876-12-00	Holder, Brake Hose 2
35	3MA-25876-22-00	Holder, Brake Hose 2
36	95817-06012-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-W2645-00-00	Master Cylinder Sub Assy
02	3GM-W0099-00-00	• . Cylinder Kit, Master (clutch)
03	3GM-26464-00-00	• . Rod, Push
04	3GM-26455-00-00	• . Bush
05	93210-15620-00	• . O-ring
06	2VN-25866-00-00	• . Circlip
07	3FV-2589A-00-00	• . Cover, Dust
08	3GK-25854-50-00	Diaphragm, Reservoir
09	4FM-25852-00-00	Cap, Reservoir
10	3GK-25855-50-00	Bush,diaphragm
11	4FM-83912-01-00	Lever 1
12	3FV-2589F-00-00	Bolt, Lever
13	95706-06500-00	Nut, Flange
14	3GM-83980-00-00	Front Stop Switch Assy
15	98706-04016-00	Screw, Flat Head
16	95027-06025-00	Bolt, Flange
17	4FM-25894-00-00	Tank, Reservoir
18	56A-25867-00-00	Bracket, Master Cylinder
19	3PA-24356-00-00	Clip, Pipe 1
20	4FM-2585F-00-00	O-ring
21	4FM-26296-00-00	Bracket
22	91317-06012-00	Bolt
23	4FM-26475-00-00	Holder
24	98507-04008-00	Screw, Pan Head
25	3GM-26470-A0-00	Hose, Clutch
26	90401-10159-00	Bolt, Union
27	90201-10118-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-27311-00-00	Stand, Side
02	4FM-27321-00-00	Bracket, Side Stand
03	90110-08155-00	Bolt, Hexagon Socket Head
04	90109-104E6-00	Bolt
05	90185-10037-00	Nut, Self-locking
06	90506-18224-00	Spring, Tension
07	90506-26225-00	Spring, Tension
08	4FM-27315-00-00	Link, Side Stand
09	1TX-27351-00-00	Guide, Side Stand
10	4FM-27410-00-00	Front Footrest Assy (left)
11	2GH-27413-00-00	• . Cover, Footrest
12	90157-05079-00	• . Screw, Pan Head
13	4FM-27471-00-00	• . Bar, Footrest 1
14	4FN-27435-00-00	• . Bolt
15	4FM-27420-00-00	Front Footrest Assy (right)
16	2GH-27413-00-00	• . Cover, Footrest
17	90157-05079-00	• . Screw, Pan Head
18	4FM-27471-00-00	• . Bar, Footrest 1
19	4FM-27435-00-00	• . Bolt
20	4FM-27442-00-00	Bracket 2
21	4FM-27443-00-00	Bracket 3
22	4BP-27434-01-00	Bolt
23	90201-08326-00	Washer, Plate
24	90201-127J6-00	Washer, Plate
25	90179-10658-00	Nut
26	90506-20377-00	Spring, Tension
27	90446-17346-00	Hose
28	90110-08231-00	Bolt, Hexagon Socket Head
29	4FM-27430-10-00	Rear Footrest Assy 1
30	90501-12743-00	• . Spring, Compression
31	93501-04011-00	• . Ball
32	4HX-27437-00-00	• . Washer, Special
33	90387-064H8-00	• . Collar
34	91317-06045-00	• . Bolt
35	95607-06200-00	• . Nut, Self U-flange
36	4FM-27440-10-00	Rear Footrest Assy 2
37	90501-12743-00	• . Spring, Compression
38	93501-04011-00	• . Ball
39	1HX-27437-00-00	• . Washer, Special
40	90387-064H8-00	• . Collar
41	91317-06045-00	• . Bolt
42	95607-06200-00	• . Nut, Self U-flange
43	95817-08030-00	Bolt, Flange
44	2H7-27414-00-00	Damper, Footrest
45	90387-10636-00	Collar
46	90105-10316-00	Bolt, Washer Based
47	90201-10669-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-27211-00-00	Pedal, Brake
02	4FM-27254-00-00	Hook
03	90159-06045-00	Screw, With Washer
04	3YF-27261-00-00	Shaft
05	90201-104R2-00	Washer, Plate
06	90206-14086-00	Washer, Wave
07	4BH-2583V-00-00	Rr. Master Cylinder Assy.
08	4BH-W0042-50-00	• . Cylinder Kit, Master
09	3LN-2585G-00-00	•• .. Circlip
10	4BP-2582A-00-00	• . Joint
11	4BP-2585F-00-00	• . O-ring
12	4FM-27222-00-00	Joint
13	95307-08700-00	Nut
14	92017-08020-00	Bolt, Button Head
15	90240-08124-00	Pin, Clevis
16	90201-08083-00	Washer, Plate
17	91490-20025-00	Pin, Cotter
18	4FM-2144G-00-00	Stay, Stop Switch
19	98507-06010-00	Screw, Pan Head
20	31A-25894-01-00	Tank, Reservoir
21	360-25854-00-00	Diaphragm, Reservoir
22	2GU-25855-00-00	Bush,diaphragm
23	2KF-25852-50-00	Cap, Reservoir
24	3PJ-25888-00-00	Cover, Reservoir Tank
25	98517-06020-00	Screw, Pan Head
26	92901-06100-00	Washer, Spring
27	4FM-2133G-00-00	Bracket, Reserver
28	95807-06016-00	Bolt, Flange
29	4FM-25895-00-00	Hose, Reservoir
30	90467-14057-00	Clip
31	90401-10159-00	Bolt, Union
32	90201-10118-00	Washer, Plate
33	4FM-25874-01-00	Hose, Brake
34	4FM-25875-00-00	Holder, Brake Hose 1
35	4FM-25876-00-00	Holder, Brake Hose 2
36	95027-06016-00	Bolt, Flange
37	95027-06008-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-28381-00-00	Windshield
02	90149-05273-00	Screw
03	4FM-28215-00-00	Washer, Special
04	95707-05500-00	Nut, Flange
05	4FM-Y2835-30-4B	Cowling Ass'y
05	4FM-Y2835-80-4B	Cowling Ass'y
06	89X-77167-00-00	• . Trim 3
07	90183-05024-00	• . Nut, Spring
08	90480-13398-00	• . Grommet
09	99236-00100-00	• . Emblem, Yamaha
09	99237-00100-00	• . Emblem, Yamaha
10	3MA-21649-00-00	• . Damper
11	4FM-2834V-00-00	• . Protector 1
12	4FM-2834W-00-00	• . Protector 2
13	4FM-28356-00-00	Stay 1
14	90480-13163-00	Grommet
15	90560-06201-00	Spacer
16	97707-50016-00	Screw, Tapping
17	51L-28371-00-00	Damper
18	95617-08200-00	Nut, Self-locking
19	90183-05024-00	Nut, Spring
20	90150-05039-00	Screw, Round Head
21	90150-05039-00	Screw, Round Head
22	4FM-26280-10-00	Rear View Mirror Assy(left)
23	4FM-26290-10-00	Rear View Mirror Assy(right)
24	4FM-2831W-00-00	Stay, Mirror 1
25	90480-13398-00	Grommet
26	90387-067N5-00	Collar
27	95027-06016-00	Bolt, Flange
28	4FM-2832W-00-00	Stay, Mirror 2
29	95027-06012-00	Bolt, Flange
30	4FM-26299-00-00	Plate, Mirror Fitting 2
31	3XV-26298-00-00	Plate, Mirror Fitting 1
32	98707-06025-00	Screw, Flat Head
33	90176-06055-00	Nut, Crown

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-Y283U-70-P0	Panel Assembly 1
01	4FM-Y283U-80-P1	Panel Assembly 1
02	90480-13398-00	• . Grommet
03	8V7-21961-00-00	Patch 1
04	4FM-28371-10-00	• . Damper
05	90183-05024-00	• . Nut, Spring
06	4FM-2836K-00-00	• . Panel, Inner 1
07	97707-40014-00	• . Screw, Tapping
08	4FM-28301-40-00	• . Graphic Set, Lower Cover 1
08	4FM-28301-50-00	• . Graphic Set, Lower Cover 1
09	4FM-Y283V-70-P0	Panel Assembly 2
09	4FM-Y283V-80-P1	Panel Assembly 2
10	90480-13398-00	• . Grommet
11	8V7-21961-00-00	Patch 1
12	4FM-28371-10-00	• . Damper
13	90183-05024-00	• . Nut, Spring
14	90464-25160-00	• . Clamp
15	4FM-2836L-00-00	• . Panel, Inner 2
16	97707-40014-00	• . Screw, Tapping
17	4FM-28303-20-00	• . Graphic Set,lower Cover 2
17	4FM-28303-30-00	• . Graphic Set,lower Cover 2
18	4FM-28322-00-00	Stay 2
19	95817-06010-00	Bolt, Flange
20	4FM-2836H-00-00	Bracket 5
21	95817-08012-00	Bolt, Flange
22	90150-06036-00	Screw, Round Head
23	1A8-21518-00-00	Holder, Cable
24	4FM-Y2808-50-P0	Cover Assy, Under
24	4FM-Y2808-60-P1	Cover Assy, Under
25	90480-13398-00	• . Grommet
26	4FM-28304-20-00	• . Graphicset, Lower Cover 3
27	4FM-28315-60-00	• . Emblem
27	4FM-28315-70-00	• . Emblem
28	4FM-2848K-10-00	• . Seat 2
29	8V7-21961-00-00	• . Patch 1
30	90150-06036-00	Screw, Round Head
31	90150-05039-00	Screw, Round Head
32	4FM-2836F-00-00	Bracket 3
33	4FM-2836G-00-00	Bracket 4
34	4FM-2831T-00-00	Stay, Support 1
35	90119-06018-00	Bolt, With Washer

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4BH-81600-00-00	A.c. Generator Assy
02	4BH-81634-00-00	• . Head Wire Assy
03	4BH-81643-00-00	•• .. Bearing
04	4BH-81645-00-00	•• .. Screw
05	4BH-81643-10-00	• . Bearing
06	4BH-81970-00-00	• . Rectifier Assy
07	36Y-81910-50-00	• . Voltage Regulator Assy
08	3FV-81619-00-00	• . Brush Holder Assy
09	4BH-81972-00-00	• . Cover, Rectifier
10	3FV-81645-00-00	• . Screw
11	98507-05018-00	• . Screw, Pan Head
12	92901-05100-00	• . Washer, Spring
13	92990-05600-00	• . Washer, Plate
14	4BH-81604-00-00	• . Cover Assy
15	95707-05500-00	• . Nut, Flange
16	36Y-81638-50-00	• . Oil Seal
17	2KT-81642-50-00	• . O-ring
18	4BH-81660-00-00	• . Field Coil Assy
19	95817-08065-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-81670-00	Pick-up Assy
02	93210-19216-0	O-ring
03	95027-06012-0	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3XF-81800-00-00	Starting Motor Assy
02	26H-81847-00-00	• . O-ring
03	11H-81844-00-00	• . Gasket
04	2KT-81815-00-00	• . Cord, Starter Motor
05	3KS-81840-00-00	• . Brush Holder Assy
06	3HE-81826-00-00	• . Bolt
07	95827-06024-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4JH-83310-00-00	Front Flasher Light Assy 1
02	306-83311-40-00	• . Bulb, Flasher (12v-21w)
03	4JH-83332-00-00	• . Lens, Flasher
04	97702-40610-00	• . Screw, Tapping
05	4JH-83320-00-00	Front Flasher Light Assy 2
06	306-83311-40-00	• . Bulb, Flasher (12v-21w)
07	4JH-83342-00-00	• . Lens, Flasher 2
08	97702-40610-00	• . Screw, Tapping
09	4JH-83318-00-00	Stay, Flasher 1
10	4JH-83318-00-00	Stay, Flasher 1
11	98507-04008-00	Screw, Pan Head
12	92907-04600-00	Washer
13	4JH-83330-00-00	Rear Flasher Light Assy 1
14	306-83311-40-00	• . Bulb, Flasher (12v-21w)
15	4JH-83332-00-00	• . Lens, Flasher
16	97702-40610-00	• . Screw, Tapping
17	4JH-83340-00-00	Flasher Light Assy 2
18	306-83311-40-00	• . Bulb, Flasher (12v-21w)
19	4JH-83342-00-00	• . Lens, Flasher 2
20	97702-40610-00	• . Screw, Tapping
21	4FM-83345-00-00	Plug, Blind
22	4FM-83369-00-00	Stay, Flasher 2
23	95707-06500-00	Nut, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-83570-00-00	Speedometer Assy
02	4FM-83540-00-00	Tachometer Assy
03	4FM-83590-00-00	Water Temperature Assy
04	4FM-83559-00-00	Cover, Meter
05	4FM-8353H-00-00	Case, Under
06	2GH-83578-00-00	Knob, Trip Meter
07	4FM-83509-80-00	Socket Cord Assy
08	4G1-84744-00-00	Bulb (12v-3.4w)
09	2GV-83517-00-00	Bulb (12v-1.7w, T6.5)
10	98507-04010-00	Screw, Pan Head
11	92907-04100-00	Washer, Spring
12	92907-04600-00	Washer
13	97902-04122-00	Screw, With Washer
14	98507-03010-00	Screw, Pan Head
15	92990-03100-00	Washer, Spring
16	90159-03102-00	Screw, With Washer
17	90164-04023-00	Screw, Tapping
18	4FM-83520-00-00	Socket Cord Assy
19	5J0-83513-00-00	Damper
20	90201-06059-00	Washer, Plate
21	95307-06600-00	Nut
22	4FM-83550-01-00	Speedometer Cable Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-84330-41-00	Body Assy
02	4FM-84320-10-00	Lens Assy
03	4FM-8432A-10-00	Lens Assy
04	2F9-84314-00-00	Bulb, Headlight (12v-60/55w)
05	4JG-84397-00-00	Cover, Socket
06	51L-84334-00-00	Nut, Adjusting
07	90480-10584-00	Grommet
08	97707-60014-00	Screw, Tapping
09	3GM-84301-00-00	Pilot Light Assy 1
10	3GM-84321-00-00	• . Lens Assy
11	3GM-84322-00-00	• . Gasket, Lens
12	2JE-84744-00-00	• . Bulb (12v 5w)
13	3GM-84744-00-00	• . Bulb
14	3GM-84367-50-00	Damper, Headlight 2
15	97707-50012-00	Screw, Tapping
16	3GM-8431R-00-00	Stay, Setting
17	90480-10517-00	Grommet
18	90387-052U5-00	Collar
19	90167-05037-00	Screw, Tapping
20	4FM-84359-20-00	Cord, Headlight
21	90462-05061-00	Clamp
22	97707-50012-00	Screw, Tapping
23	90464-13073-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4FM-84710-00-00	Taillight Unit Assy
02	31L-84714-00-00	• . Bulb (12v-21/5w)
03	4FM-84735-00-00	• . Cord Assy
04	90179-05523-00	Nut
05	92907-05600-00	Washer, Plate
06	90110-05112-00	Bolt, Hexagon Socket Head
07	4FM-84745-00-00	Licence Light Unit Assy
08	4FM-84749-00-00	• . Body, Licence Light
09	2JE-84744-00-00	• . Bulb (12v 5w)
10	3F9-84742-00-00	Seat, Base
11	3F9-84553-00-00	Damper
12	90201-05033-00	Washer, Plate
13	90387-06241-00	Collar
14	95707-06016-00	Nut, Flange
15	3YF-84751-00-00	Bracket, License
16	95027-06016-00	Bolt, Flange
17	90201-06059-00	Washer, Plate
18	95607-06100-00	Nut, U
19	99236-00080-00	Emblem, Yamaha
19	99237-00080-00	Emblem, Yamaha

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4HN-82305-10-00	Ignitor Unit Assy
02	97707-60016-00	Screw, Tapping
03	90338-08226-00	Plug
04	4FM-82310-00-00	Ignition Coil Assy
05	4FM-82320-00-00	Ignition Coil Assy
06	2KT-82370-00-00	Plug Cap Assy
07	4FM-82540-00-00	Neutral Switch Assy
08	93210-29196-00	O-ring
09	98507-06016-00	Screw, Pan Head
10	3GM-85720-00-00	Oil Level Gauge Assy
11	95027-06014-00	Bolt, Flange
12	3LN-82560-00-00	Thermo Switch Assy
13	11H-83591-00-00	Thermo Unit
14	98507-05600-00	Screw, Pan Head
15	92907-05600-00	Washer, Plate
16	4FM-85820-00-00	Servo Motor Assy
17	90480-14412-00	Grommet
18	90387-065V1-00	Collar
19	95807-06030-00	Bolt, Flange
20	90464-13073-00	Clamp
21	3GM-83350-00-00	Flasher Relay Assy
22	4FM-83371-00-00	Horn
23	95817-06010-00	Bolt, Flange
24	90464-10186-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4FM-81940-00-00	Starter Relay Assy
02	95027-06008-00	Bolt, Flange
03	3VD-82100-00-00	Battery Assy (ytx12-bs)
04	4BP-82131-00-00	Band, Battery
05	4FM-82115-00-00	Wire, Plus Lead
06	3FV-82116-00-00	Wire, Minus Lead
07	4JH-82501-01-00	Main Switch Steering Lock
08	90109-080G5-00	Bolt
09	1KT-82530-02-00	Stop Switch Assy
10	4FM-82590-10-00	Wire Harness Assy
11	2KW-82151-00-00	• . Fuse (7.5a-bl)
12	2GH-82151-00-00	• . Fuse (20a)
13	36Y-82151-00-00	• . Fuse (15a-bl)
14	4FM-82151-00-00	• . Fuse (30a)
15	90464-12089-00	Clamp
16	90465-13355-00	Clamp
17	90464-13073-00	Clamp
18	90464-13073-00	Clamp
19	90464-15195-00	Clamp
20	3EN-81950-00-00	Relay Assy
21	3GM-81950-00-00	Relay Assy
22	4FM-82566-00-00	Switch, Side Stand
23	90157-05079-00	Screw, Pan Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.