




Ref No	Part No	Description
01	4KM-11101-00-00	Cylinder Head Assy
02	99510-08016-00	• . Pin, Dowel
03	93440-12117-00	• . Circlip
04	90105-06153-00	• . Bolt, Washer Based
05	90153-06029-00	• . Screw, Hexagon
06	90430-06014-00	• . Gasket
07	26H-11133-10-00	• . Guide, Intake Valve
08	95617-06625-00	Bolt, Stud
09	90116-08595-00	Bolt, Stud
10	95617-06630-00	Bolt, Stud
11	90176-10075-00	Nut, Crown
12	90201-10131-00	Washer, Plate
13	90201-10128-00	Washer, Plate
14	94701-00241-00	Plug, Spark (ngk Dpr8ea-9)
14	94701-00242-00	Plug, Spark (nd X24epr-u9)
15	4KM-11181-00-00	Gasket, Cylinder Head 1
16	4KM-11190-00-00	Cover, Cylinder Head 1
17	4KM-11193-00-00	Gasket, Head Cover 1
18	90109-066F0-00	Bolt
19	4KM-1111G-00-00	Rubber, Mount 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-11310-00-00	Cylinder
02	93210-71462-00	O-ring
03	99530-14016-00	Pin, Dowel
04	90430-14131-00	Gasket
05	4KM-11351-00-00	Gasket, Cylinder
06	95627-08335-00	Bolt, Stud
07	90201-084G3-00	Washer, Plate
08	92907-06600-00	Washer, Plate
09	95317-08600-00	Nut
10	95317-06600-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-11411-00-00	Crankshaft
02	93102-32144-00	Oil Seal
03	4KM-11416-00-00	Plane Bearing, Crankshaft 1
03	4KM-11416-10-00	Plane Bearing, Crankshaft 1
03	4KM-11416-20-00	Plane Bearing, Crankshaft 1
03	4KM-11416-30-00	Plane Bearing, Crankshaft 1
03	4KM-11416-40-00	Plane Bearing, Crankshaft 1
04	4KM-11418-00-00	Plane Bearing, Crankshaft 3
04	4KM-11418-10-00	Plane Bearing, Crankshaft 3
04	4KM-11418-20-00	Plane Bearing, Crankshaft 3
04	4KM-11418-30-00	Plane Bearing, Crankshaft 3
04	4KM-11418-40-00	Plane Bearing, Crankshaft 3
05	4KM-11631-00-A0	Piston (std)
05	4KM-11636-00-00	Piston (0.50mm O/s)
05	4KM-11638-00-00	Piston (1.00mm O/s)
06	4KM-11603-00-00	Piston Ring Set (std)
06	4KM-11605-00-00	Piston Ring Set (0.50mm O/s)
06	4KM-11607-00-00	Piston Ring Set (1.00mm O/s)
07	58L-11633-00-00	Pin, Piston
08	93450-17044-00	Circlip
09	4KM-11650-00-00	Connecting Rod Assy
10	12R-11654-00-00	• . Bolt, Connecting Rod
11	90179-08327-00	• . Nut
12	31A-11656-00-00	Plane Bearing, Connecting Rod
12	31A-11656-10-00	Plane Bearing, Connecting Rod
12	31A-11656-20-00	Plane Bearing, Connecting Rod
12	31A-11656-30-00	Plane Bearing, Connecting Rod

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4KM-12111-00-00	Valve, Intake
02	4KM-12121-00-00	Valve, Exhaust
03	26H-12116-00-00	Seat, Valve Spring
04	51Y-12113-00-00	Spring, Valve Inner
05	51Y-12114-00-00	Spring, Valve Outer
06	26H-12117-00-00	Retainer, Valve Spring
07	4G0-12118-00-00	Cotter, Valve
08	4KM-12119-00-00	Seal, Valve Stem
09	26H-12168-00-00	Pad, Adjusting
09	26H-12168-M0-00	Pad, Adjusting (2.45)
09	26H-12168-R0-00	Pad, Adjusting (2.50)
09	26H-12168-U0-00	Pad, Adjusting (2.55)
09	26H-12168-W0-00	Pad, Adjusting (2.60)
09	26H-12168-Y0-00	Pad, Adjusting (2.65)
09	26H-12169-10-00	Pad, Adjusting (2.70)
09	26H-12169-30-00	Pad, Adjusting (2.75)
09	26H-12169-50-00	Pad, Adjusting (2.80)
09	26H-12169-70-00	Pad, Adjusting (2.85)
09	26H-12169-90-00	Pad, Adjusting (2.90)
09	26H-12168-20-00	Pad, Adjusting (2.05)
09	26H-12169-E0-00	Pad, Adjusting (2.95)
09	26H-12169-G0-00	Pad, Adjusting (3.00)
09	26H-12169-J0-00	Pad, Adjusting (3.05)
09	26H-12169-L0-00	Pad, Adjusting (3.10)
09	26H-12169-N0-00	Pad, Adjusting (3.15)
09	26H-12169-T0-00	Pad, Adjusting (3.20)
09	26H-12168-40-00	Pad, Adjusting (2.10)
09	26H-12168-60-00	Pad, Adjusting (2.15)
09	26H-12168-80-00	Pad, Adjusting (2.20)
09	26H-12168-A0-00	Pad, Adjusting (2.25)
09	26H-12168-F0-00	Pad, Adjusting (2.30)
09	26H-12168-H0-00	Pad, Adjusting (2.35)
09	26H-12168-K0-00	Pad, Adjusting (2.40)
10	26H-12153-00-Y0	Lifter, Valve
10	26H-12153-00-J0	Lifter, Valve (o/s)


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4KM351-5050


Ref No	Part No	Description
01	4KM-12171-00-00	Camshaft 1
02	4KM-12176-00-00	Sprocket, Cam Chain
03	90105-07342-00	Bolt, Washer Based
04	94591-40150-00	Chain
05	4KM-12241-00-00	Guide, Stopper 2
06	98907-06010-00	Screw, Bind
07	4KM-12210-00-00	Tensioner Assy, Cam Chain
08	3YX-12213-00-00	Gasket, Tensioner Case
09	4KM-12251-00-00	Damper, Chain 1
10	4KM-12252-00-00	Damper, Chain 2
11	95817-08080-00	Bolt, Flange
12	90201-080L8-00	Washer, Plate
13	91317-06025-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-13300-00-00	Oil Pump Assy
02	4KM-13355-00-00	• . Sprocket, Driven
03	90105-06154-00	• . Bolt, Washer Based
04	90110-06035-00	Bolt, Hexagon Socket Head
05	4KM-13327-00-00	Cover, Pump Gear
06	4KM-13317-00-00	Plate, Baffle
07	4H7-13328-00-00	Grommet, Gear Cover
08	93210-18319-00	O-ring
09	91317-06025-00	Bolt
10	94580-25060-00	Chain (did25 6le)
11	4H7-13354-00-00	Sprocket, Drive (25z)
12	93315-23208-00	• . Bearing

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-13461-00-00	Plate, Adaptor
02	4KM-13493-00-00	Plunger
03	90501-12413-00	Spring, Compression
04	90209-06339-00	Washer
05	99009-17500-00	Circlip
06	4KM-13479-00-00	Seat, Valve
07	90201-113K2-00	Washer, Plate
08	99009-11400-00	Circlip
09	93210-87723-00	O-ring
10	90401-20162-00	Bolt, Union
11	90387-2005R-00	Collar
12	4KM-13464-00-00	Hose, Oil 1
13	4KM-13465-00-00	Hose, Oil 2
14	90401-12122-00	Bolt, Union
15	90430-12202-00	Gasket
16	93210-10197-00	O-ring
17	91317-06016-00	Bolt
18	4KM-13470-00-00	Oil Cooler Assy
19	90480-12475-00	Grommet
20	90387-067K8-00	Collar
21	90338-20188-00	Plug
22	95817-06020-00	Bolt, Flange
23	95707-06500-00	Nut, Flange
24	90462-10066-00	Clamp
25	4KM-13151-00-00	Stay
26	90387-07598-00	Collar
27	91317-06025-00	Bolt
28	95707-06500-00	Nut, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3TJ-13461-00-00	Plate, Adaptor
02	3FV-13440-00-00	Element Assy, Oil Cleaner
03	93210-87723-00	O-ring
04	4KM-13417-00-00	Cover, Strainer
05	4H7-13337-00-00	Plate, Baffle Lower
06	98507-06010-00	Screw, Pan Head
07	4BB-13414-00-00	Gasket, Strainer Cover
08	99510-08016-00	Pin, Dowel
09	3VD-13455-00-00	Plug
10	98907-06008-00	• . Screw, Bind
11	214-11198-01-00	Gasket
12	91317-06030-00	Bolt
13	91317-06040-00	Bolt
14	91317-06025-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-13586-00-00	Joint, Carburetor 1
02	4KM-13596-00-00	Joint, Carburetor 2
03	16G-13569-00-00	Plug, Blind
04	90467-10039-00	Clip
05	93210-44545-00	O-ring
06	91317-06020-00	Bolt
07	4KM-81317-00-00	Clamp, Cord
08	90464-09221-00	Clamp
09	4KM-13575-00-00	Band
10	4KM-14401-00-00	Air Cleaner Case Assy
11	4KM-14454-00-00	Joint
12	1AE-14451-00-00	Element, Air Cleaner
13	4KM-14422-00-00	Cap, Cleaner Case 2
14	97707-50130-00	Screw, Tapping
15	5T0-14457-00-00	Seal
16	90387-060M9-00	Collar
17	90480-14023-00	Grommet
18	4KM-14148-00-00	Pipe
19	90467-10008-00	Clip
20	34X-1443E-00-00	Pipe, Drain
21	90467-10008-00	Clip
22	90460-64065-00	Clamp, Hose
23	1JK-21735-00-00	Seal 2
24	95817-06025-00	Bolt, Flange
25	4KM-14349-00-00	Pipe
26	90467-11106-00	Clip
27	90467-10008-00	Clip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-14714-00-00	Gasket, Muffler
02	4KM-14872-00-00	Pipe 2
03	4KM-14881-00-00	Hose, Bend 1
04	90468-08104-00	Clip
05	4KM-14808-01-00	Reed Valve Assy
06	91317-06012-00	Bolt
07	4KM-14882-00-00	Hose, Bend 2
08	90467-19160-00	Clip
09	4KM-14714-00-00	Gasket, Muffler
10	4KM-14873-00-00	Pipe 3
11	4KM-14881-00-00	Hose, Bend 1
12	90468-08104-00	Clip
13	4KM-14808-01-00	Reed Valve Assy
14	91317-06012-00	Bolt
15	4KM-14883-00-00	Hose, Bend 3
16	4KM-14874-00-00	Pipe 4
17	4KM-14884-00-00	Hose, Bend 4
18	4KM-14885-00-00	Hose, Bend 5
19	90467-19160-00	Clip
20	4KM-14840-00-00	Air Cut Valve Ass'y
21	90462-20188-00	Clamp
22	98507-06012-00	Screw, Pan Head
23	92907-06100-00	Washer, Spring
24	92907-06600-00	Washer, Plate
25	4KM-14886-00-00	Hose, Bend 6
26	4KM-14887-00-00	Hose, Bend 7
27	90467-08092-00	Clip
28	1RV-13595-00-00	Joint
29	90445-090E5-00	Hose
30	90467-24113-00	Clip
31	4KM-14868-01-00	Bracket 2
32	4KM-14844-00-00	Damper
33	95807-06012-00	Bolt, Flange
34	90464-20178-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-14900-00-00	Carburetor Assy
02	4KM-14901-00-00	• . Carburetor Assy 1
03	4KM-14902-00-00	• . Carburetor Assy 2
04	4KM-14903-00-00	• . Carburetor Assy 3
05	4KM-14904-00-00	• . Carburetor Assy 4
06	256-14997-00-00	•• .. Seal
07	1A8-14953-00-00	•• .. Washer
08	4KM-14216-00-00	•• .. Screw
09	4KM-1410A-10-00	•• .. Starter Set
10	4KM-14105-00-00	•• .. Pilot Screw Set
11	354-14147-00-00	•• .. O-ring
12	4KM-14194-00-00	•• .. Ring
13	4KM-1490J-00-00	•• .. Needle Set
14	4KM-14933-00-00	•• .. Spring, Diaphragm
15	4KM-14940-00-00	•• .. Diaphragm Assy
16	1HX-1423A-65-00	•• .. Jet, Main (72.5)
17	4KM-14142-12-00	•• .. Jet, Pilot (12.5)
18	4KM-14185-00-00	•• .. Float
19	4KM-14479-00-00	•• .. Funnel
20	4KM-14567-00-00	•• .. Screw
21	98507-03014-00	•• .. Screw, Pan Head
22	4KM-14107-15-00	•• .. Needle Valve Set
23	353-14186-00-00	•• .. Pin, Float
24	4KM-14141-32-00	•• .. Nozzle, Main
25	4KM-14261-01-00	•• .. Holder
26	1AE-14227-00-00	•• .. Washer
27	4KM-1414G-00-00	•• .. Pipe, Main Breed
28	3G2-14231-20-00	•• .. Jet, Main (100)
29	812-14594-00-00	•• .. Nut
30	4KM-14388-00-00	•• .. Valve, Vacuum Control
31	4KM-14275-00-00	•• .. Spring
32	3BT-83790-00-00	•• .. Heater Assy
33	90201-081K4-00	•• .. Washer, Plate
34	3BT-82103-00-00	•• .. Terminal 1
35	4KM-14291-00-00	•• .. Bracket 1
36	98507-05018-00	•• .. Screw, Pan Head
37	98507-04010-00	•• .. Screw, Pan Head
38	12R-14191-00-00	•• .. Plug, Drain
39	4KM-14103-00-00	•• .. Throttle Screw Set
40	92907-08100-00	•• .. Washer, Spring
41	1FN-14565-00-00	•• .. Screw
42	98507-04008-00	•• .. Screw, Pan Head
43	1HX-14231-24-00	•• .. Jet, Main (120)
44	4KM-14147-00-00	•• .. O-ring
45	4KM-14148-00-00	• . Pipe
46	4KM-14265-00-00	• . Collar
47	3EN-14997-00-00	• . Seal
48	4KM-14348-00-00	• . Pipe 1
49	4KM-1490K-00-00	• . Stop Screw Set
50	4KM-1410G-00-00	• . Connector
51	98507-05012-00	• . Screw, Pan Head
52	4KM-24453-00-00	• . Screw
53	4KM-14995-00-00	• . Bracket
54	4KG-85885-00-00	• . Throttle Sensor Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
55	4KM-14167-00-00	• . Connector
56	4KM-14137-00-00	• . Clip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-14611-00-00	Pipe, Exhaust 1
02	4KM-14621-00-00	Pipe, Exhaust 2
03	4KM-14631-00-00	Pipe, Exhaust 3
04	4KM-14641-00-00	Pipe, Exhaust 4
05	4KM-14615-00-00	Joint, Exhaust 1
06	3YF-14714-00-00	Gasket, Muffler
07	95027-08020-00	Bolt, Flange
08	90101-06576-00	Bolt
09	92907-06600-00	Washer, Plate
10	4KM-14711-00-00	Muffler 1
11	3VD-14755-00-00	Gasket, Silencer
12	95027-08025-00	Bolt, Flange
13	1A0-27114-00-00	Stopper, Main Stand
14	4KM-14721-00-00	Muffler 2
15	3VD-14755-00-00	Gasket, Silencer
16	95027-08025-00	Bolt, Flange
17	4BR-14613-00-00	Gasket, Exhaust Pipe
18	4KM-14612-00-00	Nut, Ring
19	90179-08507-00	Nut
20	36Y-14747-00-00	Damper, Muffler
21	4KM-14638-00-00	Collar
22	4KM-14791-00-00	Stay, Muffler
23	95807-10040-00	Bolt, Flange
24	97007-08025-00	Bolt
25	92907-08600-00	Washer, Plate
26	95814-10040-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-15100-00-00	Crankcase Assy
02	4H7-15138-00-00	• . Nozzle 1
03	4KM-13572-00-00	• . Nozzle
04	4KM-13741-00-00	• . Nozzle
05	99510-12016-00	• . Pin, Dowel
06	99530-14016-00	Pin, Dowel
07	90387-16547-00	Collar
08	90116-10330-00	Bolt, Stud
09	90116-10329-00	Bolt, Stud
10	90116-10328-00	Bolt, Stud
11	4KM-15412-00-00	Cover, Oil Pump
12	4H7-11363-00-00	Bolt, Cylinder Holding 3
13	99510-12016-00	Pin, Dowel
14	93210-11124-00	O-ring
15	4H7-15167-10-00	Plug, Blind 1
16	95817-08105-00	Bolt, Flange
17	90201-094G1-00	Washer, Plate
18	95817-08065-00	Bolt, Flange
19	95817-06135-00	Bolt, Flange
20	95817-06100-00	Bolt, Flange
21	95817-06080-00	Bolt, Flange
22	95817-06120-00	Bolt, Flange
23	95817-06055-00	Bolt, Flange
24	95817-08045-00	Bolt, Flange
25	95817-06035-00	Bolt, Flange
26	95817-06070-00	Bolt, Flange
27	95817-06050-00	Bolt, Flange
28	95817-06065-00	Bolt, Flange
29	31A-15381-00-00	Plate, Bearing Cover
30	31A-15383-00-00	Plate, Bearing Cover
31	90149-08152-00	Screw
32	4KM-15164-00-00	Housing, Bearing 2
33	93210-07438-00	O-ring
34	91317-06020-00	Bolt
35	4KM-15365-00-00	Grommet
36	4H7-15189-00-00	Plug
37	93210-20573-00	O-ring
38	1AA-15336-00-00	Damper, Engine Mount 3
39	1AA-15316-01-00	Damper, Engine Mount 1
40	4KM-15317-00-00	Spacer, Engine Mount
41	4KM-15327-00-00	Spacer, Engine Mount
42	4KM-13454-00-00	Nozzle
43	93210-07540-00	O-ring
44	4KM-15105-00-00	Nozzle Assy
45	93210-06632-00	O-ring

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-15416-00-00	Cover, Oil Pump
02	98907-06020-00	Screw, Bind
03	90149-06310-00	Screw
04	4KM-15411-00-00	Cover, Crankcase 1
05	4KM-15451-00-00	Gasket, Crankcase Cover 1
06	99530-10014-00	Pin, Dowel
07	91317-06035-00	Bolt
08	91317-06045-00	Bolt
09	371-11167-01-00	Pipe, Breather 2
10	4KM-11166-00-00	Pipe, Breather 1
11	90467-14015-00	Clip
12	90468-08104-00	Clip
13	4H7-15346-00-00	Breather 1
14	4BB-15457-00-00	Gasket
15	98507-06016-00	Screw, Pan Head
16	4H7-15347-00-00	Breather 2
17	4BB-15467-00-00	Gasket
18	98507-06016-00	Screw, Pan Head
19	4KM-15421-00-00	Cover, Crankcase 2
20	4KM-15461-00-00	Gasket, Crankcase Cover 2
21	99530-10014-00	Pin, Dowel
23	91317-06050-00	Bolt
24	2H7-15361-00-00	Gauge, Level
25	3F9-15362-00-00	Plug, Oil Level
26	93210-27778-00	O-ring
27	4KM-15441-00-00	Holder, Clutch Cable
28	91317-06020-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4H7-15512-00-00	Gear, Idler 1 (27z)
02	3TJ-15521-00-00	Shaft 1
03	2H7-15531-00-00	Plate, Stopper
04	90215-06040-00	Washer, Lock
05	97007-06016-00	Bolt
06	4KM-15580-00-00	Starter Clutch Outer Assy
07	4KM-15524-00-00	Wheel, Starter
08	93420-62070-00	Circlip
09	4KM-15517-00-00	Gear, Idler 2
10	4H7-16155-01-00	Absorber 1
11	4H7-15519-00-00	Sprocket, Starter 2 (21z)
12	93410-32052-00	Circlip
13	90387-201L2-00	Collar
14	4KM-15522-00-00	Shaft 2
15	90331-12028-00	Plug
16	93306-00426-00	Bearing
17	93306-20541-00	Bearing (b6205)
18	4KM-11456-00-00	Chain, Primary
19	4KM-11474-00-00	Guide, Upper
20	97007-06014-00	Bolt
21	4KM-15381-00-00	Plate, Bearing Cover
22	95027-06016-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-16150-00-00	Primary Driven Gear Comp.
02	3LD-1637A-01-00	Rod Push Assy
03	93340-21505-00	Bearing
04	90201-150H2-00	Washer, Plate
05	4H7-16154-00-00	Plate, Thrust 1
06	4KM-16371-00-00	Boss, Clutch
07	1J7-16384-00-00	Plate, Seat
08	5G2-16383-00-00	Spring, Clutch Boss
09	168-16324-00-00	Plate, Clutch 1
10	1J7-16385-00-00	Ring, Clutch Boss
11	4H7-16321-01-00	Plate, Friction
12	58L-16351-00-00	Plate, Pressure 1
13	90501-224A8-00	Spring, Compression
14	90159-06092-00	Screw, With Washer
15	31A-16325-00-00	Plate, Clutch 2
16	90215-20231-00	Washer, Lock
17	90170-20327-00	Nut
18	4KM-16340-00-00	Push Lever Assy
19	90508-16459-00	Spring, Torsion
20	4H7-16382-01-00	Axle, Push Lever
21	3LD-16398-00-00	Pinion, Releas
22	92907-08600-00	Washer, Plate
23	99080-07600-00	Circlip
24	93317-11020-00	Bearing
25	93102-12224-00	Oil Seal
26	90201-12M34-00	Washer, Plate
27	93315-11206-00	Bearing
28	99001-09600-00	Circlip
29	360-16154-00-00	Plate, Thrust 1
30	90387-252A8-00	Collar
31	4H7-16181-00-00	Spacer 1
32	93310-365H3-00	Bearing

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-17401-00-00	Main Axle Assy
02	4H7-17141-00-00	Gear, 4th Pinion (30z)
03	90209-22191-00	Washer
04	93440-25084-00	Circlip
05	4KM-17121-01-00	Gear, 2nd Pinion (20z/26z)
06	4KM-17151-00-00	Gear, 5th Pinion (32z)
07	90201-20276-00	Washer, Plate (1.0d)
08	99009-20400-00	Circlip
09	93306-20458-00	Bearing
10	93306-30550-00	Bearing
11	278-17424-01-00	Circlip 1
12	4KM-17402-00-00	Drive Axle Assy
13	4BB-17221-00-00	Gear, 2nd Wheel (30z)
14	90209-22252-00	Washer
15	93440-25084-00	Circlip
16	4BB-17231-00-00	Gear, 3rd Wheel (30z)
17	90209-25196-00	Washer
18	93440-28062-00	Circlip
19	4KM-17241-01-00	Gear, 4th Wheel (28z)
20	4KM-17211-00-00	Gear, 1st Wheel (35z)
21	4KM-17582-00-00	Gear, Middle Drive (38z)
22	90201-243A2-00	Washer, Plate
23	4KM-17251-01-00	Gear, 5th Wheel (26z)
24	93306-30318-00	Bearing
25	93306-20439-00	Bearing
26	4KM-17583-00-00	Gear, Middle Driven (46z)
27	93306-91101-00	Bearing (b6911)
28	93410-55057-00	Circlip
29	93440-80082-00	Circlip
30	93311-36042-00	Bearing
31	93440-72049-00	Circlip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-W1751-00-00	Middle Gear Comp.
02	93306-20709-00	Bearing (b6207)
03	90179-18360-00	Nut
04	31A-17526-01-00	Cam, Drive
05	4KM-17527-00-00	Cam, Driven
06	90501-70762-00	Spring, Compression
07	4H7-17524-00-00	Holder
08	3H5-17529-00-00	Washer, Thrust
09	90215-23265-00	Washer, Lock
10	4H7-17537-00-20	Shim, Thrust (0.20t)
10	4H7-17537-00-30	Shim, Thrust (0.30t)
10	4H7-17537-00-40	Shim, Thrust (0.40t)
11	93440-47081-00	Circlip
12	93306-00519-00	Bearing
13	31A-W1752-00-00	Houshing Comp.
14	93210-71360-00	O-ring
15	93101-35097-00	Oil Seal
16	4KM-17556-00-00	Yoke, Joint
17	90201-14633-00	Washer, Plate
18	90185-14070-00	Nut, Self-locking
19	3JB-17531-10-00	Shim, Pinion (0.15t)
19	3JB-17531-20-00	Shim, Pinion (0.20t)
19	3JB-17531-40-00	Shim, Pinion (0.40t)
20	95827-08030-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-18540-00-00	Shift Cam Assy
02	93306-90503-00	• . Bearing
03	4KM-18185-00-00	• . Segment
04	93604-17198-00	• . Pin, Dowel
05	93604-10011-00	• . Pin, Dowel
06	90151-06013-00	• . Screw, Countersunk
07	136-18542-00-00	• . Point, Neutral
08	90387-2505G-00	• . Collar
09	4KM-15383-00-00	Plate, Bearing Cover
10	90151-06059-00	Screw, Countersunk
11	4KM-18511-00-00	Fork, Shift 1
12	4KM-18512-00-00	Fork, Shift 2
13	4KM-18513-00-00	Fork, Shift 3
14	4KM-18531-00-00	Bar, Shift Fork Guide 1
15	93440-11029-00	• . Circlip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-18101-00-00	Shift Shaft Assy
02	90506-08227-00	• . Spring, Tension
03	4KM-18140-00-00	Stopper Lever Assy
04	90508-297A1-00	Spring, Torsion
05	4KM-18120-01-00	Shift Lever Assy
06	90508-267A2-00	• . Spring, Torsion
07	99006-10600-00	• . Circlip
08	90387-124F4-00	• . Collar
09	90201-12166-00	Washer, Plate
10	93608-50158-00	Pin, Dowel
11	93102-12106-00	Oil Seal (12-22-5 Hs)
12	4KM-18111-00-00	Pedal, Shift
13	2H9-18154-00-00	Cover, Dust
14	132-18113-01-00	Cover, Shift Pedal
15	97027-06020-00	Bolt
16	4KM-18112-00-00	Arm, Shift
17	2UJ-18115-02-00	Rod, Shift
18	95307-06700-00	Nut
19	90170-06228-00	Nut (verkehtheit Schraube)
20	2H9-18154-00-00	Cover, Dust

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-21110-00-P0	Frame Comp.
01	4KM-21110-00-33	Frame Comp.
02	90105-10393-00	Bolt, Washer Based
03	4KM-21140-00-P0	Down Tube Comp.
03	4KM-21140-00-33	Down Tube Comp.
04	95617-10200-00	Nut, Self-locking
05	90201-101J1-00	Washer, Plate
06	4KM-21315-00-00	Stay, Engine 2
07	90105-08391-00	Bolt, Washer Based
08	90179-08246-00	Nut
09	4KM-21318-00-00	Stay, Engine 5
10	95817-08016-00	Bolt, Flange
11	90105-10170-00	Bolt, Washer Based
12	95827-10050-00	Bolt, Flange
13	90105-10730-00	Bolt, Washer Based
14	90105-10113-00	Bolt, Washer Based
15	90179-10247-00	Nut
16	4KM-2119A-00-00	Pipe, Cross 6
17	4DN-21652-00-00	Protector
18	4KM-2136A-00-00	Bracket, Cooler 1
19	90464-20191-00	Clamp
20	3YX-2143A-00-00	Cap
21	90464-25217-00	Clamp
22	4KM-2116M-00-00	Bracket 10
23	95827-06012-00	Bolt, Flange
24	90480-15520-00	Grommet
25	1TX-28371-00-00	Damper

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-Y2151-00-P1	Front Fender Comp.
01	4KM-Y2151-00-4B	Front Fender Comp.
02	3GM-21512-00-00	• . Bracket, Fender
03	90267-32071-00	• . Rivet, Blind
04	4KM-21512-00-00	Bracket, Fender
05	90338-12192-00	• . Plug
06	90387-0702E-00	• . Collar
07	90105-06456-00	Bolt, Washer Based
08	4KM-21611-00-00	Fender, Rear
09	90159-06078-00	Screw, With Washer
10	95807-06014-00	Bolt, Flange
11	90183-06053-00	Nut, Spring
12	4KM-21651-00-P0	Cover, Rear Fender
12	4KM-21651-00-4B	Cover, Rear Fender
13	99237-00100-00	Emblem, Yamaha
13	99236-00100-00	Emblem, Yamaha
14	4KM-21691-00-00	Flap
15	90269-10075-00	Rivet
16	90269-05074-00	Rivet
17	30X-2139X-00-00	Damper
18	4BP-21644-00-00	Stay, Rear
19	90109-060E9-00	Bolt
20	4BP-21645-00-00	Stay, Rear
21	90109-060E9-00	Bolt
22	4BR-21621-00-00	Flap
23	90149-04278-00	Screw
24	90201-04018-00	Washer, Plate
25	95607-04100-00	Nut, U
26	90183-06053-00	Nut, Spring
27	2AL-2162A-00-00	Hook
28	97707-40010-00	Screw, Tapping
29	116-82131-00-00	Band, Battery
30	36F-28379-00-00	Hook
31	8U9-77162-00-00	Strip, Weather 2
32	4KM-28100-00-00	Tool Kit
33	3YF-84751-00-00	Bracket, License
34	95027-06016-00	Bolt, Flange
35	95607-06100-00	Nut, U
36	90201-06765-00	Washer, Plate
37	3G1-85130-01-00	Rear Reflector Assy
38	95707-05500-00	Nut, Flange
39	4KM-26131-00-00	Guide, Cable 1
40	4KM-26132-00-00	Guide, Cable 2

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-Y2171-00-4B	Cover, Side 1
01	4KM-Y2171-10-P0	Cover, Side 1
02	83R-14425-00-00	• . Damper 1
03	90183-05024-00	• . Nut, Spring
04	4KM-2173E-00-00	• . Graphic 1
04	4KM-2173E-10-00	• . Graphic 1
05	92907-04200-00	Washer
06	97707-40010-00	Screw, Tapping
07	90154-05059-00	Screw, Binding
08	90480-01558-00	Grommet
09	4KM-Y2172-00-4B	Cover, Side 2
09	4KM-Y2172-10-P0	Cover, Side 2
10	83R-14425-00-00	• . Damper 1
11	90185-05024-00	• . Nut, Self-locking
12	4KM-2173F-00-00	• . Graphic 2
12	4KM-2173F-10-00	• . Graphic 2
13	92907-04200-00	Washer
14	97707-40010-00	Screw, Tapping
15	90154-05059-00	Screw, Binding
16	90480-01558-00	Grommet
17	4KM-2171E-00-00	Cover, Side 5
18	95807-06012-00	Bolt, Flange
19	90480-01558-00	Grommet
20	4KM-2171X-00-00	Cover, Side 6
21	95807-06016-00	Bolt, Flange
22	90480-01558-00	Grommet

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-22110-00-00	Rear Arm Comp.
02	4KM-22141-00-00	Shaft, Pivot
03	90338-20113-00	Plug
04	93332-00010-00	Bearing
05	93102-25017-00	Oil Seal
06	90387-17543-00	Collar
07	1J7-22141-00-00	Shaft, Pivot
08	1J7-22143-00-00	Nut
09	4KM-2219X-00-00	Cover
10	97007-08035-00	Bolt
11	92907-08600-00	Washer, Plate
12	4KM-22189-00-00	Boot, Rubber
13	4KM-2217A-00-00	Arm, Relay
14	93317-42060-00	Bearing
15	90387-100T8-00	Collar
16	90105-10731-00	Bolt, Washer Based
17	95617-10100-00	Nut, U
18	90201-101J1-00	Washer, Plate
19	93317-41761-00	Bearing
20	90387-126T1-00	Collar
21	90101-12673-00	Bolt
22	90201-126A7-00	Washer, Plate
23	95617-12100-00	Nut, U
24	2KT-2217M-00-00	Arm 1
25	93317-31771-00	Bearing
26	93109-17048-00	Oil Seal
27	90387-127W0-00	Collar
28	90101-10659-00	Bolt
29	90201-101J1-00	Washer, Plate
30	95617-10100-00	Nut, U
31	4KM-22210-00-00	Shock Absorber Assy, Rear
32	1YW-22216-00-00	• . Bush, Rear Shock Absorber
33	90109-10554-00	Bolt
34	90201-101J1-00	Washer, Plate
35	95607-10100-00	Nut, U

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-46101-00-00	Rear Axle Gear Case Assy
02	90116-10361-00	• . Bolt, Stud
03	90116-08360-00	• . Bolt, Stud
04	4H7-46153-00-00	• . Collar, Guide
05	93101-30084-00	• . Oil Seal
06	93311-43729-00	• . Bearing
07	93317-41510-00	• . Bearing
08	2H7-46122-00-00	• . Race, Inner
09	1J7-17537-Y0-30	• . Shim, Thrust (0.30t)
09	1J7-17537-Y0-40	• . Shim, Thrust (0.40t)
09	1J7-17537-Y0-50	• . Shim, Thrust (0.50t)
10	93306-30533-00	• . Bearing
11	4H7-46125-00-00	• . Retainer, Bearing
12	93210-60426-00	• . O-ring
13	93101-38098-00	• . Oil Seal
14	4H7-46123-01-00	• . Coupling, Gear
15	90201-14632-00	• . Washer, Plate
16	90185-14070-00	• . Nut, Self-locking
17	4H7-46152-00-00	• . Housing, Bearing
18	1J7-46117-Y0-25	• . Shim, Ring Gear (0.25t)
18	1J7-46117-Y0-30	• . Shim, Ring Gear (0.30t)
18	1J7-46117-Y0-40	• . Shim, Ring Gear (0.40t)
18	1J7-46117-Y0-50	• . Shim, Ring Gear (0.50t)
19	93316-01403-00	• . Bearing
20	22U-46118-00-12	• . Washer, Thrust (1.2t)
20	22U-46118-00-14	• . Washer, Thrust (1.4t)
20	22U-46118-00-16	• . Washer, Thrust (1.6t)
20	22U-46118-00-18	• . Washer, Thrust (1.3t)
20	22U-46118-00-20	• . Washer, Thrust (2.0t)
21	93211-44348-00	• . O-ring
22	95317-08600-00	• . Nut
23	92907-08700-00	• . Washer
24	90109-10748-00	• . Bolt
25	93102-70167-00	• . Oil Seal
26	90340-14132-00	• . Plug, Straight Screw
27	214-11198-01-00	• . Gasket
28	2H7-17590-00-00	• . Breather Comp.
29	90340-14118-00	• . Plug, Straight Screw
30	90157-10043-00	• . Screw, Pan Head
31	4KM-46172-00-00	Shaft, Drive
32	93108-23007-00	Oil Seal
33	90201-231A2-00	Washer, Plate
34	93410-23056-00	Circlip
35	93410-22039-00	Circlip
36	90501-16491-00	Spring, Compression
37	4X7-46180-00-00	Cross Joint Comp.
38	93399-99926-00	Bearing
39	93440-20088-00	Circlip
40	95317-10600-00	Nut
41	92907-10100-00	Washer, Spring
42	90387-1705N-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	93399-99931-00	Bearing
02	93399-99932-00	Bearing
03	3FV-23462-00-00	Seal, Steering
04	90202-24190-00	Washer, Plate
05	3HE-23416-00-00	Cover, Ball Race 2
06	90179-25033-00	Nut
07	90202-26142-00	Washer, Plate
08	26H-23418-01-00	Washer, Special
09	90176-22050-00	Nut, Crown
10	4KM-23435-00-00	Crown, Handle
11	91317-08030-00	Bolt
12	4KM-23389-00-00	Guide, Cable
13	95027-06010-00	Bolt, Flange
14	4KM-2637G-00-00	Holder, Wire
15	95807-08012-00	Bolt, Flange
16	4KM-26331-00-00	Cable, Starter 1
17	1VJ-26333-00-00	Nut
18	4H7-23441-00-P0	Holder, Handle Upper
19	91314-08030-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-23102-00-00	Front Fork Assy (l.h)
02	4KM-23126-00-00	• . Tube, Outer (left)
03	4KM-23110-00-00	• . Inner Tube Comp.1
04	4KM-23170-00-00	• . Cylinder Comp., Front Fork
05	3JD-23125-L0-00	• . Metal, Slide 1
06	36Y-23146-10-00	• . Washer, Oil Seal
07	3SP-23145-L0-00	• . Oil Seal
08	26H-23156-00-00	• . Clip, Oil Seal
09	3XV-23144-50-00	• . Seal, Dust
10	3GM-23173-00-00	• . Spindle, Taper
11	509-23158-L0-00	• . Gasket
12	278-23181-50-00	• . Bolt, Hexagon Socket Head
13	4KM-23141-00-00	• . Spring, Front Fork
14	4KM-23149-00-00	• . Washer, Spring Upper
15	2YY-23118-00-00	• . Spacer
16	3EN-23111-50-00	• . Bolt, Cap
17	43F-23188-10-00	• . O-ring
18	4KM-23103-00-00	Front Fork Assy (r.h)
19	4KM-23136-00-00	• . Tube, Outer (right)
20	4KM-23110-00-00	• . Inner Tube Comp.1
21	4KM-23170-00-00	• . Cylinder Comp., Front Fork
22	3JD-23125-L0-00	• . Metal, Slide 1
23	36Y-23146-10-00	• . Washer, Oil Seal
24	3SP-23145-L0-00	• . Oil Seal
25	26H-23156-00-00	• . Clip, Oil Seal
26	3XV-23144-50-00	• . Seal, Dust
27	3GM-23173-00-00	• . Spindle, Taper
28	509-23158-L0-00	• . Gasket
29	278-23181-50-00	• . Bolt, Hexagon Socket Head
30	4KM-23141-00-00	• . Spring, Front Fork
31	4KM-23149-00-00	• . Washer, Spring Upper
32	2YY-23118-00-00	• . Spacer
33	3EN-23111-50-00	• . Bolt, Cap
34	43F-23188-10-00	• . O-ring
35	91317-08040-00	• . Bolt
36	4KM-23340-00-00	Under Bracket Comp.
37	2NX-23356-00-00	Bolt 2

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-24110-10-01	Fuel Tank Comp.
01	4KM-24110-10-02	Fuel Tank Comp.
02	4KM-24240-00-00	• . Graphic Set
02	4KM-24240-10-00	• . Graphic Set
03	99227-00160-00	• . Emblem, Yamaha
03	99226-00160-00	• . Emblem, Yamaha
04	4KM-24191-00-00	Bracket, Fuel Tank 1
05	2GH-24181-00-00	Damper, Locating 1
06	2GH-24183-00-00	Damper, Locating 3
07	2GH-24186-00-00	Washer, Special
08	90387-06299-00	Collar
09	97007-06025-00	Bolt
10	92907-06600-00	Washer, Plate
11	90119-06213-00	Bolt, With Washer
12	33M-24182-01-00	Damper, Locating 2
13	3Y6-24183-00-00	Damper, Locating 3
14	12R-24186-00-00	Washer, Special
15	95807-08030-00	Bolt, Flange
16	4KM-24500-10-00	Fuel Cock Assy 1
17	4X8-24512-00-00	• . Gasket
18	98507-03008-00	• . Screw, Pan Head
19	3AJ-24534-00-00	• . Seal, Cock
20	3AJ-24523-00-00	• . Valve
21	90149-06008-00	Screw
22	90202-05187-00	Washer, Plate
23	4KM-2452B-00-00	Hose, Fuel Outlet
24	90467-11044-00	Clip
25	4KM-2451B-00-00	Hose, Fuel Inlet
26	90467-11044-00	Clip
27	90445-105G5-00	Hose
28	90445-104H3-00	Hose
29	90467-09006-00	Clip
30	4HN-24602-00-00	Cap Assy
31	90110-05112-00	Bolt, Hexagon Socket Head
32	91314-05010-00	Bolt
33	3CV-24491-00-00	Bracket, Fuel Pump
34	90387-062L2-00	Collar
35	90480-13163-00	Grommet
36	95807-06016-00	Bolt, Flange
37	98507-05010-00	Screw, Pan Head
38	1FK-24560-00-00	Filter Assy
39	1FK-24566-00-00	Bracket, Filter
40	4JH-24183-00-00	Damper, Locating 3
41	4KM-13907-00-00	Fuel Pump Comp.
42	5H0-8235Y-M0-00	Damper
43	4KM-14294-00-00	Hose
44	90467-13123-00	Clip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-24730-00-00	Double Seat Assy
02	4KM-24731-00-00	• . Cover, Seat
03	4HM-24728-00-00	• . Bracket, Seat
04	95701-06500-00	• . Nut, Flange
05	4BP-24780-00-00	Seat Lock Assy
06	4BP-24792-00-00	Plate
07	95707-06500-00	Nut, Flange
08	4KM-2478E-00-00	Cable, Seat Lock
09	3CK-W2470-00-00	Seat Lock Assy
10	98507-06012-00	Screw, Pan Head
11	4KM-2117K-00-00	Stay, Lock
12	22W-24741-00-00	Pad, Seat
13	4KM-2475H-00-00	Bracket, Seat Lever 1 `
14	4KM-2475J-00-00	Bracket, Seat Lever 2
15	95707-06500-00	Nut, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-25168-00-WN	Cast Wheel, Front
02	90560-17356-00	Spacer
03	93306-20314-00	Bearing
04	93102-25017-00	Oil Seal
05	341-25149-00-00	Clutch, Meter
06	341-25846-00-00	Retainer, Clutch
07	93105-45017-00	Oil Seal
08	94112-1705U-00	Tire (120/70-17 58v K505f)
09	93900-00030-00	Valve, Rim
10	29L-25398-00-00	Balancer, Wheel (10g)
10	29L-25398-10-00	Balancer, Wheel (20g)
10	29L-25398-20-00	Balancer, Wheel (30g)
11	4HM-25190-00-00	Gear Unit Assy
12	4KM-25181-00-00	Axle, Wheel
13	90387-17530-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-2582T-00-00	Disc, Brake
02	90109-08718-00	Bolt
03	4KM-2580T-00-00	Caliper Assy (left)
04	3JB-W0057-00-00	• . Piston Assy, Caliper
05	3JB-W0047-00-00	•• .. Caliper Seal Kit
06	5R2-25937-00-00	• . Boot 2
07	3YX-25937-00-00	• . Boot 2
08	4KM-W0045-00-00	• . Brake Pad Kit
09	3YX-25919-00-00	• . Support, Pad
10	3YX-25929-00-00	• . Spring, Anti Rattle
11	51L-W0048-00-00	• . Bleed Screw Kit
12	4KM-2580U-00-00	Caliper Assy (right)
13	3JB-W0057-00-00	• . Piston Assy, Caliper
14	3JB-W0047-00-00	•• .. Caliper Seal Kit
15	5R2-25937-00-00	• . Boot 2
16	3YX-25937-00-00	• . Boot 2
17	4KM-W0045-00-00	• . Brake Pad Kit
18	3YX-25919-00-00	• . Support, Pad
19	3YX-25929-00-00	• . Spring, Anti Rattle
20	51L-W0048-00-00	• . Bleed Screw Kit
21	4KM-23317-00-00	Holder, Cable
22	90105-10638-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-25338-00-WN	Cast Wheel, Rear
02	93306-30317-00	Bearing
03	93306-20331-00	Bearing
04	93102-25044-00	Oil Seal
05	90560-17322-00	Spacer
06	4G0-25364-00-00	Damper
07	94115-1705V-00	Tire (150/70-17 69v K505)
08	93900-00030-00	Valve, Rim
09	4KM-25327-00-00	Cover, Plate
10	98507-05010-00	Screw, Pan Head
11	29L-25398-00-00	Balancer, Wheel (10g)
11	29L-25398-10-00	Balancer, Wheel (20g)
11	29L-25398-20-00	Balancer, Wheel (30g)3
12	4KM-25366-00-00	Clutch, Hub
13	93306-00444-00	Bearing
14	93210-57428-00	O-ring
15	90387-1705S-00	Collar
16	3HE-25371-50-00	Bar, Tension
17	90105-08321-00	Bolt, Washer Based
18	95707-08500-00	Nut, Flange
19	91490-20025-00	Pin, Cotter
20	90387-177Y4-00	Collar
21	4KM-25381-00-00	Axle, Wheel
22	95607-14200-00	Nut, Self-locking
23	90201-141A3-00	Washer, Plate
24	90387-172J0-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-2582W-A0-00	Disc, Rear Brake 2
02	90109-08718-00	Bolt
03	3GM-2580W-A0-00	Caliper Assy, Rear 2
04	31A-W0057-00-00	• . Piston Assy, Caliper
05	31A-W0047-00-00	•• .. Caliper Seal Kit
06	1FK-W0046-02-00	• . Brake Pad Kit 2
07	29L-25919-A0-00	• . Support, Pad
08	3HE-25924-00-00	• . Pin, Pad
09	3GM-25925-00-00	• . Clip
10	1J3-W0048-00-00	• . Bleed Screw Kit
11	51J-25836-00-00	• . Cover, Dust
12	1FK-25827-00-00	• . Shim, Caliper
13	1FK-25828-00-00	• . Shim, Caliper
14	1AE-25819-52-00	Bracket, Caliper
15	90105-10363-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-26111-00-00	Handlebar
02	31A-26241-00-00	Grip (left)
03	36Y-26240-00-00	Grip Assy
04	51J-26246-00-00	End, Grip
05	4KM-26302-00-00	Throttle Cable Assy
06	3XW-26281-01-00	Cap, Grip Upper
07	3XW-26282-01-00	Cap, Grip Lower
08	98507-05035-00	Screw, Pan Head
09	4KM-26335-00-00	Cable, Clutch
10	4KM-26280-00-00	Rear View Mirror Assy(left)
11	4KM-26290-00-00	Rear View Mirror Assy(right)

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-W2587-00-00	Master Cylinder Sub Assy
02	4BH-W0041-00-00	• . Cylinder Kit, Master
03	3YX-25854-00-00	• . Diaphragm, Reservoir
04	3YX-25852-00-00	• . Cap, Reservoir
05	98707-04012-00	• . Screw, Flat Head
06	4BH-83980-00-00	• . Front Stop Switch Assy
07	98506-04012-00	• . Screw, Pan Head
08	92906-04600-00	• . Washer, Plate
09	3YX-25880-00-00	• . Push Rod Comp.
10	95380-06600-00	• . Nut, Hexagon
11	3YX-W0091-02-00	Screw Kit, Master Cylinder
12	3YX-25866-00-00	• . Circlip
13	3YX-25866-10-00	• . Circlip
14	3YX-2583H-00-00	• . Boot
15	3YX-25867-00-00	Bracket, Master Cylinder
16	3YX-83922-09-00	Lever 2
17	3YX-25838-00-00	Sleeve, Caliper
18	3YX-25838-00-00	Sleeve, Caliper
19	95617-06100-00	Nut, U
20	95027-06030-00	Bolt, Flange
21	4KM-25872-00-00	Hose, Brake 1
22	3MA-26279-00-00	Guide, Cable
23	4KM-25873-00-00	Hose, Brake 2
24	90401-10159-00	Bolt, Union
25	90401-10160-00	Bolt, Union
26	90201-10118-00	Washer, Plate
27	4KM-25875-00-00	Holder, Brake Hose 1
28	4KM-25876-00-00	Holder, Brake Hose 2
29	95027-06012-00	Bolt, Flange
30	4KM-25886-00-00	Holder, Brake Hose
31	4KM-25887-00-00	Holder, Brake Hose
32	95027-06025-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-27311-00-00	Stand, Side
02	36Y-27352-00-00	Hook, Side Stand
03	90101-08662-00	Bolt
04	90201-084K3-00	Washer, Plate
05	90506-18224-00	Spring, Tension
06	90506-26225-00	Spring, Tension
07	4KM-27315-00-00	Link, Side Stand
08	1TX-27351-00-00	Guide, Side Stand
09	4BP-27451-00-00	Footrest
10	4BP-27461-00-00	Footrest
11	4BP-27413-00-00	Cover, Footrest
12	90159-05122-00	Screw, With Washer
13	91701-08042-00	Pin, Clevis
14	90508-20572-00	Spring, Torsion
15	91401-25020-00	Pin, Cotter
16	4KM-27442-00-00	Bracket 2
17	4KM-27443-00-00	Bracket 3
18	90110-08199-00	Bolt, Hexagon Socket Head
19	90109-087F1-00	Bolt
20	90380-20213-00	Bush, Solid
21	4DN-27431-00-00	Footrest, Rear 1
22	4DN-27441-00-00	Footrest, Rear 2
23	90501-12743-00	Spring, Compression
24	93501-04011-00	Ball
25	4DN-27437-00-00	Washer, Special
26	91701-08045-00	Pin, Clevis
27	91401-25020-00	Pin, Cotter
28	4BP-27413-00-00	Cover, Footrest
29	90159-05122-00	Screw, With Washer
30	4KM-2741L-00-00	Bracket 4
31	4KM-2742L-00-00	Bracket 5
32	90110-08199-00	Bolt, Hexagon Socket Head
33	36Y-27424-00-00	Damper, Footrest 2
34	90387-104L8-00	Collar
35	90201-10669-00	Washer, Plate
36	4KM-27111-00-00	Stand, Main
37	90109-101E6-00	Bolt
38	90445-252G5-00	Hose
39	90506-35297-00	Spring, Tension
40	90185-10091-00	Nut, Self-locking
41	4BP-27434-01-00	Bolt
42	90201-08326-00	Washer, Plate
43	90201-127J6-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-27211-00-00	Pedal, Brake
02	4KM-27212-00-00	Shaft, Brake Pedal
03	90109-06468-00	Bolt
04	92907-06100-00	Washer, Spring
05	90506-20192-00	Spring, Tension
06	4KM-2583V-00-00	Rr. Master Cylinder Assy.
07	4KM-W0042-50-00	• . Cylinder Kit, Master
08	3LN-2585G-00-00	•• .. Circlip
09	4BP-2582A-00-00	• . Joint
10	4BP-2585F-00-00	• . O-ring
11	4BP-27222-00-00	• . Joint
12	95303-08700-00	• . Nut
13	92017-08025-00	Bolt, Button Head
14	90240-08124-00	Pin, Clevis
15	90201-08083-00	Washer, Plate
16	91490-20025-00	Pin, Cotter
17	98517-06020-00	Screw, Pan Head
18	92907-06600-00	Washer, Plate
19	4KM-25895-00-00	Hose, Reservoir
20	90467-14057-00	Clip
21	4KM-2581K-00-00	Hose, Brake 5
22	90401-10159-00	Bolt, Union
23	3LC-25885-00-00	Joint
24	90201-10118-00	Washer, Plate
25	31A-25894-01-00	Tank, Reservoir
26	306-25854-00-00	Diaphragm, Reservoir
27	2GU-25855-00-00	Bush,diaphragm
28	2KF-25852-50-00	Cap, Reservoir

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4KM-Y2835-00-4B	Cowling Ass'y
01	4KM-Y2835-10-P0	Cowling Ass'y
02	4KM-28390-00-00	• . Graphic Set, Cowling
02	4KM-28390-10-00	• . Graphic Set, Cowling
03	99236-00100-00	• . Emblem, Yamaha
03	99237-00100-00	• . Emblem, Yamaha
04	90183-05024-00	• . Nut, Spring
05	4KM-28371-00-00	• . Damper
06	90149-05299-00	Screw
07	90179-05523-00	Nut
08	90149-05312-00	Screw
09	90179-05271-00	Nut
10	4U5-2176E-00-00	Plate
11	90202-10120-00	Washer, Plate
12	4KM-28381-00-00	Windshield
13	90150-05024-00	Screw, Round Head
14	90179-05271-00	Nut
15	4KM-2836K-00-00	Panel, Inner 1
16	36Y-28348-00-00	Mole 4
17	90154-05013-00	Screw, Binding
18	4KM-28356-00-00	Stay 1
19	95817-08035-00	Bolt, Flange
20	95807-06012-00	Bolt, Flange


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



4KM351-5390


Ref No	Part No	Description
01	4KM-81600-00-00	A.c. Generator Assy
02	4KG-81634-00-00	• . Head Wire Assy
03	4BH-81643-00-00	•• .. Bearing
04	4BH-81645-00-00	•• .. Screw
05	4BH-81643-10-00	• . Bearing
06	4BH-81970-00-00	• . Rectifier Assy
07	36Y-81910-50-00	• . Voltage Regulator Assy
08	3FV-81619-00-00	• . Brush Holder Assy
09	4BH-81972-00-00	• . Cover, Rectifier
10	3FV-81645-00-00	• . Screw
11	98507-05018-00	• . Screw, Pan Head
12	92901-05100-00	• . Washer, Spring
13	92901-05600-00	• . Washer, Plate
14	4KM-81604-00-00	• . Cover Assy
15	95701-05500-00	• . Nut, Flange
16	36Y-81638-50-00	• . Oil Seal
17	2KT-81642-50-00	• . O-ring
18	4BH-81660-00-00	• . Field Coil Assy
19	95817-08065-00	Bolt, Flange
20	90105-08746-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-81673-00-00	Rotor
02	4KM-81671-00-00	Base, Pickup
03	90105-10445-00	Bolt, Washer Based
04	90159-06107-00	Screw, With Washer
05	93604-08071-00	Pin, Dowel
06	90465-08369-00	Clamp
07	90465-08371-00	Clamp
08	90464-30040-00	Clamp
09	90465-12160-00	Clamp
10	90462-12221-00	Clamp


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4KM-81800-00-00	Starting Motor Assy
02	4H7-81847-01-00	• . O-ring
03	4H7-81840-01-00	• . Brush Holder Assy
04	4H7-81811-00-00	•• .. Brush 1
05	4H7-81812-01-00	• . Brush 2
06	4H7-81844-00-00	• . Gasket
07	4H7-81826-01-00	• . Bolt
08	95807-06060-00	Bolt, Flange


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.






Ref No	Part No	Description
01	3GM-83310-00-00	Front Flasher Light Assy 1
02	306-83311-40-00	• . Bulb, Flasher (12v-21w)
03	51L-83332-01-00	• . Lens, Flasher
04	97707-40620-00	• . Screw, Tapping
05	3GM-83320-00-00	Front Flasher Light Assy 2
06	306-83311-40-00	• . Bulb, Flasher (12v-21w)
07	51L-83342-01-00	• . Lens, Flasher 2
08	97707-40620-00	• . Screw, Tapping
09	95307-12700-00	Nut
10	10V-83365-00-00	Cap
11	51J-83330-00-00	Rear Flasher Light Assy 1
12	1VU-83332-00-00	• . Lens, Flasher
13	97707-40620-00	• . Screw, Tapping
14	306-83311-40-00	• . Bulb, Flasher (12v-21w)
15	51J-83340-00-00	Flasher Light Assy 2
16	1VU-83342-00-00	• . Lens, Flasher 2
17	97707-40620-00	• . Screw, Tapping
18	306-83311-40-00	• . Bulb, Flasher (12v-21w)
19	95707-12500-00	Nut, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-83500-00-00	Speedometer Assy
02	4KM-83570-00-00	• . Speedometer Assy
03	4KM-83540-00-00	• . Tachometer Assy
04	4KM-85750-00-00	• . Fuel Meter Assy
05	1TX-83511-00-00	• . Lens, Speedometer
06	4KM-8353H-00-00	• . Case, Under
07	4KM-83612-00-00	• . Cover, Meter Panel
08	90159-03102-00	• . Screw, With Washer
09	98517-04012-00	• . Screw, Pan Head
10	92907-04100-00	• . Washer, Spring
11	92907-04600-00	• . Washer
12	90167-04057-00	• . Screw, Tapping
13	98507-03010-00	• . Screw, Pan Head
14	92990-03100-00	• . Washer, Spring
15	90164-04023-00	• . Screw, Tapping
16	97707-30518-00	• . Screw, Tapping
17	4KM-83509-00-00	• . Socket Cord Assy
18	4G1-84744-00-00	• . Bulb (12v-3.4w)
19	29L-83578-00-00	• . Knob, Trip Meter
20	36Y-83523-00-00	• . Damper
21	2GG-8352K-00-00	• . Plug, Blind
22	1TX-83740-00-00	• . Digital Clock Assy
23	4H7-83616-00-00	• . Screw, Tapping
24	1TX-83524-00-00	• . Washer, Special
25	8V7-21961-00-00	Patch 1
26	90387-060J4-00	Collar
27	95027-06030-00	Bolt, Flange
28	90201-060A3-00	Washer, Plate
29	4KM-83550-00-00	Speedometer Cable Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-84320-00-00	Lens Assy
02	4KM-8413H-00-00	• . Plate, Spring
03	97707-40614-00	• . Screw, Tapping
04	4KM-8413K-00-00	• . Plate, Adjusting
05	4KM-8432M-00-00	• . Knob Assy
06	2F9-84314-00-00	Bulb, Headlight (12v-60/55w)
07	4KM-84397-00-00	Cover, Socket
08	4KM-84312-00-00	Holder, Socket
09	4KM-84347-00-00	Bulb
10	95807-06020-00	Bolt, Flange
11	47X-21736-00-00	Nut,plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4BP-84710-00-00	Taillight Unit Assy
02	4BP-84721-00-00	• . Lens, Taillight
03	137-84714-61-00	• . Bulb
04	4BP-84712-00-00	• . Gasket, Taillight
05	4BP-8471J-00-00	• . Screw, Taillight
06	90480-18276-00	Grommet
07	90387-07037-00	Collar
08	90201-063J2-00	Washer, Plate
09	95317-06600-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4BP-83975-10-00	Switch, Handle 2
02	90157-05057-00	• . Screw, Pan Head
03	4KM-83969-00-00	Switch, Handle 5
04	98507-05030-00	• . Screw, Pan Head
05	98506-05040-00	• . Screw, Pan Head
06	3YX-82911-00-00	Holder, Lever 1
07	3YX-83912-00-00	Lever 1
08	3YX-82917-00-00	Switch
09	90123-08096-00	Bolt
10	90179-08316-00	Nut
11	3YX-83945-00-00	Bolt, Lever
12	95607-06100-00	Nut, U
13	98707-03020-00	Screw, Flat Head
14	95027-06020-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4KM-81940-00-00	Starter Relay Assy
02	95027-06008-00	Bolt, Flange
03	3EN-81950-00-00	Relay Assy
04	3GM-83350-00-00	Flasher Relay Assy
05	4KM-83371-00-00	Horn
06	95027-06012-00	Bolt, Flange
07	4KM-85752-00-00	Sender Unit Assy, Fuel Meter
08	5G3-85753-00-00	Gasket, Sender Unit
09	90119-05071-00	Bolt, With Washer

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	3XW-82100-00-00	Battery Assy (ytx14-bs)
02	4KM-82115-00-00	Wire, Plus Lead
03	4KM-82116-00-00	Wire, Minus Lead
04	4KM-82310-00-00	Ignition Coil Assy
05	4KM-82320-00-00	Ignition Coil Assy
06	90464-60067-00	Clamp
07	95807-06020-00	Bolt, Flange
08	3NS-82370-00-00	Plug Cap Assy
09	4KM-82305-00-00	Ignitor Unit Assy
10	98507-06018-00	Screw, Pan Head
11	92907-06600-00	Washer, Plate
12	4KM-82540-00-00	Neutral Switch Assy
13	90430-10148-00	Gasket
14	4H7-85720-01-00	Oil Level Gauge Assy
15	95027-06016-00	Bolt, Flange
16	2TK-82530-02-00	Stop Switch Assy
17	4JH-82501-01-00	Main Switch Steering Lock
18	90109-080G5-00	Bolt
19	4KM-82590-00-00	Wire Harness Assy
20	2GH-82151-00-00	• . Fuse (20a-bl)
21	42X-82151-00-00	• . Fuse (10a-bl)
22	36Y-82151-00-00	• . Fuse (15a-bl)
23	4FM-82151-00-00	• . Fuse (30a)
24	90464-13073-00	Clamp
25	5Y9-12491-00-00	Clamp 1
26	437-83936-01-00	Band, Switch Cord
27	12R-82591-00-00	Band
28	3MA-82591-00-00	Band
29	1UY-82591-00-00	Band
30	5Y9-12491-00-00	Clamp 1
31	90464-14117-00	Clamp
32	12R-82591-00-00	Band
33	12R-82591-00-00	Band
34	12R-82591-00-00	Band
35	12R-82591-00-00	Band
36	12R-82591-00-00	Band
37	12R-82591-00-00	Band
38	12R-82591-00-00	Band
39	3LD-82566-70-00	Switch, Side Stand
40	90157-05079-00	Screw, Pan Head
41	90464-23041-00	Clamp
42	3BT-82560-00-00	Thermo Switch Assy
43	4U8-81950-02-00	Relay Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.